




Parts Manual

Mfg. No: 212412-0117-E1


Model Components	Page
Air Cleaner, Exhaust System.	4
Alternator, Electric Starter, Ignition.	6
Blower Housing/Shrouds, Flywheel, Rewind Starter.	10
Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/Rings/Connecting	12
Carburetor, Kit - Carburetor Overhaul.	16
Controls, Fuel Supply, Governor Spring.	18
Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Valves.	22
Replacement Engine - US & Canada.	24

Not For
Reproduction




Air Cleaner, Exhaust System

REF NO	PART NO	QTY	DESCRIPTION
11C	696796		TUBE, Breather
53	694869		STUD -(Carburetor)
161	695384		BASE, Air Cleaner -(Metal)
161B	699960		BASE, Air Cleaner -(Metal)
163	692277		GASKET, Air Cleaner -(Air Cleaner)
185	690958		NUT -(Air Cleaner Base)
298	696757		LOCKNUT -(Muffler and Elbow)
300C	793701		MUFFLER
300D	791407		MUFFLER
300E	790729		MUFFLER
355	691075		WASHER -(Muffler Bracket)
425	790043		SCREW -(Air Cleaner Cover)
425A	694515		SCREW -(Air Cleaner Cover)
436C	792374		MANIFOLD, Exhaust
437	696705		SCREW -(Exhaust Manifold)
445	491588S		FILTER, A/C Cartridge
613	695312		SCREW -(Muffler)
613B	696705		SCREW -(Muffler)
676C	697816		DEFLECTOR, Muffler
677	691660		SCREW -(Muffler Deflector)
740	710090		LOCKNUT -(Muffler Bracket)
740A	793859		NUT -(Muffler Bracket)
819	690352		SCREW -(Muffler Bracket)
832C	792380		MUFFLER
836C	710023		SCREW -(Muffler Guard)
863C	793700		BRACKET, Muffler
883	695398		GASKET, Exhaust
883A	697255		GASKET, Exhaust
883C	710250		GASKET, Exhaust
967	491435S		FILTER, Pre Cleaner
968	790959		COVER, Air Cleaner
994	790153		ARRESTOR, Spark
1177	710090		LOCKNUT -(Muffler)




Alternator, Electric Starter, Ignition

REF NO	PART NO	QTY	DESCRIPTION
286C	699951		MODULE, Oil Sensor
310	690323		SCREW -(Starter Motor)
333	492341		ARMATURE, Magneto
334	691061		SCREW -(Magneto Armature)
347	697854		SWITCH, Rocker
356	692603		WIRE, Stop
356A	692390		WIRE, Stop
356B	699340		WIRE, Stop
356E	696328		WIRE, Stop
356H	696482		WIRE, Stop
356G	697336		WIRE, Stop
356K	697397		WIRE, Stop
356L	792609		WIRE, Stop
361	691681		SCREW -(Starting Switch)
361A	690297		SCREW -(Starting Switch)
364A	699947		TERMINAL, Oil Plug
415	691363		PLUG
493A	691177		BRACKET, Mounting
500	691086		WASHER -(Key Switch)
500A	792613		WASHER -(Key Switch)
503	691532		STRAP, Starter
510	693699		DRIVE, Starter
513	692024		CLUTCH, Drive
544	692034		ARMATURE, Starter -(3 5/8 Housing)
575	692303		SWITCH-STARTING
577	690630		CABLE, Starter
577A	690795		CABLE, Starter
578	692306		WIRE ASSEMBLY
578A	790948		WIRE ASSEMBLY
579	691029		NUT -(Starter Cable)
627	696064		BRACKET, Stopswitch
627A	792608		BRACKET, Stopswitch
636	691029		NUT -(Starting Switch)
641	691075		WASHER -(Starting Switch)
641A	690282		WASHER -(Starting Switch)
664	691087		NUT -(Key Switch)
668A	693604		SPACER
697	690372		SCREW -(Drive Cap)
783	693713		GEAR, Pinion
799	690297		SCREW -(Oil Sensor)
801	694482		CAP-DRIVE





Alternator, Electric Starter, Ignition

REF NO	PART NO	QTY	DESCRIPTION
802	691286		CAP, End
813	690635		CLAMP
851	692424		TERMINAL, Spark Plug
892	392833		SWITCH, Key
892A	791944		SWITCH, Key
920	691656		SOLENOID, Starter
990	691959		SET, Key
990A	695756		SET, Key
1046	691337		PLUG, Blower Housing
1051	691265		RING, Retaining
1052A	791159		SENSOR, Oil
1054	280275		TIE, Cable
1090	691293		RETAINER, Brush
1119	691183		SCREW -(Alternator)





Blower Housing/Shrouds, Flywheel, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
23	794814		FLYWHEEL
37	790730		GUARD, Flywheel
55	695288		HOUSING-REWIND STR
58	693389		ROPE, Starter -(Cut To Required Length)
59	805957		INSERT, Grip
60	490652		GRIP-STARTER ROPE
65	690837		SCREW -(Rewind Starter)
78	690372		SCREW -(Flywheel Guard)
304	791478		HOUSING, Blower
305	691108		SCREW -(Blower Housing)
332	694685		NUT -(Flywheel)
363	19203		PULLER, Flywheel
455	694683		CUP, Flywheel
456	692299		PLATE-PAWL FRICTION
459	281505S		PAWL-RATCHET
592	690800		NUT -(Rewind Starter)
597	691696		SCREW -(Pawl Friction Plate)
608	695287		STARTER-REWIND
622	698839		WASHER -(Heat Shield)
689	691855		SPRING-FRICTION
695	698807		SCREW -(Ring Gear)
725A	792995		SHIELD, Heat
725B	698837		SHIELD, Heat
727A	697465		COVER, Starter Drive
732	691097		SCREW -(Starter Drive Cover)
1005	694684		FAN, Flywheel
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1070	690364		SCREW -(Flywheel Fan)
1210	498144		PULLEY/SPRING ASSY -(Pulley)
1212	792614		STUD -(Blower Housing)
1298	696757		LOCKNUT -(Shield-Heat)



Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/


REF NO	PART NO	QTY	DESCRIPTION
1	790038		CYLINDER ASSEMBLY
2	698340		KIT, Bushing/Seal -(Magneto Side)
3	391086S		SEAL, Oil -(Magneto Side)
12	694953		GASKET, Crankcase
15	691686		PLUG-OIL DRAIN
16	794716		CRANKSHAFT
17	695434		BEARING, Ball
18	791965		COVER, Crankcase
19	698340		KIT, Bushing/Seal -(PTO Side)
20	391086S		SEAL, Oil -(PTO Side)
21	281658S		CAP, Oil Fill
22	695174		SCREW -(Crankcase Cover/Sump)
24	222698S		KEY, Flywheel
25	791819		PISTON ASSEMBLY -(Standard)
25	791818		PISTON ASSEMBLY -(.020 Oversize)
26	697692		SET, Ring -(Standard)
26	697698		SET, Ring -(.020 Oversize)
27	690975		LOCK, Piston Pin
28	696581		PIN, Piston -(Standard)
29	694691		ROD, Connecting
30	694692		DIPPER, Connecting Rod
32	690976		SCREW -(Connecting Rod)
46	790958		CAMSHAFT
146	690979		KEY, Woodruff
170	695296		STUD -(Crankcase Cover/Sump)
219	693578		GEAR, Governor
220	691724		WASHER -(Governor Gear)
287	691693		SCREW -(Dipstick Tube)
306	697240		SHIELD, Cylinder
307	691660		SCREW -(Cylinder Shield)
523	695344		DIPSTICK
524	691876		SEAL, O-Ring
525	695343		TUBE, Dipstick
529	791822		GROMMET
552	694674		BUSHING, Governor Crank
718	690959		PIN, Locating
718A	695178		PIN, Locating
725A	792995		SHIELD, Heat
741	691288		GEAR, Timing
742	692564		RETAINER, E Ring



Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/


REF NO	PART NO	QTY	DESCRIPTION
746	694679		GEAR, Idler
842	691031		SEAL, O-Ring -(Dipstick Tube)
847	695342		DIPSTICK/TUBE ASSEMBLY
1058	277040		MANUAL, Operator's
1319	794467		LABEL, Warning

Not For Reproduction




Carburetor, Kit - Carburetor Overhaul

REF NO	PART NO	QTY	DESCRIPTION
51	694874		GASKET, Intake
51A	694875		GASKET, Intake
95A	690718		SCREW -(Throttle Valve)
97A	696387		SHAFT, Throttle
98A	695408		KIT, Idle Speed
104A	694918		PIN, Float Hinge
105A	696136		VALVE, Float Needle
108A	696143		VALVE, Choke
109D	790149		SHAFT, Choke
109E	696735		SHAFT, Choke
117	696134		JET, Main -(Standard)
118	696135		JET, Main -(High Altitude)
121A	696146		KIT, Carburetor Overhaul -(Nikki Carburetor)
122	694876		SPACER, Carburetor
125A	699966		CARBURETOR
127A	690727		PLUG, Welch
130A	696139		VALVE, Throttle
133A	694914		FLOAT, Carburetor
135	696142		TUBE, Fuel Transfer
137A	695426		GASKET, Float Bowl
141	696145		KIT, Choke Shaft
141C	699979		KIT, Choke Shaft
163	692277		GASKET, Air Cleaner -(Air Cleaner)
369	695422		SPRING, Float Bowl
632	695917		SPRING/LINK, Mechanical Governor -(Use With Nikki Carburetor)
633B	690998		SEAL, Choke/Throttle Shaft
951	699961		LEVER, Choke
975A	696138		BOWL, Float
1127A	695407		SCREW -(Float Bowl) (Float Bowl to Carburetor Body)



Controls, Fuel Supply, Governor Spring




REF NO	PART NO	QTY	DESCRIPTION
187	791766		LINE, Fuel -(15" Long)(Cut to Required Length)
187A	695429		LINE, Fuel -Used Before Code Date 05070100
187A	791869		LINE, Fuel -Used After Code Date 05063000
188	690877		SCREW -(Control Bracket)
190	692127		SCREW -(Fuel Tank)
209	694867		SPRING, Governor
211	695307		SPRING, Governed Idle
222	695380		BRACKET, Control
222A	694866		BRACKET, Control
222B	791753		BRACKET, Control
227	694864		LEVER, Governor Control
240	394358S		FILTER, Fuel
265	691024		CLAMP, Casing
267	692577		SCREW -(Casing Clamp)
268	691025		CASING, Control Wire
269	691026		WIRE, Control
270	691027		NUT -(Control Wire Casing)
271	691028		LEVER, Control
271A	695381		LEVER, Control
278	792008		WASHER -(Governor Lever)
281	697268		PANEL, Control
410	695382		LINK, Control
504	695383		SET, Friction Washer
505	691251		NUT -(Governor Control Lever)
562	793216		BOLT -(Governor Lever)
564	692577		SCREW -(Control Cover)
564A	692198		SCREW -(Control Cover)
601	791850		CLAMP, Hose
604	697326		COVER-CONTROL
604A	791752		COVER, Control
615	694676		RETAINER, Governor Shaft
616	694675		CRANK, Governor
621	692310		SWITCH, Stop
632	695917		SPRING/LINK, Mechanical Governor -(Use With Nikki Carburetor)
663B	692577		SCREW -(Control Panel)
668	694257		SPACER -(Control Bracket)
773	694258		RETAINER
957	792647		CAP, Fuel Tank -(Plastic)
958	698180		VALVE, Fuel Shutoff -(Plastic)



Controls, Fuel Supply, Governor Spring

REF NO	PART NO	QTY	DESCRIPTION
972A	694260		TANK, Fuel -(Plastic)
1138	694255		NUT -(Control Bracket)
1230	791754		STUD -(Control Bracket)
1404	696757		LOCKNUT -(Control Cover)

Not For Reproduction



Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Valves

REF NO	PART NO	QTY	DESCRIPTION
3	391086S		SEAL, Oil -(Magneto Side)
5	793009		HEAD, Cylinder
7	697690		GASKET, Cylinder Head
12	694953		GASKET, Crankcase
13	690360		SCREW -(Cylinder Head)
20	391086S		SEAL, Oil -(PTO Side)
33	499596		VALVE, Exhaust
34	792200		VALVE, Intake
35	694865		SPRING, Valve -(Intake)
36	694865		SPRING, Valve -(Exhaust)
42	499586		KEEPER, Valve
45	690977		TAPPET, Valve
51	694874		GASKET, Intake
51A	694875		GASKET, Intake
163	692277		GASKET, Air Cleaner -(Air Cleaner)
192	690083		ADJUSTER, Rocker Arm
337	491055S		PLUG, Spark
337	84007216	1	PLUG, SPARK -(China Only)
358	695438		GASKET SET, Engine
383	19374S		WRENCH, Spark Plug
635	691909		BOOT, Spark Plug
798	697890		SCREW -(Rocker Arm)
868	690968		SEAL, Valve
883	695398		GASKET, Exhaust
883A	697255		GASKET, Exhaust
914	693732		SCREW -(Rocker Cover)
1022	690971		GASKET, Rocker Cover
1023	697691		COVER, Rocker
1026	695177		ROD, Push
1029	690972		ARM, Rocker
1095	695440		GASKET SET, Valve
1100	791959		PIVOT, Rocker Arm
1171	696754		STUD -(Rocker Cover)

Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
	21S2321036	1	Replacement Engine
	794914	1	Replacement Short Block
	794716	1	CRANKSHAFT -Add Part
	794717	1	CRANKSHAFT -Remove Part
-----			Top No-Load Speed: 3800 -Trim: ALL
-----			Service Note: For all Go-Karts use only a Model 136200 series engine as a replacement, regardless of the original Model.
-----			Service Note: Transfer the Extended Oil Fill Tube and Dipstick Assembly to the replacement engine.
-----			Service Note: Transfer Oil Sensor to the replacement engine.
-----			Service Note: Original engine was equipped special Remote Throttle Control or Governor Control. Transfer these parts to replacement engine.

