







Parts Manual

Mfg. No: 21B977-0218-H1






Model Components	Page
Air Cleaner, Blower Housing.	4
Alternator, Controls, Electric Starter, Governor Spring, Ignition.	6
Camshaft, Crankshaft, Lubrication, Piston, Rings, Connecting Rod.	12
Carburetor.	14
Carburetor, Fuel Supply, Kit - Carburetor Overhaul.	16
Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Intake Manifold, Valves.	20
Cylinder, Engine Sump, Operator's Manual, Warning Label.	24
Exhaust System, Flywheel, Rewind Starter.	26
Replacement Engine - US & Canada.	30



Not For
Reproduction



Air Cleaner, Blower Housing





REF NO	PART NO	QTY	DESCRIPTION
187	791805		LINE, Fuel -(Formed)(10-1/4" Long)(Cut to Required Length)
187D	791744		LINE, Fuel -(Formed)(14 Inches Long)(Cut To Required Length)
304	-----		Housing-Blower -(Compatible With Panel Style Filter. No Longer Available. See Reference304H For Replacement Blower Housing Kit.)
304G	591641		HOUSING, Blower -(Black-Compatible With Canister Style Filter)
304H	591906		HOUSING, Blower
305	697102		SCREW -(Blower Housing)
305A	793376		SCREW -(Blower Housing) (Used On Non-Grommet Style Blower Housings)
305C	799370		SCREW -(Blower Housing) (Used On Grommet Style Blower Housings)
305B	795891		SCREW -(Blower Housing) (Blower Housing To Intake Elbow)
431B	797901		ELBOW, Intake
445	797007		FILTER, A/C Cartridge -(Flat Panel)
445B	591583		FILTER, A/C Cartridge -(Canister)
601	791850		CLAMP, Hose -(Green)
601	691038		CLAMP, Hose -(Black)
643	697155		RETAINER, Air Filter
773	796448		RETAINER
964	799159		CAP, Connector
967	697292		FILTER, Pre Cleaner
968	697420		COVER, Air Cleaner -(Black-Compatible With Panel Style Filter)
968B	591646		COVER, Air Cleaner -(Black-Compatible With Canister Style Filter)
1040A	697381		PLATE, Trim
1139	796449		WASHER -(Fuel Pump Bracket)
1266	691917		SEAL, O-Ring -(Intake Elbow)
1266A	697123		SEAL, O-Ring -(Intake Elbow)
1267	697419		LATCH, Blower Housing -(Black)

DC ONLY		DUAL CIRCUIT		5/9 AMP		TRI CIRCUIT		10/16 AMP	
474A	1059	474B	1059	474C	1059	474C	1059	474D	1059
									








NOTE: All stators use a No. 1119 mounting screw.


NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.



Alternator, Controls, Electric Starter, Governor Spring, Ignition


REF NO	PART NO	QTY	DESCRIPTION
188	691693		SCREW -(Control Bracket)
202	691841		LINK, Mechanical Governor
203	691381		CRANK, Bell
205	691693		SCREW -(Bell Crank)
209	792602		SPRING, Governor
216	691840		LINK, Choke
222	694042		BRACKET, Control
227	691374		LEVER, Governor Control
232	691842		SPRING, Governor Link
265	691024		CLAMP, Casing
267	794904		SCREW -(Casing Clamp)
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing)
271	691028		LEVER, Control
309	693551		MOTOR, Starter
310	690323		SCREW -(Starter Motor)
311	497608		SET, Brush
333	799650		ARMATURE, Magneto
334	691061		SCREW -(Magneto Armature)
356	697397		WIRE, Stop
356A	398808		WIRE, Stop -(Cut To Required Length)
356B	697089		WIRE, Stop
356C	399222		WIRE, Stop
359	691077		WASHER -(Ground Terminal)
373	691612		NUT -(Ground Terminal)
404	691691		WASHER -(Governor Crank)
462	691261		WASHER -(Starter Cable)
474A	696578		ALTERNATOR -(DC Only)
474B	592831		ALTERNATOR -(Dual Circuit)
474D	696458		ALTERNATOR -(10 and 16 Amp Regulated)
474C	592829		ALTERNATOR -(Tri Circuit Or 5/9 Amp. Regulated)
501A	794360		REGULATOR -(5/9 Amp. Regulated)
501D	845907		REGULATOR -(10-16 Amp Regulated)
501B	698315		REGULATOR -9 Amp Battery-Less
501C	790292		REGULATOR -(Dual Circuit)

DC ONLY		DUAL CIRCUIT		5/9 AMP		TRI CIRCUIT		10/16 AMP	
474A	1059	474B	1059	474C	1059	474C	1059	474D	1059
									








NOTE: All stators use a No. 1119 mounting screw.


NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.



Alternator, Controls, Electric Starter, Governor Spring, Ignition


REF NO	PART NO	QTY	DESCRIPTION
503	691532		STRAP, Starter
505	691251		NUT -(Governor Control Lever)
507	691972		INSULATOR
510	693699		DRIVE, Starter
513	692024		CLUTCH, Drive
520	691084		TERMINAL, Ground
521	690581		SHIELD, Cable
526A	697088		SCREW -(Regulator) (5/9 Amp. Regulated)
526B	697348		SCREW -(Regulator) 9 Amp Battery-Less
559	697561		SCREW -(Remote Choke Stop) (Length .375 Inches)
559A	693675		SCREW -(Remote Choke Stop) (Length .419 Inches)
562	691119		BOLT -(Governor Control Lever)
578	692306		WIRE ASSEMBLY
579	691029		NUT -(Starter Cable)
614	691620		PIN, Cotter
616	692012		CRANK, Governor
621	692310		SWITCH, Stop
697	791680		SCREW -(Starter Motor) (Drive Cap)
729	691335		CLIP, Wire -(Wire Retainer)
729A	691224		CLIP, Wire -(Starter Motor)
729B	694123		CLIP, Wire -(Wire Retainer)
783	693713		GEAR, Pinion
789	698329		HARNESS, Wiring
789B	692037		HARNESS-WIRING
797	693167		NUT -(Brush Retainer)
801	691283		CAP, Drive
802	691286		CAP, End
851	692424		TERMINAL, Spark Plug
877	393456		WIRE/CONNECTOR, Alternator -(Dual Circuit)
877A	393814		WIRE/CONNECTOR, Alternator -(DC Only)
877D	790544		WIRE/CONNECTOR, Alternator
877C	399916		WIRE/CONN-ALTERNATOR -(10 and 16 Amp Regulated)
878	398661		HARNESS, Wiring
878A	691955		HARNESS, Alternator
920	691656		SOLENOID, Starter
1051	691265		RING, Retaining
1054	280275		TIE, Cable
1059	698516		KIT, Screw/Washer
1090	691293		RETAINER, Brush
1119	691183		SCREW -(Alternator)

DC ONLY		DUAL CIRCUIT		5/9 AMP		TRI CIRCUIT		10/16 AMP	
474A	1059	474B	1059	474C	1059	474C	1059	474D	1059
									



NOTE: All stators use a No. 1119 mounting screw.


NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.



Alternator, Controls, Electric Starter, Governor Spring, Ignition




REF NO	PART NO	QTY	DESCRIPTION
1448	690260		WASHER -(Magneto Armature)

Not For Reproduction




Camshaft, Crankshaft, Lubrication, Piston, Rings, Connecting Rod

REF NO	PART NO	QTY	DESCRIPTION
16	591953		CRANKSHAFT -Used After Code Date 12071600
16	697390		CRANKSHAFT -Used Before Code Date 12071700
24	591757		KEY, Flywheel -Used After Code Date 12071600
24	796335		KEY, Flywheel -Used Before Code Date 12071700
25	792728		PISTON ASSEMBLY -(.020 Oversize)
25	792307		PISTON ASSEMBLY -(Standard)
26	792643		SET, Ring -(.020 Oversize)
26	792306		SET, Ring -(Standard)
27	698138		LOCK, Piston Pin -Used Before Code Date 02100400
27	698469		LOCK, Piston Pin -Used After Code Date 02100300
28	697099		PIN, Piston
29	791633		ROD, Connecting -(Standard)
32	791118		SCREW -(Connecting Rod)
43	691968		SLINGER, Governor/Oil
45	690564		TAPPET, Valve
46	793880		CAMSHAFT
357	691483		KEY, Drive Pulley
377	691639		KEY, Woodruff
523	699908		DIPSTICK
524	691032		SEAL, O-Ring
525	697085		TUBE, Dipstick -(Used On Engines With Fuel Pump)
741	697128		GEAR, Timing
757	793242		LINK, Counterweight
758	-----		Counterweight -(Must Use Kit 795940, Includes Sump And Counterweight) -Used Before Code Date 05100300
758	697391		COUNTERWEIGHT -Used After Code Date 05100200
759	697392		PIN, Counterweight
842	691031		SEAL, O-Ring -(Dipstick Tube)
847	790443		DIPSTICK/TUBE ASSEMBLY
1270	793243		PLUG, AVS Counterweight



Carburetor

REF NO	PART NO	QTY	DESCRIPTION
51	692137		GASKET-INTAKE
94A	793610		KIT, Idle Mixture -(Nikki)
95A	690718		SCREW -(Throttle Valve) (Nikki)
98A	695408		KIT, Idle Speed -(Nikki)
104A	694918		PIN, Float Hinge -(Nikki)
105A	696136		VALVE, Float Needle -(Nikki)
108A	698773		VALVE, Choke -(Nikki)
117	591936		JET, Main -(Standard)
118	698788		JET, Main -(High Altitude)
125	590400		CARBURETOR -Used After Code Date 08121400 -Used Before Code Date 13092400 (Hose Not Included.)
125	593433		CARBURETOR -Used After Code Date 13092300
127A	690727		PLUG, Welch -(Nikki)
130A	698774		VALVE, Throttle -(Nikki)
131A	698776		KIT, Throttle Shaft -(Nikki)
133A	694914		FLOAT, Carburetor -(Nikki)
135A	796400		TUBE, Fuel Transfer -Used After Code Date 13092300
137A	698781		GASKET, Float Bowl -(Nikki)
141A	698778		KIT, Choke Shaft -(Nikki)
187	791805		LINE, Fuel -(Formed)(10-1/4" Long)(Cut to Required Length)
217	695409		SPRING, Choke Return
276A	695410		WASHER, Sealing -(Nikki)
633	699813		SEAL, Choke/Throttle Shaft -(Nikki)
634A	698779		SPRING/SEAL ASSEMBLY -(Nikki)
652	793380		SCREW -(Support Bracket)
947	699915		SOLENOID, Fuel
951	793386		KIT, Choke Shaft -Used Before Code Date 08121500
975	698783		BOWL, Float -(Nikki Without Solenoid)
975A	699502		BOWL, Float -(Includes Solenoid)
987A	698777		SEAL, Choke/Throttle Shaft
1091	691333		CAP, Limiter
1127	695407		SCREW -(Float Bowl) (Float Bowl to Carburetor Body)




121 CARBURETOR OVERHAUL KIT			
51	104	137	987
	105		617
			1266
93	106		634
95	127	276	1266A

121A CARBURETOR OVERHAUL KIT			
51	127A	137A	98A
104A	987A		
105A	633	1266	217
51A	617	1266A	276A

Carburetor, Fuel Supply, Kit - Carburetor Overhaul

REF NO	PART NO	QTY	DESCRIPTION
51	692137		GASKET-INTAKE
51A	796081		GASKET, Intake
93	690602		BUSHING, Throttle Shaft -(Walbro)
94	794176		KIT, Idle Mixture -(Walbro)
95	691636		SCREW -(Throttle Valve) (Walbro)
98	495800		KIT, Idle Speed -(Walbro)
98A	695408		KIT, Idle Speed -(Nikki)
104	690525		PIN, Float Hinge -(Walbro)
104A	694918		PIN, Float Hinge -(Nikki)
105	231855S		VALVE-FLOAT NEEDLE -(Walbro)
105A	696136		VALVE, Float Needle -(Nikki)
106	690577		SEAT, Inlet -(Walbro)(Gravity Feed)
106	691780		SEAT, Inlet -(Walbro)(Pump Feed)
108	691227		VALVE, Choke -(Walbro)
121	796185		KIT, Carburetor Overhaul -(Walbro)
121A	796184		KIT, Carburetor Overhaul -(Nikki)
127	694524		PLUG, Welch -(Walbro)
127A	690727		PLUG, Welch -(Nikki)
130	690468		VALVE, Throttle -(Walbro) -Used Before Code Date 04100400
130	790024		VALVE, Throttle -(Walbro) -Used After Code Date 04100300
131	790901		KIT, Throttle Shaft -(Walbro)
133	494381		FLOAT, Carburetor -(Walbro)
137	281165S		GASKET, Float Bowl -(Walbro)
137A	698781		GASKET, Float Bowl -(Nikki)
141	790902		KIT, Choke Shaft -(Walbro)
142	790025		NOZZLE, Carburetor -(Walbro) -Used After Code Date 04100300
142	697491		NOZZLE, Carburetor -(Walbro) -Used Before Code Date 04100400
143	790028		NOZZLE, Carburetor -(High Altitude) -Used After Code Date 04100300
143	697492		NOZZLE, Carburetor -(High Altitude) (Walbro) -Used Before Code Date 04100400






121 CARBURETOR OVERHAUL KIT			
51	104	137	987
	105		617
	106		1266
93			634
95	127	276	1266A

121A CARBURETOR OVERHAUL KIT			
51	127A	137A	98A
104A	987A		
105A	633	1266	217
51A	617	1266A	276A




Carburetor, Fuel Supply, Kit - Carburetor Overhaul

REF NO	PART NO	QTY	DESCRIPTION
187	791805		LINE, Fuel -(Formed)(10-1/4" Long)(Cut to Required Length)
187A	791806		LINE, Fuel -(Formed)(21)(Cut to Required Length)
187D	791744		LINE, Fuel -(Formed)(14 Inches Long)(Cut To Required Length)
187C	791745		LINE, Fuel -(23 Inches)(Cut To Required Length)
187B	791766		LINE, Fuel -(15" Long)(Cut to Required Length)
190	796174		SCREW -(Fuel Tank)
217	695409		SPRING, Choke Return
240A	84001895		FILTER, Fuel -(Clear, 40 Microns)
276	692255		WASHER, Sealing -(Walbro)
276A	695410		WASHER, Sealing -(Nikki)
385	694476		SCREW -(Fuel Pump)
385A	690297		SCREW -(Fuel Pump)
387	697090		PUMP, Fuel -(Includes Mounting Bracket) -Used Before Code Date 08073000
387A	808656		PUMP, Fuel
601	791850		CLAMP, Hose -(Green)
601	691038		CLAMP, Hose -(Black)
617	692138		SEAL, O-Ring -(Intake Manifold)
633	699813		SEAL, Choke/Throttle Shaft -(Nikki)
634	690802		SPRING/SEAL ASSEMBLY -(Walbro)
773	796448		RETAINER
788	699347		BRACKET, Fuel Pump -Used Before Code Date 08073000
918	791851		HOSE, Vacuum -(Molded)
950	691657		SCREW -(Float Bowl) (Bottom Of Bowl)
957A	795027		CAP, Fuel Tank
958	698183		VALVE, Fuel Shut Off
972	792168		TANK, Fuel -(Plastic)
975C	495933		BOWL, Float -(Walbro)
987	691326		SEAL, Choke/Throttle Shaft
987A	698777		SEAL, Choke/Throttle Shaft
1091	691333		CAP, Limiter
1139	796449		WASHER -(Fuel Pump Bracket)
1266	691917		SEAL, O-Ring -(Intake Elbow)
1266A	697123		SEAL, O-Ring -(Intake Elbow)



Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Intake Manifold, Valves

REF NO	PART NO	QTY	DESCRIPTION
3	391086S		SEAL, Oil -(Magneto Side)
5	796183		HEAD, Cylinder
7	273280S		GASKET, Cylinder Head
9	697109		GASKET, Breather -(After Date Code Use Liquid Sealant Reference 850) -Used Before Code Date 07071900
12	697110		GASKET, Crankcase -(.015" Thick)(Standard)
13	690360		SCREW -(Cylinder Head)
14	790560		STUD -(Cylinder Head)
20	795387		SEAL, Oil -(PTO Side)
33	792868		VALVE, Exhaust
34	791935		VALVE, Intake
35	691279		SPRING, Valve -(Intake)
36	691279		SPRING, Valve -(Exhaust)
42	499586		KEEPER, Valve
45	690564		TAPPET, Valve
50	592845		MANIFOLD, Intake
51	692137		GASKET-INTAKE
51A	796081		GASKET, Intake
53	591260		STUD -(Carburetor) -Used After Code Date 11120100
53	690227		STUD -(Carburetor) -Used Before Code Date 11120200
54	691148		SCREW -(Intake Manifold)
186	794873		CONNECTOR, Hose
192	691986		ADJUSTER, Rocker Arm
238	691843		CAP, Valve
337	691043		PLUG, Spark
358	796181		GASKET SET, Engine
383	19576S		WRENCH, Spark Plug
415	794903		PLUG
524	691032		SEAL, O-Ring
617	692138		SEAL, O-Ring -(Intake Manifold)
635	691909		BOOT, Spark Plug
654	690958		NUT -(Carburetor)
691	692407		SEAL, Governor Shaft
705	790561		NUT -(Fuel Tank)
830	691095		STUD, Rocker Arm
842	691031		SEAL, O-Ring -(Dipstick Tube)
850	100106		SEALANT, Liquid -Used After Code Date 07071800
868	794086		SEAL, Valve
883	692236		GASKET, Exhaust



Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Intake Manifold, Valves

REF NO	PART NO	QTY	DESCRIPTION
914	691108		SCREW -(Rocker Cover)
943	690589		SEAL, O-Ring -(Oil Pump Cover)
1022	272475S		GASKET, Rocker Cover -(After Date Code Use Liquid Sealant Reference 850) -Used Before Code Date 07091000
1023	797421		COVER-ROCKER
1026	697394		ROD, Push -(Intake)
1026	794573		ROD, Push -(Exhaust)
1029	691751		ARM, Rocker
1034	690822		GUIDE, Push Rod
1095	796189		GASKET SET, Valve
1266	691917		SEAL, O-Ring -(Intake Elbow)
1266A	697123		SEAL, O-Ring -(Intake Elbow)

1319 WARNING LABEL


REQUIRED when replacing parts with warning labels affixed.

1319A WARNING LABEL

REQUIRED when replacing parts with warning labels affixed.
















1058 OPERATOR'S MANUAL

1036 EMISSIONS LABEL


















Cylinder, Engine Sump, Operator's Manual, Warning Label

REF NO	PART NO	QTY	DESCRIPTION
1	697377		CYLINDER ASSEMBLY
2	797673		KIT, Bushing/Seal -(Magneto Side)
4A	592849		SUMP, Engine
9	697109		GASKET, Breather -(After Date Code Use Liquid Sealant Reference 850) -Used Before Code Date 07071900
11	794683		TUBE, Breather
12	697110		GASKET, Crankcase -(.015" Thick)(Standard)
15	690946		PLUG, Oil Drain -(3/8" Standard)
20	795387		SEAL, Oil -(PTO Side)
22	692125		SCREW -(Crankcase Cover/Sump)
239	491657S		SWITCH, Oil Pressure
306	592778		SHIELD, Cylinder
307	691693		SCREW -(Cylinder Shield)
415	794903		PLUG
552	697144		BUSHING, Governor Crank
584	794682		COVER, Breather Passage -(Use with Liquid Sealant Reference 850)
684	697157		SCREW -(Breather Passage Cover)
691	692407		SEAL, Governor Shaft
718	690959		PIN, Locating
750	790832		SCREW -(Oil Pump Cover)
850	100106		SEALANT, Liquid -Used After Code Date 07071800
943	690589		SEAL, O-Ring -(Oil Pump Cover)
965	499613		COVER, Oil Pump
1017	796981		SCREEN, Oil Pump
1024A	794644		PUMP-OIL
1027	492932S		FILTER, Oil -(Standard)
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1058	276344TRI		MANUAL, Operator's
1058	276344WST		MANUAL, Operator's
1058	276344EST		MANUAL, Operator's
1263	697124		REED, Breather
1264	697104		SCREW -(Breather Reed)
1319	794467		LABEL, Warning
1319A	797669		LABEL, Warning



Exhaust System, Flywheel, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
23	591761		FLYWHEEL
24	591757		KEY, Flywheel -Used After Code Date 12071600
24	796335		KEY, Flywheel -Used Before Code Date 12071700
37	697352		GUARD, Flywheel
55	695130		HOUSING, Rewind Starter -Used Before Code Date 12082700
56	695129		PULLEY, Starter -Used Before Code Date 12082700
57	695131		SPRING, Rewind Starter -Used Before Code Date 12082700
58	695132		ROPE, Starter -Used Before Code Date 12082700
58A	697316		ROPE, Starter -Used After Code Date 12082600
60	493926		GRIP, Starter Rope
60A	281434S		GRIP, Starter Rope
65	690940		SCREW -(Rewind Starter) -Used After Code Date 12082600
65	690837		SCREW -(Rewind Starter) -Used After Code Date 07040800 -Used Before Code Date 12082700
65	697725		SCREW -(Rewind Starter) -Used Before Code Date 07040900
73	-----		Screen-Rotating -(No Longer Available)(See Reference 1005A for Service Flywheel Fan) -Used Before Code Date 07040900
74	697897		SCREW -(Rotating Screen) -Used Before Code Date 07040900
75	690582		WASHER -(Flywheel)
78	691693		SCREW -(Flywheel Guard)
81	691178		LOCK, Muffler Screw
300B	795997		MUFFLER
324	796308		SCREEN/CUP ASSEMBLY -Used After Code Date 07040800
363	19203		PULLER, Flywheel
415A	794129		COVER, Flywheel -(Sump) -Used After Code Date 07040800
455	695113		CUP, Flywheel -Used Before Code Date 12082700
455A	796615		CUP, Flywheel -Used After Code Date 12082600
456	695128		PLATE, Pawl Friction -Used Before Code Date 12082700
459	281505S		PAWL-RATCHET -Used Before Code Date 12082700
493	695450		BRACKET, Mounting -(Debris Screen Guard)
563	695449		SCREW -(Debris Screen Guard)
563A	799359		SCREW -(Debris Screen Guard)



Exhaust System, Flywheel, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
597	691696		SCREW -(Pawl Friction Plate) -Used Before Code Date 12082700
608	695058		STARTER, Rewind -Used Before Code Date 12082700
608A	591606		STARTER, Rewind -Used After Code Date 12082600
613	691416		SCREW -(Muffler)
613A	691678		SCREW -(Muffler)
613B	690297		SCREW -(Muffler)
677	690661		SCREW -(Muffler Deflector)
689	691855		SPRING-FRICTION
783	693713		GEAR, Pinion
823	698941		SCREW -(Muffler Adapter)
832	790244		GUARD, Muffler
836	690367		SCREW -(Muffler Guard)
864	796002		ADAPTER, Muffler -(2 1/4" Long)
883	692236		GASKET, Exhaust
949	695448		GUARD, Debris Screen
949A	799358		GUARD, Debris Screen
1005	796082		FAN, Flywheel -Used After Code Date 07040800
1005A	796200		FAN, Flywheel -Used Before Code Date 07040900
1005B	-----		Fan-Flywheel -(No Longer Available)(See Reference 1005A for Service Flywheel Fan)
1044	698139		SCREW -(Flywheel)
1051	691265		RING, Retaining
1070	791680		SCREW -(Flywheel Fan) -Used Before Code Date 07040900
1070A	690363		SCREW -(Flywheel Fan) -Used After Code Date 07040800 -Used Before Code Date 08061900

Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
--------	---------	-----	-------------

Not For Reproduction

