













Parts Manual

Mfg. No: 21C114-0936-E1

Model Components	Page
Alternator, Electric Starter, Fuel Supply, Ignition.	4
Blower Housing/Shrouds, Flywheel.	6
Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/Rings/Connecting	8
Carburetor, Kit - Carburetor Overhaul.	12
Controls, Governor Spring.	14
Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Valves.	16
Exhaust System, Rewind Starter.	18
Replacement Engine - US & Canada.	20


Not For
Reproduction

DC ONLY	
474A	
NOTE: All stators use a No. 1119 mounting screw.  NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.	
578	















Alternator, Electric Starter, Fuel Supply, Ignition

REF NO	PART NO	QTY	DESCRIPTION
187	791766		LINE, Fuel
187A	791869		LINE, Fuel -Used After Code Date 05063000
187A	695429		LINE, Fuel -Used Before Code Date 05070100
187D	698080		LINE, Fuel -Used Before Code Date 05070100
187D	791879		LINE, Fuel -Used After Code Date 05063000
190	692127		SCREW -(Fuel Tank)
309A	793524		MOTOR, Starter
333	492341		ARMATURE, Magneto
334	691061		SCREW -(Magneto Armature)
347	698338		SWITCH, Rocker
356	692603		WIRE, Stop
474A	791743		ALTERNATOR
578	790481		WIRE ASSEMBLY
578A	792576		WIRE ASSEMBLY
601	791850		CLAMP, Hose
697	698113		SCREW -(Drive Cap)
851	692424		TERMINAL, Spark Plug
853	790455		ADAPTER, Wire
957	792647		CAP, Fuel Tank -(Plastic)
958	698180		VALVE, Fuel Shutoff -(Plastic)
972A	694260		TANK, Fuel -(Plastic)
1119	691183		SCREW -(Alternator)



Blower Housing/Shrouds, Flywheel


REF NO	PART NO	QTY	DESCRIPTION
11B	696750		TUBE, Breather
23	695485		FLYWHEEL
37A	696701		GUARD, Flywheel
53C	794542		STUD -(Carburetor)
78A	695724		SCREW -(Flywheel Guard)
163	692277		GASKET, Air Cleaner -(Air Cleaner)
304	791478		HOUSING, Blower
305	691108		SCREW -(Blower Housing)
332	694685		NUT -(Flywheel)
363	19203		PULLER, Flywheel
455	697226		CUP, Flywheel
472B	790472		KNOB, Choke Shaft
472C	791948		KNOB, Choke Shaft
528	793006		HOSE, Primer -(Cut To Required Length)
610	794541		ARRESTER, Intake
668B	794539		SPACER -(Snow Hood)
695	698807		SCREW -(Ring Gear)
727A	697465		COVER, Starter Drive
731B	794540		HOOD, Snow
731C	791990		HOOD, Snow
732	691097		SCREW -(Starter Drive Cover)
892A	791944		SWITCH, Key
976	790221		PRIMER, Carburetor -Used Before Code Date 07042700
976	793382		PRIMER, Carburetor -Used After Code Date 07042600
990A	695756		SET, Key
1005	694684		FAN, Flywheel
1011	794544		TUBE, Vent
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1070	691058		SCREW -(Flywheel Fan)
1196	699166		SCREW -(Snow Hood)
1196A	696692		SCREW -(Snow Hood) (Black)
1230	696747		STUD -(Control Bracket)
1251	696762		SHIELD, Snow
1251A	790471		SHIELD, Snow
1252	691108		SCREW -(Snow Shield)
1288	696757		LOCKNUT -(Snow Hood)
1352	698111		KNOB, Snow Hood -(Spark Plug Shield)



Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/

REF NO	PART NO	QTY	DESCRIPTION
1	793617		CYLINDER ASSEMBLY
2	698340		KIT, Bushing/Seal -(Magneto Side)
3	391086S		SEAL, Oil -(Magneto Side)
12	694953		GASKET, Crankcase
15	691686		PLUG-OIL DRAIN
15B	695757		PLUG, Oil Drain
16	794720		CRANKSHAFT
18	791965		COVER, Crankcase
19	698340		KIT, Bushing/Seal -(PTO Side)
20	391086S		SEAL, Oil -(PTO Side)
21	281658S		CAP, Oil Fill
22	695174		SCREW -(Crankcase Cover/Sump)
24	222698S		KEY, Flywheel
25	793794		PISTON ASSEMBLY -(Standard) -Used After Code Date 06102900
25	793797		PISTON ASSEMBLY -(.020 Oversize) -Used After Code Date 06102900
25	697695		PISTON ASSEMBLY -(.020 Oversize) -Used Before Code Date 06103000
25	793318		PISTON ASSEMBLY -(Standard) -Used Before Code Date 06103000
26	793319		SET, Ring -(Standard) -Used After Code Date 06061800
26	793324		SET, Ring -(.020 Oversize) -Used After Code Date 06061800
26	697692		SET, Ring -(Standard) -Used Before Code Date 06061900
26	697698		SET, Ring -(.020 Oversize) -Used Before Code Date 06061900
27	690975		LOCK, Piston Pin
28	696581		PIN, Piston -(Standard)
29	694691		ROD, Connecting
30	694692		DIPPER, Connecting Rod
32	690976		SCREW -(Connecting Rod)
46	790958		CAMSHAFT
146	690979		KEY, Woodruff
170	695296		STUD -(Crankcase Cover/Sump)
219	693578		GEAR, Governor
220	691724		WASHER -(Governor Gear)
287	691693		SCREW -(Dipstick Tube)
306	697240		SHIELD, Cylinder

1058 OPERATOR'S MANUAL



1319 WARNING LABEL

WARNING











Read and follow Operating Instructions before running engine.

Gasoline is flammable. Allow engine to cool at least 2 minutes before refueling.

Engines emit carbon monoxide, DO NOT run in enclosed area.


Muffler area temperature may exceed 150°F. Do not touch hot parts.

REQUIRED when replacing parts with warning labels affixed.




Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/

REF NO	PART NO	QTY	DESCRIPTION
307	691660		SCREW -(Cylinder Shield)
415	691363		PLUG
523	790477		DIPSTICK
524	691876		SEAL, O-Ring
525	792041		TUBE, Dipstick
529	791822		GROMMET
552	694674		BUSHING, Governor Crank
718	690959		PIN, Locating -(Cylinder)
718A	695178		PIN, Locating -(Head)
725	696756		SHIELD, Heat
741	691288		GEAR, Timing
742	692564		RETAINER, E Ring
746	694679		GEAR, Idler
842	691031		SEAL, O-Ring -(Dipstick Tube)
847	790476		DIPSTICK/TUBE ASSEMBLY
998A	696683		PIPE, Oil
1058	277104TRI		MANUAL, Operator's
1171	696754		STUD -(Rocker Cover)
1194	691876		SEAL, O-Ring -(Plug)
1298	790026		NUT -(Shield-Heat)
1298A	696757		LOCKNUT -(Shield-Heat)
1319	794467		LABEL, Warning
1351	790017		STUD -(Cylinder Shield)






Carburetor, Kit - Carburetor Overhaul

REF NO	PART NO	QTY	DESCRIPTION
51	694874		GASKET, Intake
51A	694875		GASKET, Intake
95A	690718		SCREW -(Throttle Valve)
97A	696387		SHAFT, Throttle
98A	695408		KIT, Idle Speed
104A	694918		PIN, Float Hinge
105A	696136		VALVE, Float Needle
108C	696736		VALVE, Choke
109E	696735		SHAFT, Choke
109H	793520		SHAFT, Choke
117	696134		JET, Main -(Standard)
118	696135		JET, Main -(High Altitude)
121A	696146		KIT, Carburetor Overhaul -(Nikki Carburetor)
122	694876		SPACER, Carburetor
125B	794593		CARBURETOR
127A	690727		PLUG, Welch
130A	696139		VALVE, Throttle
133A	694914		FLOAT, Carburetor
135	696142		TUBE, Fuel Transfer
137A	695426		GASKET, Float Bowl
163	692277		GASKET, Air Cleaner -(Air Cleaner)
369	695422		SPRING, Float Bowl
632	695917		SPRING/LINK, Mechanical Governor -(Use With Nikki Carburetor)
633B	690998		SEAL, Choke/Throttle Shaft
975A	696138		BOWL, Float
1127A	695407		SCREW -(Float Bowl) (Float Bowl to Carburetor Body)










Controls, Governor Spring

REF NO	PART NO	QTY	DESCRIPTION
188	690877		SCREW -(Control Bracket)
209	695491		SPRING, Governor
222A	694866		BRACKET, Control
227	694864		LEVER, Governor Control
265	691024		CLAMP, Casing
267	692577		SCREW -(Casing Clamp)
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing)
271	691028		LEVER, Control
278	792008		WASHER -(Governor Lever)
281	697268		PANEL, Control
505	691251		NUT -(Governor Control Lever)
562	793216		BOLT -(Governor Lever)
564	696692		SCREW -(Control Cover)
604A	696758		COVER, Control
604B	790473		COVER, Control
615	694676		RETAINER, Governor Shaft
616	694675		CRANK, Governor
632	695917		SPRING/LINK, Mechanical Governor -(Use With Nikki Carburetor)
663C	790282		SCREW -(Control Panel)
1230	696747		STUD -(Control Bracket)



Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Valves

REF NO	PART NO	QTY	DESCRIPTION
3	391086S		SEAL, Oil -(Magneto Side)
5	793305		HEAD, Cylinder
7	697690		GASKET, Cylinder Head
12	694953		GASKET, Crankcase
13	690360		SCREW -(Cylinder Head)
20	391086S		SEAL, Oil -(PTO Side)
33	499596		VALVE, Exhaust
34	795199		VALVE, Intake
35	694865		SPRING, Valve -(Intake)
36	694865		SPRING, Valve -(Exhaust)
42	499586		KEEPER, Valve
45	690977		TAPPET, Valve
51	694874		GASKET, Intake
51A	694875		GASKET, Intake
163	692277		GASKET, Air Cleaner -(Air Cleaner)
192	690083		ADJUSTER, Rocker Arm
337	691043		PLUG, Spark
358	795201		GASKET SET, Engine
383	19374S		WRENCH, Spark Plug
635	691909		BOOT, Spark Plug -(Alternator)
798	697890		SCREW -(Rocker Arm)
868	794086		SEAL, Valve
883	695398		GASKET, Exhaust
914	693732		SCREW -(Rocker Cover)
1022	690971		GASKET, Rocker Cover
1023A	698042		COVER, Rocker
1026	695177		ROD, Push
1029	690972		ARM, Rocker
1095	795200		GASKET SET, Valve
1100	791959		PIVOT, Rocker Arm
1171	696754		STUD -(Rocker Cover)



Exhaust System, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
55A	696710		HOUSING, Rewind Starter
58	693389		ROPE, Starter -(Cut To Required Length)
60A	699334		GRIP, Starter Rope
65	697725		SCREW -(Rewind Starter)
300A	794694		MUFFLER
300C	793701		MUFFLER
355	691075		WASHER -(Muffler Bracket)
436C	792374		MANIFOLD, Exhaust
437	696705		SCREW -(Exhaust Manifold)
456	692299		PLATE-PAWL FRICTION
459	281505S		PAWL-RATCHET
592	690800		NUT -(Rewind Starter)
597	691696		SCREW -(Pawl Friction Plate)
608A	699335		STARTER-REWIND
613	695312		SCREW -(Muffler) (3/4)
613	691003		SCREW -(Muffler) (1/2" Long)
613B	696705		SCREW -(Muffler)
676C	697816		DEFLECTOR, Muffler
677	691660		SCREW -(Muffler Deflector)
689	691855		SPRING-FRICTION
740	710090		LOCKNUT -(Muffler Bracket)
740A	793859		NUT -(Muffler Bracket)
819	690352		SCREW -(Muffler Bracket)
832	699223		GUARD, Muffler
832C	792380		MUFFLER
836	691003		SCREW -(Muffler Guard)
836C	710023		SCREW -(Muffler Guard)
863C	793700		BRACKET, Muffler
883	695398		GASKET, Exhaust
883C	710250		GASKET, Exhaust
930	696709		GUARD, Rewind
1177	710090		LOCKNUT -(Muffler)
1210	498144		PULLEY/SPRING ASSY -(Pulley)
1211	498144		PULLEY/SPRING ASSY -(Spring)

Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
	21M3140017	1	Replacement Engine
	794915	1	Replacement Short Block
	-----		Top No-Load Speed: 3600 -Trim: ALL
	-----		Service Note: For all Go-Karts use only a Model 136200 series engine as a replacement, regardless of the original Model.

Not For Reproduction

