




Parts Manual

Mfg. No: 226432-0050-99

Model Components	Page
Air Cleaner Grp.	4
Blower Hsg, Flywheel, Screens.	6
Carburetor Assy.	8
Controls.	10
Crankcase Cvr, Cam.	12
Cylinder, Head.	14
Electric Starter.	16
Electric Starter.	18
Fuel Tank Grps.	20
Gear Reducer Assy.	22
Kits/Gasket Sets.	24
Muffler Grps.	26
Piston Grp, Crankshaft.	28
Replacement Engine - US & Canada.	30
Rewind Assy.	31
Switch Plate, Elect, Oil Grp.	33

Not For
Reproduction



Air Cleaner Grp


REF NO	PART NO	QTY	DESCRIPTION
11	280819		TUBE, Breather
11	280819		TUBE, Breather
161	497669		BASE, Air Cleaner
161	498544		BASE, Air Cleaner
163	272706		GASKET, Air Cleaner -(Air Cleaner)
163	692277		GASKET, Air Cleaner -(Air Cleaner)
423	94930		SCREW -(Cylinder Shield)
445	496077		FILTER, A/C Cartridge
485	280715		KNOB, Control
534	94777		SCREW -(Air Cleaner Cover)
643	281358		BRACKET, Air Cleaner
967	492889		FILTER, Pre Cleaner
968	281357		COVER, Air Cleaner

Footnotes:

Used Before Code Date 95010200

Used After Code Date 95010100

Used After Code Date 95040200




Blower Hsg, Flywheel, Screens

REF NO	PART NO	QTY	DESCRIPTION
23A	498911		FLYWHEEL
23A	391988		FLYWHEEL -(Plastic Motor Drive)
23	498896		FLYWHEEL -(Rewind Starter)
24	222698		KEY, Flywheel
37	224886		GUARD, Flywheel
73	224874		SCREEN, Rotating
75A	224061		WASHER -(5/8 Hole)
78	94811		SCREW
215	221760		GUIDE, Air
304	497474		HOUSING, Blower
305	94786		SCREW -(1/2)
325	280457		PULLEY, Rope Starter
347	495098		SWITCH, Rocker -(With Lamp)
363	19203		PULLER, Flywheel
594	94928		SCREW
668	225124		SPACER
726	392134		GEAR, Ring
727	395405		COVER, Starter Drive
732	94625		SCREW


Footnotes:

Used Before Code Date 96062400
Used After Code Date 96062300



Carburetor Assy

REF NO	PART NO	QTY	DESCRIPTION
50	214170		MANIFOLD, Intake
51A	272707		GASKET, Intake
51	272708		GASKET, Intake
54	94616		SCREW -(T-30)
93	281346		BUSHING, Throttle Shaft
94	494383		KIT, Idle Mixture -(Lmt 71,101,102,113,114,116)
94	496589		KIT, Idle Mixture -(Lmt 149,150,172,175)
95	94098		SCREW -(Throttle Valve)
98	495800		KIT, Idle Speed -(Idle Speed) (Lmt 54, 55, 91)
104	231789		PIN, Float Hinge
105	231935		VALVE, Float Needle
106	231856		SEAT, Inlet -(Pump Feed)
108	224666		VALVE, Choke -(Choke-A-Matic)
125	497451		CARBURETOR
130	224539		VALVE, Throttle
131	497846		KIT, Throttle Shaft
133	494381		FLOAT, Carburetor
137	281165		GASKET, Float Bowl
141	497160		KIT, Choke Shaft
142	497448		NOZZLE, Carburetor -(High Altitude)(Lmt 101)
142	497449		NOZZLE, Carburetor -(High Altitude)(Lmt 101)
142	499744		NOZZLE, Carburetor -(Standard) (Lmt 175)
142	499826		NOZZLE, Carburetor -(High Altitude)(Lmt 175)
147	497472		JET, Pilot -(Lmt 101)
186A	493496		CONNECTOR, Hose
276	281164		WASHER, Sealing
365	94778		STUD -(Intake Manifold)
634	494455		SPRING/SEAL ASSEMBLY -(Choke-A-Matic)
654	94010		NUT -(Air Cleaner Base)
950	94642		SCREW -(Float Bowl)
975	495933		BOWL, Float -(Float Bowl)
987	281166		SEAL, Choke/Throttle Shaft




Controls

REF NO	PART NO	QTY	DESCRIPTION
98A	493280		KIT-IDLE SPEED -(Idle Speed)
165	94692		NUT
209A	263055		SPRING, Governor
209	263237		SPRING, Governor
211	263238		SPRING, Governor -(Idle)
212A	263050		LINK, Throttle
212	263049		LINK, Throttle
222	496313		BRACKET, Control
222	499104		BRACKET, Control
227	496254		LEVER, Governor Control
227	692143		LEVER, Governor Control
231	94620		SCREW -(Control Panel)
232	263020		SPRING/LINK, Governor
265	221535		CLAMP, Casing -(Stamped Steel)
268	65616		CASING, Control Wire -(Cut To Required Length)
269	26633		WIRE, Control -(Cut To Required Length)
270	63426		NUT -(Control Wire Casing)
271	290568		LEVER, Control
356	496868		WIRE, Stop
359	92791		WASHER
373	90576		NUT -(Ground Terminal)
373	92987		STARTER, Rewind
404	94927		WASHER -(Governor Lever)
489	231520		SCREW -(8-32)
504	495659		SET, Friction Washer
507	398525		INSULATOR
520	93722		TERMINAL, Ground
562	94907		BOLT
592	231082		NUT -(Governor Control)
614	93306		PIN, Cotter
616	496845		CRANK, Governor
621	396847		SWITCH, Stop
624	497207		LEVER, Linkage
657	93496		SCREW -(10-32 X 5/8)
843	280643		SLEEVE, Lever


Footnotes:

Used After Code Date 97042700
 Used Before Code Date 97042700
 Used Before Code Date 97042800



Crankcase Cvr, Cam

REF NO	PART NO	QTY	DESCRIPTION
12	272125		GASKET, Crankcase -(.015)
12	272219		GASKET, Crankcase -(.005)
12	272220		GASKET, Crankcase -(.009)
15A	94880		PLUG, Oil Drain -(Flush)
18	496977		COVER, Crankcase
20	291675		SEAL, Oil -(Crankcase Cover)
22A	93764		SCREW -(Crankcase Cover)(Position 6)
22	93585		SCREW -(Crankcase Cover)
46	692123		CAMSHAFT
170	94931		STUD -(2 1/2)
186	230318		CONNECTOR, Hose
219	497037		GEAR, Governor
220	221551		WASHER -(Governor Lever)



1058 OWNER'S MANUAL

1019 LABEL KIT

★ REQUIRES SPECIAL TOOLS TO INSTALL.
SEE REPAIR INSTRUCTION MANUAL.

Cylinder, Head


REF NO	PART NO	QTY	DESCRIPTION
1	497411		CYLINDER ASSY
2	399265		KIT, Bushing/Seal -(Magneto Side)
3	391086		SEAL, Oil -(Magneto Side)
5	214194		HEAD, Cylinder
7	271866		GASKET, Cylinder Head
8B	497710		BREATHER ASSEMBLY
8A	495736		BREATHER ASSEMBLY
8	498038		BREATHER ASSEMBLY
9	27803		GASKET, Rocker Cover
10	94621		SCREW -(Breather Assembly)
11A	280225		TUBE, Breather
11	280819		TUBE, Breather
11	280819		TUBE, Breather
13	94622		SCREW -(3)
14	94776		STUD -(3 15/16)
15	92738		PLUG, Oil Drain
15	94239		PLUG, Oil Drain -(Square Head)
87	491323		SEAL, Governor Shaft
306	224882		SHIELD, Cylinder
307	94930		SCREW -(Cylinder Shield)
308	224897		COVER, Cylinder Head
337	802592		PLUG, Spark -(Resistor)
354	94726		NUT
362	392273		SHIELD, Spark Plug
383	89838		WRENCH, Spark Plug
552	491893		BUSHING, Governor Crank -(Includes Seal, Ref. 87)
635	66538		BOOT, Spark Plug
729	281396		CLIP, Wire
869	261463		SEAT, Valve -(Intake)
870	262924		SEAT, Valve -(Exhaust)
871	261961		BUSHING, Valve Guide -(Exhaust)
978	271736		GASKET, Oil Guard -(Oil Guard)
979	494807		COVER, Oil Guard
982	94658		SCREW
1019	497156		KIT, Label
1058	272848		MANUAL, Operator's
1058	273682		MANUAL, Operator's

Footnotes:

Used After Code Date 95040200


Used After Code Date 95010100 and Before Code Date 95040300

Used Before Code Date 95010200




Electric Starter

REF NO	PART NO	QTY	DESCRIPTION
309	693054		MOTOR, Starter -(3 5/8) (Aluminum Ring Gear)
310	94003		SCREW -(3 5/8 Housing)
311	497608		SET, Brush
503	806000		STRAP, Ground -(4 9/16 Housing)
510	497606		DRIVE, Starter
513	398003		CLUTCH, Starter
544	497603		ARMATURE, Starter -(3 5/8 Housing)
783	693059		GEAR, Pinion -(Aluminum Ring Gear Only)
797	693167		NUT
797	94010		NUT -(Air Cleaner Base)
801	394856		CAP, Drive
802	497607		CAP, End
803	497604		HOUSING, Starter -(3 5/8 Housing)
1051	263080		RING, Retaining
1090	497605		RETAINER, Brush




Electric Starter

REF NO	PART NO	QTY	DESCRIPTION
310	94003		SCREW -(3 5/8 Housing)
311A	395538		SET, Brush -(3 5/8 Housing)
510A	495878		DRIVE, Starter -(4 3/8 Housing)
513	398003		CLUTCH, Starter
544A	390837		ARMATURE, Starter -(3 5/8 Housing)
783	693059		GEAR, Pinion -(Aluminum Ring Gear Only)
801	394856		CAP, Drive
802A	395537		CAP, End -(3 5/8 Housing)
803A	398159		HOUSING, Starter -(3 5/8 Housing)
876	495877		DRIVE, Starter -(4 3/8 Housing)
896	94288		PIN, Drive Retainer







Fuel Tank Grps

REF NO	PART NO	QTY	DESCRIPTION
179	91257		SCREW -(1/4-20 X 1-1/2)
180	291488		TANK, Fuel -(6 Quart)
181	392305		CAP, Fuel Tank -(Metal)
182B	224856		BRACKET, Fuel Tank -(Lower)
182A	224854		BRACKET, Fuel Tank
182	224878		BRACKET, Fuel Tank -(6 Quart)
183	291490		STRAP, Fuel Tank -(6 Quart)
186	230318		CONNECTOR, Hose
187A	497029		LINE, Fuel -(Molded)
187	296004		LINE, Fuel -(Cut To Required Length)
199A	293934		VALVE, Fuel Shut Off
199	297563		OUTLET, Tank
240A	493629		FILTER, Fuel -(Fuel Pump)
240	394358		FILTER, Fuel -(Fuel Pump)
385	94789		SCREW -(Fuel Pump)
387	496257		PUMP, Fuel
464	280203		SEAL, O-Ring -(Fuel Shut Off)
601	93053		CLAMP, Hose -(Green)
674A	94095		SCREW -(Tapping)
674B	94627		SCREW -(Fuel Tank)
674	94622		SCREW -(3)
707	90970		NUT -(1/4-20)
917	223271		VALVE, Handle Shutoff
918	398367		HOSE/CLAMP ASSEMBLY
957	493988		CAP, Fuel Tank -(Plastic)
958	399517		VALVE, Fuel Shut Off -(Plastic)
972	493337		TANK, Fuel -(4 Quart) (Plastic)











Gear Reducer Assy

REF NO	PART NO	QTY	DESCRIPTION
15B	94886		PLUG, Oil Drain -(Flush)
15C	91488		PLUG -(1/8)
20A	391086		SEAL, Oil -(Magneto Side)
79	296179		CASE, Gear Reduction
80	27884		GASKET, Gear Cover/Housing
81	223016		LOCK, Muffler Screw
82	92502		SCREW
83	495985		SHAFT, Auxiliary Drive
84	94918		PLUG, Breather
85	91386		SCREW
86	296053		COVER, Gear
88	27328		GASKET, Gear Cover/Housing




Kits/Gasket Sets

REF NO	PART NO	QTY	DESCRIPTION
3	391086		SEAL, Oil -(Magneto Side)
7	271866		GASKET, Cylinder Head
9	27803		GASKET, Rocker Cover
12	272125		GASKET, Crankcase -(.015)
12	272219		GASKET, Crankcase -(.005)
12	272220		GASKET, Crankcase -(.009)
20	291675		SEAL, Oil -(Crankcase Cover)
51A	272707		GASKET, Intake
51	272708		GASKET, Intake
93	281346		BUSHING, Throttle Shaft
95	94098		SCREW -(Throttle Valve)
104	231789		PIN, Float Hinge
105	231935		VALVE, Float Needle
106	231856		SEAT, Inlet -(Pump Feed)
121	497450		KIT, Carburetor Overhaul
137	281165		GASKET, Float Bowl
142	497448		NOZZLE, Carburetor -(High Altitude)(Lmt 101)
142	497449		NOZZLE, Carburetor -(High Altitude)(Lmt 101)
142	499744		NOZZLE, Carburetor -(Standard) (Lmt 175)
142	499826		NOZZLE, Carburetor -(High Altitude)(Lmt 175)
147	497472		JET, Pilot -(Lmt 101)
163	272706		GASKET, Air Cleaner -(Air Cleaner)
163	692277		GASKET, Air Cleaner -(Air Cleaner)
276	281164		WASHER, Sealing
358	497511		GASKET SET, Engine
524	281370		SEAL, O-Ring -(Dipstick Tube)
634	494455		SPRING/SEAL ASSEMBLY -(Choke-A-Matic)
883	272293		GASKET, Exhaust
977	497069		SET, Carburetor Gasket
978	271736		GASKET, Oil Guard -(Oil Guard)
987	281166		SEAL, Choke/Throttle Shaft
1081	271170		SEAL, O-Ring -(Dipstick Tube)
1095	498538		GASKET SET, Valve



Muffler Grps

REF NO	PART NO	QTY	DESCRIPTION
81	223016		LOCK, Muffler Screw
300A	497966		MUFFLER
300	497470		MUFFLER
346	93705		SCREW -(8-32 X 3/8)
354	94726		NUT
436	497469		ADAPTER, Muffler
437	94755		SCREW -(Exhaust Manifold)
613	93927		SCREW -(Muffler)
676A	396903		DEFLECTOR, Muffler
676	393761		DEFLECTOR, Muffler -(Side Outlet)
677	93705		SCREW -(8-32 X 3/8)
823	94755		SCREW -(Exhaust Manifold)
832	496778		GUARD, Muffler
836A	94786		SCREW -(1/2)
836	94887		SCREW -(Tapping)
864	497965		ADAPTER, Muffler
883	272293		GASKET, Exhaust
994	392390		ARRESTOR, Spark



Piston Grp, Crankshaft

REF NO	PART NO	QTY	DESCRIPTION
16	497487		CRANKSHAFT
17	291667		BEARING, Ball
25	497518		PISTON ASSEMBLY -(Standard)
25	497519		PISTON ASSEMBLY -(.010 Oversize)
25	497520		PISTON ASSEMBLY -(.020 Oversize)
25	497521		PISTON ASSEMBLY -(.030 Oversize)
26	497522		SET, Ring
26	497523		SET, Ring -(.010 Oversize)
26	497524		SET, Ring -(.020 Oversize)
26	497525		SET, Ring -(.030 Oversize)
27	260924		LOCK, Piston Pin
27	263129		LOCK, Piston Pin
28	299691		PIN, Piston -(Standard)
28	391286		PIN, Piston -(.005 Oversize)
28	498319		PIN, Piston -(Standard)
28	498320		PIN, Piston -(.005 Oversize)
29	393860		ROD, Connecting -(Standard)
29	393861		ROD, Connecting -(.020 Undersize)
30	222329		DIPPER, Connecting Rod
32	95017		SCREW -(Connecting Rod)
33	261185		VALVE, Exhaust
34	261462		VALVE, Intake
35	65906		SPRING, Valve -(Intake)
36	26828		SPRING, Valve -(Exhaust)
40A	292260		RETAINER, Valve -(Exhaust)
40	221596		RETAINER, Valve -(Valves With Groove In Stem)
42	494553		KEEPER, Valve -(Exhaust)
45	262248		TAPPET, Valve
146	94196		KEY, Woodruff
741	262932		GEAR, Timing


Footnotes:

Used After Code Date 95101500
Used Before Code Date 95101600

Replacement Engine - US & Canada










REF NO	PART NO	QTY	DESCRIPTION
	-----		No engine replacement. Repair engine with individual parts.
	-----		Top No-Load Speed: 3150 -Trim: ALL
	-----		Service Note: For all Go-Karts use only a Model 136200 series engine as a replacement, regardless of the original Model.

Not For Reproduction



Rewind Assy

REF NO	PART NO	QTY	DESCRIPTION
55	393576		HOUSING, Rewind Starter
56	295871		PULLEY, Starter -(63 Rope)
57	490179		SPRING-REWIND STR
58	66884		ROPE, Starter -(Cut To Required Length)
59	490653		INSERT, Grip
60	490652		GRIP-STARTER ROPE
63	260414		SPRING, Ratchet
64	281204		ADAPTER, Ratchet Spring
65	94686		SCREW
66	399671		CLUTCH-STARTER
67	394897		HOUSING, Clutch
68	63770		BALL, Clutch
70	298799		RATCHET, Clutch
71	394506		COVER, Ratchet -(Rubber Coated)
373	90576		NUT -(Ground Terminal)
373	92987		STARTER, Rewind
608	390391		STARTER, Rewind
655	222598		ANCHOR, Rewind Spring
678	490817		SPACER-REWIND -(Rewind)
930	280685		GUARD, Rewind



Switch Plate, Elect, Oil Grp

REF NO	PART NO	QTY	DESCRIPTION
310	94003		SCREW -(3 5/8 Housing)
333	398811		ARMATURE, Magneto -(Magnetron Ignition)
334	94731		SCREW -(Magneto)
356A	496612		WIRE, Stop
428	90576		NUT -(Ground Terminal)
441	225111		BRACKET, Oil Fill
449	94984		SCREW
474A	391529		ALTERNATOR -(DC Only)
474	393295		ALTERNATOR
478	395410		KIT, Panel
482	93621		SCREW -(Tapping)
493	222934		BRACKET, Mounting
501	394890		REGULATOR
523	497214		DIPSTICK
524	281370		SEAL, O-Ring -(Dipstick Tube)
525	495347		TUBE, Dipstick
526	93343		SCREW -(Control Panel)
575	299139		SWITCH, Starting
577	392683		CABLE, Starter
578	397674		WIRE, Stop
636	92278		NUT -(Starting Switch)
641	91325		WASHER
663	94620		SCREW -(Control Panel)
664	94881		SCREW
795	496590		SWITCH, Toggle
813	393514		CLAMP
840	395408		KIT, Panel -(Toggle Switch)
847	497458		DIPSTICK/TUBE ASSEMBLY
851	493880		TERMINAL, Spark Plug
877A	393814		WIRE/CONNECTOR, Alternator -(10 Amp Regulated)
877	393456		WIRE/CONNECTOR, Alternator
878	393422		WIRE ASSEMBLY -(Dc Only)
945	223159		BRACKET, Starter Motor
978	271736		GASKET, Oil Guard -(Oil Guard)
980	496605		KIT, Oil Gard
982A	94657		SCREW
1081	271170		SEAL, O-Ring -(Dipstick Tube)

