















Parts Manual

Mfg. No: 25U232-0015-01


Model Components	Page
Air Cleaner, Exhaust System.	4
Armature, Controls, Electrical System, Governor Spring, Ignition, Spark Plug.	6
Blower Housing, Flywheel, Rewind Starter.	8
Camshaft, Crankcase Cover, Crankshaft, Cylinder, Piston/Rings/Connecting Rod, Warning Label.	10
Carburetor.	12
Cylinder Head, Gasket Sets.	14
Fuel Supply.	16
Replacement Engine - US & Canada.	18

Not For
Reproduction






Air Cleaner, Exhaust System

REF NO	PART NO	QTY	DESCRIPTION
11	799832		TUBE, Breather
11A	797768		TUBE, Breather
163A	-----		Gasket-Air Cleaner -(Not Available Individually) (See Reference 121, 125 & 358 For Replacement)
176	799834		SEAL, O-Ring -(Air Cleaner Base)
300	594258		MUFFLER
412	799830		NUT -(Air Cleaner Cover)
445	594216		FILTER, A/C Cartridge
467	691985		KNOB, Air Cleaner Cover
549	799833		WASHER -(Air Cleaner)
643	591806		RETAINER, Air Filter
676	590953		DEFLECTOR, Muffler
875	596320		BASE, Air Cleaner
875A	591804		BASE, Air Cleaner
883	-----		Gasket-Exhaust -(Not Available Individually) (See Reference 300 & 358 For Replacement)
968	596319		COVER, Air Cleaner
968A	591803		COVER, Air Cleaner
1453	591807		SEAL, Air Cleaner Cover




Armature, Controls, Electrical System, Governor Spring, Ignition, Spark Plug

REF NO	PART NO	QTY	DESCRIPTION
202	797810		LINK, Mechanical Governor
209	592073		SPRING, Governor
222	596321		BRACKET, Control
286	797772		MODULE, Oil Sensor
333	797769		ARMATURE, Magneto
337	798615		PLUG, Spark
347	596300		SWITCH, Rocker
383	-----		Wrench-Spark Plug -(Currently Not Available)
621	-----		Switch-Stop -(Currently Not Available)
789	590372		HARNESS, Wiring
1052	797771		SENSOR, Oil



Blower Housing, Flywheel, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
23	597639		FLYWHEEL
58	691921		ROPE, Starter -(Cut To Required Length)
304	596322		HOUSING, Blower
332	797811		NUT -(Flywheel)
455	797746		CUP, Flywheel
608	594263		STARTER, Rewind
1005	797748		FAN, Flywheel
1210	-----		Pulley/Spring Assembly -(Pulley) (Not Available Individually) (See Reference 608 For Replacement)
1211	-----		Pulley/Spring Assembly -(Spring) (Not Available Individually) (See Reference 608 For Replacement)



1319 WARNING LABEL

WARNING
Read and follow Operating Instructions before running engine.

Gasoline is flammable. Allow engine to cool at least 2 minutes before refueling.

Engines emit carbon monoxide, DO NOT run in enclosed area.








Muffler area temperature may exceed 150°F. Do not touch hot parts.

REQUIRED when replacing parts with warning labels affixed.

1319A WARNING LABEL







REQUIRED when replacing parts with warning labels affixed.

1036 EMISSIONS LABEL







Camshaft, Crankcase Cover, Crankshaft, Cylinder, Piston/Rings/Connecting Rod, Warning

REF NO	PART NO	QTY	DESCRIPTION
1	-----		Cylinder Assembly -(Currently Not Available)
3	-----		Seal-Oil -(Magneto Side) (Not Available Individually) (See Reference 358 For Replacement)
12	-----		Gasket-Crankcase -(Not Available Individually) (See Reference 358 For Replacement)
15	797793		PLUG, Oil Drain
16	591098		CRANKSHAFT
17	797765		BEARING, Ball
18	596317		COVER, Crankcase
20	-----		Seal-Oil -(PTO Side) (Not Available Individually) (See Reference 358 For Replacement)
22	-----		Screw -(Crankcase Cover/Sump) (Currently Not Available)
24	797812		KEY, Flywheel
25	799535		PISTON ASSEMBLY -(Standard)
28	797799		PIN, Piston
29	797804		ROD, Connecting
46	797851		CAMSHAFT
227	799924		LEVER, Governor Control
306	797749		SHIELD, Cylinder
522	594253		PLUG, Dipstick/Fill
616	797805		CRANK, Governor
842	-----		Seal-O Ring -(Dipstick Tube) (Not Available Individually) (See Reference 358 & 522 For Replacement)
842A	-----		Seal-O Ring -(Dipstick Tube) (Not Available Individually) (See Reference 358 & 522A For Replacement)
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1319	794467		LABEL, Warning
1319A	797669		LABEL, Warning






Carburetor

REF NO	PART NO	QTY	DESCRIPTION
51	-----		Gasket-Intake -(Not Available Individually) (See Reference 121, 125 & 358 For Replacement)
51A	-----		Gasket-Intake -(Not Available Individually) (See Reference 121, 125 & 358 For Replacement)
53	590390		STUD -(Carburetor)
104	-----		Pin-Float Hinge -(Not Available Individually) (See Reference 121 For Replacement)
105	-----		Valve-Float Needle -(Not Available Individually) (See Reference 121 For Replacement)
106	-----		Seat-Inlet -(Not Available Individually) (See Reference 121 For Replacement)
117	596389		JET, Main -(Standard)
118	596390		JET, Main -(High Altitude)
121	594261		KIT, Carburetor Overhaul
122	799961		SPACER, Carburetor
125	594259		CARBURETOR
137	-----		Gasket-Float Bowl -(Not Available Individually) (See Reference 121 For Replacement)
163	-----		Gasket-Air Cleaner -(Not Available Individually) (See Reference 121, 125A & 358 For Replacement)
163A	-----		Gasket-Air Cleaner -(Not Available Individually) (See Reference 121, 125 & 358 For Replacement)
950	-----		Screw-Float Bowl -(Not Available Individually) (See Reference 121 For Replacement)
951	-----		Lever-Choke -(Not Available Individually) (See Reference 121 & 125 For Replacement)
951A	-----		Lever-Choke -(Not Available Individually) (See Reference 121 & 125A For Replacement)



Cylinder Head, Gasket Sets

REF NO	PART NO	QTY	DESCRIPTION
3	-----		Seal-Oil -(Magneto Side) (Not Available Individually) (See Reference 358 For Replacement)
5	799801		HEAD, Cylinder
7	-----		Gasket-Cylinder Head -(Not Available Individually) (See Reference 358 For Replacement)
12	-----		Gasket-Crankcase -(Not Available Individually) (See Reference 358 For Replacement)
13	-----		Screw -(Cylinder Head) (Currently Not Available)
20	-----		Seal-Oil -(PTO Side) (Not Available Individually) (See Reference 358 For Replacement)
33	594257		VALVE, Exhaust
34	594256		VALVE, Intake
35	797780		SPRING, Valve -(Intake)
36	797780		SPRING, Valve -(Exhaust)
40	797781		RETAINER, Valve
40A	797782		RETAINER, Valve
42	797783		KEEPER, Valve
45	-----		Tappet-Valve -(Currently Not Available)
51	-----		Gasket-Intake -(Not Available Individually) (See Reference 121, 125 & 358 For Replacement)
51A	-----		Gasket-Intake -(Not Available Individually) (See Reference 121, 125 & 358 For Replacement)
53	590390		STUD -(Carburetor)
163A	-----		Gasket-Air Cleaner -(Not Available Individually) (See Reference 121, 125 & 358 For Replacement)
238	797784		CAP, Valve
276	797847		WASHER, Sealing -(Rocker Cover)
358	594255		GASKET SET, Engine
830	591088		STUD, Rocker Arm
842	-----		Seal-O Ring -(Dipstick Tube) (Not Available Individually) (See Reference 358 & 522 For Replacement)
868	-----		Seal-Valve -(Currently Not Available)
883	-----		Gasket-Exhaust -(Not Available Individually) (See Reference 300 & 358 For Replacement)
1022	-----		Gasket-Rocker Cover -(Not Available Individually) (See Reference 358 For Replacement)
1023	799778		COVER, Rocker
1026	-----		Rod-Push -(Currently Not Available)
1029	591087		ARM, Rocker
1034	-----		Guide-Push Rod -(Currently Not Available)



Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
187	595725		LINE, Fuel
240	-----		Filter-Fuel -(Not Available Individually) (See Reference 972 For Replacement)
957	594135		CAP, Fuel Tank
972	594262		TANK, Fuel

Not For Reproduction

Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
--------	---------	-----	-------------

Not For Reproduction

