




Parts Manual

Mfg. No: 356447-0721-B5

Model Components	Page
Air Cleaner Group.	4
Alternator Group.	6
Blower Housing Group.	8
Carburetor Group.	10
Controls Group.	12
Crankcase Cover/Sump Group.	14
Crankshaft Group.	16
Cylinder Group.	18
Cylinder Head Group.	22
Exhaust Group.	26
Flywheel, Ignition, and Starter Group.	28
Fuel Supply Group.	30
Lubrication Group.	32



Not For
Reproduction

Not For
Reproduction



Air Cleaner Group


REF NO	PART NO	QTY	DESCRIPTION
11	844921	1	TUBE, Breather
163	844931	1	GASKET, Air Cleaner
445	394018S	1	FILTER, A/C Cartridge
467A	846431	1	KNOB, Air Cleaner Cover
643	844932	1	RETAINER, Air Cleaner
717	692153	1	BRACKET, Air Cleaner
875	844929	1	BASE, Air Cleaner
967	272490S	1	FILTER, Pre Cleaner
968	699959	1	COVER, Air Cleaner
971	807084	5	SCREW -(Air Cleaner Base to Carburetor/Throttle Body)
996	844930	1	SHIELD, Carburetor
1004	842258	1	DUCT, Air



Alternator Group


REF NO	PART NO	QTY	DESCRIPTION
474	592830	1	ALTERNATOR
501	845907	1	REGULATOR
526	692067	2	SCREW -(Regulator)
1059	698516	1	KIT, Screw/Washer
1119	691552	2	SCREW -(Alternator)

Not For Reproduction




Blower Housing Group

REF NO	PART NO	QTY	DESCRIPTION
304	84003968	1	HOUSING, Blower
305	692056	2	SCREW -(Blower Housing)
305A	841233	2	SCREW -(Blower Housing)
506	807120	2	SCREW -(Carburetor/EFI Cover)
879	841607	4	COVER, Carburetor/EFI
1036	-----		LABEL, Emissions -(Available From A Briggs & Stratton Authorized Service Dealer)
1319A	797669		LABEL, Warning -(Required When Replacing Parts With Warning Labels Affixed)
1319B	278911GS		LABEL, Warning -(Required When Replacing Parts With Warning Labels Affixed)




Carburetor Group

REF NO	PART NO	QTY	DESCRIPTION
51	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
94	847026	1	KIT, Idle Mixture
95	690718	3	SCREW -(Throttle Valve)
98	808177	1	KIT, Idle Speed
102	692077	1	GASKET, Carburetor Body
104	690723	1	PIN, Float Hinge
105	797410	4	VALVE, Float Needle
108	844989	1	VALVE, Choke
109	843321	3	SHAFT, Choke
117	806373	1	JET, Main -(Standard)
118C	842439	1	JET, Main -(High Altitude)
119	690720	1	SCREW -(Upper Carburetor Body To Lower Carburetor Body)
121	845146	1	KIT, Carburetor Overhaul -(Service Kits can include parts not for this engine.)
122	846579	1	SPACER, Carburetor
125	845015	1	CARBURETOR
127	847028	1	PLUG, Welch
130	806132	1	VALVE, Throttle
131	845022	1	KIT, Throttle Shaft
133	843320	1	FLOAT, Carburetor
163	-----	1	GASKET, Air Cleaner -(Part information located in Air Cleaner Group.)
216	690705	1	LINK, Choke
231	690718	1	SCREW -(Choke Valve)
255	690721	1	BUSHING, Choke Shaft
276A	806137	1	WASHER, Sealing
365	690711	4	SCREW -(Carburetor/Throttle Body)
633	690722	1	SEAL, Choke/Throttle Shaft
633A	806131	1	SEAL, Choke/Throttle Shaft
947A	692094	1	SOLENOID, Fuel
996	844930	1	SHIELD, Carburetor




Controls Group

REF NO	PART NO	QTY	DESCRIPTION
188	691902	4	SCREW -(Control Bracket)
209	692070	1	SPRING, Governor
211	692069	1	SPRING, Governed Idle
212	847015	1	LINK, Throttle
216	690705	1	LINK, Choke
222	808454	1	BRACKET, Control
222A	690923	1	CRANK, Bell
227	690236	1	LEVER, Governor Control
232	692073	2	SPRING, Governor Link
262	841552	2	SCREW -(Rod Bracket)
265	691024	3	CLAMP, Casing
267	841552	3	SCREW -(Casing Clamp)
278	842122	1	WASHER -(Governor Control Lever)
282	841552	1	SCREW -(Control Lever)
359	691077	1	WASHER -(Ground Terminal)
373	845823	4	NUT -(Ground Terminal)
505	844752	1	NUT -(Governor Control Lever)
507	691972	1	INSULATOR
520	691084	1	TERMINAL, Ground
562	690239	1	BOLT -(Governor Control Lever)
578	844547	1	HARNESS, Wiring
663	692056	1	SCREW -(Control Panel)
729	593826	1	CLIP, Wire
1054A	5021029SM	2	TIE, Cable 11" Long
1084	848341	1	CONNECTOR, Terminal
1403	841552	1	SCREW -(Wire Assembly)
1537	703460	1	NUT, Hex #8-32




Crankcase Cover/Sump Group

REF NO	PART NO	QTY	DESCRIPTION
3	-----	1	SEAL, Oil -(Part information located in Cylinder Group.)
7	-----	1	GASKET, Cylinder Head -(Part information located in Cylinder Head Group.)
9	-----	1	GASKET, Breather -(Part information located in Cylinder Group.)
12	846487	1	GASKET, Crankcase
163	-----	2	GASKET, Air Cleaner -(Part information located in Air Cleaner Group.)
18	84004412	1	COVER, Crankcase
20	805049S	1	SEAL, Oil -(PTO Side)
22	807362	9	SCREW -(Crankcase Cover/Sump)
51	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
51A	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
85	841233	2	SCREW -(Gear Cover)
86	690745	2	COVER, Gear
273	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
358	-----	1	GASKET SET, Engine -(Part information located in Cylinder Group.)
404	690704	1	WASHER -(Governor Crank)
415	794903	1	PLUG
439	-----	1	O-RING, Oil Gallery -(Part information located in Lubrication Group.)
468	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
524	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
552	690701	1	BUSHING, Governor Crank
552A	806686	2	BUSHING, Governor Crank
614	691550	1	PIN, Cotter
616	806685	1	CRANK, Governor
691	842826	1	SEAL, Governor Shaft
868	-----	1	SEAL, Valve -(Part information located in Cylinder Head Group.)
883	-----	2	GASKET, Exhaust -(Part information located in Exhaust Group.)
988	-----	1	GASKET, Oil Adapter -(Part information located in Lubrication Group.)
1022	-----	2	GASKET, Rocker Cover -(Part information located in Cylinder Head Group.)
1516	846459	2	SCREW -(Governor Crank)
1548	843827	2	BEARING, Ball -(Crankcase Cover/Sump)




Crankshaft Group

REF NO	PART NO	QTY	DESCRIPTION
16	84004523	1	CRANKSHAFT
24	808095	1	KEY, Flywheel
25	843792	2	PISTON ASSEMBLY -(Standard)
25	843821	2	PISTON ASSEMBLY -(.020" Oversize)
26	843793	2	SET, Ring -(Standard)
26	843822	1	SET, Ring -(.020" Oversize)
27	690683	4	LOCK, Piston Pin
28	844541	2	PIN, Piston
29	807900S	1	ROD, Connecting
32	690698	2	SCREW -(Connecting Rod)
45	-----	4	TAPPET, Valve -(Part information located in Cylinder Head Group.)
46	845649	1	CAMSHAFT
146	691639	1	KEY, Woodruff
357	691483	1	KEY, Drive Pulley
598	807625	1	SHIM, End Play -(Crankshaft or Camshaft Bearing)
741	846085	4	GEAR, Timing
1025	690689	1	SPOOL, Governor
1615	84007613	1	WASHER -(Governor Spool)



Cylinder Group


REF NO	PART NO	QTY	DESCRIPTION
1	84003975	1	CYLINDER ASSEMBLY
2	845665	2	KIT, Bushing/Seal -(Magneto Side)
3	845659	1	SEAL, Oil
7	-----	1	GASKET, Cylinder Head -(Part information located in Cylinder Head Group.)
8	808984	2	BREATHER ASSEMBLY
9	844986	1	GASKET, Breather
10	690751	1	SCREW -(Breather Assembly)
11	-----	2	TUBE, Breather -(Part information located in Air Cleaner Group.)
12	-----	1	GASKET, Crankcase -(Part information located in Crankcase Cover/Sump Group.)
15	690946	1	PLUG, Oil Drain
20	-----	1	SEAL, Oil -(Part information located in Crankcase Cover/Sump Group.)
163	-----	2	GASKET, Air Cleaner -(Part information located in Air Cleaner Group.)
215	841183	1	GUIDE, Air
215A	841182	1	GUIDE, Air
273	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
276A	-----	1	WASHER, Sealing -(Part information located in Carburetor Group.)
358	841188	1	GASKET SET, Engine -(Service Kits can include parts not for this engine.)
405	807163	4	SCREW -(Back Plate)
439	-----	1	O-RING, Oil Gallery -(Part information located in Lubrication Group.)
447	841233	2	SCREW -(Air Guide Cover)
468	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
51	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
51A	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
524	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
572	690686	1	BAFFLE, Breather
573	841310	1	PLATE, Back
691	-----	1	SEAL, Governor Shaft -(Part information located in Crankcase Cover/Sump Group.)
718	806469	1	PIN, Locating
732	690688	1	SCREW -(Part information located in Flywheel/Ignition/Starter Group.)
865	843768	1	COVER, Air Guide
868	-----	1	SEAL, Valve -(Part information located in Cylinder Head Group.)
883	-----	2	GASKET, Exhaust -(Part information located in Exhaust Group.)
988	-----	1	GASKET, Oil Adapter -(Part information located in Lubrication Group.)
1022	-----	4	GASKET, Rocker Cover -(Part information located in Cylinder Head Group.)
1334	841233	1	SCREW -(Air Guide)



Cylinder Group


REF NO	PART NO	QTY	DESCRIPTION
1334A	807084	3	SCREW -(Air Guide)

Not For Reproduction




Cylinder Head Group

REF NO	PART NO	QTY	DESCRIPTION
3	-----	1	SEAL, Oil -(Part information located in Cylinder Group.)
5	84002674	1	HEAD, Cylinder -(Cylinder #1)
5A	84002675	1	HEAD, Cylinder -(Cylinder #2)
7	845884	2	GASKET, Cylinder Head
9	-----	1	GASKET, Breather -(Part information located in Cylinder Group.)
12	-----	1	GASKET, Crankcase -(Part information located in Crankcase Cover/Sump Group.)
13	692059	8	SCREW -(Cylinder Head)
20	-----	1	SEAL, Oil -(Part information located in Crankcase Cover/Sump Group.)
21	809500	1	CAP, Oil Fill
33	808687	1	VALVE, Exhaust
34	807680	2	VALVE, Intake
35	692084	2	SPRING, Valve -(Intake)
36	692084	2	SPRING, Valve -(Exhaust)
40	692058	2	RETAINER, Valve
42	807683	1	KEEPER, Valve
45	843379	4	TAPPET, Valve
50	690754	1	MANIFOLD, Intake
51	691694	2	GASKET, Intake
51A	692035	2	GASKET, Intake
54	846604	4	SCREW -(Intake Manifold)
163	-----	1	GASKET, Air Cleaner -(Part information located in Air Cleaner Group.)
192	807623	4	ADJUSTER, Rocker Arm
273	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
276A	-----	1	WASHER, Sealing -(Part information located in Carburetor Group.)
337	792015	2	PLUG, Spark
358	-----	1	GASKET SET, Engine -(Part information located in Cylinder Group.)
383	19576S	1	WRENCH, Spark Plug
439	-----	1	O-RING, Oil Gallery -(Part information located in Lubrication Group.)
468	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
524	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
635	84005066	1	BOOT, Spark Plug
691	-----	1	SEAL, Governor Shaft -(Part information located in Crankcase Cover/Sump Group.)
830	809157	4	STUD, Rocker Arm
868	691963	2	SEAL, Valve
871	692057	4	BUSHING, Valve Guide
883	-----	2	GASKET, Exhaust -(Part information located in Exhaust Group.)
988	-----	1	GASKET, Oil Adapter -(Part information located in Lubrication Group.)




Cylinder Head Group

REF NO	PART NO	QTY	DESCRIPTION
1022	806039S	2	GASKET, Rocker Cover
1023A	691494	1	COVER, Rocker
1023C	690910	1	COVER, Rocker
1026	691836	2	ROD, Push -(Intake)
1026A	691758	2	ROD, Push -(Exhaust)
1029	84012342	4	ARM, Rocker
1095	841191	1	GASKET SET, Valve -(Service Kits can include parts not for this engine.)
1100	791959	4	PIVOT, Rocker Arm
1254	699481	4	SCREW -(Rocker Arm Stud)






Exhaust Group

REF NO	PART NO	QTY	DESCRIPTION
296	84006950	2	STUD
300	692099	1	MUFFLER
436	692061	4	MANIFOLD, Exhaust
613	692067	2	SCREW -(Muffler)
676	795036	1	DEFLECTOR, Muffler
677	794845	1	SCREW -(Muffler Deflector)
819	692067	2	SCREW -(Muffler Bracket)
863	691513	1	BRACKET, Muffler
883	691613	1	GASKET, Exhaust
884	690898	1	CLAMP, Muffler
1176	842067	1	NUT -(Exhaust Manifold)




Flywheel, Ignition, and Starter Group

REF NO	PART NO	QTY	DESCRIPTION
23	841050	1	FLYWHEEL ASSEMBLY
73	841440	1	SCREEN, Rotating
74	841441	4	SCREW
309	846451	1	MOTOR, Starter
332	690887	1	NUT -(Flywheel)
334	692066	4	SCREW -(Magneto Armature)
363	19203	1	PULLER, Flywheel
529	690744	2	GROMMET
578	-----	1	WIRE ASSEMBLY -(Part information located in Controls Group.)
697	691902	4	SCREW -(Drive Cap)
727	841313	1	COVER, Starter Drive
732	690688	1	SCREW -(Starter Drive Cover)
732A	841233	1	SCREW -(Starter Drive Cover)
934	692062	2	SCREW -(Fan Retainer)
1005	841439	1	FAN, Flywheel
1006	690452	1	RETAINER, Fan



Fuel Supply Group

REF NO	PART NO	QTY	DESCRIPTION
187	791766	1	LINE, Fuel
240	845125	1	FILTER, Fuel
385	807084	2	SCREW -(Fuel Pump)
387	808656	1	PUMP, Fuel
601	691038	6	CLAMP, Hose
628	806660	1	SCREW -(Fuel Pump Bracket)
674A	692062	3	SCREW -(Fuel Tank Bracket)
674B	692056	1	SCREW -(Fuel Tank Bracket)
788	691559	1	BRACKET, Fuel Pump
918	791880	1	HOSE, Vacuum



Lubrication Group

REF NO	PART NO	QTY	DESCRIPTION
273	690681	1	SEAL, O-Ring -(Oil Pump)
287	692062	1	SCREW -(Dipstick Tube)
439	692154	1	O-RING, Oil Gallery -(Crankcase Cover/Sump or Cylinder Assembly)
468	690690	1	SEAL, O-Ring -(Oil Pump Screen)
479	807084	1	SCREW -(Oil Pump Screen)
523	693175	1	DIPSTICK
524	693172	1	SEAL, O-Ring -(Dipstick Tube)
525	693174	1	TUBE, Dipstick
596	691492	2	SCREW -(Oil Pump)
737	84006523	3	SCREW -(Oil Filter Adapter)
988	692063	1	GASKET, Oil Adapter
1017	690900	1	SCREEN, Oil Pump
1024	843825	1	PUMP, Oil
1027	842921	1	FILTER, Oil
1028	808033	1	ADAPTER, Oil Filter
1373	841233	2	SCREW -(Oil Cooler Bracket)

