


REPLACEMENT PARTS - MODEL S29SS

ELECTRIC START CAPABLE 4-CYCLE TRIMMER

PPN 41ADZ29C707



Item	Part No.	Description
1	753-06134	Engine Cover Assembly (includes 2 & 41)
2	753-04595	Cover Screw
3	791-181003	Screw
4	753-05901	Rocker Cover
5	753-05902	Rocker Cover O-Ring
6	753-05910	Cylinder O-Ring
7	791-182379	Breather Hose
8	753-05408	Oil Plug (includes 9)
9	791-182290	Oil Plug O-Ring
10	841-020721S	Crankcase Cover
11	753-05238	Crankcase Cover O-ring
12	753-06221	Flywheel Assembly
13	753-05264	Lead Wires
14	753-05447	Module Assembly
15	753-05245	Muffler Assembly (includes 16 & 17)
16	753-05244	Muffler Gasket
17	710-04809	Muffler Screw
18	794-00082	Spark Plug
19	753-05247	Insulator Gasket
20	753-05248	Nut
21	753-06947	Insulator

Item	Part No.	Description
22	753-06948	Carburetor Gasket
23	753-06258A	Carburetor w/Primer
24	791-181751	Air Cleaner O-Ring
25	753-05831	Air Cleaner Cover Assembly (includes 26)
26	753-05254	Air Filter
27	753-05253	Screw
28	753-06797	Fuel Tank Assembly (includes 29)
29	753-04084	Fuel Cap
30	753-05259	Fuel Tank Pads
31	841-021041S	Starter Housing Assembly (includes 3 & 38)
32	753-06281	Clutch Assembly
33	753-05263	Clutch Cover (includes 2)
34	791-182519	Anti-Rotation Screw
35	753-04003	Clamp Screw
36	791-180217	Nut
37	753-09424	Shortblock Assy. (includes 3-11, 18, 39 & 41)
38	753-05078	Spacer
39	791-181025	Rocker Cover Screw
40	753-06949	Heat Shield
41	753-05377	Screw
42	791-181709	Gasket

REPLACEMENT PARTS - MODEL S29SS

ELECTRIC START CAPABLE 4-CYCLE TRIMMER

PPN 41ADZ29C707

Item	Part No.	Description
43	753-05296	Throttle Housing Assembly (includes 44 - 47)
44	753-08378	Throttle Trigger Lock-Out
45	791-182405	Trigger Switch Assembly
46	753-05007	Throttle Trigger Spring
47	731-04970B-10	Throttle Trigger
48	753-05266	Throttle Cable Assembly
49	841-033532S	Upper Shaft Housing Assembly
50	731-08926	Hanger
51	753-08343	Handle
52	753-1190	Split Boom Coupler (includes 53)
53	791-182057	Anti-Rotation Screw
54	841-032146S-1	Lower Shaft Housing Assembly
55	753-05267	Lower Flexible Drive Shaft
56	753-08180	Gearbox Assembly (includes 57 - 59)
57	791-182519	Anti-rotation Screw
58	791-182195	Gearbox Mounting Hardware
59	748-05052	Cutting Head Driver
60	753-08354	Shield Assembly (includes 61 & 62)
61	753-04282	Shield Mounting Hardware
62	753-08355	Blade Assembly
63	841-031656S	Cutting Head Assembly (includes 64)
64	753-08563	Bump Knob

