










Parts Manual

Mfg. No: 441677-0754-E1

Model Components	Page
Air Cleaner, Blower Housing, Exhaust System.	4
Alternator, Fuel Supply, Ignition.	6
Camshaft, Crankshaft, Cylinder, Engine Sump, Lubrication, Piston, Rings, Connecting Rod.	8
Carburetor, Gasket Set - Engine, Kit - Carburetor Overhaul.	12
Controls, Electric Starter, Flywheel, Governor Spring.	16
Cylinder Head, Gasket Set - Valve, Intake Manifold, Valves.	20
Replacement Engine - US & Canada.	24
Model 40, 44 & 49 Engine Accessories Catalog.	25
Maintenance Kits.	26
Engine Mounted Below Deck Mufflers.	28
Engine Mounted Above Deck Mufflers.	30
Spark Arrester/Deflector.	32
Lubrication.	34
Implement Mounted Above Deck Mufflers.	36
Exhaust/Muffler Configurations.	38
Electrical.	40
Flywheel Guards.	42
Speed Control.	44
Muffler Mounting Hardware.	46














1036 EMISSIONS LABEL







Air Cleaner, Blower Housing, Exhaust System

REF NO	PART NO	QTY	DESCRIPTION
51D	699800		GASKET, Intake
300	696226		MUFFLER
304A	796597		HOUSING, Blower -Used After Code Date 08091400
304A	791243		HOUSING, Blower -Used Before Code Date 08091500
305	691005		SCREW -(Blower Housing) (21/32)
305B	790690		SCREW -(Blower Housing) (Blower Housing To Intake Elbow)
405A	697820		SCREW -(Back Plate)
431	790628		MANIFOLD, Intake
445	499486S		FILTER-A/C CARTRIDGE -(Paper Element)
447	691003		SCREW -(Air Guide Cover)
447A	691108		SCREW -(Air Guide Cover)
467	691008		KNOB, Air Cleaner Cover -(1 1/2)
467A	790697		KNOB, Air Cleaner Cover -(1" Long)
573	790444		PLATE, Back
613	690341		SCREW -(Muffler)
613A	690297		SCREW -(Muffler)
703	691010		CLIP
729	694123		CLIP, Wire
865	691012		COVER, Air Guide -(Cylinder 1)
865A	793205		SHIELD, Cylinder -(Cylinder 2)
865B	691015		COVER, Air Guide -(Valley)
883	690970		GASKET, Exhaust
967	273638S		FILTER-PRE CLEANER
968C	791242		COVER, Air Cleaner
1036	-----		Label-Emissions
1040	791237		PLATE, Trim

DUAL CIRCUIT		5-9 CIRCUIT		10 - 16 AMP		TRI CIRCUIT	
474B	1059	474C	1059	474D	1059	474C	1059
							
							
							


NOTE: All Stators Use a No. 1119 Mounting Screw. 

NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.



Alternator, Fuel Supply, Ignition

REF NO	PART NO	QTY	DESCRIPTION
10	691108		SCREW -(Breather Assembly)
333	691060		ARMATURE, Magneto
334	691061		SCREW -(Magneto Armature)
474B	696459		ALTERNATOR -(Dual Circuit)
474C	696457		ALTERNATOR -(Tri Circuit)
474D	696458		ALTERNATOR -(10 and 16 Amp Regulated)
501A	794360		REGULATOR -(9 Amp)
501D	691185		REGULATOR -(16 Amp Regulated)
526A	691129		SCREW -(Regulator)
526B	691108		SCREW -(Regulator)
578A	691208		WIRE ASSEMBLY
635	66538S		BOOT, Spark PLug
729	694123		CLIP, Wire
789A	790544		WIRE/CONNECTOR, Alternator
789B	698330		HARNESS, Wiring
789C	696576		HARNESS, Wiring
789D	691220		HARNESS, Wiring
851	493880S		TERMINAL, Spark Plug
877	393456		WIRE/CONNECTOR, Alternator
877B	393537		WIRE/CONNECTOR, Alternator -(Tri Circuit) (9 Amp)
877C	399916		WIRE/CONN-ALTERNATOR
878	398661		HARNESS, Wiring -(Dual Circuit)
878A	691955		HARNESS, Alternator -(Tri Circuit)
1054	280275		TIE, Cable
1059	698516		KIT, Screw/Washer
1119	691183		SCREW -(Alternator)












1058 OPERATOR'S MANUAL
1330 REPAIR MANUAL

1319 WARNING LABEL

WARNING


- Read and follow Operating Instructions before running engine.
- Gasoline is flammable. Allow engine to cool at least 2 minutes before refueling.
- Engines emit carbon monoxide, DO NOT run in enclosed area.
- Muffler area temperature may exceed 150°F. Do not touch hot parts.

REQUIRED when replacing parts with warning labels affixed.



Camshaft, Crankshaft, Cylinder, Engine Sump, Lubrication, Piston, Rings, Connecting

REF NO	PART NO	QTY	DESCRIPTION
1	793564		CYLINDER ASSEMBLY
2	499585		KIT, Bushing/Seal -(Magneto Side)
3	391086S		SEAL, Oil -(Magneto Side)
4	699747		SUMP, Engine
8	792185		BREATHER ASSEMBLY
9	690937		GASKET, Breather
10	691108		SCREW -(Breather Assembly)
11	792184		TUBE-BREATHER
12	697227		GASKET, Crankcase
15	691680		PLUG, Oil Drain
15A	690946		PLUG, Oil Drain
16	699700		CRANKSHAFT
20	795387		SEAL, Oil -(PTO Side)
22	694966		SCREW -(Crankcase Cover/Sump)
24	222698S		KEY, Flywheel
25	792023		PISTON ASSEMBLY -(Standard)
25	792072		PISTON ASSEMBLY -(.020 Oversize)
26	694004		SET, Ring -Used Before Code Date 05071900
26	694008		SET, Ring -(.020 Oversize) -Used Before Code Date 05071900
26	792026		SET, Ring -Used After Code Date 05071800
26	792073		SET, Ring -(.020 Oversize) -Used After Code Date 05071800
27	690975		LOCK, Piston Pin
28	690229		PIN, Piston -(Standard)
29	699699		ROD, Connecting -(Standard)
32	690976		SCREW -(Connecting Rod)
45	690977		TAPPET, Valve
46	792555		CAMSHAFT
146	690979		KEY, Woodruff
239	697049		SWITCH, Oil Pressure
250	690957		RETAINER, Breather
252	794389		COLLECTOR-OIL
287	691108		SCREW -(Dipstick Tube)
357	691483		KEY, Drive Pulley
415	794903		PLUG
523	691036		DIPSTICK
524	691032		SEAL, O-Ring
525	691037		TUBE, Dipstick
552	690552		BUSHING-GOV CRANK
691	790574		SEAL, Governor Shaft












1058 OPERATOR'S MANUAL
1330 REPAIR MANUAL

1319 WARNING LABEL

WARNING





- Read and follow Operating Instructions before running engine.
- Gasoline is flammable. Allow engine to cool at least 2 minutes before refueling.
- Engines emit carbon monoxide, DO NOT run in enclosed area.
- Muffler area temperature may exceed 150°F. Do not touch hot parts.

REQUIRED when replacing parts with warning labels affixed.






Camshaft, Crankshaft, Cylinder, Engine Sump, Lubrication, Piston, Rings, Connecting

REF NO	PART NO	QTY	DESCRIPTION
718	690959		PIN, Locating
741	690980		GEAR, Timing
750	696999		SCREW -(Oil Pump Cover)
842	691031		SEAL, O-Ring -(Dipstick Tube)
847	499602		DIPSTICK/TUBE ASSEMBLY
850	100100		SEALANT, Liquid
943	690589		SEAL, O-Ring -(Oil Pump Cover)
965	499613		COVER, Oil Pump
1013	690954		NIPPLE, Oil Filter
1017	690770		SCREEN, Oil Pump
1024A	794416		PUMP, Oil
1027	492932S		FILTER, Oil
1035	691042		SHAFT, Pump -Used Before Code Date 07022600
1058	278776TRI		MANUAL, Operator's
1319	794467		LABEL, Warning
1330	273521		MANUAL, Repair




Carburetor, Gasket Set - Engine, Kit - Carburetor Overhaul

REF NO	PART NO	QTY	DESCRIPTION
3	391086S		SEAL, Oil -(Magneto Side)
7	693997		GASKET, Cylinder Head
9	690937		GASKET, Breather
12	697227		GASKET, Crankcase
20	795387		SEAL, Oil -(PTO Side)
51	699803		GASKET, Intake
51D	699800		GASKET, Intake
51E	690949		GASKET, Intake
98	699721		KIT, Idle Speed
104	694918		PIN, Float Hinge
105	797410		VALVE, Float Needle
108A	699808		VALVE, Choke
117E	791406		JET, Main -(Standard)
118E	699820		JET, Main -(High Altitude)
121C	699814		KIT, Carburetor Overhaul
125C	699807		CARBURETOR
127	699810		PLUG, Welch
130A	699809		VALVE, Throttle
131A	699812		KIT, Throttle Shaft
133B	694914		FLOAT, Carburetor
135B	792022		TUBE-FUEL TRANSFER
137A	698781		GASKET, Float Bowl
141A	699811		KIT, Choke Shaft
187A	791766		LINE, Fuel -(Cut To Required Length)
187B	791872		LINE, Fuel -(Formed Hose)
187D	791744		LINE, Fuel -(Formed)(Cut To Required Length)
231	690718		SCREW -(Choke Valve)
240	84001895		FILTER, Fuel
276A	695410		WASHER, Sealing
358B	699823		GASKET SET-ENGINE
385	691108		SCREW -(Fuel Pump)
387	808656		PUMP, Fuel
524	691032		SEAL, O-Ring
601	791850		CLAMP, Hose -(Green)
601A	691038		CLAMP, Hose -(Black)
628	691108		SCREW -(Fuel Pump Bracket) -Used Before Code Date 06081500
633A	695414		SEAL, Choke/Throttle Shaft
691	790574		SEAL, Governor Shaft
788	691039		BRACKET, Fuel Pump -Used Before Code Date 06072800
788A	793145		BRACKET, Fuel Pump -Used After Code Date 06072700




Carburetor, Gasket Set - Engine, Kit - Carburetor Overhaul

REF NO	PART NO	QTY	DESCRIPTION
842	691031		SEAL, O-Ring -(Dipstick Tube)
868	690968		SEAL, Valve
883	690970		GASKET, Exhaust
918	694000		HOSE-VACUUM -Used Before Code Date 06072800
918	793147		HOSE, Vacuum -Used After Code Date 06072700
943	690589		SEAL, O-Ring -(Oil Pump Cover)
947	699728		SOLENOID, Fuel
958	698183		VALVE, Fuel Shut Off -(Plastic)
975B	699502		BOWL, Float
987A	699813		SEAL, Choke/Throttle Shaft
1022	690971		GASKET, Rocker Cover
1127A	695407		SCREW -(Float Bowl) (Float Bowl to Carburetor Body)






Controls, Electric Starter, Flywheel, Governor Spring

REF NO	PART NO	QTY	DESCRIPTION
23	691053		FLYWHEEL
73	494439		SCREEN, Rotating
74	698425		SCREW -(Rotating Screen)
75	691056		WASHER -(Flywheel)
165	693148		NUT -(Ring Gear)
188	691108		SCREW -(Control Bracket)
209	793339		SPRING, Governor
211	691019		SPRING, Governed Idle
212B	792265		LINK, Throttle -Used Before Code Date 08071400
212B	695238		LINK, Throttle -Used After Code Date 08071300
213	691021		BRACKET, Choke Control
216	691022		LINK, Choke
219	793338		GEAR, Governor
220	690412		WASHER -(Governor Gear)
222	698761		BRACKET, Control
227	796223		LEVER, Governor Control
265	691024		CLAMP, Casing
267	691044		SCREW -(Casing Clamp) .630 Length
267A	695134		SCREW -(Casing Clamp) .625 Length
267B	792629		SCREW -(Casing Clamp) .703 Length
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing)
271	691028		LEVER, Control
278	792651		WASHER -(Governor Lever)
309	497595		MOTOR, Starter -(3 5/8) (Plastic Ring Gear)
310	690323		SCREW -(Starter Motor)
311	497608		SET, Brush
332	691059		NUT -(Flywheel)
363	19203		PULLER, Flywheel
404	690442		WASHER -(Governor Crank)
505	691029		NUT -(Governor Control Lever)
510	696541		DRIVE, Starter
513	692024		CLUTCH, Drive
552	690552		BUSHING-GOV CRANK
552A	690553		BUSHING, Governor Crank
562	690311		BOLT -(Governor Control Lever)






Controls, Electric Starter, Flywheel, Governor Spring

REF NO	PART NO	QTY	DESCRIPTION
579	691029		NUT -(Starter Cable)
615	698290		RETAINER, Governor Shaft
616	691045		CRANK, Governor
668	691215		SPACER
691	790574		SEAL, Governor Shaft
695	693149		SCREW -(Ring Gear)
697	690372		SCREW -(Drive Cap)
726	499612		GEAR, Ring
742	690328		RETAINER, E Ring
783	695708		GEAR-PINION
797	693167		NUT -(Brush Retainer)
801	691283		CAP, Drive
802	691286		CAP, End
929	691003		SCREW -(Choke Control Bracket)
1005	791236		FAN, Flywheel
1051	691265		RING, Retaining
1070	690372		SCREW -(Flywheel Fan)
1090	691293		RETAINER, Brush



Cylinder Head, Gasket Set - Valve, Intake Manifold, Valves

REF NO	PART NO	QTY	DESCRIPTION
5	792299		HEAD, Cylinder -(Cylinder 1)
5A	792300		HEAD, Cylinder -(Cylinder 2)
7	693997		GASKET, Cylinder Head
13	793988		SCREW -(Cylinder Head) -Used After Code Date 08063000
13	791130		SCREW -(Cylinder Head) -Used Before Code Date 08070100
33	499596		VALVE, Exhaust
34	792200		VALVE, Intake
35	694865		SPRING, Valve -(Intake)
36	694865		SPRING, Valve -(Exhaust)
42	499586		KEEPER, Valve
45	690977		TAPPET, Valve
50	699801		MANIFOLD, Intake
51	699803		GASKET, Intake
51D	699800		GASKET, Intake
51E	690949		GASKET, Intake
53	690951		STUD -(Carburetor)
54	699816		SCREW -(Intake Manifold)
122A	699802		SPACER, Carburetor
192	690083		ADJUSTER, Rocker Arm
212	699805		LINK, Throttle
337	491055S		PLUG, Spark
337	84007216		PLUG, SPARK -(China Only)
383	19374S		WRENCH, Spark Plug
635	66538S		BOOT, Spark PLug
654	690958		NUT -(Carburetor)
798	697890		SCREW -(Rocker Arm)
868	690968		SEAL, Valve
883	690970		GASKET, Exhaust
914	691127		SCREW -(Rocker Cover)
1022	690971		GASKET, Rocker Cover
1023	499599		COVER, Rocker -(Cylinder 1) -Used Before Code Date 06072800
1023	793127		COVER, Rocker -(Cylinder 1) -Used After Code Date 06072700
1023A	499600		COVER, Rocker -(Cylinder #2)
1026	690981		ROD, Push -(Steel)
1026A	690982		ROD, Push -(Aluminum)
1029	690972		ARM, Rocker -Includes Reference 192



Cylinder Head, Gasket Set - Valve, Intake Manifold, Valves

REF NO	PART NO	QTY	DESCRIPTION
1095	699822		GASKET SET, Valve
1100	791959		PIVOT, Rocker Arm

Not For Reproduction


Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
	4455773037	1	Replacement Engine
	698172	1	Replacement Short Block
	-----		Top No-Load Speed: 3300 -Trim: ALL
	-----		Service Note: Original engine was equipped special Remote Throttle Control or Governor Control. Transfer these parts to replacement engine.
	-----		Service Note: Transfer Remote Choke Control Assembly from original engine to replacement engine.
	-----		Short Block Note: If repair would also require the Cylinder Head Assembly Order Short Block Part Number 792957.



Model 40, 44 & 49 Engine Accessories Catalog


Not For
Reproduction




Maintenance Kits

REF NO	PART NO	QTY	DESCRIPTION
9000	84002442		KIT, Maintenance -(Intek / EXi V-Twin Engines) (Do not use with Home Standby Generators.)
9000A	84002317		KIT, Maintenance -(Professional Series™ V-Twin Engines) (Do not use with Home Standby Generators.)
9000B	84002316		KIT, Maintenance -(Commercial Series V-Twin Engines) (Do not use with Home Standby Generators.)
9000C	84002318		KIT, Maintenance -(Oil Guard™ Engines) (Do not use with Home Standby Generators.)
9000D	84002315		KIT, Maintenance -(Non-Oil Guard™ Engines) (Do not use with Home Standby Generators.)
9000E	84007695		KIT, Maintenance -Commercial - CXi V-Twin Engines (Do not use with Home Standby Generators.)
240	84001895	1	FILTER, Fuel -(40 Micron)
240A	845125	1	FILTER, Fuel -(20 Micron)
337	491055S	2	PLUG, Spark
337A	496018S	2	PLUG, Spark
445	594201	1	FILTER, A/C Cartridge
445A	792105	1	FILTER, A/C Cartridge
445B	798897	1	FILTER, A/C Cartridge
445C	841497	1	FILTER, A/C Cartridge
967	797704	1	FILTER, Pre Cleaner
967A	593217	1	FILTER, Pre Cleaner
1027	492932S	1	FILTER, Oil -(Standard)
1027A	696854	1	FILTER, Oil -(Premium)
1027B	842921	1	FILTER, Oil -(Vanguard®)
1027C	84007094	1	FILTER, Oil -(Oil Guard™)
1027D	84007055	1	FILTER, Oil -(Oil Xtend™)
1505	100005		OIL-4 CYCLE 30W 18OZ. -(18 oz. Bottle)
1505A	100028		OIL-4 CYCLE 30W 48OZ -(48 oz. Bottle)
1505B	100170		OIL-5QT VANGUARD (CASE) -(5 qt. Bottle)
1505C	100169		OIL-1QT VANGUARD (CASE) -(1 qt. Bottle)


300




300A



300B





300C



Engine Mounted Below Deck Mufflers

REF NO	PART NO	QTY	DESCRIPTION
300	594584	1	KIT-MUFFLER/GUARD -(Oil Filter Side Outlet) (Engine Supported) (O2 Sensor Port)
300A	593877	1	MUFFLER -(Starter Side Outlet) (Engine Supported) (O2 Sensor Port)
300B	594583	1	MUFFLER -(Starter Side Outlet) (Engine Supported) (No O2 Sensor Port)
300C	692120	1	MUFFLER -(Starter Side Outlet) (No O2 Sensor Port)
415	596859	1	PLUG -(O2 Sensor Port)
613	690341	4	SCREW -(Muffler)
613A	690363	4	SCREW -(Muffler)
883	594365	2	GASKET, Exhaust
883A	690970	2	GASKET, Exhaust
1177	690941	4	NUT -(Muffler)




Not For
Reproduction

Engine Mounted Above Deck Mufflers


REF NO	PART NO	QTY	DESCRIPTION
300C	595138	1	MUFFLER -(Oil Filter Side Outlet) (Self-Supporting) (O2 Sensor Port)
300D	595139	1	MUFFLER -(Starter Side Outlet) (Self-Supporting) (O2 Sensor Port)
415	596859	1	PLUG -(O2 Sensor Port)
883	594365	2	GASKET, Exhaust

Not For Reproduction


676



994







994A



Spark Arrester/Deflector





REF NO	PART NO	QTY	DESCRIPTION
676	593869	1	DEFLECTOR, Muffler -(For Below Deck Mufflers Only)
994	593885	1	ARRESTOR, Spark -(For Below Deck Mufflers Only)
994A	593868	1	ARRESTOR, Spark -(For Below Deck Mufflers Only)

Not For Reproduction



Lubrication


REF NO	PART NO	QTY	DESCRIPTION
186	796532	1	CONNECTOR, Hose -(Threaded Engine Block Connector for EZ-Oil Drain Hose) (Order hose separate)
239	690233	1	SWITCH, Oil Pressure -(2-4 PSI Normally-Closed Switch)
239A	491657S	1	SWITCH, Oil Pressure -(3-5 PSI Normally-Closed Switch)
239B	841281	1	SWITCH, Oil Pressure -(7-10 PSI Normally-Closed Switch)
239C	694115	1	SWITCH, Oil Pressure -(9-13 PSI Normally-Closed Switch)
239D	697049	1	SWITCH, Oil Pressure -(3-6 PSI Normally-Open Switch)
295B	594271	1	ADAPTER, Remote Oil Filter -(Remote Oil Filter Kit)
512	594200	1	HOSE, Oil Drain -(EZ-Oil Drain Hose, 10.5") (Order threaded engine block connector separate)
512	593635	1	HOSE, Oil Drain -(EZ-Oil Drain Hose, 13.75") (Order threaded engine block connector separate)
512B	1723165SM	1	HOSE, Oil Drain, 10-1/2" Long, 3/8-18 Fittings -(10.5")
512C	5048681SM	1	HOSE, OIL DRAIN -(12.5")
517	593633	1	RETAINER, Oil Drain
601	841597	4	CLAMP, Hose
1013	690954	1	NIPPLE, Oil Filter
1346	844802	1	VALVE, Oil Drain Shut Off
1346A	492031	1	VALVE, Oil Drain Shut Off
1346B	5401WEB	1	VALVE, Oil Drain Shut Off -(1/4 Turn Oil Drain Valve with Hose)
1374	796863	1	SEAL, O-Ring
1505	100169		OIL-1QT VANGUARD (CASE) -(1 qt. Bottle)
1505A	100170		OIL-5QT VANGUARD (CASE) -(5 qt. Bottle)




Implement Mounted Above Deck Mufflers

REF NO	PART NO	QTY	DESCRIPTION
300A	594585	1	MUFFLER -(Oil Filter Side Outlet) (Implement Supported) (O2 Sensor Port)
300B	595134	1	MUFFLER -(Oil Filter Side Outlet) (O2 Sensor Port)
300C	595135	1	MUFFLER -(Starter Side Outlet) (O2 Sensor Port)
300D	595136	1	MUFFLER -(Oil Filter Side Outlet)
264	703465	4	NUT, 5/16-18, GR5 -(Muffler Adapter)
355	5025292SM	4	WASHER, 5/16" GD.9 FL -(Muffler Bracket)
355A	5025155SM	2	WASHER, 5/16 -(Muffler Bracket)
415	596859	1	PLUG -(O2 Sensor Port)
437	703585	4	CAPSCREW, 5/16-18X1 -(Exhaust Manifold)
740	703164	2	NUT -(Muffler Bracket)
740A	703115	2	NUT -(Muffler Bracket)
819	690341	4	SCREW -(Muffler Bracket)
863	597480	1	BRACKET, Muffler
883	594365	2	GASKET, Exhaust
883A	690970	2	GASKET, Exhaust
1176	690941	4	NUT -(Exhaust Manifold)
1317	703116	4	LCKWSHR -(Exhaust Manifold)


300A




300B



300C







300D







Exhaust/Muffler Configurations

REF NO	PART NO	QTY	DESCRIPTION
300A	771127	1	MUFFLER -(Oil Filter Side Outlet)(Commercial & Professional Series)
300B	771128	1	MUFFLER -(Starter Side Outlet)(Commercial & Professional Series)
300C	595822	1	MUFFLER -(Starter Side Outlet)(Commercial & Professional Series)
300D	84003680	1	MUFFLER -(Oil Filter Side Outlet) (Commercial & Professional Series)(Vanguard 810 & 810 EFI) (Compatible with 593868 Spark Arrester, 593885 Spark Arrester with Deflector.) (Equipped with plug for blocking off O2 sensor port for non EFI engines.)
437	690341	4	SCREW -(Exhaust Manifold)
740	704067	2	NUT, HEX FLNG,5/16-18 -(Muffler Bracket)
819	592604	2	SCREW -(Muffler Bracket)
819A	695629	4	SCREW -(Muffler Bracket)
819B	692062	2	SCREW -(Muffler Bracket)
883	594365	2	GASKET, Exhaust
884	691956	1	CLAMP, Muffler
1176	690941	4	NUT -(Exhaust Manifold)
1177	793859	1	NUT -(Muffler)










Electrical

REF NO	PART NO	QTY	DESCRIPTION
578	84007350	1	WIRE ASSEMBLY -(Wire Harness Adapter Aids in repowering engine application with Male 6-Pin connector and wires create custom adapter configurations.)
578A	19631	1	TOOL, CUSTOM HARNESS -(6-pin Wire Harness Adapter) (Aids in repowering engine application to an EFI engine)
853	84003359	1	ADAPTER, WIRE -(Wire Harness Adapter) (Aids in repowering ExMark) (Flat 6-spade connector to Briggs & Stratton 6-Pin connector)
920	84002147	1	SOLENOID, STARTER -(Starter Solenoid Kit) (Aids in Repowering when original is solenoid shift)
983	5103809YP	1	LIGHT, Indicator -(MIL Light Indicator) (LED Red)
1616	19626	1	CODE READER -(Tiny Scan Code Reader)






Flywheel Guards

REF NO	PART NO	QTY	DESCRIPTION
563	698425	1	SCREW -(Debris Screen Guard)
563A	597574	1	SCREW -(Debris Screen Guard)
563B	799359	1	SCREW -(Debris Screen Guard)
949	799357	1	GUARD, Debris Screen -(Static Cover Flywheel) (Requires 4 x 799360 Screw)
949A	797420YP	1	GUARD, Debris Screen -(Static Cover Flywheel High Flow) (Requires 4 x 799360 Screw)
949B	593206	1	GUARD, Debris Screen -(Static Cover Flywheel) (Requires 4 x 799359 Screw)
949C	597573	1	GUARD, Debris Screen -(Wire Static Flywheel Cover) (Requires 4x 597574 Screw) (For Commercial Series)



Speed Control

REF NO	PART NO	QTY	DESCRIPTION
265	691024	1	CLAMP, Casing -(Casing Clamp for Hard Casing)
265A	690798	1	CLAMP, Casing -(Casing Clamp for Soft Casing)
267	792629	1	SCREW -(Screw for Casing Clamp)
269	93907	1	WIRE, Control -(Control Wire 100')
271	691028	1	LEVER, Control -(Speed Control Lever Assembly)
271A	692105	1	LEVER, Control -(“L” formed end Speed Control Lever Assembly)
271B	692541	1	LEVER, Control -(“Z” formed end Speed Control Lever Assembly)
416	595196	1	BRACKET, Throttle Cable -(Casing Clamp for Snap-In Casing)



Muffler Mounting Hardware

REF NO	PART NO	QTY	DESCRIPTION
264	703465	4	NUT, 5/16-18, GR5 -(Muffler Adapter)
296	591756	4	STUD -(Muffler)
355	5025292SM	4	WASHER, 5/16" GD.9 FL -(Muffler Bracket)
355A	5025155SM	2	WASHER, 5/16 -(Muffler Bracket)
613	690341	4	SCREW -(Muffler)
613A	690363	4	SCREW -(Muffler)
863	597480	1	BRACKET, Muffler
883	594365	2	GASKET, Exhaust
883A	690970	2	GASKET, Exhaust
1177	690941	4	NUT -(Muffler)

