








Parts Manual

Mfg. No: 49T877-0052-Z1

Model Components	Page
Air Cleaner Group.	4
Alternator Group.	6
Blower Housing Group.	8
Carburetor Group.	10
Controls Group.	14
Crankcase Cover/Sump Group.	16
Crankshaft Group.	18
Cylinder Group.	20
Cylinder Head Group.	22
Exhaust Group.	24
Flywheel, Ignition, and Starter Group.	26
Fuel Supply Group.	28
Lubrication Group.	30
Model 40, 44 & 49 Engine Accessories Catalog.	32
Maintenance Kits.	33
Engine Mounted Below Deck Mufflers.	35
Engine Mounted Above Deck Mufflers.	37
Spark Arrester/Deflector.	39
Lubrication.	41
Implement Mounted Above Deck Mufflers.	43
Exhaust/Muffler Configurations.	45
Electrical.	47
Flywheel Guards.	49
Speed Control.	51
Muffler Mounting Hardware.	53





Air Cleaner Group

REF NO	PART NO	QTY	DESCRIPTION
163	-----	1	GASKET, Air Cleaner -(Part information located in Carburetor Group.)
186B	-----	1	CONNECTOR, Hose -(Part information located in Carburetor Group.)
431	799097	1	ELBOW, Intake
445	798897	1	FILTER, A/C Cartridge
467	790697	2	KNOB, Air Cleaner Cover
496	799095	1	LEVER, Air Cleaner Filter
875	799094	1	BASE, Air Cleaner
964	799159	1	CAP, Connector
967	593217	1	FILTER, Pre Cleaner
968	84007298	1	COVER, Air Cleaner
1406	799096	1	VALVE, Debris
1440	698304	2	SCREW -(Air Cleaner Base to Intake Elbow)

474

1059


1119



526




501



Alternator Group


REF NO	PART NO	QTY	DESCRIPTION
474	592830	1	ALTERNATOR
501	593490	1	REGULATOR
526	691108	2	SCREW -(Regulator)
1059	698516	1	KIT, Screw/Washer
1119	691183	4	SCREW -(Alternator)

Not For Reproduction




Blower Housing Group

REF NO	PART NO	QTY	DESCRIPTION
304	595600	1	HOUSING, Blower
305	594618	6	SCREW -(Blower Housing)
305A	557049	2	SCREW -(Blower Housing)
563	597574	4	SCREW -(Debris Screen Guard)
563A	698425	4	SCREW -(Debris Screen Guard)
949	597573	1	GUARD, Debris Screen
949A	593206	1	GUARD, Debris Screen
997	592782	1	COVER, Blower Housing
1036	-----	1	LABEL, Emissions -(Available from a Briggs & Stratton Authorized Dealer)
1319	797669	1	LABEL, Warning -(REQUIRED When Replacing Parts With Warning Labels Affixed)
1319A	278911GS	1	LABEL, Warning -(REQUIRED When Replacing Parts With Warning Labels Affixed)
1477	799093	2	SCREW -(Debris Shield)



Carburetor Group


REF NO	PART NO	QTY	DESCRIPTION
51A	-----	2	GASKET, Intake -(Part information located in Cylinder Head Group.)
53	690951	4	STUD -(Carburetor)
93	845864	1	BUSHING, Throttle Shaft
95	690718	4	SCREW -(Throttle Valve)
98	699721	1	KIT, Idle Speed
104	694918	1	PIN, Float Hinge
105	698537	1	VALVE, Float Needle
108	699723	1	VALVE, Choke
117	842082	1	JET, Main -(Standard)
118	842081	1	JET, Main -(High Altitude)
121	799132	1	KIT, Carburetor Overhaul -(Service Kits may include extra parts not specific to this engine.)
122	593425	1	SPACER, Carburetor
125	799511	1	CARBURETOR
130	796875	2	VALVE, Throttle
131	796872	1	KIT, Throttle Shaft
133	699724	1	FLOAT, Carburetor
135	699729	1	TUBE, Fuel Transfer
137	690994	1	GASKET, Float Bowl
141	799112	1	KIT, Choke Shaft
142	796871	1	NOZZLE, Carburetor
150	841649	1	GASKET, Nozzle
163	691001	1	GASKET, Air Cleaner
186A	799158	1	CONNECTOR, Hose
186B	845141	1	CONNECTOR, Hose
186C	594428	1	CONNECTOR, Hose
216	691022	1	LINK, Choke
217	799771	1	SPRING, Choke Return
231	690718	2	SCREW -(Choke Valve)
276	695410	1	WASHER, Sealing
418	795912	1	PLATE, Carburetor Cover
633	690722	1	SEAL, Choke/Throttle Shaft
654	690958	4	NUT -(Carburetor)
672	690234	1	GASKET, Carburetor Plate
918	-----	1	HOSE, Vacuum -(Part information located in Cylinder Head Group.)
947	596039	1	SOLENOID, Fuel
964	-----	1	CAP, Connector -(Part information located in Air Cleaner Group.)
975	799114	1	BOWL, Float
987	808183	1	SEAL, Choke/Throttle Shaft
1124	690988	1	SEAL, O-Ring -(Fuel Transfer Tube)
1124A	841653	1	SEAL, O-Ring -(Fuel Transfer Tube)
1126	690991	2	SCREW -(Fuel Transfer Tube)
1127	695407	2	SCREW -(Float Bowl) (Float Bowl to Carburetor Body)



Carburetor Group

REF NO	PART NO	QTY	DESCRIPTION
1128	690990	1	SCREW -(Carburetor Nozzle)
1169	690990	3	SCREW -(Carburetor Cover Plate)






Not For Reproduction



Not For
Reproduction


Controls Group

REF NO	PART NO	QTY	DESCRIPTION
209	799175	1	SPRING, Governor
211	593724	1	SPRING, Governed Idle
212	695238	1	LINK, Throttle
213	799510	1	BRACKET, Choke Control
213A	799153	1	BRACKET, Choke Control
216	-----	1	LINK, Choke -(Part information located in Carburetor Group.)
222	798916	1	BRACKET, Control
227	798856	1	LEVER, Governor Control
265	691024	2	CLAMP, Casing
267	792629	2	SCREW -(Casing Clamp)
505	691029	1	NUT -(Governor Control Lever)
562	690311	1	BOLT -(Governor Control Lever)
703	-----	2	CLIP -(Part information located in Fuel Supply Group.)
729	593826	1	CLIP, Wire
789A	797460	1	HARNESS, Wiring
929	691003	2	SCREW -(Choke Control Bracket)
929A	794904	1	SCREW -(Choke Control Bracket)
1550	595801	1	PIN, Speed Setting




Crankcase Cover/Sump Group

REF NO	PART NO	QTY	DESCRIPTION
4	593652	1	SUMP, Engine
20	795387	1	SEAL, Oil -(PTO Side)
22	694966	10	SCREW -(Crankcase Cover/Sump)
219	793338	1	GEAR, Governor
220	799772	1	WASHER -(Governor Gear)
221	841026	1	CUP, Governor
404	690442	1	WASHER -(Governor Crank)
552	796638	1	BUSHING, Governor Crank
552A	690553	2	BUSHING, Governor Crank
615	698290	1	RETAINER, Governor Shaft
616	691045	1	CRANK, Governor
691	790574	1	SEAL, Governor Shaft
742	690328	2	RETAINER, E Ring
750	796208	3	SCREW -(Oil Pump Cover)
850	100106	1	SEALANT, Liquid
943	796222	1	SEAL, O-Ring -(Oil Pump Cover)
965	796221	1	COVER, Oil Pump
1017	796214	1	SCREEN, Oil Pump
1024	796220	1	PUMP, Oil




Crankshaft Group

REF NO	PART NO	QTY	DESCRIPTION
16	595729	1	CRANKSHAFT
24	796335	1	KEY, Flywheel
25	595790	2	PISTON ASSEMBLY
25	595791	2	PISTON ASSEMBLY -(.020" Oversize)
26	595792	2	SET, Ring
26	595793	2	SET, Ring -(.020" Oversize)
27	690975	2	LOCK, Piston Pin
28	593650	2	PIN, Piston
29	84007297	2	ROD, Connecting
32	690976	4	SCREW -(Connecting Rod)
45	-----	4	TAPPET, Valve -(Part information located in Cylinder Head Group.)
46	797242	1	CAMSHAFT
377	690979	1	KEY, Woodruff
741	690980	1	GEAR, Timing



Cylinder Group

REF NO	PART NO	QTY	DESCRIPTION
1	594972	1	CYLINDER ASSEMBLY
2	797673	1	KIT, Bushing/Seal -(Magneto Side)
3	391086S	1	SEAL, Oil -(Magneto Side)
7	-----	2	GASKET, Cylinder Head -(Part information located in Cylinder Head Group.)
10	691108	4	SCREW -(Breather Assembly)
11	84006260	1	TUBE, Breather
20	-----	1	SEAL, Oil -(Part information located in Crankcase Cover/Sump Group.)
22	-----	10	SCREW -(Part information located in Crankcase Cover/Sump Group.)
51	-----	2	GASKET, Intake -(Part information located in Cylinder Head Group.)
51A	-----	2	GASKET, Intake -(Part information located in Cylinder Head Group.)
122	-----	1	SPACER, Carburetor -(Part information located in Carburetor Group.)
163	-----	1	GASKET, Air Cleaner -(Part information located in Carburetor Group.)
306	84004553	1	SHIELD, Cylinder
306A	84007347	1	SHIELD, Cylinder
307	691003	4	SCREW -(Cylinder Shield)
358	799117	1	GASKET SET, Engine -(Service Kits can include parts not for this engine.)
405	594937	7	SCREW -(Back Plate)
524	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
540	594325	1	PLATE, Baffle
573	594902	1	PLATE, Back
584	84006259		COVER, Breather Passage
618	594326	1	SCREW -(Baffle Plate)
691	-----	1	SEAL, Governor Shaft -(Part information located in Crankcase Cover/Sump Group.)
718	690959	6	PIN, Locating
718A	594988	1	PIN, Locating
842	-----	1	SEAL, O-Ring -(Part information located in Lubrication Group.)
850	-----	1	SEALANT, Liquid -(Part information located in Crankcase Cover/Sump Group.)
865	591667	1	COVER, Air Guide
868	-----	1	SEAL, Valve -(Part information located in Cylinder Head Group.)
883	-----	2	GASKET, Exhaust -(Part information located in Exhaust Group.)
943	-----	1	SEAL, O-Ring -(Part information located in Crankcase Cover/Sump Group.)
1263	594166	1	REED, Breather
1264	594165	1	SCREW -(Breather Reed)




Cylinder Head Group

REF NO	PART NO	QTY	DESCRIPTION
5	597136	1	HEAD, Cylinder -(Cylinder #1)
5A	597137	1	HEAD, Cylinder -(Cylinder #2)
7	796851	2	GASKET, Cylinder Head
13	592244	10	SCREW -(Cylinder Head)
33	793557	2	VALVE, Exhaust
34	793556	2	VALVE, Intake
35	694865	2	SPRING, Valve -(Intake)
36	694865	2	SPRING, Valve -(Exhaust)
42	84012308	4	KEEPER, Valve
45	690977	4	TAPPET, Valve
50	797503	1	MANIFOLD, Intake
51	690949	2	GASKET, Intake
51A	594427	2	GASKET, Intake
54	699816	4	SCREW -(Intake Manifold)
163	-----	1	GASKET, Air Cleaner -(Part information located in Carburetor Group.)
192	690083	2	ADJUSTER, Rocker Arm
337	792015	2	PLUG, Spark
383	19576S	1	WRENCH, Spark Plug
613	-----	4	SCREW -(Muffler)(Part Information located in Exhaust Group.)
635	692076	2	BOOT, Spark Plug
798	697890	4	SCREW -(Rocker Arm)
850	-----	1	SEALANT, Liquid -(Part information located in Crankcase Cover/Sump Group.)
868	690968	2	SEAL, Valve
883	-----	2	GASKET, Exhaust -(Part information located in Exhaust Group.)
914	691127	8	SCREW -(Rocker Cover)
918A	593641	1	HOSE, Vacuum
1023A	499600	1	COVER, Rocker
1023B	84003848	1	COVER, Rocker
1026	597785	2	ROD, Push
1026A	690982	2	ROD, Push
1029	690972	4	ARM, Rocker
1029A	807323	1	ARM, Rocker
1095	796920	1	GASKET SET, Valve -(Service Kits may include extra parts not specific to this engine.)
1100	791959	4	PIVOT, Rocker Arm

883




613



Exhaust Group


REF NO	PART NO	QTY	DESCRIPTION
613	690341	4	SCREW -(Muffler)
883	690970	2	GASKET, Exhaust

Not For Reproduction



Flywheel, Ignition, and Starter Group


REF NO	PART NO	QTY	DESCRIPTION
23	594169	1	FLYWHEEL
75	691056	1	WASHER -(Flywheel)
309	590476	1	MOTOR, Starter
332	691059	1	NUT -(Flywheel)
333	592846	2	ARMATURE, Magneto
334	691061	4	SCREW -(Magneto Armature)
363	19621	1	PULLER, Flywheel
697	591909	2	SCREW -(Starter Motor) (Drive Cap)
1005	593640	1	FAN, Flywheel
1070	593638	4	SCREW -(Flywheel Fan)



Fuel Supply Group

REF NO	PART NO	QTY	DESCRIPTION
187	791766	1	LINE, Fuel
240	845125	1	FILTER, Fuel
385	797409	2	SCREW -(Fuel Pump)
387	597338	1	PUMP, Fuel
601	691038	2	CLAMP, Hose
703	691010	1	CLIP

Not For Reproduction




Lubrication Group

REF NO	PART NO	QTY	DESCRIPTION
186	796532	1	CONNECTOR, Hose
239	792028	1	SWITCH, Oil Pressure
287	697820	1	SCREW -(Dipstick Tube)
305	-----	1	SCREW -(Part information located in Blower Housing Group.)
400	796862	1	COOLER, Oil
448	799103	1	BRACKET, Oil Cooler
512	84003931	1	HOSE, Oil Drain
517	593633	1	RETAINER, Oil Drain
523	594528	1	DIPSTICK
524	691032	1	SEAL, O-Ring -(Dipstick Tube)
525	597129	1	TUBE, Dipstick
601A	841597	4	CLAMP, Hose
829	799104	1	HOSE, Oil Cooler
842	691031	1	SEAL, O-Ring -(Dipstick Cap)
847	597130	1	DIPSTICK/TUBE ASSEMBLY
1027	696854	1	FILTER, Oil
1028	796864	1	ADAPTER, Oil Filter
1366	799131	1	DIVERTER, Oil Cooler
1373	695629	2	SCREW -(Oil Cooler Bracket)
1373A	799105	2	SCREW -(Oil Cooler Bracket)
1374	796863	1	SEAL, O-Ring -(Oil Cooler Diverter)
1582	593364	1	COVER, Air Cleaner -(Oil Drain Retainer)



Model 40, 44 & 49 Engine Accessories Catalog


Not For
Reproduction




Maintenance Kits

REF NO	PART NO	QTY	DESCRIPTION
9000	84002442		KIT, Maintenance -(Intek / EXi V-Twin Engines) (Do not use with Home Standby Generators.)
9000A	84002317		KIT, Maintenance -(Professional Series™ V-Twin Engines) (Do not use with Home Standby Generators.)
9000B	84002316		KIT, Maintenance -(Commercial Series V-Twin Engines) (Do not use with Home Standby Generators.)
9000C	84002318		KIT, Maintenance -(Oil Guard™ Engines) (Do not use with Home Standby Generators.)
9000D	84002315		KIT, Maintenance -(Non-Oil Guard™ Engines) (Do not use with Home Standby Generators.)
9000E	84007695		KIT, Maintenance -Commercial - CXi V-Twin Engines (Do not use with Home Standby Generators.)
240	84001895	1	FILTER, Fuel -(40 Micron)
240A	845125	1	FILTER, Fuel -(20 Micron)
337	491055S	2	PLUG, Spark
337A	496018S	2	PLUG, Spark
445	594201	1	FILTER, A/C Cartridge
445A	792105	1	FILTER, A/C Cartridge
445B	798897	1	FILTER, A/C Cartridge
445C	841497	1	FILTER, A/C Cartridge
967	797704	1	FILTER, Pre Cleaner
967A	593217	1	FILTER, Pre Cleaner
1027	492932S	1	FILTER, Oil -(Standard)
1027A	696854	1	FILTER, Oil -(Premium)
1027B	842921	1	FILTER, Oil -(Vanguard®)
1027C	84007094	1	FILTER, Oil -(Oil Guard™)
1027D	84007055	1	FILTER, Oil -(Oil Xtend™)
1505	100005		OIL-4 CYCLE 30W 18OZ. -(18 oz. Bottle)
1505A	100028		OIL-4 CYCLE30W 48OZ -(48 oz. Bottle)
1505B	100170		OIL-5QT VANGUARD (CASE) -(5 qt. Bottle)
1505C	100169		OIL-1QT VANGUARD (CASE) -(1 qt. Bottle)


300




300A



300B





300C



Engine Mounted Below Deck Mufflers

REF NO	PART NO	QTY	DESCRIPTION
300	594584	1	KIT-MUFFLER/GUARD -(Oil Filter Side Outlet) (Engine Supported) (O2 Sensor Port)
300A	593877	1	MUFFLER -(Starter Side Outlet) (Engine Supported) (O2 Sensor Port)
300B	594583	1	MUFFLER -(Starter Side Outlet) (Engine Supported) (No O2 Sensor Port)
300C	692120	1	MUFFLER -(Starter Side Outlet) (No O2 Sensor Port)
415	596859	1	PLUG -(O2 Sensor Port)
613	690341	4	SCREW -(Muffler)
613A	690363	4	SCREW -(Muffler)
883	594365	2	GASKET, Exhaust
883A	690970	2	GASKET, Exhaust
1177	690941	4	NUT -(Muffler)




Not For
Reproduction

Engine Mounted Above Deck Mufflers


REF NO	PART NO	QTY	DESCRIPTION
300C	595138	1	MUFFLER -(Oil Filter Side Outlet) (Self-Supporting) (O2 Sensor Port)
300D	595139	1	MUFFLER -(Starter Side Outlet) (Self-Supporting) (O2 Sensor Port)
415	596859	1	PLUG -(O2 Sensor Port)
883	594365	2	GASKET, Exhaust

Not For Reproduction


676



994







994A



Spark Arrester/Deflector





REF NO	PART NO	QTY	DESCRIPTION
676	593869	1	DEFLECTOR, Muffler -(For Below Deck Mufflers Only)
994	593885	1	ARRESTOR, Spark -(For Below Deck Mufflers Only)
994A	593868	1	ARRESTOR, Spark -(For Below Deck Mufflers Only)

Not For Reproduction



Lubrication


REF NO	PART NO	QTY	DESCRIPTION
186	796532	1	CONNECTOR, Hose -(Threaded Engine Block Connector for EZ-Oil Drain Hose) (Order hose separate)
239	690233	1	SWITCH, Oil Pressure -(2-4 PSI Normally-Closed Switch)
239A	491657S	1	SWITCH, Oil Pressure -(3-5 PSI Normally-Closed Switch)
239B	841281	1	SWITCH, Oil Pressure -(7-10 PSI Normally-Closed Switch)
239C	694115	1	SWITCH, Oil Pressure -(9-13 PSI Normally-Closed Switch)
239D	697049	1	SWITCH, Oil Pressure -(3-6 PSI Normally-Open Switch)
295B	594271	1	ADAPTER, Remote Oil Filter -(Remote Oil Filter Kit)
512	594200	1	HOSE, Oil Drain -(EZ-Oil Drain Hose, 10.5") (Order threaded engine block connector separate)
512	593635	1	HOSE, Oil Drain -(EZ-Oil Drain Hose, 13.75") (Order threaded engine block connector separate)
512B	1723165SM	1	HOSE, Oil Drain, 10-1/2" Long, 3/8-18 Fittings -(10.5")
512C	5048681SM	1	HOSE, OIL DRAIN -(12.5")
517	593633	1	RETAINER, Oil Drain
601	841597	4	CLAMP, Hose
1013	690954	1	NIPPLE, Oil Filter
1346	844802	1	VALVE, Oil Drain Shut Off
1346A	492031	1	VALVE, Oil Drain Shut Off
1346B	5401WEB	1	VALVE, Oil Drain Shut Off -(1/4 Turn Oil Drain Valve with Hose)
1374	796863	1	SEAL, O-Ring
1505	100169		OIL-1QT VANGUARD (CASE) -(1 qt. Bottle)
1505A	100170		OIL-5QT VANGUARD (CASE) -(5 qt. Bottle)




Implement Mounted Above Deck Mufflers

REF NO	PART NO	QTY	DESCRIPTION
300A	594585	1	MUFFLER -(Oil Filter Side Outlet) (Implement Supported) (O2 Sensor Port)
300B	595134	1	MUFFLER -(Oil Filter Side Outlet) (O2 Sensor Port)
300C	595135	1	MUFFLER -(Starter Side Outlet) (O2 Sensor Port)
300D	595136	1	MUFFLER -(Oil Filter Side Outlet)
264	703465	4	NUT, 5/16-18, GR5 -(Muffler Adapter)
355	5025292SM	4	WASHER, 5/16" GD.9 FL -(Muffler Bracket)
355A	5025155SM	2	WASHER, 5/16 -(Muffler Bracket)
415	596859	1	PLUG -(O2 Sensor Port)
437	703585	4	CAPSCREW, 5/16-18X1 -(Exhaust Manifold)
740	703164	2	NUT -(Muffler Bracket)
740A	703115	2	NUT -(Muffler Bracket)
819	690341	4	SCREW -(Muffler Bracket)
863	597480	1	BRACKET, Muffler
883	594365	2	GASKET, Exhaust
883A	690970	2	GASKET, Exhaust
1176	690941	4	NUT -(Exhaust Manifold)
1317	703116	4	LCKWSHR -(Exhaust Manifold)


300A




300B



300C







300D







Exhaust/Muffler Configurations

REF NO	PART NO	QTY	DESCRIPTION
300A	771127	1	MUFFLER -(Oil Filter Side Outlet)(Commercial & Professional Series)
300B	771128	1	MUFFLER -(Starter Side Outlet)(Commercial & Professional Series)
300C	595822	1	MUFFLER -(Starter Side Outlet)(Commercial & Professional Series)
300D	84003680	1	MUFFLER -(Oil Filter Side Outlet) (Commercial & Professional Series)(Vanguard 810 & 810 EFI) (Compatible with 593868 Spark Arrester, 593885 Spark Arrester with Deflector.) (Equipped with plug for blocking off O2 sensor port for non EFI engines.)
437	690341	4	SCREW -(Exhaust Manifold)
740	704067	2	NUT, HEX FLNG,5/16-18 -(Muffler Bracket)
819	592604	2	SCREW -(Muffler Bracket)
819A	695629	4	SCREW -(Muffler Bracket)
819B	692062	2	SCREW -(Muffler Bracket)
883	594365	2	GASKET, Exhaust
884	691956	1	CLAMP, Muffler
1176	690941	4	NUT -(Exhaust Manifold)
1177	793859	1	NUT -(Muffler)










Electrical

REF NO	PART NO	QTY	DESCRIPTION
578	84007350	1	WIRE ASSEMBLY -(Wire Harness Adapter Aids in repowering engine application with Male 6-Pin connector and wires create custom adapter configurations.)
578A	19631	1	TOOL, CUSTOM HARNESS -(6-pin Wire Harness Adapter) (Aids in repowering engine application to an EFI engine)
853	84003359	1	ADAPTER, WIRE -(Wire Harness Adapter) (Aids in repowering ExMark) (Flat 6-spade connector to Briggs & Stratton 6-Pin connector)
920	84002147	1	SOLENOID, STARTER -(Starter Solenoid Kit) (Aids in Repowering when original is solenoid shift)
983	5103809YP	1	LIGHT, Indicator -(MIL Light Indicator) (LED Red)
1616	19626	1	CODE READER -(Tiny Scan Code Reader)






Flywheel Guards

REF NO	PART NO	QTY	DESCRIPTION
563	698425	1	SCREW -(Debris Screen Guard)
563A	597574	1	SCREW -(Debris Screen Guard)
563B	799359	1	SCREW -(Debris Screen Guard)
949	799357	1	GUARD, Debris Screen -(Static Cover Flywheel) (Requires 4 x 799360 Screw)
949A	797420YP	1	GUARD, Debris Screen -(Static Cover Flywheel High Flow) (Requires 4 x 799360 Screw)
949B	593206	1	GUARD, Debris Screen -(Static Cover Flywheel) (Requires 4 x 799359 Screw)
949C	597573	1	GUARD, Debris Screen -(Wire Static Flywheel Cover) (Requires 4x 597574 Screw) (For Commercial Series)



Speed Control

REF NO	PART NO	QTY	DESCRIPTION
265	691024	1	CLAMP, Casing -(Casing Clamp for Hard Casing)
265A	690798	1	CLAMP, Casing -(Casing Clamp for Soft Casing)
267	792629	1	SCREW -(Screw for Casing Clamp)
269	93907	1	WIRE, Control -(Control Wire 100')
271	691028	1	LEVER, Control -(Speed Control Lever Assembly)
271A	692105	1	LEVER, Control -(“L” formed end Speed Control Lever Assembly)
271B	692541	1	LEVER, Control -(“Z” formed end Speed Control Lever Assembly)
416	595196	1	BRACKET, Throttle Cable -(Casing Clamp for Snap-In Casing)



Muffler Mounting Hardware

REF NO	PART NO	QTY	DESCRIPTION
264	703465	4	NUT, 5/16-18, GR5 -(Muffler Adapter)
296	591756	4	STUD -(Muffler)
355	5025292SM	4	WASHER, 5/16" GD.9 FL -(Muffler Bracket)
355A	5025155SM	2	WASHER, 5/16 -(Muffler Bracket)
613	690341	4	SCREW -(Muffler)
613A	690363	4	SCREW -(Muffler)
863	597480	1	BRACKET, Muffler
883	594365	2	GASKET, Exhaust
883A	690970	2	GASKET, Exhaust
1177	690941	4	NUT -(Muffler)

