



Parts Manual

Mfg. No: 525607x692B
Lawn Tractor (2002)


Model Components	Page
Blade Drive System.....	4
Decals.....	6
Drive Assembly.....	8
Electrical System.....	12
Engine Mount.....	14
Frame Assembly.....	16
Front Axle.....	18
Hood & Grill.....	20
Mower Housing.....	22
Mower Housing Suspension (part 1).....	24
Mower Housing Suspension (part 2).....	26
Rear Body.....	28
Steering Assembly.....	30
Torque Specification Chart.....	32

Not For
Reproduction

Blade Drive System

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B



Blade Drive System

REF NO	PART NO	QTY	DESCRIPTION
1	690444MA		Pulley
2	15X121		Nut
3	094607E700		Cover, Right Pulley
4	26X250MA		Screw
5	015X98MA		Locknut, Flange
6	7769223		Belt, Secondary
7	690369MA		Spacer
8	165X138MA		Spring, Extension
9	015X84MA		Locknut
10	095068MA		Pulley, Idler
11	7769212		Belt, Primary
12	094809MA		Spring, Belt Guide
13	015X89MA		NUT .25-20 FLANGELOCK
14	1001197MA		Spacer, Pulley
15	690549MA		Pulley, Backside Idler
16	009X42MA		Bolt, Shoulder
17	009X54MA		Bolt, Shoulder
18	690068E700		Bracket, Idler
19	095074		Assembly, Brake Arm
20	26X277MA		Screw
21	094645E700		Cover, Left Pulley
22	690221E700		Bracket, Pulley Cover
23	0025X7MA		Bolt
24	166X41MA		Spring, Torsion
25	009X39MA		Bolt, Shoulder
26	01X111MA		Bolt
27	094698		Assembly, Brake Arm
28	094808E700		Bellcrank
29	690119 Z		Link
30	030X20MA		Pin, Cotter
31	015X79MA		Locknut, Flange
32	094701		Assembly, Idler Arm
33	165X130MA		Spring, Extension
34	001X84MA		CAPSCREW, Hex Head, 5/16-18 x 1
35	690414E700		Bracket, Brake Mounting
36	092424		Rod, Belt Guide
37	002X53MA		Bolt, Carriage
38	025X15MA		Screw
39	092140E700		Bracket, Cover
40	7769213MA		Adapter, Blade
41	7769205		Blade
42	17X166MA		Washer
43	17X165MA		Washer
44	15X100MA		Nut
45	1001200MA		JACKSHAFT HSNG ASSY
46	015X88MA		Nut
47	091797 Z		Guide, Belt
48	025X15MA		Screw
49	017X87		Washer

No
Diagram
Available

Parts List
Only


Decals

REF NO	PART NO	QTY	DESCRIPTION
	44X7325MA	1	Warning (Seat Deck)
	48X778	1	1-6 Height Adjust -Lift (Seat Deck -Left Side)
	44X6668	1	Brake / Park Brake (Foot Rest -Left Side)
	44X6669	1	Dump Valve (Under Seat on Pivot Bracket)
	48X771	2	Stanley Logo (Hood Sides)
	44X6456MA	1	Deck Level Position / only (Ht. Adjust Detent Plate)
	48X772	2	LT Hydro Auto (Hood Sides)
	48X773	1	Stanley Logo
	48X774	1	Stanley Logo
	48X793	1	Steel Frame (Seat Deck)
	48X777	2	Pedal Control Hydro / Auto (Console Sides)
	48X3006	1	Servive Replacement Parts 52" (Under Hood)
	48X776	1	Stanley Deck - 52" (Mower Deck - Left Side)
	44X8063	1	Ever Start (Battery)
	44X7228MA	2	Gage Wheel - Leveling (Suspension Plate - Left)
	44X6870MA	1	No Step (Mower Deck -Left Side)
	44X6600	1	Gage Wheel Instructions (Mower Deck - Left Side)
	48X236MA	1	Cut Finger (Mower Deck (Right Side)

Drive Assembly

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B



Drive Assembly

REF NO	PART NO	QTY	DESCRIPTION
1	26X249MA		Screw
2	095315MA		Knob, Parking Brake
3	711691MA		Nut, Push
4	1001217 Z		Rod, Parking Brake
5	094185E700		Bracket, Left Transaxle
6	1001013 Z		Rod, Clutch
7	094045 Z		Latch, Parking Brake
8	7769209		V-Belt, Drive
9	015X79MA		Nut, Flange
10	095220MA		Pad, Brake/Clutch
11	1001190E701		Rod Assembly, Clutch/Brake
12	094384MA		Screw, Guide
13	094798		Pad, Pedal
14	002X53MA		Bolt, Carriage
15	017X57MA		Washer
16	0031X4MA		Pin, Hair
17	1001231		Pedal Assembly, Hydro
18	094756010		Wheel & Tire Assembly
--	342117		Tire ONLY
--	407050		Tube ONLY
19	17X160MA		Washer
20	690554 Z		Spacer
21	024373MA		VALVE STM&CP,TR41 SE
22	17X195MA		Washer
23	0011X3MA		RING, E .750D .050T
24	094618MA		HUB CAP
25	015X88MA		Nut, Centerlock
26	-----		Transaxle **
27	1001085E701		Strap, Torque
28	26X216MA		Screw
29	1001234 Z		Rod, Control
30	092132MA		NUT, Adjusting, 1/2-13
31	015X84MA		Nut, Centerlock
32	030X20MA		Pin, Cotter
33	017X48MA		Washer
34	165X92MA		Spring, Extension
35	17X148MA		Washer
36	1001086ZMA		ARM, Disconnect
37	06X105MA		Capscrew
38	165X150MA		Spring, Brake
39	015X98MA		Locknut, Flange
40	690409MA		Pulley, Idler
41	690369MA		Spacer
42	1001121E701MA		Plate, Steering Mount
43	009X49MA		Bolt, Shoulder
44	1001007 Z		Link, Clutch
45	1001014MA		Nut, Tee
46	690410MA		Pulley, Idler


Footnotes:

Note** For information on Replacement Parts see the Central Parts Distributor on your area.

Drive Assembly

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B



Drive Assembly

REF NO	PART NO	QTY	DESCRIPTION
47	1001012MA		Bushing, Pivot
48	1001018 Z		Arm Assembly, Idler
49	094184E700		Bracket, Right Transaxle
50	01X155MA		Bolt, Hex
51	1001214 Z		Bracket, Disconnect
52	1001215ZMA		Rod, Disconnect
53	1001108E701		Bracket, Idler Pivot
54	002X92		Bolt, Carriage
55	002X78		Bolt, Carriage
56	165X155MA		Spring, Clutch
57	017X38MA		Washer
58	021553MA		Key, Square
59	1001187MA		Pulley, Idler
60	01X111MA		Bolt
61	1001122		Screw, Belt Guide

Not For
Reproduction


Footnotes:

Note** For information on Replacement Parts see the Central Parts Distributor on your area.

Electrical System

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B




Electrical System

REF NO	PART NO	QTY	DESCRIPTION
1	250X106		Harness, Light Wire
--	092372		Socket, Light
--	090084MA		Bulb, Light
2	250X105		Harness, Chassis Wire
3	092556MA		Switch, Ignition
--	7769214MA		Key, Ignition
--	091489MA		Nut, Hex
--	091488		Cap, Ignition
4	094136MA		Switch, Limit
5	054212		Fuse
--	407078MA		Holder, Fuse
6	7769224		Solenoid
--	26X229MA		Screw, Mounting
--	15X116MA		Locknut
7	024X32MA		Cable, Battery Ground
--	26X213MA		Screw, Ground Cable
8	021075		Battery
--	002X82MA		Bolt, Carriage
--	014X79MA		Wingnut
--	024196		Boot, Cable
9	250X104		Harness, Seat Switch Wire
10	094159MA		Switch, Seat Sensor
11	024X31MA		Cable

Engine Mount

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B



Engine Mount

REF NO	PART NO	QTY	DESCRIPTION
1	26X270		Screw
2	1001114		Dash
3	095173		Console
4	26X253MA		Screw
5	092317MA		FUEL CAP -(Included with Ref. No. 6)
6	1001220		Tank, Fuel
7	1001225		Control, Throttle
8	095197MA		Clamp, Hose -(Included with Ref. No. 6)
9	7601033MA		Fuel Line (Must cut to length) -(Included with Ref. No. 6)
10	-----		Engine *
11	711851MA		Gasket, Exhaust
12	1001038		Tube, Right Exhaust
13	015X88MA		Nut
14	001X91MA		Bolt
15	26X249MA		Screw
16	26X263MA		SCREW.25-20 S-T
17	690538E701MA		Bracket, Muffler
18	093259MA		Muffler
19	690537E701MA		BRKT - MUFF MTG HP
20	26X214MA		Screw
21	0025X7MA		Bolt, Engine Mount
22	690507MA		Pulley, Stack
23	17X170MA		WASHER.46.97.25 FLAT
24	019X35MA		Washer, Star
25	01X140MA		Bolt, Hex
26	325547MA		Drain, Oil
27	1001039		Tube, Left Exhaust
28	018X15MA		Washer
29	690401		Choke
30	015X68MA		Nut
31	032618MA		Strap, Tie


Footnotes:

Note* For information on Replacement Parts see the Central Parts Distributor in your area.

Frame Assembly

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B




Frame Assembly

REF NO	PART NO	QTY	DESCRIPTION
1	094186E700		Plate, Top Rear
2	26X270		Screw
3	690218E700		Plate, Rear
4	26X249MA		Screw
5	1001002E701		Plate, Hitch
6	690482E700		Bracket, Support
7	094184E700		Bracket, Right Transaxle
8	094185E700		Bracket, Left Transaxle
9	1001269E700		Frame, Left
10	1001268E700		Frame, Right

Front Axle

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B




Front Axle

REF NO	PART NO	QTY	DESCRIPTION
1	15X118MA		Locknut, Flange
2	1001270E701MA		Bracket, Rear Hanger
3	1001460E700		Assembly, Axle (with Zerk)
4	030X49MA		Pin, Cotter
5	17X195MA		Washer
6	690150MA		Bearing, Spindle
7	092530MA		Fitting, Grease
8	094027E701MA		Hanger, Left Deck
9	26X249MA		Screw
10	17X113MA		WASHER.76-1.2 13G FL
11	094007E701MA		Hanger, Axle
12	094026E701MA		Hanger, Right Deck
13	01X146MA		Bolt, Hex
14	1001173E701MA		LEFT FRONT SPINDLE
15	1001175E701MA		Assembly, Right Spindle
16	009X62MA		Bolt, Shoulder
17	15X111MA		Locknut, Flange
18	015X79MA		Locknut, Flange
19	1001121E701MA		Plate, Steering Mount
20	1001176		Gear, Sector
21	17X168ZMA		Washer
22	015X84MA		Nut, Flange Centerlock
23	1001178E701MA		Link, Drag -Right
24	094384MA		Guide, Belt
25	1001177E701MA		Link, Drag -Left
26	094123MA		Bearing, Sector Gear
27	001X84MA		CAPSCREW, Hex Head, 5/16-18 x 1
28	17X104MA		Washer
29	002X96MA		Bolt, Carriage

Hood & Grill

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B




Hood & Grill

REF NO	PART NO	QTY	DESCRIPTION
1	26X270		Screw
2	1001114		Dash
3	7601029		Trim 2.23"
4	643129		Cable
5	1001186E010		Hood Assembly
6	26X238MA		Screw
7	95234		Lens & Reflector Assembly
8	690113MA		Cap, Pivot
9	009X49MA		Bolt, Shoulder
10	690114		Base, Pivot
11	1001169E700		Brace, Right Grille Assembly
12	1001171E700		Brace, Left Grille Assembly
14	094457E700		Panel, Left Side
15	014X79MA		Wingnut
16	7601029		Trim 0.39"
17	1001126E700		Grille
18	094458E700		Panel, Right Side
19	26X277MA		Screw
20	26X249MA		Screw
21	1001191		Guard Assembly, Muffler
22	1001156		Shield, Upper Heat
23	26X263MA		SCREW.25-20 S-T
24	095173E700		Console
25	26X239MA		Screw
26	1001099E700		Deck Seat
27	1001158		Plenum
28	028X49MA		Retainer, Push
29	028X23MA		Cap, Push
30	1001491MA		Bearing, Steering
31	028X57		U-Nut
32	093007		Panel, Access
33	094464E700		Bracket, Right Console
34	094465E700		Bracket, Left Console
35	015X84MA		Nut
--	F-020758L		Book, Instruction

Mower Housing

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B




Mower Housing

REF NO	PART NO	QTY	DESCRIPTION
1	094117E701		Baffle, Right Bottom
2	015X79MA		Locknut, Flange
3	002X53MA		Bolt, Carriage
4	26X249MA		Screw
5	015X88MA		Locknut
6	015X84MA		Locknut
7	690078E701		Brace, Hi Lifter
8	1001154E701		Plate, Suspension
9	009X51MA		BOLT-SHD.38-16X.499D
10	166X42MA		Spring, Torsion
11	094118E701		Baffle, Left Bottom
12	094717E700		Bracket, Rear Gage Wheel
13	690164E701		Bracket, Left Lifter
14	690118E700		Bracket, Bellcrank
15	094694E700		Bracket, Right Lifter
16	092104E701MA		Bracket, Hinge
17	094716E700		Bracket, Rear Gage Wheel
18	1001272E700		Bracket, Front Gage Wheel
19	1001181E700		Assembly, Reinforcement
20	094693E700MA		Bracket, Front Deck
21	002X64MA		Bolt, Carriage
22	690135E701		Assembly, Baffle
23	095176E701MA		Bracket, Chute Support
24	-----		UNKNOWN

Mower Housing Suspension (part 1)

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B




Mower Housing Suspension (part 1)

REF NO	PART NO	QTY	DESCRIPTION
1	94496MA		Grip, PTO
2	094826 Z		Handle, PTO
3	094022 Z		Pad, Switch
4	0025X3MA		Screw, Hex
5	094497		Grip
6	166X40MA		Spring
7	17X103MA		Washer
8	690533MA		Lever, Lift
9	094017 Z		Lever, PTO
10	009X39MA		Bolt, Shoulder
11	030X20MA		Pin, Cotter
12	017X57MA		Washer
13	094004 Z		Link, PTO
14	015X84MA		Nut, Flange
15	26X249MA		Screw
16	166X39MA		Spring
17	094018E701MA		Bracket, PTO
18	165X120MA		Spring
19	690394E700		Crank, PTO
20	690550E700		Link, Lift
21	690122E700		Link, Lift Handle
22	17X168ZMA		Washer
23	017X57MA		Washer
24	0031X4MA		Pin, Hair
25	017X91 Z		Washer
26	002X85MA		Bolt, Carriage
27	1001111E700MA		Lever Assembly, Lift
30	094067MA		Pin
31	094055E700		Bracket, Rear Suspension
32	690151MA		Spacer, Lifter
33	009X53MA		Bolt, Shoulder
34	094015E700		Bracket, Pivot
36	17X191MA		Washer
37	015X84MA		Nut, Flange
38	165X133MA		Spring
39	015X68MA		Nut, Flange
40	094005E700		Bracket, PTO Crank
41	094027E700		Hanger, Left Deck
42	094026E700		Hanger, Right Deck
43	094158ZMA		Rod, Hanger
44	690539E700		Bracket, Suspension
45	1001098E700		Plate, Stiffening
46	094042ZMA		Stud, Spring Mount
47	690182MA		Stud, Swivel
48	015X79MA		Nut
49	015X84MA		Nut

Mower Housing Suspension (part 2)

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B




Mower Housing Suspension (part 2)

REF NO	PART NO	QTY	DESCRIPTION
1	092265MA		Wheel, Gage
2	094025MA		BOLT, Gauge Wheel
3	017X91MA		Washer
4	031X11MA		Pin, Hair
5	690550E701MA		Link, Lift
6	017X91 Z		Washer
7	0031X4MA		Pin, Hair
8	015X84MA		Locknut
9	095194		Pin, Hanger
10	019X44MA		Washer
11	017X45MA		WASHER,FLAT .33 1. 16
12	095004MA		Wingnut
13	009X52MA		Bolt, Shoulder
14	094055E701MA		Bracket, Rear Suspension
15	028X23MA		Cap, Push
16	094996MA		Rod, Deck Suspension
17	17X103MA		Washer
18	1001252MA		Roller
21	26X249MA		Screw
22	094158ZMA		Rod, Hanger
23	690539E700		Bracket, Front Suspension
24	094604E700		Stiffener
25	030X49MA		Pin, Cotter
26	092159ZMA		Rod, Deflector
27	166X34MA		Spring, Torsion
28	092100MA		Deflector, Chute

Rear Body

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B




Rear Body

REF NO	PART NO	QTY	DESCRIPTION
1	1001028MA		Seat
2	094154E700		Support, Seat
3	028X23MA		Capo, Push
4	094057MA		Spring, Leaf
5	017X47MA		Washer
6	009X56MA		Bolt, Shoulder
7	1001054MA		Bolt, Wing
8	26X229MA		Screw
9	1001218MA		U-Clip
10	1001095		Panel, Left Shoulder
11	009X47MA		Bolt, Shoulder
12	094483		Cover, Detent Lockout
13	094194		Plate, Lift Detent
14	001X45MA		Bolt, Hex
15	094153E700MA		Bracket, Pivot
16	1001094		Panel, Right Shoulder
17	094156ZMA		Rod, Pivot
18	009X55MA		Bolt, Shoulder
19	020107MA		Cap
20	094155 Z		Washer, Cup
21	164X31		Spring, Compression
22	26X249MA		Screw
23	164X30MA		Spring, Compression
24	690424MA		Container, Battery
25	015X89MA		NUT .25-20 FLANGELOCK
26	0193X1MA		Fastener, Panel
27	015X81MA		NUT#10-24 MCLEANLOCK
28	15X123MA		Nut, Nylock
29	1001099E700		Deck, Seat
30	17X207		Washer
31	26X284MA		Screw
32	095408		Mat, Left
33	095409		Mat, Right
34	17X102MA		Washer

Steering Assembly

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 525607x692B



Steering Assembly

REF NO	PART NO	QTY	DESCRIPTION
1	1001255		Cap
2	0025X3MA		Screw, Hex
3	1001226MA		Wheel, Steering
4	690625		Shaft, Steering
5	26X267MA		Screw
6	094124MA		Bearing -(Included with Ref. No. 4)
7	690183MA		GEAR - PINION -(Included with Ref. No. 4)
8	011X25MA		Ring, Snap -(Included with Ref. No. 4)
9	094618MA		HUB CAP
10	091334		Bearing, Wheel
11	17X195MA		Washer
12	17X192MA		Washer
13	030X49MA		Pin, Cotter
14	17X146MA		Washer
15	094755601		Wheel & Tire, Front
--	091912MA		Tire *
--	407924		Tube
--	024373MA		VALVE STM&CP,TR41 SE




Footnotes:

Note* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

Hardware Identification & Torque Specifications

Torque Specification Chart								
FOR STANDARD METRIC MACHINE HARDWARE (Tolerance ± 20%)								
Property Class	 Class 5.6		 Class 8.8		 Class 10.9		 Class 12.9	
Size Of Hardware	in/lbs ft/lbs	Nm.	in/lbs ft/lbs	Nm.	in/lbs ft/lbs	Nm.	in/lbs ft/lbs	Nm.
M3	5.88	.56	13.44	1.28	19.2	1.80	22.92	2.15
M4	13.44	1.28	30.72	2.90	43.44	4.10	52.56	4.95
M5	26.4	2.50	60.96	5.75	5.97	8.10	7.15	9.7
M6	44.64	4.3	7.3	9.9	10.3	14	12.1	16.5
M7	5.2	7.1	12.1	16.5	16.9	23	19.9	27
M8	7.7	10.5	17.7	24	25	34	29	40
M10	15	21	35	48	50	67	59	81
M12	26	36	61	83	86.2	117	103	140
M14	42	58	101	132	136	185	162	220
M16	64	88	147	200	210	285	250	340
M18	89	121	202	275	287	390	346	470
M20	126	171	290	390	405	550	486	660
M22	169	230	390	530	559	745	656	890
M24	217	295	497	375	708	960	840	1140
M27	320	435	733	995	1032	1400	1239	1680
M30	435	590	995	1350	1401	1900	1681	2280
M33	590	800	1349	1830	1902	2580	2278	3090
M36	759	1030	1740	2360	2441	3310	2935	3980
M39	988	1340	2249	3050	3163	4290	3798	5150

The guides and ruler furnished below are designed to help you select the appropriate hardware.



Standard Hardware Sizing

When a washer or nut is identified as 1/2" (M8), this is the *Nominal size*, meaning the *inside diameter* is 1/2 inch (8mm metric thread diameter); if a second number is present it represents the *threads per inch* (distance between threads).


When bolt or capscrew is identified as 1/2 - 16 x 2" (M8 - 1.25 x 50), this means the *Nominal size*, or body diameter is 1/2 inch (8mm metric thread diameter), the second number, 16, represents the *threads per inch*, (*distance between threads*). The final number is the body length of the bolt or screw, 2 inches (50mm).

Torque Specification Chart						
FOR STANDARD MACHINE HARDWARE (Tolerance ± 20%)						
Hardware Grade	 SAE Grade 2		 SAE Grade 5		 SAE Grade 8	
Size Of Hardware	in/lbs ft/lbs	Nm.	in/lbs ft/lbs	Nm.	in/lbs ft/lbs	Nm.
8-32	19	2.1	30	3.4	41	4.6
8-36	20	2.3	31	3.5	43	4.9
10-24	27	3.1	43	4.9	60	6.8
10-32	31	3.5	49	5.5	68	7.7
1/4-20	66	7.6	8	10.9	12	16.3
1/4-28	76	8.6	10	13.6	14	19.0
5/16-18	11	15.0	17	23.1	25	34.0
5/16-24	12	16.3	19	25.8	29	34.0
3/8-16	20	27.2	30	40.8	45	61.2
3/8-24	23	31.3	35	47.6	50	68.0
7/16-14	30	40.8	50	68.0	70	95.2
7/16-20	35	47.6	55	74.8	80	108.8
1/2-13	50	68.0	75	102.0	110	149.6
1/2-20	55	74.8	90	122.4	120	163.2
9/16-12	65	88.4	110	149.6	150	204.0
9/16-18	75	102.0	120	163.2	170	231.2
5/8-11	90	122.4	150	204.0	220	299.2
5/8-18	100	136	180	244.8	240	326.4
3/4-10	160	217.6	260	353.6	386	525.0
3/4-16	180	244.8	300	408.0	420	571.2
7/8-9	140	190.4	400	544.0	600	816.0
7/8-14	155	210.8	440	598.4	660	897.6
1-8	220	299.2	580	788.8	900	1,244.0
1-12	240	326.4	640	870.4	1,000	1,360.0

NOTES

- These torque values are to be used for all hardware excluding: locknuts, self-tapping screws, thread forming screws, sheet metal screws and socket head setscrews.
- Recommended seating torque values for locknuts:
 - for prevailing torque locknuts - use 65% of grade 5 torques.
 - for flange whizlock nuts and screws - use 135% of grade 5 torques.
- Unless otherwise noted on assembly drawings, all torque values must meet this specification.

Common Hardware Types



Wrench & Fastener Size Guide

 1/4" Bolt or Nut Wrench—7/16"	 5/16" Bolt or Nut Wrench—1/2"	 3/8" Bolt or Nut Wrench—9/16"	 7/16" Bolt or Nut Wrench (Bolt)—5/8" Wrench (Nut)—11/16"	 1/2" Bolt or Nut Wrench—3/4"
M6 Bolt or Nut Wrench—10mm	M8 Bolt or Nut Wrench—13mm	M10 Bolt or Nut Wrench—17mm	M12 Bolt or Nut Wrench—19mm	M14 Bolt or Nut Wrench—22mm

