

Parts Manual for

SNAPPER® PAC-N-SAC CATCHER

*** KIT #6-0793**

IT IS THE POLICY OF SNAPPER POWER EQUIPMENT TO IMPROVE ITS PRODUCTS WHENEVER IT IS POSSIBLE AND PRACTICAL TO DO SO. WE RESERVE THE RIGHT TO MAKE CHANGES OR ADD IMPROVEMENTS AT ANY TIME WITHOUT INCURRING ANY OBLIGATION TO MAKE SUCH CHANGES ON PRODUCTS MANUFACTURED PREVIOUSLY.



SNAPPER POWER EQUIPMENT
McDonough, GA • 30253




*** NOTE: KIT 6-0793 REPLACES KIT 6-0664.**

(REV. 2 4/89)
(REPLACES 10/86)

MANUAL #06121


① KIT, PAC-N-SAC

SIGNAL INSTRUCTIONS		
STOP BLADE IMMEDIATELY WHEN SIGNAL CHANGES FROM GO TO STOP IN ORDER TO PREVENT CLOGGING		
SIGNAL	CONDITION	RECOMMENDED ACTION
GO	BOX NOT FULL	KEEP MOWING
	BOX FULL	STOP BLADE EMPTY BOX OR STOP BLADE PACK GRASS DOWN, & BOW BACK TO EMPTYING PLACE
STOP	FLOW PATH IS CLOGGED	STOP ENGINE CLEAR TUBE, ADAPTER, & ELBOW BRUSH OFF SCREEN
	MARGINAL PERFORMANCE CAUSED BY INCORRECT OPERATION	INCREASE ENGINE SPEED, DECREASE GROUND SPEED, AND/OR RAISE CUTTING HEIGHT



SNAPPER PAC-N-SAC CATCHER


DECAL 1-8731



*51 3-2670 SUPPORT, SIDE (2)

*** NOTE: THESE PARTS ARE USED ON '89 MODELS
& LATER WHICH HAVE WIDER HANDLES.**

ITEM	PART NO.	DESCRIPTION
1	6-0793	KIT, Pac-N-SAC (Includes items 2 thru 50)
2	5-1548	ASSEMBLY, Cover (Incl. items 3 & 4 & 45 thru 48)
3	1-8731	DECAL, Pac-N-Sac
4	1-8732	DECAL, Operation
5	1-9995	CONTAINER
6	5-1550	ASSEMBLY, Adapter (Includes item 7)
7	1-5111	DECAL, CPSC
8	1-9997	GRASS TUBE, Lower
9	5-1547	ASSMY, Grass Tube (Incl. items 10 & 11)
10	1-5106	DRAWBOLT, Bottom
11	1-5113	EYELET, Flat Flange (3)
12	1-9999	SHIELD
13	1-9998	DEFLECTOR
14	5-1551	ASSEMBLY, Screen (Incl. items 14 thru 18)
15	1-8730	SCREEN
16	3-8197	ANGLE, Screen
17	9-0890	SCREW, #10-24x3/4" RH Machine (2)
18	9-0010	WASHER, 3/16" Flat (2)
19	1-2688	NUT, #10-24 Hex Lock (2)
20	5-1559	ASSEMBLY, Handle (Incl. items 20 thru 24)
21	1-8729	HANDLE, Latch
22	3-2450	LATCH, Container
23	3-2448	PIVOT, Latch
24	1-5359	PIN, Latch (2)
25	9-0921	NUT, 5/32" Self-Threading (2)
26	5-1545	ASSEMBLY, Indicator
27	3-8198	BRACE (2) ('88' Models & Eariler)
28	3-8325	BRACE (2) ('89 Models & Later) (Not Shown)
29	1-5101	DRAWBOLT, Top
30	3-2449	PLATE, Pivot
31	3-2470	RETAINER, Screen
32	9-0206	CAPSCREW, 5/16-18x3/4" Hex Head (2)
33	9-0188	WASHER, 5/16 Flat (2)
34	9-0666	CARRIAGE BOLT, 1/4-20x5/8" Short Neck (2)
35	9-0015	CARRIAGE BOLT, 1/4-20x1-3/4" Short Neck (2)
36	9-0972	CARRIAGE BOLT, 1/4-20x3" Short Neck (2)
37	9-0639	CAPSCREW, 1/4-20x1 1/2 Hex Head (2)
38	9-0055	WASHER, 1/4" Flat (2)
39	9-0053	LOCKWASHER, 1/4" Internal Tooth (7)
40	9-0189	WASHER, Int./Ext. Tooth Lock (2)
41	9-0917	MACHINE SCREW, #10-16x3/4" Slotted (9)
42	1-5338	NUT, #10-16 Clip (9)
43	9-0063	NUT, 1/4-20 Hex (9)
44	9-0196	NUT, 5/16-18 Hex (2)
45	1-8773	GASKET
46	9-0074	BOLT, 1/4-20x3/4" Short Neck (3)
47	9-0391	WASHER, 5/16 Internal Tooth Lock (2)
48	3-2517	SEAL, Left Hand
49	3-2518	SEAL, Right Hand
50	9-0944	SCREW, #10-24x1/2" FH Machine (6)
	9-0945	NUT, #10-24 Acorn (6)
	1-5349	ADHESIVE SQUARE (3)
	1-5813	SPACER (2)



Parts Manual for

SNAPPER® **PAC-N-SAC** **CATCHER**

SIGNAL INSTRUCTIONS

STOP BLADE IMMEDIATELY WHEN SIGNAL CHANGES FROM

GO TO **STOP** IN ORDER TO PREVENT CLOGGING

SIGNAL	CONDITION	RECOMMENDED ACTION
GO	BOX NOT FULL	KEEP MOWING
	BOX FULL	STOP BLADE-EMPTY BOX OR STOP BLADE-PACK GRASS DOWN, & MOW BACK TO EMPTYING PLACE
	OR FLOW PATH IS CLOGGED	STOP ENGINE-CLEAR TUBE, ADAPTER, & ELBOW-BRUSH OFF SCREEN
	OR MARGINAL PERFORMANCE CAUSED BY INCORRECT OPERATION	INCREASE ENGINE SPEED, DECREASE GROUND SPEED, AND/OR RAISE CUTTING HEIGHT



SNAPPER POWER EQUIPMENT
McDonough, GA • 30253



REVISION 2, 4/89 Issue)