



INSTALLATION INSTRUCTIONS

REFRIGERATOR WATER FILTER

MODEL: RF6448451PK

COMPATIBILITY:

BOSCH® 644845, REPLFLTR10, BT-644845, BT644845, 641425, 740560, 740568, D570104, 499850, 667256101443, 101443-A, 667256, AP3962558, 643046, 740572, D405434, 9000077095, 9000077096, 9000077104, 9000194412, 9000 077104, 9000 193 914, 9000194412, 9000225170, 9000077095, 9000 077 096, 1014430109, 1014430510, 101732, 0109, 1017320109, B26FT70SNS, B22CS80SNS, B22CS50SNS
HAIER® 0060218743, 0060820860, RF-2800-13, RF-2800-15, 10169, 101698B, 101699, 101699B 9557031, RF280013, RF280015, 0060822300, 3039382
MIELE® KWF1000

FILTER USE: 6 MONTHS OR 750 GALLONS, WHICHEVER COMES FIRST WILL VARY BASED ON WATER CONDITION

INSTALLATION INSTRUCTIONS:

1. Close and shut off valves before (inlet) and after (outlet) filter head. Depressurize filter.
2. Grasp head and cartridge securely, and turn used cartridge slowly to the left. If water line has not been properly depressurized, a small discharge of water may occur. Gently pull cartridge straight out and discard.
3. Align tabs of new cartridge with head and insert new cartridge into head. Turn cartridge to the right until the filter stops.
4. Place the inlet shut-off valves in regular working position. Dispense water for 5 minutes and discard. Discard ice cubes produced within first 24 hours.

RESETTING YOUR CHANGE FILTER INDICATOR:

Note: These are the most common filter reset instructions. If the instructions don't work for your refrigerator brand, see the documentation that came with your refrigerator.

REFRIGERATOR BRAND	INSTRUCTIONS
Bosch®	Manual reset - Press "menu" button. Press "change filter" button. Press "up/down" setting button until settings display shows "0." Press "menu" button. Filter timer is reset. Automatic reset - Press and hold "change filter" button for three seconds. The filter alarm is now switched off and the "change filter" button is no longer illuminated. Water filter timer is automatically reset.



COMPONENT

This RF6448451PK is Tested and Certified by NSF International against NSF/ANSI Standard 42 & 372 for materials and structural integrity requirements.

CAUTION: This filter should not be use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

OPERATING SPECIFICATIONS

Operating Temperature:33°F-100°F/0.6°C-38°C
Working Pressure: 20 psi-100 psi/140 kPa-689 kPa
Rated Capacity:750 gallons/2,839 liters
Flow Rate: 0.5 gpm/1.9 lpm

SUBSTANCE REDUCTION

The system has been tested and certified by the NSF International according to NSF/ANSI Standard 42 for the reduction of the substances listed below. The concentration of the indicated substances in water entering the system was reduced to a concentration less than or equal to the permissible limit for the water leaving the system, as specified by NSF/ANSI Standard 42. While testing was performed under standard laboratory conditions, actual performance may vary.

Substance	Inf. Average	NSF Specified Challenge Concentration	Ave. % Reduction (%)	Average Product Water Concentration	Max Permissible Product Water Concentration	NSF Reduction Requirements	NSF Test Report
Chlorine Taste and Odor	2.1 mg/L	2.0mg/L ± 10%	97.6%	0.05 mg/L	N/A	≥50%	C0472739-01

FREQUENTLY ASKED QUESTIONS:

Q: Do I need remove the filter prior to descaling equipment?

A: Yes, remove filter prior to descaling and inspect for integrity. If needed replace with a new **RF6448451PK**

Q: Why are there black specks in the water or why does my water taste funny?

A: Water filters are made from the purest carbon blocks. When the filter ships it bounces around and knocks carbon granules loose from the block. These little carbon granules are called fines. All of the quality filters in the market place require a preliminary flushing to remove the carbon fines.

Some systems may need to be flushed more than once. This is especially true if you have scale or lime water. If you go on vacation and do not use your filtered water for several days, flush the systems again to remove any stagnant water.

Q: If I do not change my filter every 6 months, can this damage the system?

A: Yes, you must replace the filter every six months or whenever the filter light comes on (whichever comes first), or sooner if water flow to dispenser or icemaker is reduced or if there is heavy sediment/rust present. Filters left in longer will fatigue and burst causing water damage. We recommend a water hammer arrester be installed in any home that uses a refrigerator water filter.

WARNING:

To reduce the risk of property damage due to water leakage, this filter **MUST** be installed in accordance with the manufacturer's specifications and instructions. This filter unit must be replaced every 750 gallons or 6 months. Failure to follow instructions and operating specifications will void your warranty. Further, manufacturer assumes no responsibility or liability for damages arising out of misuse of the product.

BOSCH® is a registered trademark of BSH Home Appliance Corp.