



INSTALLATION INSTRUCTIONS

REFRIGERATOR WATER FILTER

MODEL: RF8472001PK

COMPATIBILITY:

FISHER & PAYKEL® 847200, RF605QDUVX1, RF522ADUX5, RF610ADUSX5, RS36A, RF170B, RF540A, RS9120, RF605Q, RS90A, RS36A, RS36W, E442B, RF610A, E522B, RF522A, RF522W, E402B, RF201A, RF402B, RF522B, RF135B, RF170

FILTER USE: 6 MONTHS OR 300 GALLONS, WHICHEVER COMES FIRST WILL VARY BASED ON WATER CONDITION

INSTALLATION INSTRUCTIONS:

1. Open filter compartment door and remove the old filter by lifting it upward until it can no longer move. Gently pull the old filter straight out of the cartridge holder (Do NOT twist cartridge). A small amount of water may drip down.
2. Remove protective cap from new replacement filter.
3. Insert top of filter into the cartridge holder, and push until filter is fully seated into position.
4. Gently swing the filter cartridge downward back into a vertical position. If the filter does not move downward easily, check the alignment of the top of the filter with the cartridge holder and ensure that it is fully seated.
5. Run water from the dispenser for 5 minutes (about 2½ gallons) to clear the system and prevent sputtering.

NOTE: A newly installed water filter cartridge may cause water to spurt from the dispenser. Initial flow rate may be slower than expected. Full flow rate should be restored within 24-36 hours.

RESETTING THE FILTER INDICATOR (FISHER & PAYKEL®)

A replacement indicator 🔄 of filter reminder message will show on the control panel of your product when you need to replace the water filter.

To reset indicator 🔄

- Press 🔄 and + together for 4 seconds.
- To reset the filter reminder message, follow onscreen instructions.

IMPORTANT!

- We recommend the water filter to be used from the time of installation.
- Do not reset indicator before filter is changed or filter monitoring will be inaccurate.



COMPONENT

This RF8472001PK is Tested and Certified by NSF International against NSF/ANSI Standard 42&372 for materials and structural integrity requirements.

CAUTION: This filter should not be use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

OPERATING SPECIFICATIONS

Operating Temperature: 33°F-100°F/0.6°C-38°C
Working Pressure: 20 psi-100 psi/140 kPa-689 kPa
Rated Capacity: 300 gallons/1,137 liters
Flow Rate: 0.5 gpm/1.9 lpm

SUBSTANCE REDUCTION

The system has been tested and certified by the NSF International according to NSF/ANSI Standard 42 for the reduction of the substances listed below. The concentration of the indicated substances in water entering the system was reduced to a concentration less than or equal to the permissible limit for the water leaving the system, as specified by NSF/ANSI Standard 42. While testing was performed under standard laboratory conditions, actual performance may vary.

Substance	Inf. Average	NSF Specified Challenge Concentration	Ave. % Reduction (%)	Average Product Water Concentration	Max Permissible Product Water Concentration	NSF Reduction Requirements	NSF Test Report
Chlorine Taste and Odor	2.1 mg/L	2.0mg/L ± 10%	97.6%	0.05 mg/L	N/A	≥50%	C0472739-01

FREQUENTLY ASKED QUESTIONS:

Q: Do I need remove the filter prior to descaling equipment?

A: Yes, remove filter prior to descaling and inspect for integrity. If needed replace with a new **RF8472001PK**

Q: Why are there black specks in the water or why does my water taste funny?

A: Water filters are made from the purest carbon blocks. When the filter ships it bounces around and knocks carbon granules loose from the block. These little carbon granules are called fines. All of the quality filters in the market place require a preliminary flushing to remove the carbon fines.
Some systems may need to be flushed more than once. This is especially true if you have scale or lime water. If you go on vacation and do not use your filtered water for several days, flush the systems again to remove any stagnant water.

Q: If I do not change my filter every 6 months, can this damage the system?

A: Yes, you must replace the filter every six months or whenever the filter light comes on (whichever comes first), or sooner if water flow to dispenser or icemaker is reduced or if there is heavy sediment/rust present. Filters left in longer will fatigue and burst causing water damage. We recommend a water hammer arrester be installed in any home that uses a refrigerator water filter.

WARNING:

To reduce the risk of property damage due to water leakage, this filter MUST be installed in accordance with the manufacturer's specifications and instructions. This filter unit must be replaced every 300 gallons or 6 months. Failure to follow instructions and operating specifications will void your warranty. Further, manufacturer assumes no responsibility or liability for damages arising out of misuse of the product.

Fisher & Paykel® is a trademark of Fisher & Paykel Appliances Limited.