

SAFETY TIPS

INSTRUCTIONS PERTAIN- ING TO A RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

IMPORTANT SAFETY INSTRUCTIONS

WARNING: When using electric appliances, basic precautions should always be followed, including the following:

1 READ AND FOLLOW ALL SAFETY INSTRUCTIONS

and all the important notices on the appliance before using the pump. Failure to do so may result in damage to this appliance.

2 DANGER - To avoid possible electrical shock, special care should be taken since water is employed in the use of this product. For each of the following situations, do not attempt repairs yourself; return the pump to an authorized service facility for service if it is still under warranty or discard the appliance.

A If the pump shows any sign of abnormal water leakage, disconnect the power supply cord.

B Carefully examine the appliance after installation. It should not be plugged in if there is water on parts not intended to be wet.

C Do not operate the appliance if it has a damaged electrical cord or plug, or if it is malfunctioning or if it is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment in order to avoid a hazard. Never cut the cord.

D The electrical outlet should always be above the level of the appliance. If the plug or outlet does get wet, **DO NOT** unplug the electrical cord. Disconnect the fuse or circuit breaker that supplies power to the appliance, then unplug and examine for presence of water in the outlet.

3 This appliance is not intended for use by persons (including children) with significantly impaired physical or mental capabilities, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should always be supervised to ensure that they do not play with the appliance. To reduce the risk of injury, close supervision is necessary when an appliance is used near children.

4 To avoid injury, do not contact moving or hot parts.

5 CAUTION Always unplug or disconnect the appliance

from the outlet before putting on or taking off parts and while the equipment is being installed, maintained, cleaned, or handled. When inserting the pump, pull out the main electrical plug. Never connect or disconnect the pump plug when there is water in the reservoir. Never yank the cord to pull the plug from outlet. Grasp the plug and pull to disconnect, then remove adaptor from outlet. Always unplug an appliance from an outlet when not in use. Never lift the pump by the cord.

6 CAUTION.

THIS IS A PET DRINKING FOUNTAIN PUMP.

This pump has been evaluated for use with freshwater only. Do not use this pump for other than its intended use (i.e. don't use in swimming pools, bath tubs, etc.). The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition. Only use attachments recommended or sold by the manufacturer.

- Do not use the pump in swimming pools or other situations where people are immersed.
- This pump is suitable for use in water temperatures up to 35°C.
- Do not use this pump with inflammable liquids.

7 Do not install or store the appliance where it will be exposed to temperatures below freezing. Shelter the pump from direct sunlight.

8 Ensure that the appliance is placed on a flat, even surface. Monitor the appliance regularly. Do not leave appliance unattended for extended periods.

9 If an extension cord is necessary, ensure the connection is watertight and dust proof. A cord with a proper rating should be used. A cord rated for less amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.

10 Do not use this unit outdoors. This unit is for indoor and household use only.

11 To reduce the risk of electrical shock, do not put pet fountain in water or other liquid. Do not place or store appliance where it can fall or be pulled into a tub or sink.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.


Only the faithful observation of these installation, electrical and maintenance guidelines will ensure the safe and efficient use of this drinking fountain.



RECYCLING: This product bears the selective sorting symbol for waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European Directive 2012/19/EU in order to be

recycled or dismantled to minimize its impact on the environment. Check with your local Environmental Agency for possible disposal instructions or take to an official council registered refuse collection point. Electronic products not included in the selective sorting process are potentially dangerous for the environment and human health due to the presence of hazardous substances.

CONTENTS



1. Cap
2. Flower accessory
3. Fountain top
4. Filter pad
5. Filter tray
6. Connector tube
7. Impeller
8. Water reservoir
9. Pump module
10. Adapter (5V, 1A)
11. Base

All pictures shown in the manual are for illustration purposes only. Actual product may vary due to product enhancement.

USAGE


Cats can be picky drinkers, some prefer large water surfaces over vertical streams and vice-versa. The Catit® Flower Fountain provides your cat with a continuous indoor source of fresh, clean water and allows different water flow settings to encourage your pet to drink more. Drinking more water helps ensure proper kidney function, helping to prevent crystal formation that can lead to urinary diseases.

The anti-overflow openings in the filter tray will prevent water from rising in case the filter cartridge gets clogged, though the filter should always be replaced if it is visibly dirty, damaged or clogged.


The pump is equipped with a sensor that detects when the water level inside of the reservoir is too low. At that point, the fountain will shut down automatically, to prevent the pump from running dry.

Note: After refilling the water reservoir, lift it up (if not already removed) and place it back on the base. This step is required for the water flow to restart.


INSTALLATION




Remove the unit from the packaging. Take the parts out of the reservoir and set them aside.




Clean the fountain before use to remove any dirt or debris. Wash the complete unit (excluding the filter) with a sponge. Do not use abrasive cleansers or materials on any part of the unit. Rinse thoroughly.




Insert the impeller into the opening in the base.




Place the tube connector onto the impeller, aligning the shape with the designated opening. Make sure to press the tube connector all the way down for optimal water flow.




Fill the reservoir with water until it nearly reaches the top rim. Do not overfill the fountain.




Take the filter pad out of the polybag. Rinse the filter to remove excess dust and soak it completely.




Place the filter tray onto the fountain reservoir.



Place the filter pad into the filter tray with the pockets facing down. Press down on the mesh part of the filter so it tucks underneath the plastic tabs in center.



Place the fountain top on top of the filter tray.



Insert the flower accessory into the center opening on the fountain top. Gently press down on the flower accessory until it reaches its stop position for optimal water flow.



Help & Advice

Scan the QR code or visit <https://www.catit.com/help-advice/> for the latest information and guides.

Distributed by:

U.S.A.: Rolf C. Hagen (U.S.A.) Corp., Mansfield, MA 02048

U.K.: Rolf C. Hagen (U.K.) Ltd., Castleford, W. Yorkshire WF10 5QH

Canada: Rolf C. Hagen Inc., Montréal (Quebec) H9X 0A2

Germany: HAGEN Deutschland GmbH & Co. KG, Lehmweg 99-105, 25488 Holm

España y Portugal: Rolf C. Hagen España S.A., Av. de Beniparrell n.11 y 13, 46460 Silla, Valencia

Malaysia: Rolf C. Hagen (SEA) Sdn. Bhd., 43500 Semenyih, Selangor D.E.

Argentina: Hagen S.A. Argentina, Rutherford 4459, Malvinas Argentina - CP 1615, Pcia. Bs.As.

Made in Malaysia


#43621

Printed in Malaysia

VER.: 01/26



CATIT.COM




Attach the power cord to a compatible USB adapter (5V, 1A), and plug it into the power socket. Secure excess power cord with a tie-wrap and place it behind the fountain to avoid pet chewing and entanglement.

MAINTENANCE


It's recommended to clean the fountain and rinse the filter every 3 days, and to clean the impeller and impeller opening on a weekly basis.

WARNING: Always unplug the fountain from the electrical wall socket with dry hands before putting on or taking off parts and whenever the pump is being installed, maintained or handled. Wash and rinse fountain with a soft sponge and a non-abrasive cleanser. Rinse thoroughly, ensuring no




Optional: Insert the flower accessory with or without the cap, or leave it out altogether, to offer different drinking options. Observe which option your cat prefers.

soapy residue. Remove the filter from the base and rinse. Do not wash the filter with soap. If filter contains excess debris or other foreign matter, replace it (replacement filters sold separately). The filter should be replaced every 3-4 weeks or when there are visible signs that the filter is saturated with foreign matter (debris, food, hair, etc.) or if the water flow is impeded. More frequent changes may be necessary due to indoor environmental and water conditions, as well as multiple pet use.



For cleaning or refilling the fountain, the top can be lifted from the base.



Use a cleaning brush to clean individual elements, such as the flower accessory, connector tube, and impeller opening. Be careful not to apply too much pressure, as this could bend the brush and/or damage the drinking fountain.

BUTTON & LED INDICATORS

Pump LEDs	Steady white	Fountain ON
	White OFF	Fountain OFF
	Blinking red	Out of water
	Steady red	Impeller blocked / Reservoir removed / Impeller removed

TROUBLESHOOTING



[HTTPS://WWW.CATIT.COM/QR/CATIT-FLOWER-FOUNTAIN-Q2-WMT/](https://www.catit.com/QR/CATIT-FLOWER-FOUNTAIN-Q2-WMT/)

Scan the QR code for the latest information and guides.

WARRANTY


Your **Flower Fountain** is guaranteed for defective parts and workmanship for a period of 2 years from the date of purchase. This guarantee is valid with proof of purchase only. The guarantee is limited to repair or replacement only and does not cover consequential loss, loss or damage to livestock and personal property or damage to animate or inanimate objects, irrespective of the cause thereof. This guarantee is valid only under normal operating conditions for which the unit is intended.

It excludes any damage caused by unreasonable use, negligence, improper installation, tampering, abuse or commercial use. The warranty does not cover wear and tear or parts which have not been adequately or correctly maintained. **THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS.** For warranty service, contact your local pet product dealer or write to the Catit® representative in your country.

ACCESSORIES


Replacement Flower Filter Pads available, sold separately.

#43722 12-pack



REPLACEMENT PARTS

#44849 Replacement pump module



REGISTER ONLINE!

catit® FLOWER FOUNTAIN®

USER MANUAL



#43621



SCAN QR CODE
TO GET STARTED!

CATIT.COM