




CHRYSLER 300
2020 QUICK REFERENCE GUIDE



VEHICLE USER GUIDE — IF EQUIPPED

VEHICLE USER GUIDE

To access the Vehicle User Guide on your Uconnect Touchscreen: Tap the Uconnect **Apps** button, then tap the **Vehicle User Guide** icon on your touchscreen. No Uconnect registration is required.



Vehicle User Guide Touchscreen Icon

NOTE:

Vehicle User Guide features are not available while the vehicle is moving. If you try to access while the vehicle is in motion, the system displays the message “Feature not available while the vehicle is in motion”.

Pre-Installed Features

- Your User Guide — Updated in real-time
- Touchscreen convenience
- Maintenance schedules and information
- Comprehensive icon and symbol glossary
- Available when and where you need it
- Customizable interface
- Multilingual


For further information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (US Residents) or www.owners.mopar.ca (Canadian Residents).

PASSIVE ENTRY

KEYLESS ENTER-N-GO — PASSIVE ENTRY

The Keyless Enter-N-Go system is an enhancement to the vehicle's key fob. This feature allows you to lock and unlock the vehicle's door(s) and trunk without having to press the key fob lock or unlock buttons.

TO UNLOCK FROM THE DRIVER OR PASSENGER SIDE




Grab The Door Handle To Unlock

With a valid Keyless Enter-N-Go key fob located outside the vehicle and within 5 ft (1.5 m) of the driver's or passenger's side front door handle, grab either handle to unlock the door automatically.

TO LOCK THE VEHICLE

- Both front door handles have buttons located on the outside of the handle. With a valid Keyless Enter-N-Go key fob located outside the vehicle and within 5 ft (1.5 m) of the driver's or passenger's front door handle, push the door handle button to lock all four doors and trunk.
- DO NOT grab the door handle, when pushing the door handle button. This could unlock the door(s).



Push The Door Handle Button To Lock




Do Not Grab The Door Handle When Locking

NOTE:

- If “Unlock All Doors 1st Press” is programmed, all doors will unlock when you grab hold of the front driver's door handle.
- If “Unlock All Doors 1st Press” is programmed, all doors and trunk will unlock when you push the trunk button. If “Unlock Driver Door 1st Press” is programmed, only the trunk will unlock when you push the trunk button.

- If a key fob is detected in the vehicle when locking the vehicle using the power door lock switch, the doors and trunk will unlock, and the horn will chirp three times. On the third attempt, your key fob can be locked inside the vehicle.
- After pushing the Keyless Enter-N-Go lock button, you must wait two seconds before you can lock or unlock the vehicle using the door handle. This is done to allow you to check if the vehicle is locked by pulling the door handle without the vehicle reacting and unlocking.
- If a Keyless Enter-N-Go door handle has not been used for 72 hours, the Keyless Enter-N-Go feature for that handle may time out. Pulling the deactivated front door handle will reactivate the door handle's Keyless Enter-N-Go feature.

TO ENTER THE TRUNK



Trunk Passive Entry Button

- With a valid Keyless Enter-N-Go key fob located outside the vehicle and within 5 ft (1.5 m) of the deck lid, push the button located on the right side of the Center High Mounted Stop Light (CHMSL), which is located on the deck lid above the license plate.

INSTRUMENT CLUSTER DISPLAY

CLUSTER DISPLAY

The instrument cluster display features a driver interactive display that is located in the instrument cluster. Pushing the controls on the left side of the steering wheel allows the driver to select Vehicle Information and Personal Settings.



Instrument Cluster Display Controls

- Push the **up** arrow button to scroll upward through the main menus (Speedometer, Vehicle Info, Driver Assist, Fuel Economy, Trip, Audio, Messages, Screen Setup) and sub menus.

- Push the **down** arrow button to scroll downward through the main menus and sub menus.
- Push the **right** arrow button to scroll forward to the next menu or sub menu.
- Push the **left** arrow button to scroll back to a previous menu or sub menu.
- Push the **OK** button to access/select the information screens, the submenu screens of a main menu item, or to select a personal setting in the setup menu. Push and hold the **OK** button for two seconds to reset displayed/selected features that can be reset.

Compass Calibration

This compass is self-calibrating, which eliminates the need to set the compass manually. When the vehicle is new, the compass may appear erratic, and the cluster will display dashes (- -) until the compass is calibrated.

You may also calibrate the compass by completing one or more 360 degree turns (in an area free from large metal or metallic objects) until the dashes (- -) displayed in the cluster turn off. The compass will now function normally.

PHONE PAIRING

PAIRING PROCEDURE

Mobile phone pairing is the process of establishing a wireless connection between a cellular phone and the Uconnect system.

Start Pairing Procedure On The Radio

Uconnect 4C, 4C NAV:



Uconnect 4C & 4C NAV

1. Place the ignition in the ACC or ON/RUN position.

2. Tap the Phone icon in the Menu Bar on the touchscreen.

- If no phone is connected to the vehicle, a message will display asking to pair a phone. Select Yes to this message. After pressing Yes, the radio prompts will take you through the steps to connect your phone via Bluetooth®.
- Uconnect Phone will display an “In progress” screen while the system is connecting. A message will display if pairing is successful. Click “OK” to this message.

Phone pairing can also be accessed by:

1. Placing the ignition in the ACC or ON/ RUN position.
2. Pressing the Apps button in the Menu Bar on the touchscreen.
3. Pressing “Settings”.
4. Pressing “Phone/Bluetooth®”.
5. Pressing “Paired Phones and Audio Devices”.
6. Pressing “Add Devices”.

Then, proceed to follow on-screen instructions to pair phone with vehicle.

NOTE:

Uconnect Phone will display an “In progress” screen while the system is connecting.

NOTE:

During the pairing procedure, you may receive a pop-up on your mobile phone for the Uconnect System to access your “messages” and “contacts”. Selecting “Ok” or “Allow” will sync your contacts with the Uconnect System.

NOTE:

Uconnect screen images are for illustration purposes only and may not reflect exact software for your vehicle.

Pair Your iPhone®:

For further information on how to activate Bluetooth® on your iPhone®, refer to your phone’s User Manual.

Complete The iPhone® Pairing Procedure:

After Bluetooth® is activated on your mobile phone, confirm the passkey shown on the mobile phone matches the passkey shown on the Uconnect system, then accept the Bluetooth® pairing request.

Pair Your Android™ Device:

For further information on how to activate Bluetooth® on your Android™ device, refer to your phone’s User Manual.

Complete The Android™ Pairing Procedure:

After Bluetooth® is activated on your mobile phone, confirm the passkey shown on the mobile phone matches the passkey shown on the Uconnect system, then accept the Bluetooth® pairing request.

For further information on Uconnect Phone, please refer to “Uconnect Phone” in the vehicle’s Owner’s Manual or the Uconnect Supplement.

LIGHTS

AUTOMATIC HIGH BEAM – IF EQUIPPED

This system automatically controls the operation of the headlamp high beams as oncoming vehicles approach.

- The Automatic High Beam Headlamp Control can be turned on or off using the Uconnect System.
- Push the turn signal lever away from you.
- With the headlight switch in the “AUTO” position, the high beams are controlled automatically.
- Pull the turn signal lever toward you to manually deactivate the system.
- This system will not activate until the vehicle is at or above 15 mph (24 km/h).


NOTE:

If the windshield or Automatic High Beam Headlamp Control mirror is replaced, the mirror must be re-aimed to ensure proper performance. See a local authorized dealer.

SPEED CONTROL

SPEED CONTROL

When engaged, the Speed Control system takes over accelerator operations at speeds greater than 25 mph (40 km/h), or 20 mph (32 km/h) depending on the powertrain used.



Speed Control Switches

- 1 — On/Off
- 2 — SET (+)/Accelerate
- 3 — RES/Resume
- 4 — SET (-)/Decelerate
- 5 — CANCEL/Cancel

To Activate/Turn Off

To turn the system on, push the On/Off button. To turn the system off, push the On/Off button a second time. The system should be turned off when not in use.

To Set A Desired Speed

Turn the Speed Control on. When the vehicle has reached the desired speed, push the SET (+) or the SET (-) button and release. Release the accelerator and the vehicle will operate at the selected speed.

To Deactivate

A soft tap on the brake pedal, pushing the CANCEL button, or normal brake pressure while slowing the vehicle will deactivate Speed Control without erasing the set speed memory. Pushing the On/Off button or placing the ignition switch in the OFF position erases the set speed in memory.

To Resume Speed

To resume a previously set speed, push the RES button and release.

To Increase Speed

When the Speed Control is set, you can increase speed by pushing the SET (+) button.

To Decrease Speed

When the Speed Control is set, you can decrease speed by pushing the SET (-) button.

To Accelerate For Passing

Press the accelerator as you would normally. When the pedal is released, the vehicle will return to the set speed.

ADAPTIVE CRUISE CONTROL (ACC) – IF EQUIPPED

If your vehicle is equipped with Adaptive Cruise Control, the controls operate similar to the standard Speed Control, with one difference. You can set a specified distance you would like to maintain between you and the vehicle in front of you.

- If the ACC sensor detects a vehicle ahead, ACC will apply limited braking or acceleration automatically to maintain a preset following distance while matching the speed of the vehicle ahead.
- If the sensor does not detect a vehicle directly ahead of you, it functions like the standard Speed Control system, maintaining the speed you set.



Adaptive Cruise Switches

- 1 — Adaptive Cruise Control (ACC) On/Off
- 2 — Distance Setting – Decrease
- 3 — Distance Setting – Increase

SAFETY FEATURES

FORWARD COLLISION WARNING WITH MITIGATION – IF EQUIPPED

The Forward Collision Warning (FCW) system provides the driver with active braking, audible and visual warnings (within the instrument cluster display) and may apply a brake jerk to warn the driver when it detects a potential frontal collision. The warnings and limited braking are intended to provide the driver with enough time to react and avoid or mitigate the potential collision.

FCW monitors the information from the forward-looking sensor, as well as the Electronic Brake Controller (EBC) to calculate a probable collision. When the system determines that a collision is probable, a warning message (both audible and visual) will be displayed within the cluster display along with a brake jerk warning (previously enabled in the Uconnect Settings). When the system senses the driver applying the brakes to avoid a probable collision, additional brake force will be provided to the vehicle. When the system determines a collision with the vehicle in front of you is no longer probable, the warning message will be deactivated.

NOTE:

The FCW feature can be customized and turned off through the Uconnect System touchscreen.

LANESENSE — IF EQUIPPED

The LaneSense system is operational at speeds above 37 mph (60 km/h) and below 112 mph (180 km/h). The LaneSense system uses a forward looking camera to detect lane markings and measure vehicle position within the lane boundaries.

Turning LaneSense On Or Off



The default status of LaneSense is “off”. The LaneSense button is located on the center stack.

LaneSense Warning Message

The LaneSense system will indicate the current lane drift condition through the instrument cluster display. The instrument cluster display will provide a visual warning depicting the unintentional lane departure.

When both lane markings are detected and the driver drifts out of the lane (no turn signal applied), the LaneSense system provides a haptic warning in the form of torque applied to the steering wheel to prompt the driver to remain within the lane boundaries. The driver may manually override the haptic warning by applying torque into the steering wheel at any time. When only a single lane marking is detected and the driver drifts across the lane marking (no turn signal applied), the LaneSense system provides a visual warning through the instrument cluster display to prompt the driver to remain within the lane. When only a single lane marking is detected, a haptic (torque) warning will not be provided.

NOTE:

The LaneSense system can be customized and turned off through the Uconnect System touchscreen.

SIRIUSXM GUARDIAN™ — IF EQUIPPED

ACTIVATION

Activate your account to enjoy advanced safety, security and convenience features.

1. Press the Apps icon on the bottom of your in-vehicle touchscreen.
2. Select the “Activate Services” icon from your list of apps.
3. Select “Customer Care” to speak with a SiriusXM Guardian™ Customer Care agent who will activate services in your vehicle, or select “Enter Email” to activate on the web.

Once you have activated your services, you're only a few steps away from using remote services.



Mobile App

Download the Uconnect mobile app:

- Once downloaded, use your Owner Account login and password to access the app.
- A PIN is required to execute remote services.
- Tap the Location button on the bottom menu bar of the app to locate your vehicle or send a destination to your Uconnect Navigation (if equipped).
- Tap the “Settings” side menu in the upper left corner of the app to bring up app settings and access the Assist Call Centers.

For further information:

- US residents visit: siriusxm.com/guardian
- Canadian residents visit: siriusxm.ca/guardian/

FEATURES

In-Vehicle

SiriusXM Guardian™ enhances your ownership and driving experience by connecting your vehicle to an operable network. When connected to an operable network, you have access to:

- SOS Call: Connect to a live agent who will contact emergency services and stay on the line with you until help arrives.
- Customer Care Assistance: Speak with a live agent by pressing the ASSIST button on your rearview mirror to get Roadside Assistance or support.

Remote Services

- Vehicle Finder helps you find where you parked your car.
- Send & Go allows you to send destinations to your navigation system for easy access on the go.
- Remote Door Lock/Unlock lets you unlock or lock your doors from any distance.
- Remote Horn & Lights allows you to sound your horn and flash your lights to easily find your car.
- Receive monthly Vehicle Health Reports, and Alerts whenever a problem is detected under the hood.

Security Services

- Receive stolen vehicle assistance, using GPS technology to help authorities locate your vehicle if it is stolen.

SiriusXM Guardian™ remote services can be used with the Uconnect app from virtually anywhere.

For further information on SiriusXM Guardian™ or the Uconnect mobile App, refer to your Uconnect Owner's Manual Supplement.

VEHICLE FINDER AND SEND & GO

Vehicle Finder

Vehicle Finder allows you to find the location of your vehicle. To find your vehicle:

1. Press the “Location” tab on the Uconnect mobile App bottom bar.
2. Select the “Vehicle” icon to determine the location of your vehicle.
3. Select the “Find Route” button that appears, once your vehicle is located.
4. Select your preferred Navigation app to route a path to your vehicle.

Send & Go

To send an address to your Uconnect Navigation (if equipped) using the Uconnect mobile app:

1. Press the “Location” tab on the bottom bar of the Uconnect mobile app.
2. Type in the destination you would like to navigate to, or search through one of the categories provided.
3. Select the destination you want to send from the list that appears.
4. Press the “Send To Vehicle” button, and then confirm the destination by pressing “Yes,” to send the destination to the Uconnect Navigation in your vehicle.
5. Finally, confirm the destination inside your vehicle by pressing the “Go Now” option on the pop-up that appears on the touchscreen when the vehicle is started.

AMAZON ALEXA® — IF EQUIPPED

AMAZON ALEXA® INTEGRATION

Alexa® is Amazon's cloud-based voice service and it lets you voice-command your Uconnect system from just about anywhere you Alexa®.

To link your Uconnect system to Amazon Alexa®:

1. Download the Amazon Alexa® app on your iPhone® or Android™ smartphone.
2. Launch the app, then tap MENU, and go to SKILLS.
3. Search for your vehicle. Then tap "ENABLE."


4. Select LINK ACCOUNT.
5. Log in using your vehicle's Owner Account ID and password.

Examples of commands:

- "Alexa®, ask Dodge Durango how much gas is in my vehicle."
- "Alexa®, ask Jeep Grand Cherokee to send directions to Iron Mountain to my vehicle."
- "Alexa®, ask Chrysler 300 to start my vehicle."

ANDROID AUTO™ AND APPLE CARPLAY® — IF EQUIPPED

ANDROID AUTO™ INTEGRATION



Android Auto™

With easy touchscreen navigation and voice recognition, Android Auto™ brings you useful information and organizes it into

simple cards that appear just when they are needed. To use Android Auto™ follow these steps:


1. Download the Android Auto™ app from the Google Play store on your Android™-powered smartphone.
2. Connect your Android™-powered smartphone to one of the media USB ports in your vehicle. If the Android Auto™ app was not downloaded, the first time you plug your device in, the app will begin to download.
3. Once the device is connected and recognized, the “Phone” icon on the personalized menu bar will automatically change to the Android Auto™ Icon.

NOTE:

Uconnect screen images are for illustration purposes only and may not reflect exact software for your vehicle.

APPLE CARPLAY® INTEGRATION

Apple CarPlay® is the smarter, safer way to use your iPhone® to get directions with Apple Maps, listen to Apple Music®, make calls and send messages — all through the Uconnect touchscreen or with your voice through Siri.



Apple CarPlay®

To use Apple CarPlay®, make sure you are using iPhone® 5 or later, have Siri enabled in Settings, ensure your iPhone® is unlocked

for the very first connection only, and then follow these steps:

1. Connect your iPhone® to one of the media USB ports in your vehicle.
2. Once the device is connected and recognized, the “Phone” icon on the personalized menu bar will automatically change to the Apple CarPlay® icon.

NOTE:

Long Press: Press and hold the VR button to activate Siri or Google Assistant.

Short Press: Briefly tap the Voice Recognition (VR) button to activate the native Uconnect voice recognition system.

When using Android Auto™ or Apple CarPlay®, be sure to use the manufacturer-provided cable that came with your phone, as aftermarket cables may not work.

NOTE:

Uconnect screen images are for illustration purposes only and may not reflect exact software for your vehicle.

CHRYSLER VEHICLE OWNER'S MOBILE APP

NOTE:

The Owner's Mobile App content is applicable to vehicles sold in the US market and are not available from the Canadian App Store® or Google Play Store.

KEY FEATURES

- Owner Information For Your Vehicle
- Accident Assistant
- Online Service Scheduling
- Roadside Assistance
- Maintenance History
- And More

To get this FREE application, go directly to the App Store® or Google Play Store and enter the search keyword "Chrysler".

The Chrysler Vehicle Owner's Information Application is the essential app for owners of Chrysler brand vehicles. The app puts driver and lifestyle information right in the palm of your hand, anywhere you go. Whether it's providing information about specific product features, taking a tour through your vehicle's equipment, staying up to date on your vehicle's health, knowing what steps to take following an accident, or scheduling your next appointment, we know you'll find the app an important extension of your Chrysler vehicle. Simply download the FREE app, select your make and model and enjoy the ride.

FEATURES/BENEFITS

- Available for free on iOS and Android™ smartphones and tablets.
- Select Chrysler brand vehicles from model year 2011 to current model year.
- You can also add other Jeep®, Dodge, Ram, FIAT®, or Alfa Romeo vehicles.*
- Easy access to vehicle information anywhere you go using categories, bookmarks, search and an A-Z index.
- Vehicle information such as operating instructions, maintenance, service history, vehicle controls and emergency procedures.
- Find a dealer or an FCA-certified repair facility.
- Easily document and email an accident report.

- A parking reminder that allows you to drop a pin on your location and navigate back to your vehicle.
- Contact customer care with one click.
- Access to vehicle heritage, parts, accessories, and social media networks.
- Schedule your next service appointment.
- Available in English and Spanish.

*App supports selected vehicles from model year 2011 to present.

To get this FREE application, go directly to the App Store® or Google Play Store and enter the search keyword “Chrysler”.

MAINTAINING YOUR VEHICLE

VEHICLE CARE

Due to the high performance nature of the brake system, the wheels will get coated with brake dust. It is recommended that Mopar® Wheel Cleaner be used on your wheels to avoid any possible damage to the finish. However, do not use wheel cleaner if your vehicle is equipped with Dark Vapor or Black Satin Chrome wheels, which must only be cleaned with mild soap, water, and a soft cloth. Please see your Owner's Manual for further information.

Due to lower ground clearance, driving your vehicle up steep driveways, approach ramps, or near parking blocks may cause damage to the front fascia and ground effects.

Caution should be taken when driving through water or snow more than 4 inches (100 mm) deep to avoid any potential for damage to your vehicle.





Whether it's providing information about specific product features, taking a tour through your vehicle's heritage, knowing what steps to take following an accident or scheduling your next appointment, we know you'll find the app an important extension of your Chrysler brand vehicle.

Simply download the app, select your make and model and enjoy the ride. To get this app, go directly to the App Store® or Google Play® Store and enter the search keyword "Chrysler" (U.S. residents only).

U. S.



mopar.com/om

DOWNLOAD A FREE ELECTRONIC COPY OF THE MOST
UP-TO-DATE OWNER'S MANUAL, UCONNECT AND
WARRANTY BOOKLETS

Canada



owners.mopar.ca

©2019 FCA US LLC. All Rights Reserved. Tous droits réservés. Chrysler is a registered trademark of FCA US LLC or FCA Canada Inc., used under license. Chrysler est une marque déposée de FCA US LLC ou FCA Canada Inc., utilisée sous le permis. App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.