

Supplement Sheet

DATE: 12/27/2006

SUBJECT: Drive Cable Adjustment

MODEL AFFECTED: Self-Propelled
Model Series 18M

USE THE FOLLOWING INSTRUCTIONS FOR ADJUSTING THE DRIVE CABLE:

Drive Cable

Your unit is equipped with an adjustable drive cable to adjust the tension on the drive cable. You will need to adjust the drive cable if the mower does not propel itself with the drive control engaged or if the mower's wheels hesitate with the drive control engaged. If either of these conditions occur, rotate adjuster barrel - making it longer will give more drive and shortening it will give less. This will also increase or decrease the force required to engage the drive control. See Figure 1.




Figure 1