

Cub Cadet®

ILLUSTRATED PARTS MANUAL



Enduro Series™ Lawn/Garden Tractor

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

To The Owner

Thank You

Thank you for purchasing a Cub Cadet Lawn Tractor. It was carefully engineered to provide excellent performance when properly operated and maintained.

All information in this manual is relative to the most recent product information available at the time of printing. Please be aware that this Illustrated Part's Manual may cover a range of product specifications for various models.

Components listed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and equipment without notice and without incurring obligation.

Throughout this manual, all references to *right* (RH) and *left* (LH) are observed from the operating position.

Table of Contents

Front and Rear Wheels	3	54-inch Deck (Stamped)	36
Steering	4	54-inch Deck (LX Fab)	38
Frame	6	54-inch Deck (GX Fab)	40
Manual PTO	8	Hydrostatic Transmission (Tuff-Torq 618-06972)	42
Electric PTO	9	Hydrostatic Transmission (Tuff-Torq 618-06974)	46
Seat	10	Hydrostatic Transmission (Tuff-Torq 618-07082)	50
Front Axle	11	Engine Accessories (Kawasaki Twin)	53
Deck Lift	12	Engine Accessories (Kohler Twin)	54
Pedals	13	LX Labels	55
Fender (GX)	14	GX Labels	56
Fender (LX)	16	Electrical Schematic (Man. PTO)	57
Hood	18	Electrical Schematic (Elec. PTO)	58
Fuel Tank and Dash	20	Kawasaki FR600V-AS06	61
Electrical	22	Kawasaki FR651V-AS08	77
Drive System (GX)	24	Kawasaki FR691V-AS17	92
Drive System (LX)	26	Kawasaki FR730V-AS21	106
42-inch Deck	28	Kohler KT725-3013	120
46-inch Deck (Stamped)	30	Kohler KT735-3012	136
46-inch Deck (Fab)	32	Kohler KT745-3001	152
50-inch Deck	34		

Record Product Information

To ease in ordering replacement parts, please locate the model plate on the equipment and record the information in the provided area to the right. You can locate the model plate by looking beneath the seat.

MODEL NUMBER

--	--	--	--	--	--	--	--	--	--	--

SERIAL NUMBER


--	--	--	--	--	--	--	--	--	--	--

Painted Parts

When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXXX-0637). Please refer to the table below for current color codes:


0637	Black
4021	Yellow (Cub Cadet)
0499	Beige (Cub Cadet)

0685	Blue (Cub Cadet)
0691	Black Jack (Cub Cadet Commercial)




Ref.	Part Number	Description
1.	634-05160-0931	Wh'l, Complete, 20 x 8 x 8
—	634-05114-0931	Wh'l, Complete, 22 x 9.5 x 12 (GX)
2.	634-04369-0499	Rim Ass'y, 8.0 x 7.0 x .750 ID
—	634-05112-0499	Rim Ass'y, 12.0 x 7.0 (GX)
3.	734-04364	Tire, 20 x 8 x 8 Mult Trac
—	734-04580	Tire, 22 x 9.5 x 12 (GX)
4.	934-0255	Valve, Tubeless Air
5.	634-05159-0931	Wh'l, Complete, 15 x 6 x 6
—	634-05163-0931	Wh'l, Complete, 16 x 6.5 x 8 (GX)
6.	941-04137	Bearing, Ball, .750 ID

Ref.	Part Number	Description
7.	737-0224	Grease Fitting
8.	710-06154A	Screw, 5/16-24 x .850
9.	934-04091B-0499	Rim Ass'y, 6.0 x 4.5
—	934-04090A-0499	Rim Ass'y, 8.0 x 5.38, (GX)
10.	734-3186A	Tire, 15 x 6 x 6
—	734-05117-0901	Tire, 16 x 6.5 x 8 (GX)
11.	783-08746	Bearing Cover
12.	931-3020	Hubcap
13.	736-3040	Flat Washer, .406 x 1.92 x .060
14.	712-3050	Lug Nut 7/16-14 (GX)



Ref.	Part Number	Description
1.	712-05093	Jam Nut, 7/16-20
2.	723-05009	Ball Joint, 7/16-20, Lock
3.	710-06133	Screw, M6-1 x .625
4.	710-06154A	Screw, 5/16-24 x .850
5.	710-3005	Hex Cap Screw, 3/8-16 x 1.25
6.	912-0214	Nut, Hex Lock, 3/8-24, Grb
7.	712-04065	Nut, Flange Lock, 3/8-16, Grf,
8.	717-05193A	Pinion Gear, 13T
9.	717-05225	Steering Gear
10.	936-0227	Flat Washer, .390 x 1.5 x .134
11.	738-05043	Shaft, Steering, .625 OD x 20
12.	748-05071	Steering Support
13.	783-08386	Steering Mounting Plate
14.	747-06456	Steering Rod, LH
15.	747-06457	Steering Rod, RH
16.	631-05102	Steering Wheel
17.	731-09764A	Cap, Steering Wheel


Frame




Frame

Ref.	Part Number	Description
1.	983-05067	Frame Assembly
2.	710-06133	Screw, M6-1 x .625
3.	710-3005	Hex Cap Screw, 3/8-16 x 1.25
4.	712-04217	Flange Lock Nut, 3/8-16
5.	728-05015	Rivet, 1/4-20 x .750
6.	731-10069A	Pivot Bracket
7.	731-10281	Wear Pad
8.	738-04058	Shoulder Spacer, .38 x 1.0 x .70
9.	738-05090	Shoulder Screw, M6-1
10.	747-06329	Rod, Battery
11.	783-08276	Lower Frame Brace Bracket
12.	783-08567	Battery Bracket
13.	683-05155†	Bumper Assenbly
14.	731-05368†	Hub Cap
15.	710-06012A†	Hex Flange Screw, 3/8-16

† If Equipped




Ref.	Part Number	Description
1.	983-05105	PTO Handle Assembly
2.	710-06133	Screw, M6-1 x .625
3.	710-06266	Hex Cap Screw, 7/16-20 x 3.50
4.	714-05005	Bow-Tie Cotter Pin
5.	731-10066	PTO Handle Mount, RH
6.	731-10067	PTO Handle Mount, Top
7.	732-05119	Extension Spring, .56 OD x 4.52 LG
8.	720-05086	Grip
9.	738-04425	Shoulder Screw, .342 x .335, 1/4-28
10.	946-05087	PTO Cable
11.	747-06239	Engine Pulley Keeper Rod
12.	747-06308	Cable Guide
13.	748-05078	Spacer, Engine Pulley
14.	956-04067A	Pulley, Engine, 3.56 x 6.12 Dia.
15.	725-04363	Switch, Interlock
16.	738-04237A	Shoulder Screw, #10-32 x .500



Ref.	Part Number	Description
1.	710-06133	Screw, M6-1 x .625
2.	710-06266	Hex Cap Screw, 7/16-20 x 3.50
3.	917-05209	Clutch, Electric PTO
4.	731-10576	Grommit
5.	736-05107	Flat Washer, .450 x 1.375 x .250
6.	783-08656	Clutch Bracket
7.	756-05061A	Engine Pulley


Seat



Ref.	Part Number	Description
1.	983-05111	Seat Pivot Plate Assembly
2.	710-04482	Hex Flange Screw, 3/8/16, .875, Gr5
3.	710-06133	Screw, M6-1 x .625
4.	712-04063	Nut, Flange Lock, 5/16-18, Grf
5.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
6.	732-04563	Compression Spring, .68 x 1.065 x .055
7.	938-0140	Shoulder Screw, .435 x .178, 5/16 x .56
8.	741-05128	Flange Bearing, .4385 ID
9.	783-06050	Seat Lever
10.	783-08451	Pivot Bracket, Short
11.	783-08550	Bracket, Mounting, Seat
12.	757-05022	Seat, High, Cub
—	757-05009	Seat, High, Cub
13.	710-1611B †	Screw, 5/16-18 x .75
14.	757-05035 †	Armrest


† If Equipped

Front Axle




Ref.	Part Number	Description
1.	983-05145	Front Axle Assembly
2.	710-0182	Hex Cap Screw, 1/2-13 x 3.00
3.	712-3083	Nut, Hex Lock, 1/2-13
4.	714-0162	Pin, Cotter, 5/32, 1.25
5.	726-0341	Push Cap, 3/4
6.	738-05056	Shoulder Spacer, 1.00 x .515 x .760
7.	931-3020	Hubcap
8.	736-0866	Flat Washer, .755 x 1.92 x .060

Deck Lift




Ref.	Part Number	Description
1.	983-05077	Shaft Assembly, Lift
2.	711-06143A	Ferrule, .510 x .496
3.	711-06346	Spring Insert
4.	912-3048	Nut, Jam, 1/2-13
5.	714-05005	Bow-Tie Cotter Pin
6.	731-09629A	Spacer, .76 ID x .93 LG
7.	732-05086A	Torsion Spring
8.	747-06186A	Deck Lift Handle
9.	747-06247A	Deck Lift Rod
10.	747-06392	Lift Adjustment Link
11.	748-04069	Pivot Cup
12.	783-08280	Rear Lift Arm
13.	720-05087	Grip
14.	732-05241	Lift Assist Spring, (42"/46")
15.	732-05242	Lift Assist Spring, (46" Fab/50"/54")



Ref.	Part Number	Description
1.	947-05033	Brake Pedal Assembly
2.	949-05026	FWD/REV Pedal Assembly
3.	712-04217	Flange Lock Nut, 3/8-16
4.	731-09957A	Clip
5.	732-05155	Torsion Spring, .725 ID
6.	735-05028	Reverse Pedal Pad
7.	735-05030	Forward Pedal Pad
8.	735-05051	Brake Pedal Pad
9.	938-0380	Shoulder Screw, .50 x .27, 3/8-16
10.	741-05074	Flange Bearing, .63 x .84 x .71
11.	741-05085	Plastic Sleeve Bearing
12.	748-04203	Cruise Latch


Fender (GX)



Fender (GX)

Ref.	Part Number	Description
1.	710-04666	Hex flange Screw, 1/4-20 x .75
2.	710-06133	Screw, M6-1 x .625
3.	710-06147	Screw, 1/4-10 x .75
4.	710-1260A	Screw, Self-tapping, 5/16-18, 0.750,
5.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
6.	726-3046	Ratchet Clip, .250 DIA
7.	731-09767	Upper Cover, RH
8.	731-09768	Upper Cover, LH
9.	731-10354	Lower Cover, LH
10.	731-10434	Cover Handle, LH
11.	731-10523	Lower Cover, RH
12.	731-10524	Cover Handle. RH
13.	732-05182	Compression Spring, 2.50 x 3.951 x .207
14.	783-08279	Fender
15.	783-08559	Lift Index Bracket
16.	731-09731	Pad, Foot, LH
17.	731-09812	Pad, Foot, RH


Fender (LX)



Fender (LX)

Ref.	Part Number	Description
1.	710-04666	Hex flange Screw, 1/4-20 x .75
2.	710-06133	Screw, M6-1 x .625
3.	710-06147	Screw, 1/4-10 x .75
4.	710-1260A	Screw, Self-tapping, 5/16-18, 0.750,
5.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
6.	726-3046	Ratchet Clip, .250 DIA
7.	731-10172	Cover, LH
8.	631-05261	Cover, RH, Manual PTO
—	631-05259	Cover, RH, Electric PTO
9.	732-05182	Compression Spring, 2.50 x 3.951 x .207
10.	783-08279	Fender
11.	783-08559	Lift Index Bracket
12.	731-09731	Pad, Foot, LH
13.	731-09812	Pad, Foot, RH


Hood



Hood


Ref.	Part Number	Description
1.	631-05249	Hood Frame
2.	710-06147	Screw, 1/4-10 x .75
3.	931-09849	Grill
4.	931-09850	Hood, Top
5.	931-10542	Hood, Side, LH
6.	931-10543	Hood, Side, RH
7.	931-09856	Headlight Lens, LH
8.	931-09857	Headlight Lens, RH
9.	731-10070	Hood Pin

Fuel Tank and Dash



Fuel Tank and Dash

Ref.	Part Number	Description
1.	710-06133	Screw, M6-1 x .625
2.	711-06378	Hinge Pin, .25 Dia x 4.50 LG
3.	714-04040	Pin, Cotter, Bow-Tie 72
4.	926-04012	Push Nut, .25 dia.
5.	931-09815	Upper Dash
6.	931-09816	Dash Cap
7.	731-10618	Steering Shaft Bearing
8.	731-10636	Dash Lever
9.	732-05199	Torsion Spring, .330 ID
10.	738-05090	Shoulder Screw, .368 x .115, M6-1
11.	747-06192	Control Rod
12.	783-08391	Lower Dash
13.	783-08453	Dash Plate
14.	783-08538	Steering Bearing Mounting Bracket
15.	951-05101	Tank, Fuel, 3 Gal.
16.	951-14767	Fuel Cap
—	951-12426A	Cap, Fuel Carb
17.	735-04081	Grommet, Rubber, 23.0 ID
18.	751-12118	Valve, Rollover Grommet
19.	751-12089-34	Hose, Vent
—	751-12089-45	Hose, Vent (Kohler 7000)
—	751-10749-22	Hose Vent (CARB)
20	751-10750-28	Hose, Fuel, Low Perm, 7/32 Yellow (CARB)
21	951-12372	Carbon Canister (CARB)




Ref.	Part Number	Description
1.	710-06133	Screw, M6-1 x .625
2.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
3.	725-04232	Switch, 3-Pole (Man. PTO)
4.	725-04363	Switch, Interlock
5.	925-06119	Key Switch (Man. PTO)
—	725-06102A	Key Switch (Elec. PTO)
6.	725-06173	Jumper Harness (Elec. PTO)
7.	925-06170	Hour Meter
—	925-06221	Hour Meter (GX)
8.	925-1707D	Battery
9.	925-06261	Dash Harness (Man. PTO)
—	925-06129	Dash Harness (Elec. PTO)
10.	925-3233	PTO Switch (Elec. PTO)
—	731-10634	Dash Plug (Man. PTO)
11.	738-04237A	Shoulder Screw, #10-32 x .500
12.	946-05114A	Choke Control
—	731-09956	Choke Plug
13.	946-05095	Throt Cable, 36.6"
—	946-05098A	Throt/Choke Cable, 43.5"
14.	726-0475	Clamp, 1.0 Dia.
15.	925-05041	Headlight Harness Assembly
16.	625-05000	Key, Assembly
17.	725-06153	Solenoid
18.	747-06308††	Cable Guide Rod
—	925-06130†	Harness Assembly, Main (Man. PTO)
—	925-06127†	Harness Assembly, Main (Elec. PTO)
—	925-06167†	Reverse Harness

† Not Shown

†† If Equipped


Drive System (GX)



Drive System (GX)

Ref.	Part Number	Description
1.	918-04317	Hub Assembly, Wheel
2.	918-06974	Transmission, Tuff Torq K58
3.	983-05090	Idler bracket Assembly
4.	710-0176	Hex Screw, 5/16-18, 2.75, Gr5, Std
5.	710-06133	Screw, M6-1 x .625
6.	710-06168	Hex Cap Screw, 3/8-16 x .750
7.	710-1611B	Screw, Self-tapping, 5/16-18, 0.750
8.	710-3011	Hex Screw, 3/8-16, 2.25, Gr5
9.	712-04063	Nut, Flange Lock, 5/16-18, Nylon
10.	712-04217	Flange Lock Nut, 3/8-16
11.	714-04040	Pin, Cotter, Bow-Tie 72
12.	731-10547	Sleeve, 1.02 ID x 1.75
13.	732-05108	Spring, Extension, .700 Dia x 8.41
14.	732-05146	Spring, Extension, .90 Dia x 8.14
15.	738-04162C	Shoulder Spacer, .884 x .190
16.	747-05608	Deck Spring Rod
17.	747-06193	Idler Link
18.	747-06251A	Rod, Brake, Tuff Torq
19.	747-06281A	Rod, Control, Tuff Torq
20.	747-06447	Rod, Transmission, Bypass
21.	748-05037A	Shoulder Spacer
22.	954-05027	Belt, V-Type
23.	756-05024	Idler Pulley, 3.56 OD
24.	756-05032	Idler Pulley, 3.00 OD
25.	783-08342	Belt Keeper Bracket
26.	783-08463	Transmission Bracket


Drive System (LX)



Drive System (LX)

Ref.	Part Number	Description
1.	918-06972	Transmission, Tuff Torq K46
—	918-07082	Transmission, Tuff Torq K46 ETC
2.	983-05090	Idler bracket Assembly
3.	710-0378	Hex Screw, 5/16-18, 2.50, Gr5, Std
4.	710-06133	Screw, M6-1 x .625
5.	710-1611B	Screw, Self-tapping, 5/16-18, 0.750
6.	710-3011	Hex Screw, 3/8-16, 2.25, Gr5
7.	712-04063	Nut, Flange Lock, 5/16-18, Nylon
8.	712-04217	Flange Lock Nut, 3/8-16
9.	714-04040	Pin, Cotter, Bow-Tie 72
10.	731-08237	Sleeve, .765 Id x 2.11
11.	732-05108	Spring, Extension, .700 Dia x 8.41
12.	732-05146	Spring, Extension, .90 Dia x 8.14
13.	738-04162C	Shoulder Spacer, .884 x .190
14.	747-05608	Deck Spring Rod
15.	747-06193	Idler Link
16.	747-06251A	Rod, Brake, Tuff Torq
17.	747-06281A	Rod, Control, Tuff Torq
18.	747-06447	Rod, Transmission, Bypass
19.	748-05037A	Shoulder Spacer
20.	750-06201	Spacer, .34 x .75 x .63
21.	954-05027	Belt, V-Type
22.	756-05024	Idler Pulley, 3.56 OD
23.	756-05032	Idler Pulley, 3.00 OD
24.	783-08342	Belt Keeper Bracket
25.	783-08463	Transmission Bracket


42-inch Deck



Ref.	Part Number	Description
1.	918-06976	Spindle Ass'y, Pulley, 6.3 Dia
2.	983-05076	Deck Assembly, 42"
3.	983-05182	Brake Assembly, Deck, RH
4.	983-05183	Brake Assembly, Deck, LH
5.	710-06133	Screw, M6-1 x .625
6.	710-06178	Hex Cap Screw, 3/8-16 x 2.00
7.	710-06213	Hex Cap Screw, 5/16-18 x 1.25
8.	710-0805A	Hex Cap Screw, 5/16-18 x 1.50
9.	710-1260A	Screw, Self-tapping, 5/16-18, 0.750,
10.	710-3005	Hex Cap Screw, 3/8-16 x 1.25
11.	712-04063	Nut, Flange Lock, 5/16-18, Nylon
12.	712-0417A	Nut, Flange, 5/8-18
13.	712-04217	Flange Lock Nut, 3/8-16
14.	714-05005	Bow-Tie Cotter Pin
15.	720-05075	Vinyl Cap, .29 x 1.00
16.	728-05016	Rivet Nut, 3/8-16
17.	732-04629	Spring, Extension, .750 x .477
18.	732-05151	Spring, Torsion, LH Brake
19.	783-08435	Bearing Shield
20.	936-0227	Flat Washer, .39 x 1.5 x .134
21.	738-05088	Shoulder Spacer, .75 x .145
22.	738-05099	Shoulder Spacer, .854 x .191
23.	942-04308	Blade, Cut, 21.23" 2-In-1, Cub
24.	747-06452	Rod, Brake, Deck
25.	748-05029A	Shoulder Spacer, Idler

Ref.	Part Number	Description
26.	954-05021	Belt, V-Type, A Sec x 99.75
27.	756-05034	Pulley, Idler, 4.50" Dia.
28.	783-08284	Idler Bracket
29.	783-08389	Pulley Cap
30.	783-08406	Bracket, Cable, PTO
31.	783-08510	Belt Cover
32.	921-04041	Coupler, Water
33.	731-07487	Deck Wash Nozzle
34.	738-04502	Shoulder Screw, 1/4-20 x 0.50
35.	734-04155	Wheel, Deck, 5.0 Dia. Ball
36.	734-0973	Wheel, Deck 5.0 x 1.38
37.	938-0373	Bolt, Shoulder, .496 x 1.525, 3/8-16
38.	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
39.	631-04354	Chute Deflector Assembly
40.	732-05261	Spring, Torsion, .440 ID x 1.75
41.	747-06290A	Hinge Pin
42.	783-08504A	Bracket, Chute, 42"
43.	710-0751	Hex Cap Screw, 1/4-20 x .62
44.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
45.	783-08690	Belt Keeper
46.	738-1010A	Shaft, Spindle, 5.75
47.	941-0919B	Bearing, Ball, .787id x 1.85 Od x .551
48.	750-04936	Spacer, .792 x 1.060 x 1.860
49.	750-06142	Spacer, .800 x 1.10 x 1.470
50.	756-05031	Pulley, Deck, 5.40 Dia.

46-inch Deck (Stamped)




46-inch Deck (Stamped)

Ref.	Part Number	Description
1.	918-06977	Spindle Ass'y, Pulley, 6.93 Dia
2.	983-05078	Deck Assembly, 46"
3.	710-06133	Screw, M6-1 x .625
4.	710-06178	Hex Cap Screw, 3/8-16 x 2.00
5.	732-04960	Extension Spring, .94 Dia. x 7.57
6.	710-0805A	Hex Cap Screw, 5/16-18 x 1.50
7.	710-1260A	Screw, Self-tapping, 5/16-18, 0.750,
8.	710-3005	Hex Cap Screw, 3/8-16 x 1.25
9.	712-04063	Nut, Flange Lock, 5/16-18, Nylon
10.	712-0417A	Nut, Flange, 5/8-18
11.	712-04217	Flange Lock Nut, 3/8-16
12.	747-05608	Deck Spring Rod
13.	714-05005	Bow-Tie Cotter Pin
14.	720-05075	Vinyl Cap, .29 x 1.00
15.	631-04354	Chute Deflector Assembly
16.	728-05016	Rivet Nut, 3/8-16
17.	732-05261	Spring, Torsion, .440 ID x 1.75
18.	747-06290A	Hinge Pin
19.	783-08435	Bearing Shield
20.	936-0227	Flat Washer, .39 x 1.5 x .134
21.	783-08504A	Bracket, Chute, 42"
22.	738-05099	Shoulder Spacer, .854 x .191

Ref.	Part Number	Description
23.	942-04244A	Blade, Cut, 23.25" 2-In-1, Cub
24.	738-1010A	Shaft, Spindle, 5.75
25.	710-0751	Hex Cap Screw, 1/4-20 x .62
26.	941-0919B	Bearing, Ball, .787id x 1.85 Od x .551
27.	748-05029A	Shoulder Spacer, Idler
28.	954-05022A	Belt, V-Type, A Sec x 108.3
29.	756-05034	Pulley, Idler, 4.50" Dia.
30.	750-04936	Spacer, .792 x 1.060 x 1.860
31.	783-08284	Idler Bracket
32.	783-08389	Pulley Cap
33.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
34.	783-08547	Belt Cover
35.	783-08690	Belt Keeper
36.	750-06142	Spacer, .800 x 1.10 x 1.470
37.	756-05030	Pulley, Deck, 6.74 Dia.
38.	921-04041	Coupler, Water
39.	731-07487	Deck Wash Nozzle
40.	738-04502	Shoulder Screw, 1/4-20 x 0.50
41.	734-04155	Wheel, Deck, 5.0 Dia. Ball
42.	734-0973	Wheel, Deck 5.0 x 1.38
43.	938-0373	Bolt, Shoulder, .496 x 1.525, 3/8-16
44.	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16

46-inch Deck (Fab)




46-inch Deck (Fab)

Ref.	Part Number	Description
1.	918-06977	Spindle Ass'y, Pulley, 6.93 Dia
2.	683-05153	Deck Assembly, 46"
3.	710-06133	Screw, M6-1 x .625
4.	710-06178	Hex Cap Screw, 3/8-16 x 2.00
5.	710-0376	Hex Cap Screw, 5/16-18 x 1.00
6.	710-1260A	Screw, Self-tapping, 5/16-18, 0.750,
7.	710-3005	Hex Cap Screw, 3/8-16 x 1.25
8.	712-04063	Nut, Flange Lock, 5/16-18, Nylon
9.	712-0417A	Nut, Flange, 5/8-18
10.	712-04217	Flange Lock Nut, 3/8-16
11.	714-05005	Bow-Tie Cotter Pin
12.	720-05010	Vinyl Cap, .29 x .50
13.	736-0258	Flat Washer, .385 x 1.00 x .135
14.	731-10629	Baffle, Discharge
15.	732-04960	Extension Spring, .94 Dia. x 7.57
16.	783-08435	Bearing Shield
17.	936-0227	Flat Washer, .39 x 1.5 x .134
18.	938-04033	Shoulder Screw, .428 x .160, 5/16-18
19.	738-05099	Shoulder Spacer, .854 x .191
20.	942-04244A	Blade, Cut, 23.25" 2-In-1, Cub
21.	747-05608	Deck Spring Rod
22.	748-05029A	Shoulder Spacer, Idler
23.	754-05087	Belt, V-Type, A Sec x 108.3

Ref.	Part Number	Description
24.	756-05034	Pulley, Idler, 4.50" Dia.
25.	783-08284A	Idler Bracket
26.	783-08389	Pulley Cap
27.	783-08547	Belt Cover
28.	783-08690	Belt Keeper
29.	921-04041	Coupler, Water
30.	731-07487	Deck Wash Nozzle
31.	738-04502	Shoulder Screw, 1/4-20 x 0.50
32.	734-04155	Wheel, Deck, 5.0 Dia. Ball
33.	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
34.	631-04354	Chute Deflector Assembly
35.	732-05261	Spring, Torsion, .440 ID x 1.75
36.	747-06290A	Hinge Pin
37.	783-08504A	Bracket, Chute, 42"
38.	710-0751	Hex Cap Screw, 1/4-20 x .62
39.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
40.	756-05030	Pulley, Deck, 6.74 Dia.
41.	738-1010A	Shaft, Spindle, 5.75
42.	941-0919B	Bearing, Ball, .787id x 1.85 Od x .551
43.	750-04936	Spacer, .792 x 1.060 x 1.860
44.	750-06142	Spacer, .800 x 1.10 x 1.470
45.	783-08619	Idler Keeper
46.	783-08867	Belt Keeper


50-inch Deck



Ref.	Part Number	Description
1.	918-06981	Spindle Ass'y, Pulley, 5.37 Dia
2.	983-05103	Deck Assembly, 50"
3.	710-06178	Hex Cap Screw, 3/8-16 x 2.00
4.	710-06215	Hex Cap Screw, 3/8-16 x 2.25
5.	710-0805A	Hex Cap Screw, 5/16-18 x 1.50
6.	710-1260A	Screw, Self-tapping, 5/16-18, 0.750,
7.	710-3005	Hex Cap Screw, 3/8-16 x 1.25
8.	711-06377	Roller Pin, 1/2 x 7.31 Lg
9.	712-04063	Nut, Flange Lock, 5/16-18, Nylon
10.	712-0417A	Nut, Flange, 5/8-18
11.	712-04217	Flange Lock Nut, 3/8-16
12.	714-05005	Bow-Tie Cotter Pin
13.	720-05075	Vinyl Cap, .29 x 1.00
14.	726-0299	Push Cap, 1/2"
15.	728-05016	Rivet Nut, 3/8-16
16.	731-05679B	Front Roller
17.	731-09968	Belt Cover, RH
18.	731-09969A	Belt Cover, LH
19.	732-04927	Spring, Extension, 1.25 OD x 8.5
20.	783-08435	Bearing Shield
21.	738-04502	Shoulder Screw, 1/4-20 x 0.50
22.	738-05082	Shoulder Spacer, .970 x .190

Ref.	Part Number	Description
23.	942-05052A	Blade, Cut, 17.27" 2-In-1, Cub
24.	747-05608	Deck Spring Rod
25.	748-05037A	Shoulder Spacer
26.	954-04077A	Belt, V-Type, B Sec x 134
27.	756-05034	Pulley, Idler, 4.50" Dia.
28.	783-08309A	Pivot Idler bracket
29.	783-08389	Pulley Cap
30.	921-04041	Coupler, Water
31.	731-07487	Deck Wash Nozzle
32.	734-04155	Wheel, Deck, 5.0 Dia. Ball
33.	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
34.	631-05116	Chute Deflector Assembly
35.	732-05261	Spring, Torsion, .440 ID x 1.75
36.	747-06290A	Hinge Pin
37.	783-08504A	Bracket, Chute, 42"
38.	710-0751	Hex Cap Screw, 1/4-20 x .62
39.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
40.	756-05036	Pulley, Deck, 5.00 Dia.
41.	938-04241	Shaft, Spindle, 5.50
42.	941-0919B	Bearing, Ball, .787id x 1.85 Od x .551
43.	750-04936	Spacer, .792 x 1.060 x 1.860
44.	750-06153	Spacer, .792 x 1.060 x 1.191

54-inch Deck (Stamped)




54-inch Deck (Stamped)

Ref.	Part Number	Description
1.	918-06979	Spindle Ass'y, Pulley, 5.37 Dia
2.	983-05104	Deck Assembly, 54"
3.	710-06178	Hex Cap Screw, 3/8-16 x 2.00
4.	710-06215	Hex Cap Screw, 3/8-16 x 2.25
5.	710-0805A	Hex Cap Screw, 5/16-18 x 1.50
6.	710-1260A	Screw, Self-tapping, 5/16-18, 0.750,
7.	710-3005	Hex Cap Screw, 3/8-16 x 1.25
8.	711-06377	Roller Pin, 1/2 x 7.31 Lg
9.	712-04063	Nut, Flange Lock, 5/16-18, Nylon
10.	712-0417A	Nut, Flange, 5/8-18
11.	712-04217	Flange Lock Nut, 3/8-16
12.	714-05005	Bow-Tie Cotter Pin
13.	720-05075	Vinyl Cap, .29 x 1.00
14.	726-0299	Push Cap, 1/2"
15.	728-05016	Rivet Nut, 3/8-16
16.	731-05679B	Front Roller
17.	731-09968	Belt Cover, RH
18.	731-09969A	Belt Cover, LH
19.	732-04927	Spring, Extension, 1.25 OD x 8.5
20.	783-08435	Bearing Shield
21.	738-04502	Shoulder Screw, 1/4-20 x 0.50
22.	738-05082	Shoulder Spacer, .970 x .190

Ref.	Part Number	Description
23.	942-05056A	Blade, Cut, 18.67" 2-In-1, Cub
24.	747-05608	Deck Spring Rod
25.	748-05037A	Shoulder Spacer
26.	954-05025	Belt, V-Type, B Sec x 139
27.	756-05034	Pulley, Idler, 4.50" Dia.
28.	783-08309A	Pivot Idler bracket
29.	783-08389	Pulley Cap
30.	921-04041	Coupler, Water
31.	731-07487	Deck Wash Nozzle
32.	734-04155	Wheel, Deck, 5.0 Dia. Ball
33.	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
34.	631-05116	Chute Deflector Assembly
35.	732-05261	Spring, Torsion, .440 ID x 1.75
36.	747-06290A	Hinge Pin
37.	783-08504A	Bracket, Chute, 42"
38.	710-0751	Hex Cap Screw, 1/4-20 x .62
39.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
40.	756-05038	Pulley, Deck, 4.50 Dia.
41.	938-04241	Shaft, Spindle, 5.50
42.	941-0919B	Bearing, Ball, .787id x 1.85 Od x .551
43.	750-04936	Spacer, .792 x 1.060 x 1.860
44.	750-06153	Spacer, .792 x 1.060 x 1.191

54-inch Deck (LX Fab)




54-inch Deck (LX Fab)

Ref.	Part Number	Description
1.	918-06979	Spindle Ass'y, Pulley, 5.37 Dia
2.	683-05138	Deck Assembly, 54"
3.	710-3005	Hex Cap Screw, 3/8-16 x 1.25
4.	710-06178	Hex Cap Screw, 3/8-16 x 2.00
5.	710-06215	Hex Cap Screw, 3/8-16 x 2.25
6.	710-0805A	Hex Cap Screw, 5/16-18 x 1.50
7.	710-1260A	Screw, Self-tapping, 5/16-18, 0.750,
8.	711-06377	Roller Pin, 1/2 x 7.31 Lg
9.	712-04063	Nut, Flange Lock, 5/16-18, Nylon
10.	712-0417A	Nut, Flange, 5/8-18
11.	712-04217	Flange Lock Nut, 3/8-16
12.	720-05075	Vinyl Cap, .29 x 1.00
13.	726-0299	Push Cap, 1/2"
14.	728-05016	Rivet Nut, 3/8-16
15.	731-05679B	Front Roller
16.	731-09968	Belt Cover, RH
17.	731-09969A	Belt Cover, LH
18.	732-04927	Spring, Extension, 1.25 OD x 8.5
19.	783-08435	Bearing Shield
20.	738-04502	Shoulder Screw, 1/4-20 x 0.50
21.	738-05082	Shoulder Spacer, .970 x .190
22.	942-05056A	Blade, Cut, 18.67" 2-In-1, Cub

Ref.	Part Number	Description
23.	747-05608	Deck Spring Rod
24.	748-05037A	Shoulder Spacer
25.	750-06153	Spacer, .792 x 1.060 x 1.191
26.	954-05025	Belt, V-Type, B Sec x 139
27.	756-05034	Pulley, Idler, 4.50" Dia.
28.	783-08309A	Pivot Idler bracket
29.	783-08389	Pulley Cap
30.	756-05038	Pulley, Deck, 4.50 Dia.
31.	714-05005	Bow-Tie Cotter Pin
32.	921-04041	Coupler, Water
33.	731-07487	Deck Wash Nozzle
34.	734-04155	Wheel, Deck, 5.0 Dia. Ball
35.	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
36.	631-05168A	Chute Deflector Assembly
37.	732-05261	Spring, Torsion, .440 ID x 1.75
38.	747-06290A	Hinge Pin
39.	783-08504A	Bracket, Chute, 42"
40.	710-0751	Hex Cap Screw, 1/4-20 x .62
41.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
42.	750-04936	Spacer, .792 x 1.060 x 1.860
43.	938-04241	Shaft, Spindle, 5.50
44.	941-0919B	Bearing, Ball, .787id x 1.85 Od x .551

54-inch Deck (GX Fab)




54-inch Deck (GX Fab)

Ref.	Part Number	Description
1.	918-06978	Spindle Ass'y, Pulley, 5.37 Dia
2.	683-05138	Deck Assembly, 54"
3.	710-06133	Screw, M6-1 x .625
4.	710-06178	Hex Cap Screw, 3/8-16 x 2.00
5.	710-06214	Hex Cap Screw, 3/8-16 x 2.75
6.	710-0805A	Hex Cap Screw, 5/16-18 x 1.50
7.	710-1260A	Screw, Self-tapping, 5/16-18, 0.750,
8.	711-06377	Roller Pin, 1/2 x 7.31 Lg
9.	712-04063	Nut, Flange Lock, 5/16-18, Nylon
10.	712-0417A	Nut, Flange, 5/8-18
11.	712-04217	Flange Lock Nut, 3/8-16
12.	720-05075	Vinyl Cap, .29 x 1.00
13.	726-0299	Push Cap, 1/2"
14.	728-05016	Rivet Nut, 3/8-16
15.	731-05679B	Front Roller
16.	731-09968	Belt Cover, RH
17.	731-09969A	Belt Cover, LH
18.	732-04927	Spring, Extension, 1.25 OD x 8.5
19.	783-08435	Bearing Shield
20.	738-04502	Shoulder Screw, 1/4-20 x 0.50
21.	738-05082	Shoulder Spacer, .970 x .190
22.	942-05056A	Blade, Cut, 18.67" 2-In-1, Cub
23.	747-05608	Deck Spring Rod

Ref.	Part Number	Description
24.	748-05037A	Shoulder Spacer
25.	750-06184	Spacer, .385 ID x 1.75 OD x .585
26.	954-05025	Belt, V-Type, B Sec x 139
27.	756-05034	Pulley, Idler, 4.50" Dia.
28.	783-08309A	Pivot Idler bracket
29.	783-08389	Pulley Cap
30.	783-08404A	Bracket, Lift, Stop
31.	714-05005	Bow-Tie Cotter Pin
32.	921-04041	Coupler, Water
33.	731-07487	Deck Wash Nozzle
34.	734-04155	Wheel, Deck, 5.0 Dia. Ball
35.	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
36.	631-05168A	Chute Deflector Assembly
37.	732-05261	Spring, Torsion, .440 ID x 1.75
38.	747-06290A	Hinge Pin
39.	783-08504A	Bracket, Chute, 42"
40.	710-0751	Hex Cap Screw, 1/4-20 x .62
41.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
42.	756-05038	Pulley, Deck, 4.50 Dia.
43.	738-1186A	Shaft, Spindle, 6.11
44.	941-0919B	Bearing, Ball, .787id x 1.85 Od x .551
45.	750-04936	Spacer, .792 x 1.060 x 1.860
46.	750-06152	Spacer, .792 x 1.060 x 1.782

Hydrostatic Transmission (Tuff-Torq 618-06972)



Hydrostatic Transmission (Tuff-Torq 618-06972)

Ref.	Part Number	Description
1	918-06972	K46DM Transaxle
2	TT-1A646098030	Kit, Housing
3	TT-1A646084181	Lower Case
7	TT-168T2024250	Vent Valve
8	TT-19216324360	Magnet
10	TT-1A646099950	Pump Shaft/Bearing Kit
11	TT-19215427281	Spring 25
12	TT-1A646029510	Bypass Shaft A
13	TT-1A632029520	Bypass Lever
14	TT-22242000100	Snap Ring 10
15	TT-168T2036300	Sealing Cap 30
16	TT-22252000350	Snap Ring C 35
19	TT-24311240100	O-Ring 1A P10A
20	TT-24421153507	Seal TC 153507
21	TT-26476080552	Tapping Screw 8 x 55
22	TT-26476080302	Tapping Screw 8 x 30
24	TT-1A646099070	Kit, Center Case
25	TT-19216824760	Pin 3 x 9.8
26	TT-168T2025220	Filter 105
27	TT-168T2099990	Bolt 10 x 75
28	TT-1A646024800	IDS Valve 1.2
29	TT-1A646024761	IDS Spring
30	TT-1A646024790	IDS Filter 300
31	TT-168T2025090	Kit, Cylinder Block (Pump)
32	TT-1A646025200	Spring
33	TT-1A646025251	Pump Shaft
34	TT-22272000120	E-Ring 12
35	TT-1A646034770	Bearing 6202
36	TT-19216824210	Motor Housing
37	TT-1A646034750	Thrust Bearing 51106
38	TT-168T2025080	Kit, Cylinder Block
39	TT-19216825230	Washer 12 x 24 x 1
40	TT-1A646025271	Motor Shaft
41	TT-19215425310	Snap Ring S15
42	TT-1A646025400	Brake Disc/Motor Gear
43	TT-1A646034760	Bearing 6202
44	TT-187T0027060	Thrust, Plastic
45	TT-168T2084570	Swash Plate Clamp
46	TT-19216399000	Kit, Thrust Bearing (Pump)

Ref.	Part Number	Description
47	TT-1A646029010	Magnet Holder
49	TT-1A646029911	Control Shaft
50	TT-168T2029920	Fulcrum
51	TT-168T2029800	Torsion Spring, Standard
52	TT-1A646029740	Control Lever
53	TT-1A646029400	Control Lever F
54	TT-168T2029360	Jerky Plate
55	TT-22137120000	Washer 12
56	TT-1A646029940	Cotter Pin 1/8" x 3/4"
57	TT-22351060036	Spring Pin 6 x 36
58	TT-22351060040	Roll Pin 6 x 40
59	TT-24311000140	O-Ring P14
60	TT-26776120002	Nut 12
61	TT-1A646031570	Diff Gear Kit
62	TT-1A646033520	Final Gear (54T)
63	TT-1A646033250	Final Pinion Collar
64	TT-1A646033410	Reduction Shaft
65	TT-19216833420	Washer 12 x 32 x 3.2
66	TT-1A646033450	Reduction Gear (37T)
67	TT-168T2033540	Final Pinion Gear (10T)
68	TT-1A646034370	Axle Shaft, Left
69	TT-1A646034380	Axle Shaft, Right
70	TT-19216334261	Thrust Washer
71	TT-19216834270	Ring 17
72	TT-19216334280	Seal 19 x 32 x 8
73	TT-19216834350	Bushing 19 x 25
74	TT-168T2034240	Bushing 19.05
75	TT-1A646036121	Brake Shoe
76	TT-1A646036160	Brake Lever
77	TT-1A646036171	Brake Shaft
78	TT-168T2036180	Brake Return Spring
79	TT-1A646036200	Brake Actuator
80	TT-22351050032	Spring Pin 5 x 32
81	TT-24311000120	O-Ring 1A P12
82	TT-22351040016	Spring Pin 4 x 16
83	TT-1A646025300	Spline Collar
84	TT-1A646025760	Pulley B
85	TT-1A646083070	Fan, Black
86	TT-1A646083060	Wave Washer


Continued on next page

Hydrostatic Transmission (Tuff-Torq 618-06972)

Ref.	Part Number	Description
87	TT-19215489090	Snap Ring
90	TT-22351030020	Spring Pin 3.0A x 20
91	TT-1A646024440	Oil Seal 16 x 22 x .03
95	TT-22351030016	Spring Pin 3.0A x 16
96	TT-22351035040	Roll Pin 3.5 x 40
99	N/A	Sealant
200	TT-1A646099140	Kit, Seal Incl. 7, 15, 19, 20, 26, 30, 59, 72, 81, 91 & 99
201	TT-1A646099600	Repair Kit, Incl. 24, 31, 38 & 200

This page left intentionally blank.

Hydrostatic Transmission (Tuff-Torq 618-06974)



Hydrostatic Transmission (Tuff-Torq 618-06974)

Ref.	Part Number	Description
1	918-06974	K58G Transaxle
2	TT-187Q0024100	Kit, Housing
3	TT-187Q0024160	Lower Case
7	TT-168T2024250	Vent Valve
8	TT-19216324360	Magnet
11	TT-19215427281	Spring 25
12	TT-1A646029510	Bypass Shaft A
13	TT-1A632029520	Bypass Lever
14	TT-22242000100	Snap Ring 10
15	TT-168T2036300	Sealing Cap 30
16	TT-22252000350	Snap Ring C 35
19	TT-24311240100	O-Ring 1A P10A
20	TT-24421153507	Seal TC 153507
21	TT-26476080552	Tapping Screw 8 x 55
22	TT-26476080302	Tapping Screw 8 x 30
24	TT-1A646099220	Kit, Center Case
25	TT-19216824760	Pin 3 x 9.8
26	TT-187Q0024950	Filter
27	TT-168T2099990	Bolt 10 x 75
28	TT-1A646024800	IDS Valve 1.2
29	TT-1A646024761	IDS Spring
30	TT-1A646024790	IDS Filter 300
31	TT-168T2025090	Kit, Cylinder Block (Pump)
32	TT-1A646025200	Spring
33	TT-1A646088840	Pump Shaft
34	TT-22272000120	E-Ring 12
35	TT-24101062020	Bearing 6202C3
36	TT-187Q0024810	Motor Housing
37	TT-187Q0099760	Thrust Ball Bearing
38	TT-168T2025080	Kit, Cylinder Block
39	TT-19216825230	Washer 12 x 24 x 1
40	TT-1A646025271	Motor Shaft
41	TT-19215425310	Snap Ring S15
42	TT-187Q0099400	Motor Gear
43	TT-187Q0089300	Bearing 6202
44	TT-187T0027060	Thrust, Plastic
45	TT-168T2084530	Swash Plate Clamp
46	TT-19216399000	Kit, Thrust Bearing (Pump)
47	TT-1A646029010	Magnet Holder

Ref.	Part Number	Description
49	TT-1A646029911	Control Shaft
50	TT-168T2029920	Fulcrum
51	TT-168T2029800	Torsion Spring, Standard
52	TT-168T2029740	Control Arm A
53	TT-1A646029400	Control Lever F
54	TT-168T2029360	Jerky Plate
55	TT-22137120000	Washer 12
56	TT-1A646029940	Cotter Pin 1/8" x 3/4"
57	TT-22351060036	Spring Pin 6 x 36
58	TT-22351060040	Roll Pin 6 x 40
59	TT-24311000140	O-Ring P14
60	TT-26776120002	Nut 12
61	TT-187Q0031500	Diff Gear Kit
62	TT-187Q0033520	Final Gear
63	TT-187Q0033250	Final Collar
64	TT-187Q0033410	Reduction Shaft
65	TT-19216833420	Washer 12 x 32 x 3.2
66	TT-187Q0033451	Reduction Gear
67	TT-187Q0033530	Final Pinion
68	TT-187Q0034170	Axle Shaft, Left
69	TT-187Q0034180	Axle Shaft, Right
70	TT-1A632034290	Thrust Washer
71	TT-19216734160	Ring 23
72	TT-1A632034370	Seal 25.4 x 42 x 8
73	TT-187Q0034350	Bushing 25.4
74	TT-19215434240	Bushing 25.4
75	TT-1A646036121	Brake Shoe
76	TT-1A646036160	Brake Arm
77	TT-1A646036171	Brake Shaft
78	TT-168T2036180	Brake Return Spring
79	TT-1A646036200	Brake Actuator
80	TT-22351050032	Spring Pin 5 x 32
81	TT-24311000120	O-Ring 1A P12
82	TT-22351040016	Spring Pin
83	TT-187Q0033100	Support Bushing
84	TT-1A646025760	Pulley B
85	TT-187Q0083110	Fan
86	TT-1A646083060	Wave Washer
87	TT-19215489090	Snap Ring


Continued on next page

Hydrostatic Transmission (Tuff-Torq 618-06974)

Ref.	Part Number	Description
88	TT-1A646025300	Spline Collar
90	TT-22351030020	Spring Pin 3.0A x 20
91	TT-1A646024440	Oil Seal 16 x 22 x .03
95	TT-22351030016	Spring Pin 3.0A x 16
96	TT-1A646088410	Pin 2.5 x 9.8
97	TT-1A646088450	Charge Spring
99	N/A	Sealant
100	TT-187Q0099080	Charge Pump Kit
103	TT-22351030018	Pin 3.0 x 18
200	TT-187Q0099200	Kit, Seal Incl. 7, 15, 19, 20, 26, 59, 72, 81, 91 & 99
201	TT-187Q0099060	Repair Kit, Incl. 24, 31, 38 & 200

This page left intentionally blank.

Hydrostatic Transmission (Tuff-Torq 618-07082)



1	K46DV Transmission
200	K46DV Seal Kit Kit Includes #7 (2) #59 #15 (2) #72 (2) #19 (2) #81 #20 #91 #26 #99 #30
201	K46DV Repair Kit Kit Includes #24 #38 #31 #200 - Seal Kit
205	K46DV Case Kit Kit Includes #2 #3

Hydrostatic Transmission (Tuff-Torq 618-07082)

Ref.	Part Number	Description
1	918-07082	K46DV Transaxle
2	N/A	Kit, Housing
3	N/A	Lower Case
7	TT-168T2024250	Vent Valve
8	TT-19216324360	Magnet
10	TT-1A646099950	Pump Shaft/Bearing Kit
11	TT-19215427281	Spring 25
12	TT-1A646029510	Bypass Shaft A
13	TT-1A632029520	Bypass Lever
14	TT-22242000100	Snap Ring 10
15	TT-168T2036300	Sealing Cap 30
16	TT-22252000350	Snap Ring C 35
19	TT-24311240100	O-Ring 1A P10A
20	TT-24421153507	Seal TC 153507
21	TT-26476080552	Tapping Screw 8 x 55
22	TT-26476080302	Tapping Screw 8 x 30
24	TT-1A646099070	Kit, Center Case
25	TT-19216824760	Pin 3 x 9.8
26	TT-168T2025220	Filter 105
27	TT-168T2099990	Bolt 10 x 75
28	TT-1A646024800	IDS Valve 1.2
29	TT-1A646024761	IDS Spring
30	TT-1A646024790	IDS Filter 300
31	TT-168T2025090	Kit, Cylinder Block (Pump)
32	TT-1A646025200	Spring
33	TT-1A646025251	Pump Shaft
34	TT-22272000120	E-Ring 12
35	TT-1A646034770	Bearing 6202
36	TT-19216824210	Motor Housing
37	TT-1A646034750	Thrust Bearing 51106
38	TT-168T2025080	Kit, Cylinder Block
39	TT-19216825230	Washer 12 x 24 x 1
40	TT-1A646025271	Motor Shaft
41	TT-19215425310	Snap Ring S15
42	TT-1A646025400	Brake Disc/Motor Gear
43	TT-1A646034760	Bearing 6202
44	TT-187T0027060	Thrust, Plastic
45	TT-168T2084570	Swash Plate Clamp
46	TT-19216399000	Kit, Thrust Bearing (Pump)


Ref.	Part Number	Description
47	TT-1A646029010	Magnet Holder
49	TT-1A646029911	Control Shaft
50	TT-168T2029920	Fulcrum
51	TT-168T2029800	Torsion Spring, Standard
52	TT-1A646029740	Control Lever
53	TT-1A646029400	Control Lever F
54	TT-168T2029360	Jerky Plate
55	TT-22137120000	Washer 12
56	TT-1A646029940	Cotter Pin 1/8" x 3/4"
57	TT-22351060036	Spring Pin 6 x 36
58	TT-22351060040	Roll Pin 6 x 40
59	TT-24311000140	O-Ring P14
60	TT-26776120002	Nut 12
62	TT-1A646031700	ETC Diff Comp
63	TT-1A646033250	Final Pinion Collar
64	TT-1A646033410	Reduction Shaft
65	TT-19216833420	Washer 12 x 32 x 3.2
66	TT-1A646033450	Reduction Gear (37T)
67	TT-168T2033540	Final Pinion Gear (10T)
68	TT-1A646034370	Axle Shaft, Left
69	TT-1A646034380	Axle Shaft, Right
70	TT-19216334261	Thrust Washer
71	TT-19216834270	Ring 17
72	TT-19216334280	Seal 19 x 32 x 8
73	TT-19216834350	Bushing 19 x 25
74	TT-168T2034240	Bushing 19.05
75	TT-1A646036121	Brake Shoe
76	TT-1A646036160	Brake Lever
77	TT-1A646036171	Brake Shaft
78	TT-168T2036180	Brake Return Spring
79	TT-1A646036200	Brake Actuator
80	TT-22351050032	Spring Pin 5 x 32
81	TT-24311000120	O-Ring 1A P12
82	TT-22351040016	Spring Pin 4 x 16
83	TT-1A646025300	Spline Collar
84	TT-1A646025760	Pulley B
85	TT-1A646083070	Fan, Black
86	TT-1A646083060	Wave Washer
87	TT-19215489090	Snap Ring

Continued on next page

Hydrostatic Transmission (Tuff-Torq 618-07082)

Ref.	Part Number	Description
90	TT-22351030020	Spring Pin 3.0A x 20
91	TT-1A646024440	Oil Seal 16 x 22 x .03
95	TT-22351030016	Spring Pin 3.0A x 16
96	TT-22351035040	Roll Pin 3.5 x 40
99	N/A	Sealant
200	TT-1A646099140	Kit, Seal Incl. 7, 15, 19, 20, 26, 30, 59, 72, 81, 91 & 99
201	TT-1A646099600	Repair Kit, Incl. 24, 31, 38 & 200
205	TT-1A646098030	Housing Kit


Engine Accessories (Kawasaki Twin)



Ref.	Part Number	Description
1.	983-05142	Shield Ass'y, Muffler
2.	710-04683B	Screw, Self-tapping, 3/8-16, 1.0
3.	710-06133	Screw, M6-1 x .625
4.	710-06256	Screw, Self-tapping, M8-1.25, .750
5.	726-0205	Clamp, Hose, .490 Dia.
6.	751-14857	Drain, Oil
7.	751-10349	Hose, Fuel, Low Permeation, 1/4
8.	751-14503A	Muffler, Kawasaki
9.	751-14535	Exhaust Pipe, LH (603 cc)
—	751-14481	Exhaust Pipe, LH (726 cc)
10.	751-14536	Exhaust Pipe, RH (603 cc)
—	751-14482	Exhaust Pipe, RH (726 cc)
11	731-10746 †	Push Mount Wire Clip, .750

† If Equipped

Engine Accessories (Kohler Twin)



Ref.	Part Number	Description
1.	983-05142	Shield Ass'y, Muffler
2.	710-04683C	Screw, Self-tapping, 3/8-16, 1.0
3.	710-06133	Screw, M6-1 x .625
4.	710-06256	Screw, Self-tapping, M8-1.25, .750
5.	710-1314A	Screw, Sockt Head, 5/16-18, .750
6.	726-0205	Clamp, Hose, .490 Dia.
7.	731-10746	Push Mount Wire Clip, .750
8.	783-08814	Muffler Shield
9.	751-10349-16	Hose, Fuel, Low Permeation, 1/4
10.	751-14478	Exhaust Pipe, LH
11.	751-14479	Exhaust Pipe, RH
12.	751-14503A	Muffler, Kohler
13.	751-14836	Drain, Oil

GX Labels

777D16533



777D16298



777X47146



777D20297



777D19858




777D19857




777S35416




777I25196




777I25270




777S35375



777S35376




777X47816






Electrical Schematic (Elec. PT0)




This page left intentionally blank.

[illegible]



Ref.	Part Number	Description
16146	KM-16146-0707	Cover Assembly
16146A	KM-16146-0708	Cover Assembly
21080	KM-21080-0002	Armature
21163	KM-21163-0728	Electric Starter
27012	KM-27012-7008	Hook
32085	KM-32085-0708	Stopper
59051	KM-59051-0719	Gear-Spur
92026	KM-92026-0720	Spacer
92093	KM-92093-0596	Seal
92145	KM-92145-0851	Spring
92154	KM-92154-0804	Bolt
92210	KM-92210-0741	Nut
92210A	KM-92210-0818	Nut
130	KM-130AA0830	Flanged Bolt, 8 X 30


E0110-A716A



Kawasaki FR600V-AS06 Cylinder/Crankcase


Ref.	Part Number	Description
11004	KM-11004-7027	Head Gasket
11008	KM-11008-7050	Complete Cylinder Head, #1
11008A	KM-11008-7051	Complete Cylinder Head, #2
11022	KM-11022-7034	Rocker Case, #1
11022A	KM-11022-7035	Rocker Case, #2
11061	KM-11061-7083	Rocker Case Gasket
11061A	KM-11061-7094	Breather Gasket
13272	KM-13272-7004	Breather Plate
14091	KM-14091-7064	Breather Cover
16126	KM-16126-7020	Breather Valve
27012	KM-27012-0721	Lift Hook
32154	KM-32154-7019	Pipe
32155	KM-32155-7003	Breather Pipe
49015	KM-49015-7110	Crankcase Cover
49120	KM-49120-7145	Complete Crankcase
59071	KM-59071-7025	Joint
92004	KM-92004-7024	Stud, 8 x 30
92043	KM-92043-1263	Pin
92049	KM-92049-7001	Oil Seal, RVC2, 6 X 11 X 10.2
92049A	KM-92049-7019	Oil Seal, So 8 X 14 X 5 HS
92049B	KM-92049-7010	Oil Seal, Sd 35 X 48 X 8 R HS
92049C	KM-92049-7028	Oil Seal, 38 X 62 X 8 MTCLV
92066	KM-92066-7023	Plug
92066A	KM-92066-0762	Plug
92153	KM-92153-7043	Bolt, 6 X 12
92153A	KM-92153-7054	Bolt, 8 X 50
130	KM-130CA0870	Flanged Bolt, 8 X 70
214	KM-214AA0408	Pan Screw +-, 4 X 8
670	KM-670B2011	O-Ring, 11mm

Kawasaki FR600V-AS06 Piston/Crankshaft



Ref.	Part Number	Description
13001	KM-13001-7031	Engine Piston
13002	KM-13002-7001	Piston Pin
13008	KM-13008-7006	Piston Ring Set
13025	KM-13025-7010	Piston Ring Set L, 0.5
13029	KM-13029-7011	Engine Piston L, 0.5
13031	KM-13031-7097	Complete Crankshaft
13251	KM-13251-7021	Connecting Rod Assembly
92033	KM-92033-7002	Snap Ring
92151	KM-92151-7017	Bolt, 6 X 35


Kawasaki FR600V-AS06 Lubrication Equipment



Ref.	Part Number	Description
13272	KM-13272-7011	Rotor Plate
14075	KM-14075-7013	Oil Gauge Cap Assembly
16154	KM-16154-7010	Outer Rotor Pump
16154A	KM-16154-7011	Inner Rotor Pump
49065	KM-49065-7006	Oil Filter
49065A	KM-49065-7007	Oil Filter
49116	KM-49116-7001	Valve Assembly
59071	KM-59071-7008	Joint
59231	KM-59231-0712	Filler

Ref.	Part Number	Description
92055	KM-92055-7002	O-Ring, 6mm
92066	KM-92066-7007	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7008	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12
92210	KM-92210-7012	Nut, M22
555	KM-555A0420	Spring Pin, 4 X 20
670	KM-670D2016	O-Ring, 16mm


E0130-A197A



Kawasaki FR600V-AS06 Valve & Camshaft


Ref.	Part Number	Description
11055	KM-11055-7009	Bracket
12004	KM-12004-7009	Intake Valve
12005	KM-12005-0735	Exhaust Valve
12009	KM-12009-7001	Valve Spring Retainer
12011	KM-12011-2056	Collet
12016	KM-12016-2066	Rocker Arm
12032	KM-12032-7001	Tappet
13070	KM-13070-7017	Governor Guide
13116	KM-13116-7008	Push Rod
13271	KM-13271-7007	Plate
13271A	KM-13271-7021	Governor Plate
42036	KM-42036-7021	Sleeve
49078	KM-49078-7002	Engine Valve Spring, IN
49118	KM-49118-7027	Complete Camshaft
92033	KM-92033-0727	Snap Ring
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring
92152	KM-92152-1689	Collar
92153	KM-92153-7100	Bolt, 6 X 29.5
92200	KM-92200-2151	Washer, 8.1 X 18 X 0.5
92200A	KM-92200-7009	Washer, 16 X 42 X 0.91
92200B	KM-92200-7048	Washer, 16.3 X 30 X 2.28
130	KM-130AA0814	Flanged Bolt, 8 X 14
312	KM-312AA0600	Hex Nut, 6mm

Kawasaki FR600V-AS06 Cooling Equipment



Ref.	Part Number	Description
14037	KM-14037-70089H	Screen
49089	KM-49089-7091	Engine Shroud
49089A	KM-49089-7092	Engine Shroud
59041	KM-59041-7020	Fan
59066	KM-59066-7067	Fan Housing
92009	KM-92009-2303	Screw
92153	KM-92153-7007	Bolt


Kawasaki FR600V-AS06 Electric Equipment



Ref.	Part Number	Description
21066	KM-21066-7017	Voltage Regulator
21171	KM-21171-0711	Ignition Coil Assembly
21193	KM-99999-0400	Flywheel Assembly
26011	KM-26011-7025	Lead Wire, L = 95
26031	KM-26031-7040	Harness
26031A	KM-26031-1625	Harness
26031B	KM-26031-7047	Harness
59031	KM-59031-7017	Charging Coil
92009	KM-92009-2303	Screw

Ref.	Part Number	Description
92066	KM-92066-0762	Plug
92070	KM-BPR4ES	Spark Plug, BPR4ES (NGK)
92072	KM-92072-7003	Band
92154	KM-92154-7003	Bolt, 12 X 30
92172	KM-92172-7018	Screw, 5 X 20
92200	KM-92200-7002	Washer
130	KM-130AA0620	Flanged Bolt, 6 X 20
510	KM-510A5100	Woodruff Key


Kawasaki FR600V-AS06 Control Equipment



Ref.	Part Number	Description
13107	KM-13107-7049	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-7025	Link
39129	KM-39129-7033	Governor Spring
49103	KM-49103-7017	Governor Arm
49113	KM-49113-0716	Complete Control Panel
92009	KM-92009-2303	Screw
92145	KM-92145-2180	Spring
92145A	KM-92145-7057	Spring

Ref.	Part Number	Description
92150	KM-92150-2182	Bolt, 5 X 18
92151	KM-92151-7014	Bolt, 5 x 30
92153	KM-92153-7033	Bolt, 6 X 35
92170	KM-92170-7001	Clamp
214	KM-214AA0408	Pan Screw +- , 4 X 8
311	KM-311AA0600	Hex Nut, 6mm
312	KM-312AA0500	Hex Nut, 5mm
411	KM-411AA0600	Plain Washer, 6mm


Kawasaki FR600V-AS06 Carburetor



Ref.	Part Number	Description
11061	KM-11061-7009	Chamber Gasket
11061A	KM-11061-7010	Screw Gasket
11061B	KM-11061-7103	Gasket
13107	KM-13107-7018	Shaft
15004	KM-15004-0827	Carburetor Assembly
16014	KM-16014-7011	Pilot Air Screw
16020	KM-16020-7003	Float Chamber
16025	KM-16025-7006	Throttle Valve
16030	KM-16030-7003	Float Valve
16031	KM-16031-7002	Float
16041	KM-16041-7018	Throttle Carburetor Shaft
16041A	KM-16041-7049	Choke Carburetor Shaft
16186	KM-16186-7001	Choke Valve Assembly
21188	KM-21188-7002	Solenoid
39076	KM-39076-7001	Limiter


Ref.	Part Number	Description
49121	KM-49121-7019	Main Nozzle
59076	KM-59076-7026	Intake Manifold
92009	KM-92009-2083	Screw
92009A	KM-92009-2349	Screw
92055	KM-92055-7026	O-Ring, 42mm
92063	KM-92063-7046	Main Jet, #100
92063A	KM-92063-7047	Main Jet, #098
92063B	KM-92063-7156	Main Jet, #102
92081	KM-92081-2234	Spring
92093	KM-92093-2100	Seal
92145	KM-92145-7015	Spring
92145A	KM-92145-0931	Spring
92153	KM-92153-7008	Bolt
92200	KM-92200-2061	Washer, 9.8 x 5.5 x 1.0

Kawasaki FR600V-AS06 Air Filter/Muffler



Ref.	Part Number	Description
11011	KM-11011-7068	Air Filter Case
11013	KM-99999-0383	Air Filter Element
11060	KM-11060-7016	Muffler Gasket
11061	KM-11061-7095	Air Cleaner Gasket
16060	KM-16060-7039	Intake Pipe
92009	KM-92009-2303	Screw
92015	KM-92015-1367	Nut
92066	KM-92066-0095	Plug
92170	KM-92170-2042	Clamp
92173	KM-92173-7003	Clamp
92173A	KM-92173-1001	Clamp
92173B	KM-92173-7009	Clamp
92192	KM-92192-7146	Tube, 12.6 X 18.6 X 118
92192A	KM-92192-7164	Air Filter Tube
92210	KM-92210-7027	Nut, M8
461	KM-461DA0800	Washer-Spring Washer, 8mm


Kawasaki FR600V-AS06 Fuel Tank/Fuel Valve



Ref.	Part Number	Description
42036	KM-42036-7015	Sleeve
49019	KM-49019-0014	Fuel Filter
49040	KM-49040-7008	Fuel Pump
92009	KM-92009-2303	Screw
92170	KM-92170-2009	Clamp
92171	KM-92171-7005	Clamp
92192	KM-92192-7148	Tube, 6.4 X 12.7 X 150
92192A	KM-92192-7172	Tube, 6.35 X 12.7 X 185
92192B	KM-92192-7184	Tube, 6.35 X 12.7 X 360

Kawasaki FR600V-AS06 Engine Labels

56070




Ref.	Part Number	Description
56070	KM-56070-7001	Warning Label

Page Left Blank Intentionally

[illegible]


E0120-A398A



Ref.	Part Number	Description
13001	KM-13001-7027	Engine Piston
13002	KM-13002-7006	Piston Pin
13008	KM-13008-7005	Piston Ring Set
13025	KM-13025-7009	Piston Ring Set L, 0.5
13029	KM-13029-7010	Engine Piston L, 0.5
13031	KM-13031-0747	Complete Crankshaft
13251	KM-13251-7025	Connecting Rod Assembly
92033	KM-92033-7016	Snap Ring
92151	KM-92151-7017	Bolt, 6 X 35


Kawasaki FR651V-AS08 Cylinder/Crankcase

E0110-A630A




Kawasaki FR651V-AS08 Cylinder/Crankcase

Ref.	Part Number	Description
11004	KM-11004-7026	Head Gasket
11008	KM-11008-7039	Complete Cylinder Head, #1
11008A	KM-11008-7040	Complete Cylinder Head, #2
11022	KM-11022-7019	Rocker Case, #1
11022A	KM-11022-7020	Rocker Case, #2
11061	KM-11061-7083	Rocker Case Gasket
11061A	KM-11061-7094	Breather Gasket
13272	KM-13272-7004	Breather Plate
14091	KM-14091-7064	Breather Cover
16126	KM-16126-7020	Breather Valve
32154	KM-32154-7019	Pipe
32155	KM-32155-7003	Breather Pipe
49015	KM-49015-7106	Crankcase Cover
49120	KM-49120-7129	Complete Crankcase
59071	KM-59071-2079	Joint
92043	KM-92043-1263	Pin
92049	KM-92049-7001	Oil Seal, RVC2, 6 X 11 X 10.2
92049A	KM-92049-7019	Oil Seal, So 8 X 14 X 5 HS
92049B	KM-92049-7010	Oil Seal, Sd 35 X 48 X 8 R HS
92049C	KM-92049-7028	Oil Seal, 38 X 62 X 8 MTCLV
92066	KM-92066-7023	Plug
92066A	KM-92066-0762	Plug
92153	KM-92153-7043	Bolt, 6 X 12
92153A	KM-92153-7054	Bolt, 8 X 50
130	KM-130AA0625	Flanged Bolt, 6 X 25
130A	KM-130CA1050	Flanged Bolt, 10 X 50
130B	KM-130CA1065	Flanged Bolt, 10 X 65
172	KM-172BA0818	Stud Bolt, 8 X 18
214	KM-214AA0408	Pan Screw +-, 4 X 8
670	KM-670B2011	O-Ring, 11mm



Ref.	Part Number	Description
11055	KM-11055-7009	Bracket
12004	KM-12004-0705	Intake Valve
12005	KM-12005-0720	Exhaust Valve
12009	KM-12009-7001	Valve Spring Retainer
12011	KM-12011-2056	Collet
12016	KM-12016-2066	Rocker Arm
12032	KM-12032-7001	Tappet
13070	KM-13070-7017	Governor Guide
13116	KM-13116-7007	Push Rod
13271	KM-13271-7007	Plate
13271A	KM-13271-7021	Governor Plate
42036	KM-42036-7010	Sleeve
49078	KM-49078-7002	Engine Valve Spring, IN
49118	KM-49118-7022	Complete Camshaft
92033	KM-92033-0727	Snap Ring
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring
92152	KM-92152-1689	Collar
92153	KM-92153-7100	Bolt, 6 X 29.5
92200	KM-92200-2151	Washer, 8.1 X 18 X 0.5
92200A	KM-92200-7009	Washer, 16 X 42 X 0.91
92200B	KM-92200-7048	Washer, 16.3 X 30 X 2.28
130	KM-130AA0814	Flanged Bolt, 8 X 14
312	KM-312AA0600	Hex Nut, 6mm


E0140-A447A



Ref.	Part Number	Description
13272	KM-13272-7011	Rotor Plate
14075	KM-14075-7013	Oil Gauge Cap Assembly
16154	KM-16154-7010	Outer Rotor Pump
16154A	KM-16154-7011	Inner Rotor Pump
49065	KM-49065-7006	Oil Filter
49065A	KM-49065-7007	Oil Filter
59231	KM-59231-0712	Filler
92066	KM-92066-7003	Plug
92066A	KM-92066-7028	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7008	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12
555	KM-555A0420	Spring Pin, 4 X 20
670	KM-670D2016	O-Ring, 16mm

Kawasaki FR651V-AS08 Cooling Equipment


E0150-A873A



Ref.	Part Number	Description
13070	KM-13070-7019	Cooling Air Guide
13272	KM-13272-7006	Fan Plate
14037	KM-14037-70089H	Screen
23062	KM-23062-7022	Complete Bracket
49089	KM-49089-7079	Engine Shroud
49089A	KM-49089-7080	Engine Shroud
59041	KM-59041-7014	Fan
59066	KM-59066-7052	Fan Housing
92009	KM-92009-2303	Screw
92026	KM-92026-7007	Spacer
92151	KM-92151-7012	Bolt, 6 X 12
92153	KM-92153-7007	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12

Kawasaki FR651V-AS08 Electric Equipment

E0160-B284A




Ref.	Part Number	Description
13272	KM-13272-7012	Plate
21066	KM-21066-7017	Voltage Regulator
21171	KM-21171-0711	Ignition Coil Assembly
21193	KM-21193-7038	Flywheel Assembly
26011	KM-26011-7025	Lead Wire, L = 95
26031	KM-26031-7040	Harness
26031A	KM-26031-7041	Harness
26031B	KM-26031-1625	Harness
59031	KM-59031-7017	Charging Coil
92009	KM-92009-2303	Screw

Ref.	Part Number	Description
92009A	KM-92009-2308	Screw
92066	KM-92066-0762	Plug
92070	KM-BPR4ES	Spark Plug, BPR4ES (NGK)
92072	KM-92072-7003	Band
92151	KM-92154-7003	Bolt, 12 X 30
92171	KM-92171-7008	Clamp
92172	KM-92172-7018	Screw, 5 X 20
92200	KM-92200-7002	Washer
130	KM-130AA0620	Flanged Bolt, 6 X 20
510	KM-510A5100	Woodruff Key

Kawasaki FR651V-AS08 Control Equipment

E0170-A652A




Ref.	Part Number	Description
13107	KM-13107-7047	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-7022	Link
39129	KM-39129-7035	Governor Spring
49103	KM-49103-7014	Governor Arm
49103A	KM-49103-7015	Governor Arm
49113	KM-49113-7050	Complete Control Panel
92145	KM-92145-7057	Spring
92145A	KM-92145-7058	Spring
92150	KM-92150-2182	Bolt, 5 X 18

Ref.	Part Number	Description
92153	KM-92153-0009	Bolt, 6 X 12
92153A	KM-92153-7033	Bolt, 6 X 35
92153B	KM-92153-7043	Bolt, 6 X 12
92170	KM-92170-7001	Clamp
92172	KM-92172-7035	Screw, 5 X 30
214	KM-214AA0408	Pan Screw +-, 4 X 8
311	KM-311AA0600	Hex Nut, 6mm
312	KM-312AA0500	Hex Nut, 5mm
411	KM-411AA0600	Plain Washer, 6mm

Kawasaki FR651V-AS08 Carburetor

E0180-A778A




Ref.	Part Number	Description
11061	KM-11061-7009	Chamber Gasket
11061A	KM-11061-7010	Screw Gasket
11061B	KM-11061-7093	Manifold Gasket
11061C	KM-11061-7087	Insulator Gasket
11061D	KM-11061-7088	Insulator/Manifold Gasket
13107	KM-13107-7018	Shaft
15004	KM-15004-0828	Carburetor Assembly
16014	KM-16014-7010	Pilot Air Screw
16020	KM-16020-7003	Float Chamber
16025	KM-16025-7017	Throttle Valve
16030	KM-16030-7003	Float Valve
16031	KM-16031-7002	Float
16041	KM-16041-0007	Choke Carburetor Shaft
16041A	KM-16041-7051	Throttle Carburetor Shaft
16073	KM-16073-7013	Insulator
16186	KM-16186-7006	Choke Valve Assembly

Ref.	Part Number	Description
21188	KM-21188-7002	Solenoid
39074	KM-39074-7001	Throttle Lever Assembly
49121	KM-49121-7018	Main Nozzle
59076	KM-59076-7019	Intake Manifold
92009	KM-92009-2083	Screw
92009A	KM-92009-2349	Screw
92009B	KM-92009-2402	Screw
92063	KM-92063-7141	Main Jet, #122
92063A	KM-92063-7142	Main Jet, #124
92063B	KM-92063-7149	Main Jet, #120
92081	KM-92081-2234	Spring
92093	KM-92093-2100	Seal
92093A	KM-92093-7003	Seal
92145	KM-92145-2122	Spring
130	KM-130AA0630	Flanged Bolt, 6 X 30
172	KM-172BA06115	Stud Bolt, 6 X 115

Kawasaki FR651V-AS08 Air Filter/Muffler


E0190-B094A



Ref.	Part Number	Description
11011	KM-11011-7065	Air Filter Case
11013	KM-99999-0384	Air Filter Element
11060	KM-11060-7016	Muffler Gasket
11061	KM-11061-7086	Carburetor/Intake Pipe Gasket
11065	KM-11065-7037	Cap
16060	KM-16060-7038	Intake Pipe
42036	KM-42036-7022	Breather Sleeve
92009	KM-92009-2303	Screw
92015	KM-92015-1367	Nut
92171	KM-92173-1001	Clamp
92173	KM-92173-7003	Clamp
92192	KM-92192-7146	Tube, 12.6 x 18.6 x 118
92192A	KM-99999-7082	Air Filter Tube
92210	KM-92210-7027	Nut, M8
461	KM-461DA0800	Spring Washer, 8mm


Kawasaki FR651V-AS08 Fuel Tank/Fuel Valve

E0200-A679A




Ref.	Part Number	Description
42036	KM-42036-7015	Sleeve
49019	KM-49019-0014	Fuel Filter
49040	KM-49040-7008	Fuel Pump
92009	KM-92009-2303	Screw
92170	KM-92170-2009	Clamp
92171	KM-92171-7008	Clamp
92192	KM-92192-7172	Tube, 6.35 X 12.7 X 185
92192A	KM-92192-7148	Tube, 6.4 X 12.7 X 150
92192B	KM-92192-7188	Tube, 6.35 X 12.7 X 390

E0210-A457A



Ref.	Part Number	Description
16146	KM-16146-7027	Cover Assembly
16146A	KM-16146-7028	Cover Assembly
21080	KM-21080-7006	Armature
21163	KM-21163-0727	Electric Starter
27012	KM-27012-7004	Hook
32085	KM-99999-0309	Stopper
59051	KM-59051-7034	Spur Gear
92093	KM-92093-7007	Seal
92145	KM-92145-7060	Spring
92154	KM-92154-7001	Bolt
92210	KM-92210-7017	Nut
92210A	KM-99999-0309	Nut
130	KM-130AA0840	Flanged Bolt, 8 x 40


F0290-B469A



Ref.	Part Number	Description
56033	KM-56033-7001	Manual Label
56070	KM-56070-7001	Warning Label


Page Left Blank Intentionally

Kawasaki FR691V-AS17 Valve/Camshaft




Ref.	Part Number	Description
11055	KM-11055-7009	Bracket
12004	KM-12004-0705	Intake Valve
12005	KM-12005-0720	Exhaust Valve
12009	KM-12009-7001	Valvespring Retainer
12011	KM-12011-2056	Collet
12016	KM-12016-2066	Rocker Arm
12032	KM-12032-7001	Tappet
13070	KM-13070-7017	Governor Guide
13116	KM-13116-7007	Push Rod
13271	KM-13271-7007	Plate
13271A	KM-13271-7021	Governor Plate
42036	KM-42036-7021	Sleeve

Ref.	Part Number	Description
49078	KM-49078-7002	Engine Valve Spring, IN
49118	KM-49118-7022	Complete Camshaft
92033	KM-92033-0727	Snap Ring
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring
92152	KM-92152-1689	Collar
92153	KM-92153-7100	Bolt, 6 X 29.5
92200	KM-92200-2151	Washer, 8.1 X 18 X 0.5
92200A	KM-92200-7009	Washer, 16 X 42 X 0.91
92200B	KM-92200-7048	Washer, 16.3 X 30 X 2.28
130	KM-130AA0814	Flanged Bolt, 8 X 14
312	KM-312AA0600	Hex Nut, 6mm



Ref.	Part Number	Description
13001	KM-13001-7027	Engine Piston
13002	KM-13002-0704	Piston Pin
13008	KM-13008-7005	Piston Ring Set
13025	KM-13025-7009	Piston Ring Set, L ,0.5
13029	KM-13029-7010	Engine Piston, L, 0.5
13031	KM-13031-0747	Complete Crankshaft
13031A	KM-13031-0747	Complete Crankshaft
13251	KM-13251-7025	Connecting Rod Assembly
92033	KM-92033-7018	Snap Ring
92151	KM-92151-7017	Bolt, 6 X 35


Kawasaki FR691V-AS17 Cylinder/Crankcase



Kawasaki FR691V-AS17 Cylinder/Crankcase


Ref.	Part Number	Description
11004	KM-11004-7026	Head Gasket
11008	KM-11008-7039	Complete Cylinder Head, #1
11008A	KM-11008-7040	Complete Cylinder Head, #2
11022	KM-11022-0710	Rocker Case, #1
11022A	KM-11022-7020	Rocker Case, #2
11061	KM-11061-7083	Rocker Case Gasket
11061A	KM-11061-7094	Breather Gasket
13272	KM-13272-1374	Breather Plate
14091	KM-14091-7064	Breather Cover
16126	KM-16126-7020	Breather Valve
32154	KM-32154-7019	Pipe
32155	KM-32155-7003	Breather Pipe
49015	KM-49015-7106	Crankcase Cover
49120	KM-49120-0733	Complete Crankcase
59071	KM-59071-7025	Joint
92004	KM-92004-7024	Stud, 8x30
92043	KM-92043-1263	Pin
92049	KM-92049-7001	Oil Seal, RVC 26 x 11 x 10.2
92049A	KM-92049-7019	Oil Seal, SO 8 x 14 x 5 HS
92049B	KM-92049-7010	Oil Seal, SD 35 x 48 x 8 RHS
92049C	KM-92049-7019	Oil Seal, 8 x 14 x 5 HS
92049D	KM-92049-7028	Oil Seal, 38 x 62 x 8 MTCLV
92066	KM-92066-7023	Plug
92066A	KM-92066-0762	Plug
92104	KM-92104-7001	Gasket, TB1217H
92153	KM-92153-7043	Bolt, 6 x 12
92153A	KM-92153-7054	Bolt, 8 x 50
130	KM-130AA0625	Flanged Bolt, 6 x 25
130A	KM-130CA1050	Flanged Bolt, 10 x 50
130B	KM-130CA1065	Flanged Bolt, 10 x 65
214	KM-214AA0408	Pan Screw +-, 4 x 8
670	KM-670B2011	O-Ring, 11mm

Kawasaki FR691V-AS17 Cooling Equipment



Ref.	Part Number	Description
13070	KM-13070-7019	Cooling Air Guide
13272	KM-13272-7006	Fan Plate
14037	KM-14037-70089H	Screen
23062	KM-23062-7022	Complete Bracket
49089	KM-49089-7079	Engine Shroud
49089A	KM-49089-7080	Engine Shroud
59041	KM-59041-7014	Fan
59066	KM-59066-7052	Fan Housing
92009	KM-92009-2303	Screw
92026	KM-92026-7007	Spacer
92151	KM-92151-7012	Bolt, 6 X 12
92153	KM-92153-7007	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12

Kawasaki FR691V-AS17 Lubrication Equipment




Ref.	Part Number	Description
13272	KM-13272-7011	Rotor Plate
14075	KM-14075-7013	Oil Gauge Cap Assembly
16154	KM-16154-7010	Outer Pump Rotor
16154A	KM-16154-7011	Inner Pump Rotor
49065	KM-49065-7006	Oil Filter
49065A	KM-49065-7007	Oil Filter
49116	KM-49116-7001	Valve Assembly
59071	KM-59071-7008	Joint
59231	KM-59231-0712	Filler

Ref.	Part Number	Description
92055	KM-92055-7002	O-Ring, 6MM
92066	KM-92066-7007	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7008	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12
92210	KM-92210-7012	Nut, M22
555	KM-555A0420	Spring Pin, 4 X 20
670	KM-670D2016	O-Ring, 16mm

Kawasaki FR691V-AS17 Control Equipment


E0170-A652A



Ref.	Part Number	Description
13107	KM-13107-7047	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-7022	Link
39129	KM-39129-7035	Governor Spring
49103	KM-49103-7014	Governor Arm
49103A	KM-49103-7015	Governor Arm
49113	KM-49113-0727	Complete Control Panel
92145	KM-92145-7057	Spring
92145A	KM-92145-7058	Spring
92150	KM-92150-2182	Bolt, 5 X 18

Ref.	Part Number	Description
92153	KM-92153-0009	Bolt, 6 X 12
92153A	KM-92153-7033	Bolt, 6 X 35
92153B	KM-92153-7043	Bolt, 6 X 12
92170	KM-92170-7001	Clamp
92172	KM-92172-0792	Screw, 5 X 35
214	KM-214AA0408	Pan Screw +-, 4 X 8
311	KM-311AA0600	Hex Nut, 6mm
312	KM-312AA0500	Hex Nut, 5mm
411	KM-411AA0600	Plain Washer, 6mm


Kawasaki FR691V-AS17 Electric Equipment



Ref.	Part Number	Description
13272	KM-13272-7012	Plate
21066	KM-21066-7017	Voltage Regulator
21171	KM-21171-0711	Ignition Coil Assembly
21193	KM-21193-7038	Flywheel Assembly
26011	KM-26011-7025	Lead Wire, L = 95
26031	KM-26031-7040	Harness
26031A	KM-26031-7041	Harness
26031B	KM-26031-1625	Harness
59031	KM-59031-7017	Charging Coil
92009	KM-92009-2303	Screw

Ref.	Part Number	Description
92009A	KM-92009-2308	Screw
92066	KM-92066-0762	Plug
92070	KM-BPR4ES	Spark Plug
92072	KM-92072-7003	Band
92154	KM-92154-7003	Bolt, 12 X 30
92171	KM-92171-7008	Clamp
92172	KM-92172-7018	Screw, 5 X 20
92200	KM-92200-7002	Washer
130	KM-130AA0620	Flanged Bolt, 6 X 20
510	KM-510A5100	Woodruff Key


Kawasaki FR691V-AS17 Air Filter/Muffler



Ref.	Part Number	Description
11011	KM-11011-7065	Air Filter Case
11013	KM-99999-0384	Air Filter Element
11060	KM-11060-7016	Muffler Gasket
11061	KM-11061-7086	Carburetor/Pipe Intake Gasket
16060	KM-16060-7038	Intake Pipe
42036	KM-42036-7022	Breather Sleeve
92009	KM-92009-2303	Screw
92015	KM-92015-1367	Nut
92066	KM-92066-0095	Plug

Ref.	Part Number	Description
92170	KM-92170-2042	Clamp
92173	KM-92173-7003	Clamp
92173A	KM-92173-1001	Clamp
92173B	KM-92173-1001	Clamp
92192	KM-92192-7146	Tube, 12.6 X 18.6 X 118
92192A	KM-92192-7165	Air Filter Tube
92210	KM-92210-7027	Nut, M8
461	KM-461DA0800	Spring Washer, 8mm


Kawasaki FR691V-AS17 Carburetor



Ref.	Part Number	Description
11061	KM-11061-7009	Chamber Gasket
11061A	KM-11061-7010	Screw Gasket
11061B	KM-11061-7087	Insulator Gasket
11061C	KM-11061-7088	Insulator/Manifold Gasket
11061D	KM-11061-7093	Manifold Gasket
13107	KM-13107-7018	Shaft
15004	KM-15004-0829	Carburetor Assembly
16014	KM-16014-7010	Pilot Air Screw
16020	KM-16020-7003	Float Chamber
16025	KM-16025-7017	Throttle Valve
16030	KM-16030-7003	Float Valve
16031	KM-16031-7002	Float
16041	KM-16041-0007	Choke Carburetor Shaft
16041A	KM-16041-7051	Throttle Carburetor Shaft
16073	KM-16073-7013	Insulator
16186	KM-16186-7006	Choke Valve Assembly
21188	KM-21188-7002	Solenoid


Ref.	Part Number	Description
39074	KM-39074-7001	Throttle Lever Assembly
49121	KM-49121-7018	Main Nozzle
59076	KM-59076-7019	Intake Manifold
92009	KM-92009-2083	Screw
92009A	KM-92009-2349	Screw
92009B	KM-92009-2402	Screw
92063	KM-92063-7141	Main Jet, #122
92063A	KM-92063-7142	Main Jet, #124
92063B	KM-92063-7149	Main Jet, #120
92066	KM-92066-7032	Plug
92081	KM-92081-2234	Spring
92093	KM-92093-2100	Seal
92093A	KM-92093-7003	Seal
92145	KM-92145-2122	Spring
130	KM-130AA0630	Flanged Bolt, 6 X 30
172	KM-172BA06115	Stud Bolt, 6 X 115

Kawasaki FR691V-AS17 Starter



Ref.	Part Number	Description
14020	KM-14020-7002	Retainer
16146	KM-16146-7027	Cover Assembly
16146A	KM-16146-7030	Cover Assembly
21080	KM-21080-0003	Armature
21163	KM-21163-0727	Electric Starter
27012	KM-27012-7008	Hook
39108	KM-39108-0552	Spring Retainer
59051	KM-59051-7034	Spur Gear
92093	KM-92093-7007	Seal
92145	KM-92145-7060	Spring
92154	KM-92154-7001	Bolt
92210	KM-92210-7017	Nut
130	KM-130AA0840	Flanged Bolt, 8 X 40


Kawasaki FR691V-AS17 Fuel Tank/Fuel Valve



Ref.	Part Number	Description
42036	KM-42036-7015	Sleeve
49019	KM-49019-0014	Fuel Filter
49040	KM-49040-7008	Fuel Pump
92009	KM-92009-2303	Screw
92170	KM-92170-2009	Clamp
92171	KM-92171-7005	Clamp
92192	KM-92192-7148	Tube, 6.4 X 12.7 X 150
92192A	KM-92192-7172	Tube, 6.35 X 12.7 X 185
92192B	KM-92192-7188	Tube, 6.35 X 12.7 X 390

Kawasaki FR691V-AS17 Engine Labels


56033



56071




56080



Ref.	Part Number	Description
56033	KM-56033-7001	Manual Label
56071	KM-56071-0216	Warning Label
56080	KM-56080-0815	Brand Label

This image shows a single page of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.


Kawasaki FR730V-AS21 Cylinder/Crankcase



Kawasaki FR730V-AS21 Cylinder/Crankcase


Ref.	Part Number	Description
11004	KM-11004-7026	Head Gasket
11008	KM-11008-0845	Complete Cylinder Head, #2
11008A	KM-11008-0861	Complete Cylinder Head, #1
11022	KM-11022-0710	Rocker Case, #1
11022A	KM-11022-7020	Rocker Case, #2
11061	KM-11061-7083	Rocker Case Gasket
11061A	KM-11061-7094	Breather Gasket
13272	KM-13272-1374	Breather Plate
14091	KM-14091-7064	Breather Cover
16126	KM-16126-7020	Breather Valve
32154	KM-32154-7019	Pipe
32155	KM-32155-7003	Breather Pipe
49015	KM-49015-0023	Crankcase Cover
49120	KM-49120-0858	Complete Crankcase
59071	KM-59071-7025	Joint
92004	KM-92004-7024	Stud, 8 x 30
92043	KM-92043-1263	Pin
92049	KM-92049-7001	Oil Seal, RVC 26 x 11 x 10.2
92049A	KM-92049-7010	Oil Seal, SD 35 x 48 x 8 R HS
92049B	KM-92049-7019	Oil Seal, SO 8 x 14 x 5 HS
92049C	KM-92049-7028	Oil Seal, 38 x 62 x 8MTCLV
92066	KM-92066-7023	Plug
92066A	KM-92066-0762	Plug
92066B	KM-92066-2223	Plug
92104	KM-92104-0007	Liquid Gasket, TB1217H
92153	KM-92153-7043	Bolt, 6 x 12
92153A	KM-92153-7054	Bolt, 8 x 50
92172	KM-92172-0870	Screw, 4 x 8
130	KM-130BA0625	Flanged Bolt, 6 x 25
130A	KM-130CA1050	Flange Bolt, 10 x 50
130B	KM-130CA1065	Flange Bolt, 10 x 65
670	KM-670B2011	O-Ring, 11MM

Kawasaki FR730V-AS21 Piston/Crankshaft




Ref.	Part Number	Description
13001	KM-13001-7027	Engine Piston
13002	KM-13002-0704	Piston Pin
13008	KM-13008-7005	Piston Ring Set
13025	KM-13025-7009	Piston Ring Set L, 0.5
13029	KM-13029-7010	Engine Piston L, 0.5
13031	KM-13031-0747	Complete Crankshaft
13251	KM-13251-0719	Connecting Rod Assembly
92033	KM-92033-0755	Snap Ring
92151	KM-92151-7017	Bolt, 6 x 35

Kawasaki FR730V-AS21 Lubrication Equipment



Ref.	Part Number	Description
13272	KM-13272-7011	Rotor Plate
14075	KM-14075-0037	Oil Gauge Cap Assembly
16154	KM-16154-7010	Outer Rotor Pump
16154A	KM-16154-7011	Inner Rotor Pump
49065	KM-49065-7006	Oil Filter
49065A	KM-49065-7007	Oil Filter
59231	KM-59231-0712	Filler
92066	KM-92066-0774	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-1658	Spring
92145A	KM-92145-7002	Spring
92153	KM-92153-7008	Bolt
92153A	KM-92153-7043	Bolt, 6 x 12
555	KM-555A0420	Spring Pin, 4 x 20
670	KM-670D2016	O-Ring, 16mm


Kawasaki FR730V-AS21 Valve & Camshaft



Kawasaki FR730V-AS21 Valve & Camshaft


Ref.	Part Number	Description
11055	KM-11055-7009	Bracket
12004	KM-12004-0705	Intake Valve
12005	KM-12005-0720	Exhaust Valve
12009	KM-12009-7001	Valve Spring Retainer
12011	KM-12011-2056	Collet
12016	KM-12016-2066	Rocker Arm
12032	KM-12032-7001	Tappet
13070	KM-13070-7017	Governor Guide
13116	KM-13116-7007	Push Rod
13271	KM-13271-7007	Plate
13271A	KM-13271-7021	Governor Plate
42036	KM-42036-7021	Sleeve
49078	KM-49078-7002	Engine Valve Spring, IN
49118	KM-49118-7022	Complete Camshaft
92033	KM-92033-0727	Snap Ring
92140	KM-92140-7005	Ball
92145	KM-92145-1653	Spring
92152	KM-92152-1689	Collar
92153	KM-92153-7100	Bolt, 6 x 29.5
92154	KM-92154-1267	Bolt, 8 x 18.2
92200	KM-92200-0945	Washer, 16 x 42 x 0.91
92200A	KM-92200-2151	Washer, 8.1 x 18 x 0.5
92200B	KM-92200-7048	Washer, 16.3 x 30 x 2.28
312	KM-312AA0600	Hex Nut, 6mm

Kawasaki FR730V-AS21 Cooling Equipment



Ref.	Part Number	Description
13272	KM-13272-1487	Fan Plate
14037	KM-14037-70089H	Screen
23062	KM-23062-7024	Complete Bracket
49089	KM-49089-7079	Engine Shroud
49089A	KM-49089-7080	Engine Shroud
59041	KM-59041-7014	Fan
59066	KM-59066-0014	Fan Housing
92026	KM-92026-7007	Spacer
92151	KM-92151-7012	Bolt, 6 x 12
92153	KM-92153-7007	Bolt
92153A	KM-92153-7043	Bolt, 6 x 12


Kawasaki FR730V-AS21 Electric Equipment



Ref.	Part Number	Description
13272	KM-13272-7012	Plate
21066	KM-21066-7017	Voltage Regulator
21171	KM-21171-0711	Ignition Coil Assembly
21193	KM-21193-0016	Flywheel Assembly
26011	KM-26011-7025	Lead Wire, L = 95
26031	KM-26031-1625	Harness
26031A	KM-26031-7040	Harness
26031B	KM-26031-7041	Harness
59031	KM-59031-7017	Charging Coil
92009	KM-92009-2303	Screw

Ref.	Part Number	Description
92009A	KM-92009-2308	Screw
92066	KM-92066-0762	Plug
92070	KM-BPR4ES	Spark Plug, BPR4ES (NGK)
92072	KM-92072-7003	Band
92154	KM-92154-7003	Bolt, 12 x 30
92171	KM-92171-7008	Clamp
92172	KM-92172-7018	Screw, 5 x 20
92200	KM-92200-7002	Washer
130	KM-130BA0620	Flanged Bolt, 6 x 20
510	KM-510A5100	Woodruff Key


Kawasaki FR730V-AS21 Control Equipment



Ref.	Part Number	Description
13107	KM-13107-7047	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-0033	Link
39129	KM-39129-7035	Governor Spring
49103	KM-49103-7014	Governor Arm
49103A	KM-49103-7015	Governor Arm
49113	KM-49113-0727	Complete Control Panel
92145	KM-92145-7057	Spring
92145A	KM-92145-7058	Spring
92150	KM-92150-2182	Bolt, 5 x 18

Ref.	Part Number	Description
92153	KM-92153-0009	Bolt, 6 x 12
92153A	KM-92153-7033	Bolt, 6 x 35
92153B	KM-92153-7043	Bolt, 6 x 12
92170	KM-92170-7001	Clamp
92172	KM-92172-0792	Screw, 5 x 35
92172A	KM-92172-0870	Screw, 4 x 8
311	KM-311AA0600	Hex Nut, 6mm
312	KM-312AA0500	Hex Nut, 5mm
411	KM-411AA0600	Plain Washer, 6mm


Kawasaki FR730V-AS21 Carburetor



Ref.	Part Number	Description
11061	KM-11061-7009	Chamber Gasket
11061A	KM-11061-7010	Screw Gasket
11061B	KM-11061-7087	Insulator Gasket
11061C	KM-11061-7088	Insulator/Manifold Gasket
11061D	KM-11061-7093	Manifold Gasket
13107	KM-13107-7018	Shaft
15004	KM-15004-0826	Carburetor Assembly
16014	KM-16014-7010	Pilot Air Screw
16020	KM-16020-7003	Float Chamber
16025	KM-16025-7017	Throttle Valve
16030	KM-16030-7003	Float Valve
16031	KM-16031-7002	Float
16041	KM-16041-0007	Choke Carburetor Shaft
16041A	KM-16041-7056	Throttle Carburetor Shaft
16073	KM-16073-7013	Insulator
16186	KM-16186-7006	Choke Valve Assembly
21188	KM-21188-7002	Solenoid


Ref.	Part Number	Description
49121	KM-49121-7018	Main Nozzle
59076	KM-59076-0009	Intake Manifold
92004	KM-92004-0723	Bolt-Stud, 6 x 115
92009	KM-92009-2083	Screw
92009A	KM-92009-2349	Screw
92063	KM-92063-7141	Main Jet, #122
92063A	KM-92063-7142	Main Jet, #124
92063B	KM-92063-7149	Main Jet, #120
92066	KM-92066-2204	Plug
92066A	KM-92066-2244	Plug
92066B	KM-92066-7032	Plug
92093	KM-92093-0593	Seal
92145	KM-92145-1579	Spring
92145A	KM-92145-2122	Spring
92200	KM-92200-0848	Washer
130	KM-130AA0630	Flanged Bolt, 6 x 30

Kawasaki FR730V-AS21 Air Filter/Muffler




Ref.	Part Number	Description
11011	KM-11011-7065	Air Filter Case
11013	KM-99999-0384	Air Filter Element
11060	KM-11060-7016	Muffler Gasket
11061	KM-11061-7086	Carburetor/Intake Pipe Gasket
16060	KM-16060-7038	Intake Pipe
42036	KM-42036-7022	Breather Sleeve
92009	KM-92009-2303	Screw
92015	KM-92015-1367	Nut
92066	KM-92066-0095	Plug
92170	KM-92170-2042	Clamp
92173	KM-92173-1001	Clamp
92173A	KM-92173-7003	Clamp
92173B	KM-92173-1001	Clamp
92192	KM-92192-7146	Tube, 12.6 x 18.6 x 118
92192A	KM-92192-7165	Tube
92210	KM-92210-7027	Nut, M8
461	KM-461DA0800	Spring Washer, 8mm

Kawasaki FR730V-AS21 Fuel Tank/Fuel Valve




Ref.	Part Number	Description
49019	KM-49019-7001	Fuel Filter
49040	KM-49040-7008	Fuel Pump
92009	KM-92009-2303	Screw
92170	KM-92170-2009	Clamp
92171	KM-92171-7005	Clamp
92192	KM-92192-7148	Tube, 6.4 x 12.7 x 150
92192A	KM-92192-7168	Tube, 6.35 x 12.7 x 100
92192B	KM-92192-7188	Tube, 6.35 x 12.7 x 390

Kawasaki FR730V-AS21 Starter




Ref.	Part Number	Description
14020	KM-14020-7002	Retainer
16146	KM-16146-0731	Cover Assembly
16146A	KM-16146-7030	Cover Assembly
21080	KM-21080-0007	Armature
21163	KM-21163-0743	Electric Starter
27012	KM-27012-7008	Hook
39108	KM-39108-0552	Retainer-Spring
59051	KM-59051-7034	Spur Gear
92093	KM-92093-7007	Seal
92145	KM-92145-7060	Spring
92154	KM-92154-7001	Bolt
92210	KM-92210-0884	Nut
130	KM-130BA0840	Flanged Bolt, 8 x 40




Ref.	Part Number	Description
56033	KM-56033-7001	Manual Label
56071	KM-56071-0216	Warning Label
56080	KM-56080-0023	Brand Label

Kohler KT725-3013 Crankcase



Ref.	Part Number	Description
1	KH-24-126-243-S	Lifting Strap
2	KH-24-380-16-S	Locating Pin
3	KH-24-032-19-S	Oil Seal, 1.78 x 1.26
4	KH-24-018-01-S	Piston Pin Retainer
5	KH-25-108-01-S	Piston Ring Set (STD)
—	KH-25-108-02-S	Piston Ring Set (.08)
—	KH-25-108-03-S	Piston Ring Set (.25)
—	KH-25-108-04-S	Piston Ring Set (.50)
6	KH-25-874-13-S	Piston Kit w/ Ring (STD) (Inc. 4 & 5)
—	KH-25-874-15-S	Piston Kit w/ Ring (.08)
—	KH-25-874-16-S	Piston Kit w/ Ring (.25)
—	KH-25-874-17-S	Piston Kit w/ Ring (.50)
7	KH-24-067-34-S	Connecting Rod (STD)
—	KH-24-067-31-S	Connecting Rod (U/S .010) (25mm)
8	KH-24-018-09-S	Ring Retainer
9	KH-24-468-15-S	Flat Washer, 11/32"
10	KH-28-032-09-S	Governor Cross Shaft Seal
11	KH-24-144-38-S	Governor Cross Shaft
12	KH-M-931010-S	Flat Washer, 9 mm
13	KH-25-086-398-S	Thread Forming Screw
14	KH-12-153-07	O-Ring
15	KH-25-153-09-S	O-Ring
16	KH-32-010-07-S	Camshaft Assembly
17	KH-32-038-12-S	Dipstick Assembly
18	KH-32-123-14-S	Oil Fill Tube Assembly


Kohler KT725-3013 Head/Valve/Breather




Kohler KT725-3013 Head/Valve/Breather

Ref.	Part Number	Description
1	KH-32-841-02-S	Cylinder Head Gasket Kit (Inc. Head Mounting Hardware)
2	KH-62-086-08-S	Flange Screw, M10 x 1.5 x 90
3	KH-32-017-01-S	Intake Valve
4	KH-32-016-01-S	Exhaust Valve
5	KH-275067	Spacer (.010")
6	KH-12-755-03	Retainer Kit
7	KH-25-032-14-S	Valve Band Seal
8	KH-25-173-28-S	Valve Spring Cap
9	KH-32-089-05-S	Valve Spring
10	KH-25-599-01-S	Rocker Arm Pivot
11	KH-32-019-02-S	Tappet
12	KH-32-072-04-S	Rocker Stud
13	KH-32-100-05-S	Hex Nut Assembly (Inc. #14)
14	KH-25-086-168-S	Set Screw
15	KH-32-146-09-S	Guide Plate
16	KH-32-186-03-S	Rocker Arm
17	KH-32-411-04-S	Push Rod
18	KH-25-086-374-S	Pan Head Screw
19	KH-25-096-09-S	Rocker Cover
20	KH-12-402-02	Breather Reed
21	KH-32-050-06-S	Breather Filter
22	KH-32-468-01-S	Sealing Washer
23	KH-M-547050-S	Lock Nut, M5 x 8
24	KH-25-096-11-S	Rocker Cover
25	KH-32-318-21-S	Cylinder Head Assembly Kit, #1 (Inc. Exhaust Mounting Hardware)
26	KH-32-318-22-S	Cylinder Head Assembly Kit, #2 (Inc. Exhaust Mounting Hardware)
27	KH-25-326-62-S	Breather Hose
28	KH-32-096-16-S	Breather Cover
29	KH-32-072-05-S	Stud
30	KH-16-096-02-S	Breather Media Cover
31	KH-66-018-04-S	Reed Retainer
32	KH-25-086-400-S	Thread Forming Screw

Kohler KT725-3013 Oil Pan/Lubrication




Ref.	Part Number	Description
1	KH-24-086-17-S	Flange Screw, M8 x 1.25 x 45
2	KH-25-032-06-S	Oil Seal, 2.38 x 1.45
3	KH-25-139-57-S	Square Head Pipe Plug, 3/8
4	KH-32-199-17-S	Oil Pan Assembly
5	KH-12-144-02	Governor Gear Shaft
6	KH-12-380-01	Governor Regulating Pin
7	KH-24-448-02-S	Locking Tab
8	KH-32-310-02-S	Governor Gear Kit
9	KH-32-393-18-S	Oil Pump Assembly
10	KH-25-086-414-S	Button Head Screw
11	KH-12-050-01-S	Oil Filter
12	KH-32-089-06-S	Compression Spring
13	KH-32-162-06-S	Oil Screen
14	KH-25-139-60-S	Pipe Plug, 1/8




Ref.	Part Number	Description
1	KH-52-139-09-S	Cup Plug
2	KH-32-014-327-S	Crankshaft

Kohler KT725-3013 Ignition/Electrical



Ref.	Part Number	Description
1	KH-12-132-02-S	Spark Plug
2	KH-25-086-402-S	Thread Forming Screw
3	KH-237878	15 Amp Stator Kit
4	KH-25-086-361-S	Hex Flange Screw
5	KH-25-340-04-S	Square Key
6	KH-25-468-09-S	Flat Washer
7	KH-20-146-05-S	Fan Mounting Plate
8	KH-32-018-03-S	Flywheel Fan Retainer
9	KH-32-157-04-S	Fan
10	KH-32-162-03-S	Grass Screen
11	KH-25-086-473-S	Thread Forming Screw
12	KH-25-155-41-S	Connector
13	KH-25-454-03-S	Wire Tie
14	KH-32-025-25-S	Flywheel Assembly
15	KH-32-584-06-S	Ignition Module
16	KH-32-176-34-S	Wiring Harness
17	KH-32-518-02-S	Jumper Lead
18	KH-41-403-10-S	Rectifier Regulator


Kohler KT725-3013 Blower Housing & Baffles



Kohler KT725-3013 Blower Housing & Baffles


Ref.	Part Number	Description
1	KH-25-086-473-S	Thread Forming Screw
2	KH-25-086-450-S	Hi-Low Screw
3	KH-25-086-397-S	Thread Forming Screw
4	KH-32-146-15-S	Backing Plate
5	KH-32-063-19-S	Valley Baffle, #1 Cylinder
6	KH-32-063-20-S	Valley Baffle, #2 Cylinder
7	KH-25-086-400-S	Thread Forming Screw
8	KH-25-086-406-S	Thread Forming Screw
9	KH-32-063-17-S	Left Barrel Baffle
10	KH-32-063-18-S	Right Barrel Baffle
11	KH-32-027-16-S	Blower Housing
12	KH-32-445-01-S	Lift Strap

Kohler KT725-3013 Engine Controls




Ref.	Part-Number	Description
1	KH-25-086-397-S	Thread Forming Screw
2	KH-24-089-03	Choke Return Spring
3	KH-32-089-03-S	Speed Control Spring
4	KH-24-089-55-S	Governor Spring
5	KH-25-158-08	Linkage Retaining Bushing
6	KH-25-158-11	Throttle Linkage Bushing
7	KH-32-090-07-S	Governor Spring Lever
8	KH-32-090-08-S	Speed Control Lever
9	KH-32-090-09-S	Speed Setting Lever
10	KH-32-090-12-S	Choke Lever
11	KH-24-112-27-S	Control Assembly Spacer
12	KH-24-468-01	Flat Washer, 5.5mm
13	KH-25-086-429-S	Thread Forming Screw
14	KH-25-086-398-S	Thread Forming Screw
15	KH-32-079-01-S	Throttle Linkage
16	KH-32-126-04-S	Control Bracket
17	KH-41-468-03	Spring Washer, 1/4
18	KH-32-089-07-S	Linkage Spring
19	KH-M-547050-S	Lock Nut, M5 x .8
20	KH-12-237-01	Cable Clamp
21	KH-25-086-405-S	Thread Forming Screw
22	KH-24-090-69-S	Governor Lever
23	KH-24-211-03-S	Bolt, M6 x 1.0 x 25
24	KH-M-641060-S	Flange Nut, M6 x 1.0
25	KH-24-079-22-S	Choke Linkage
26	KH-24-089-25-S	Governor Spring

Kohler KT725-3013 Air Intake/Filtration




Ref.	Part Number	Description
1	KH-25-173-09-S	Masking Cap
2	KH-32-094-13-S	Air Cleaner Base Assembly
3	KH-32-883-09-S1	Air Filter Element
4	KH-25-153-15-S	O-Ring
5	KH-32-083-10-S	Pre-Cleaner Element
6	KH-32-041-04-S	Air Cleaner Base Gasket
7	KH-32-096-20-S	Air Cleaner Cover Assembly



Ref.	Part Number	Description
1	KH-32-098-04-S	Starter Assembly
2	KH-M-851080-S	Flange Screw, M8 x 1.25 x 80


Kohler KT725-3013 Fuel System



Ref.	Part Number	Description
1	KH-25-072-25-S	Stud
2	KH-25-086-398-S	Thread Forming Screw
3	KH-M-641060-S	Flange Nut, M6 x 1.0
4	KH-25-050-22-S1	Fuel Filter
5	KH-24-153-27-S	Intake Port O-Ring
6	KH-25-111-81-S	Fuel Line, 24"
7	KH-25-237-37-S	Spring Hose Clamp
8	KH-47-154-01-S	Cable Clip
9	KH-24-086-12	Tap Screw, M6 x 1.7 x 18

Ref.	Part Number	Description
10	KH-24-393-16	Fuel Pump
11	KH-25-086-400-S	Thread Forming Screw
12	KH-32-326-08-S	Pulse Pump Hose
13	KH-32-853-43-S	Carburetor Kit
14	KH-24-164-91-S	Intake Manifold Kit
15	KH-M-651040-S	Flange Screw, M6 x 1.0 x 40
16	KH-24-041-52-S	Carburetor Gasket
17	KH-25-139-60-S	Pipe Plug, 1/8


Kohler KT725-3013 Labels



Artwork is representative.
Actual labels may differ depending on model and specification number.


Ref.	Part Number	Description
1	KH-25-113-70-S	Clear Laminate Decal
2	KH-25-454-05-S	Tie
3	KH-32-113-108-S	Decal, 22 HP

Kohler KT735-3012 Crankcase



Ref.	Part Number	Description
1	KH-24-126-243-S	Oil Fill Tube Bracket
2	KH-24-380-16-S	Locating Pin
3	KH-24-032-19-S	Oil Seal, 1.78 x 1.26
4	KH-24-018-01-S	Piston Pin Retainer
5	KH-25-108-01-S	Piston Ring Set (STD)
—	KH-25-108-02-S	Piston Ring Set (.08)
—	KH-25-108-03-S	Piston Ring Set (.25)
—	KH-25-108-04-S	Piston Ring Set (.50)
6	KH-25-874-13-S	Piston Kit w/ Ring (STD) (Inc. 4 & 5)
—	KH-25-874-15-S	Piston Kit w/ Ring (.08)
—	KH-25-874-16-S	Piston Kit w/ Ring (.25)
—	KH-25-874-17-S	Piston Kit w/ Ring (.50)
7	KH-24-067-34-S	Connecting Rod (STD)
—	KH-24-067-31-S	Connecting Rod (U/S .010) (25mm)
8	KH-24-018-09-S	Ring Retainer
9	KH-24-468-15-S	Flat Washer, 11/32"
10	KH-28-032-09-S	Governor Cross Shaft Seal
11	KH-24-144-38-S	Governor Cross Shaft
12	KH-M-931010-S	Flat Washer, 9 mm
13	KH-25-086-398-S	Thread Forming Screw
14	KH-12-153-07	O-Ring
15	KH-25-153-09-S	O-Ring
16	KH-32-010-07-S	Camshaft Assembly
17	KH-32-038-12-S	Dipstick Assembly
18	KH-32-123-14-S	Oil Fill Tube Assembly


Kohler KT735-3012 Head/Valve/Breather




Kohler KT735-3012 Head/Valve/Breather

Ref.	Part Number	Description
1	KH-32-841-02-S	Cylinder Head Gasket Kit (Inc. Head Mounting Hardware)
2	KH-62-086-08-S	Flange Screw, M10 x 1.5 x 90
3	KH-32-017-01-S	Intake Valve
4	KH-32-016-01-S	Exhaust Valve
5	KH-275067	Spacer (.010")
6	KH-12-755-03	Retainer Kit
7	KH-25-032-14-S	Valve Band Seal
8	KH-25-173-28-S	Valve Spring Cap
9	KH-32-089-05-S	Valve Spring
10	KH-25-599-01-S	Rocker Arm Pivot
11	KH-32-019-02-S	Tappet
12	KH-32-072-04-S	Rocker Stud
13	KH-32-100-05-S	Hex Nut Assembly (Inc. #14)
14	KH-25-086-168-S	Set Screw
15	KH-32-146-09-S	Guide Plate
16	KH-32-186-03-S	Rocker Arm
17	KH-32-411-04-S	Push Rod
18	KH-25-086-374-S	Pan Head Screw
19	KH-25-096-09-S	Rocker Cover
20	KH-12-402-02	Breather Reed
21	KH-32-050-06-S	Breather Filter
22	KH-32-468-01-S	Sealing Washer
23	KH-M-547050-S	Lock Nut, M5 x 8
24	KH-25-096-11-S	Rocker Cover
25	KH-32-318-21-S	Cylinder Head Assembly Kit, #1 (Inc. Exhaust Mounting Hardware)
26	KH-32-318-22-S	Cylinder Head Assembly Kit, #2 (Inc. Exhaust Mounting Hardware)
27	KH-25-326-62-S	Breather Hose
28	KH-32-096-16-S	Breather Cover
29	KH-32-072-05-S	Stud
30	KH-16-096-02-S	Breather Media Cover
31	KH-66-018-04-S	Reed Retainer
32	KH-25-086-400-S	Thread Forming Screw

Kohler KT735-3012 Oil Pan/Lubrication




Ref.	Part Number	Description
1	KH-24-086-17-S	Flange Screw, M8 x 1.25 x 45
2	KH-25-032-06-S	Oil Seal, 2.38 x 1.45
3	KH-25-139-57-S	Square Head Pipe Plug, 3/8
4	KH-32-199-17-S	Oil Pan Assembly
5	KH-12-144-02	Governor Gear Shaft
6	KH-12-380-01	Governor Regulating Pin
7	KH-24-448-02-S	Locking Tab
8	KH-32-310-02-S	Governor Gear Kit
9	KH-32-393-18-S	Oil Pump Assembly
10	KH-25-086-414-S	Button Head Screw
11	KH-12-050-01-S	Oil Filter
12	KH-32-089-06-S	Compression Spring
13	KH-32-162-06-S	Oil Screen
14	KH-25-139-60-S	Pipe Plug, 1/8




Ref.	Part Number	Description
1	KH-52-139-09-S	Cup Plug
2	KH-32-014-327-S	Crankshaft

Kohler KT735-3012 Ignition/Electrical



Ref.	Part Number	Description
1	KH-12-132-02-S	Spark Plug
2	KH-25-086-402-S	Thread Forming Screw
3	KH-237878	15 Amp Stator Kit
4	KH-25-086-361-S	Hex Flange Screw
5	KH-25-340-04-S	Square Key
6	KH-25-468-09-S	Flat Washer
7	KH-20-146-05-S	Fan Mounting Plate
8	KH-32-018-03-S	Flywheel Fan Retainer
9	KH-32-157-04-S	Fan
10	KH-32-162-03-S	Grass Screen
11	KH-25-086-473-S	Thread Forming Screw
12	KH-25-155-41-S	Connector
13	KH-25-454-03-S	Wire Tie
14	KH-32-025-25-S	Flywheel Assembly
15	KH-32-584-06-S	Ignition Module
16	KH-32-176-34-S	Wiring Harness
17	KH-32-518-02-S	Jumper Lead
18	KH-41-403-10-S	Rectifier Regulator


Kohler KT735-3012 Blower Housing & Baffles



Kohler KT735-3012 Blower Housing & Baffles


Ref.	Part Number	Description
1	KH-25-086-473-S	Thread Forming Screw
2	KH-25-086-450-S	Hi-Low Screw
3	KH-25-086-397-S	Thread Forming Screw
4	KH-32-146-15-S	Backing Plate
5	KH-32-063-19-S	Valley Baffle, #1 Cylinder
6	KH-32-063-20-S	Valley Baffle, #2 Cylinder
7	KH-25-086-400-S	Thread Forming Screw
8	KH-25-086-406-S	Thread Forming Screw
9	KH-32-063-17-S	Left Barrel Baffle
10	KH-32-063-18-S	Right Barrel Baffle
11	KH-32-027-16-S	Blower Housing
12	KH-32-445-01-S	Lift Strap

Kohler KT735-3012 Engine Controls




Ref.	Part-Number	Description
1	KH-25-086-397-S	Thread Forming Screw
2	KH-24-089-03	Choke Return Spring
3	KH-32-089-03-S	Speed Control Spring
4	KH-24-089-55-S	Governor Spring
5	KH-25-158-08	Linkage Retaining Bushing
6	KH-25-158-11	Throttle Linkage Bushing
7	KH-32-090-07-S	Governor Spring Lever
8	KH-32-090-08-S	Speed Control Lever
9	KH-32-090-09-S	Speed Setting Lever
10	KH-32-090-12-S	Choke Lever
11	KH-24-112-27-S	Control Assembly Spacer
12	KH-24-468-01	Flat Washer, 5.5mm
13	KH-25-086-429-S	Thread Forming Screw
14	KH-25-086-398-S	Thread Forming Screw
15	KH-32-079-01-S	Throttle Linkage
16	KH-32-126-04-S	Control Bracket
17	KH-41-468-03	Spring Washer, 1/4
18	KH-32-089-07-S	Linkage Spring
19	KH-M-547050-S	Lock Nut, M5 x .8
20	KH-12-237-01	Cable Clamp
21	KH-25-086-405-S	Thread Forming Screw
22	KH-24-090-69-S	Governor Lever
23	KH-24-211-03-S	Bolt, M6 x 1.0 x 25
24	KH-M-641060-S	Flange Nut, M6 x 1.0
25	KH-24-079-22-S	Choke Linkage
26	KH-24-089-25-S	Governor Spring

Kohler KT735-3012 Air Intake/Filtration




Ref.	Part Number	Description
1	KH-25-173-09-S	Masking Cap
2	KH-32-094-13-S	Air Cleaner Base Assembly
3	KH-32-883-09-S1	Air Filter Element
4	KH-25-153-15-S	O-Ring
5	KH-32-083-10-S	Pre-Cleaner Element
6	KH-32-041-04-S	Air Cleaner Base Gasket
7	KH-32-096-20-S	Air Cleaner Cover Assembly



Ref.	Part Number	Description
1	KH-32-098-04-S	Starter Assembly
2	KH-M-851080-S	Flange Screw, M8 x 1.25 x 80


Kohler KT735-3012 Fuel System



Ref.	Part Number	Description
1	KH-25-072-25-S	Stud
2	KH-25-086-398-S	Thread Forming Screw
3	KH-M-641060-S	Flange Nut, M6 x 1.0
4	KH-24-050-13-S	Fuel Filter
5	KH-24-153-27-S	Intake Port O-Ring
6	KH-25-111-81-S	Fuel Line, 24"
7	KH-25-237-37-S	Spring Hose Clamp
8	KH-47-154-01-S	Cable Clip
9	KH-24-086-12	Tap Screw, M6 x 1.7 x 18

Ref.	Part Number	Description
10	KH-24-393-16	Fuel Pump
11	KH-25-086-400-S	Thread Forming Screw
12	KH-32-326-08-S	Pulse Pump Hose
13	KH-32-853-34-S	Carburetor Kit
14	KH-24-164-91-S	Intake Manifold Kit
15	KH-M-651040-S	Flange Screw, M6 x 1.0 x 40
16	KH-24-041-52-S	Carburetor Gasket
17	KH-25-139-60-S	Pipe Plug, 1/8


Kohler KT735-3012 Labels



Artwork is representative.
Actual labels may differ depending on model and specification number.


Ref.	Part Number	Description
1	KH-25-113-70-S	Clear Laminate Decal
2	KH-25-454-05-S	Tie
3	KH-32-113-106-S	Decal, 24 HP

Kohler KT745-3001 Crankcase



Ref.	Part Number	Description
1	KH-24-126-243-S	Lifting Strap
2	KH-24-380-16-S	Locating Pin
3	KH-24-032-19-S	Oil Seal, 1.78 x 1.26
4	KH-24-018-01-S	Piston Pin Retainer
5	KH-25-108-01-S	Piston Ring Set (STD)
—	KH-25-108-02-S	Piston Ring Set (.08)
—	KH-25-108-03-S	Piston Ring Set (.25)
—	KH-25-108-04-S	Piston Ring Set (.50)
6	KH-25-874-14-S	Piston Kit w/ Ring (STD) (Inc. 4 & 5)
—	KH-25-874-18-S	Piston Kit w/ Ring (.08)
—	KH-25-874-19-S	Piston Kit w/ Ring (.25)
—	KH-25-874-20-S	Piston Kit w/ Ring (.50)
7	KH-24-067-34-S	Connecting Rod (STD)
—	KH-24-067-31-S	Connecting Rod (U/S .010) (25mm)
8	KH-24-018-09-S	Ring Retainer
9	KH-24-468-15-S	Flat Washer, 11/32"
10	KH-28-032-09-S	Governor Cross Shaft Seal
11	KH-24-144-38-S	Governor Cross Shaft
12	KH-M-931010-S	Flat Washer, 9 mm
13	KH-25-086-398-S	Thread Forming Screw
14	KH-12-153-07	O-Ring
15	KH-25-153-09-S	O-Ring
16	KH-32-010-07-S	Camshaft Assembly
17	KH-32-038-12-S	Dipstick Assembly
18	KH-32-123-14-S	Oil Fill Tube Assembly


Kohler KT745-3001 Head/Valve/Breather




Kohler KT745-3001 Head/Valve/Breather

Ref.	Part Number	Description
1	KH-32-841-02-S	Cylinder Head Gasket Kit (Inc. Head Mounting Hardware)
2	KH-62-086-08-S	Flange Screw, M10 x 1.5 x 90
3	KH-32-017-01-S	Intake Valve
4	KH-32-016-01-S	Exhaust Valve
5	KH-275067	Spacer (.010")
6	KH-12-755-03	Retainer Kit
7	KH-25-032-14-S	Valve Band Seal
8	KH-25-173-28-S	Valve Spring Cap
9	KH-32-089-05-S	Valve Spring
10	KH-25-599-01-S	Rocker Arm Pivot
11	KH-32-019-02-S	Tappet
12	KH-32-072-04-S	Rocker Stud
13	KH-32-100-05-S	Hex Nut Assembly (Inc. #14)
14	KH-25-086-168-S	Set Screw
15	KH-32-146-09-S	Guide Plate
16	KH-32-186-03-S	Rocker Arm
17	KH-32-411-04-S	Push Rod
18	KH-25-086-374-S	Pan Head Screw
19	KH-25-096-09-S	Rocker Cover
20	KH-12-402-02	Breather Reed
21	KH-32-050-06-S	Breather Filter
22	KH-32-468-01-S	Sealing Washer
23	KH-M-547050-S	Lock Nut, M5 x 8
24	KH-25-096-11-S	Rocker Cover
25	KH-32-318-21-S	Cylinder Head Assembly Kit, #1 (Inc. Exhaust Mounting Hardware)
26	KH-32-318-22-S	Cylinder Head Assembly Kit, #2 (Inc. Exhaust Mounting Hardware)
27	KH-25-326-62-S	Breather Hose
28	KH-32-096-16-S	Breather Cover
29	KH-32-072-05-S	Stud
30	KH-16-096-02-S	Breather Media Cover
31	KH-66-018-04-S	Reed Retainer
32	KH-25-086-400-S	Thread Forming Screw

Kohler KT745-3001 Oil Pan/Lubrication




Ref.	Part Number	Description
1	KH-24-086-17-S	Flange Screw, M8 x 1.25 x 45
2	KH-25-032-06-S	Oil Seal, 2.38 x 1.45
3	KH-25-139-57-S	Square Head Pipe Plug, 3/8
4	KH-32-199-17-S	Oil Pan Assembly
5	KH-12-144-02	Governor Gear Shaft
6	KH-12-380-01	Governor Regulating Pin
7	KH-24-448-02-S	Locking Tab
8	KH-32-310-02-S	Governor Gear Kit
9	KH-32-393-18-S	Oil Pump Assembly
10	KH-25-086-414-S	Button Head Screw
11	KH-12-050-01-S	Oil Filter
12	KH-32-089-06-S	Compression Spring
13	KH-32-162-06-S	Oil Screen
14	KH-25-139-60-S	Pipe Plug, 1/8




Ref.	Part Number	Description
1	KH-52-139-09-S	Cup Plug
2	KH-16-014-12-S	Crankshaft

Kohler KT745-3001 Ignition/Electrical



Ref.	Part Number	Description
1	KH-12-132-02-S	Spark Plug
2	KH-25-086-402-S	Thread Forming Screw
3	KH-237878	15 Amp Stator Kit
4	KH-25-086-361-S	Hex Flange Screw
5	KH-25-340-04-S	Square Key
6	KH-25-468-09-S	Flat Washer
7	KH-20-146-05-S	Fan Mounting Plate
8	KH-32-018-03-S	Flywheel Fan Retainer
9	KH-32-157-04-S	Fan
10	KH-32-162-03-S	Grass Screen
11	KH-25-086-473-S	Thread Forming Screw
12	KH-25-155-41-S	Connector
13	KH-25-454-03-S	Wire Tie
14	KH-32-025-21-S	Flywheel Assembly
15	KH-32-584-07-S	Ignition Module
16	KH-32-176-34-S	Wiring Harness
17	KH-32-518-02-S	Jumper Lead
18	KH-41-403-10-S	Rectifier Regulator


Kohler KT745-3001 Blower Housing & Baffles



Kohler KT745-3001 Blower Housing & Baffles


Ref.	Part Number	Description
1	KH-25-086-473-S	Thread Forming Screw
2	KH-25-086-450-S	Hi-Low Screw
3	KH-25-086-397-S	Thread Forming Screw
4	KH-32-146-15-S	Backing Plate
5	KH-32-063-19-S	Valley Baffle, #1 Cylinder
6	KH-32-063-20-S	Valley Baffle, #2 Cylinder
7	KH-25-086-400-S	Thread Forming Screw
8	KH-25-086-406-S	Thread Forming Screw
9	KH-32-063-17-S	Left Barrel Baffle
10	KH-32-063-18-S	Right Barrel Baffle
11	KH-32-027-16-S	Blower Housing
12	KH-32-445-01-S	Lift Strap

Kohler KT745-3001 Engine Controls




Ref.	Part-Number	Description
1	KH-25-086-397-S	Thread Forming Screw
2	KH-24-089-03	Choke Return Spring
3	KH-32-089-03-S	Speed Control Spring
4	KH-24-089-55-S	Governor Spring
5	KH-25-158-08	Linkage Retaining Bushing
6	KH-25-158-11	Throttle Linkage Bushing
7	KH-32-090-07-S	Governor Spring Lever
8	KH-32-090-08-S	Speed Control Lever
9	KH-32-090-09-S	Speed Setting Lever
10	KH-32-090-12-S	Choke Lever
11	KH-24-112-27-S	Control Assembly Spacer
12	KH-24-468-01	Flat Washer, 5.5mm
13	KH-25-086-429-S	Thread Forming Screw
14	KH-25-086-398-S	Thread Forming Screw
15	KH-32-079-01-S	Throttle Linkage
16	KH-32-126-04-S	Control Bracket
17	KH-41-468-03	Spring Washer, 1/4
18	KH-32-089-07-S	Linkage Spring
19	KH-M-547050-S	Lock Nut, M5 x .8
20	KH-12-237-01	Cable Clamp
21	KH-25-086-405-S	Thread Forming Screw
22	KH-24-090-69-S	Governor Lever
23	KH-24-211-03-S	Bolt, M6 x 1.0 x 25
24	KH-M-641060-S	Flange Nut, M6 x 1.0
25	KH-24-079-22-S	Choke Linkage
26	KH-24-089-25-S	Governor Spring

Kohler KT745-3001 Air Intake/Filtration




Ref.	Part Number	Description
1	KH-25-173-09-S	Masking Cap
2	KH-32-094-13-S	Air Cleaner Base Assembly
3	KH-32-883-09-S1	Air Filter Element
4	KH-25-153-15-S	O-Ring
5	KH-32-083-10-S	Pre-Cleaner Element
6	KH-32-041-04-S	Air Cleaner Base Gasket
7	KH-32-096-20-S	Air Cleaner Cover Assembly



Ref.	Part Number	Description
1	KH-32-098-04-S	Starter Assembly
2	KH-M-851080-S	Flange Screw, M8 x 1.25 x 80


Kohler KT745-3001 Fuel System



Ref.	Part Number	Description
1	KH-25-072-25-S	Stud
2	KH-25-086-398-S	Thread Forming Screw
3	KH-M-641060-S	Flange Nut, M6 x 1.0
4	KH-25-050-22-S1	Fuel Filter
5	KH-24-153-27-S	Intake Port O-Ring
6	KH-25-111-81-S	Fuel Line, 24"
7	KH-25-237-37-S	Spring Hose Clamp
8	KH-47-154-01-S	Cable Clip
9	KH-24-086-12	Tap Screw, M6 x 1.7 x 18

Ref.	Part Number	Description
10	KH-24-393-16	Fuel Pump
11	KH-25-086-400-S	Thread Forming Screw
12	KH-32-326-08-S	Pulse Pump Hose
13	KH-16-853-01-S	Carburetor Kit
14	KH-24-164-91-S	Intake Manifold Kit
15	KH-M-651040-S	Flange Screw, M6 x 1.0 x 40
16	KH-24-041-52-S	Carburetor Gasket
17	KH-25-139-60-S	Pipe Plug, 1/8

Kohler KT745-3001 Labels



Artwork is representative.
Actual labels may differ depending on model and specification number.

Ref.	Part Number	Description
1	KH-25-113-70-S	Clear Laminate Decal
2	KH-25-454-05-S	Tie
3	KH-32-113-104-S	Decal, 26 HP



To order replacement parts, call a Customer Support Representative at (800) 965-4CUB.
Locate your nearest Cub Cadet dealer at (877) 282-8684
or visit www.cubcadet.com to find the nearest Cub Cadet dealer in your area.

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
