


Cub Cadet

Parts MANUAL



Series 3000

TRACTOR

Model 3206


CUB CADET P.O. BOX 368023 CLEVELAND, OHIO 44136-9723

TABLE OF CONTENTS

DESCRIPTION	PAGE
Axle, Front	14
Baffles, Air	16
Battery	28
Brake Assembly	8
Brake Pedal and Linkage	4
Controls	
Drive Pedals and Linkage	4
Engine Control Cables	16
Cable Handles	27
Hydraulic Lift	12
Dash Panel	27
Driveshaft	16
Electrical	
Harness, Wire	16
Interlock Switches	16
Switches, Dash Panel	27
Engine Mounting	16
Engine	
Air Cleaner	26
Blower Housing	21
Breather	20
Carburetor	24
Control Bracket	25
Crankshaft	18
Cylinder Assembly	18
Cylinder Heads	20
Electrical	22
Flywheel	22
Fuel Pump	20
Oil Filter	19
Oil Pump	19
Pistons	18
Starter	23
Valves	20


DESCRIPTION	PAGE
Fender and Running Board	32
Frame	33
Fuel Tank	34
Grille	30
Hood	30
Hydrostatic Transmission	10
Hydraulic Lines	12
Lift Linkage	15
Lift Valve	12
Muffler	16
Pedestal	28
PTO, Front	3
Seat	29
Side Panels	30
Steering	
Lower Steering	13
Pump, Hydraulic Steering	13
Steering Wheel	27
Upper Steering	28
Transmission	
Neutral Linkage	6
Oil Filter	8
Transmission Mounting	6
Transmission Differential	8
Wheels	35

FRONT PTO



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0442	0637	Bracket, Idler	1	12	712-0431		Nut, Flange Lock, 3/8-16	7
2	759-3867		Bracket Assembly, Brake	1	13	714-0104		Pin, Internal Cotter	1
3	703-3009	0637	Bracket, PTO Mounting	1	14	716-0102		Snap Ring, 1.0 Dia Shaft	1
4	703-3161	0716	Bracket, Actuator	1	15	732-0470A		Spring, Extension, .530 x 4.74 ...	1
5	703-3165	0637	Belt Guide	1	16	738-0213		Shoulder Screw, .498 x 1.45	2
6	710-0237		Screw, Hex Cap	2	17	738-0706B		Shoulder Screw, .375 x .28	3
			5/16-24 x .625 GR5		18	738-3056		Shoulder Screw	2
7	710-0514		Screw, Hex Cap	2	19	741-0491		Bearing, Nylon Flange	4
			3/8-16 x 1.0 GR5		20	747-3322		Rod, PTO Brake	1
8	710-0520		Screw, Hex Cap	1	21	751-3158		Vacuum Actuator	1
			3/8-16 x 1.5 GR5		22	754-3084		V-Belt, A-Section x 37.63	1
9	710-0623		Screw, Hex Wash. Hd. Tapp	2				(Set of two belts)	
			3/8-16 x .75		23	756-3092		Pulley, PTO Drive. 6.75-Double .	1
10	711-1196		Ferrule, Brake Adjustment	1	24	756-3094		Pulley, Flat Idler, 4.0	1
11	712-0324		Nut, Hex Insert Lock, 1/4-20	1					


BRAKE AND CONTROL PEDALS



BRAKE AND CONTROL PEDALS


REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0379		Shaft Assembly, Pedal	1
2	603-0421A		Plate, Disengagement	1
3	603-0437	0637	Cam, Clutch	1
4	603-0445A		Shaft Assembly, Brake	1
5	603-0449		Shaft Assembly, Reverse	1
6	603-0634		Rod Assembly, Cruise	1
7	703-3012	0716	Link, Pedal Mounting	1
8	703-3020	0637	Bracket, Rod Adjust	1
9	703-3152	0637	Bracket, Switch	2
10	603-0733	0716	Lever, Brake Diff Lock	1
11	703-3156	0716	Link, Brake Pedal	1
12	710-0106		Screw, Hex Cap, 1/4-20 x 1.25 GR5	1
13	710-0599		Screw, Hex Wash. Hd. Tapp 1/4-20 x .5	5
14	710-0623		Screw, Hex Wash. Hd. Tapp 3/8-16 x .75	2
15	710-0642		Screw, Hex Wash. Hd. Tapp 1/4-20 x .75	6
16	710-1315		Screw, Hex Wash. Hd. Tapp 3/8-16 x 1.25	2
17	711-0679A		Pin, Clevis, 3/8 x 2.015	1
18	711-1530		Ferrule, Adjust.	1
19	711-1138		Stud, Actuator	1
20	712-3004A		Nut, Hex Flange Lock, 5/16-18	2
21	712-3027		Nut, Hex Flange Lock, 1/4-20	1
22	712-3058		Nut, Hex Insert Lock, 1/2-20	3
23	712-0429		Nut, Hex Insert Lock, 5/16-18	1
24	714-0104		Pin, Internal Cotter	7
25	714-0145		Pin, Internal Cotter	2
26	714-0147		Pin, Internal Cotter	5
27	715-0114		Pin, Spiral Spring, .25 x 1.5	1
28	731-3247		Pedal, Forward	1
29	731-3248		Pedal, Reverse	1
30	731-3249		Pedal, Brake	1
31	732-0324		Spring, Compression	1
32	732-0859		Spring, No Cut Reverse	1
33	732-0871		Spring, Torsion	1
34	732-3118		Spring, Extension, .380 OD x 1.44 .	2
35	736-0275		Washer, Flat, .344 x .688 x .065	2
36	736-0287		Washer, Flat, .79 x 1.24 x .060	1
37	736-0463		Washer, Flat, .25 x .62	1
38	736-0621		Washer, Wave, .785 x 1.0 x .012 ...	1
39	736-3019		Washer, Flat, .531 x 1.06 x .134	3
40	741-0598		Bearing, Hex Flange	4
41	741-3073		Bearing, Flange	3
42	741-3074		Bearing, Flange	2
43	741-3084		Bearing, Flange	1
44	747-3319		Rod, Rear Control	1
45	747-3320		Rod, Front Control	1
46	747-3324		Rod, Rear Connecting	1
47	747-3353		Rod, Front Connecting	1
48	747-3422		Rod, Brake	1
49	748-3060		Cruise Latch	1
50	748-3080		Plate, Cruise	1
51	603-0738		Link Assembly, Brake	1
52	703-3526		Bracket, Brake Rod Support	1

TRANSMISSION MOUNTING AND NEUTRAL LINKAGE



TRANSMISSION MOUNTING AND NEUTRAL LINKAGE


REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0698		Bracket, Torque	1	29	721-0459		O-Ring,426 ID x .566 OD x .070	2
2	703-3478		Plate, Hydro Neutral Return ...	1	30	726-0295		Clamp, Tube	2
3	703-3477		Link, Neutral Return Bearing ..	1	31	726-0324		Clamp, Hose	1
4	703-3187		Spring Plate, Hydro Bypass	1	32	727-3090		Cylinder, Damper	1
5	703-3175		Bracket, Cable Retainer	1	33	727-3139		Tube, Hydro Pickup	1
6	703-3183		Bracket, Pedal Brace	1	34	727-3148		Dipstick, Transmission	1
7	703-3410		Plate, Bolt Retainer	2	35	731-1480		Plastic Vent	1
8	710-0433		Screw, Hex Cap, 1/4-20 x .625 GR5 Lock	1	36	731-1481		Vent Cap	1
9	710-0514		Screw, Hex Cap, 3/8-16 x 1.0 GR5	7	37	731-3297		Fan, Pump	1
10	710-0599		Screw, Hex Wash. Hd. Tapp, . 1/4-20 x .5	2	38	731-3245		Holder, Dipstick	1
11	710-0623		Screw, Hex Wash. Hd. Tapp, . 3/8-16 x .75	1	39	731-3250		Pedal, Diff Lock	1
12	710-0642		Screw, Hex Wash. Hd. Tapp, . 1/4-20 x .75	1	40	732-0429A		Spring, Extension	1
13	710-0465		Screw, Hex Cap, 1/2-20 x 4.5 GR5	4	41	735-0279		Grommet	1
14	710-3015		Screw, Hex Cap, 1/4-20 x .75 GR5	1	42	736-0227		Washer, Flat,390 x 1.5 x .1	3
15	710-3170		Ball Screw, 5/16-18 x .56	1	43	736-0105		Washer, Bell, .401 x .87 x .063 Used on Tapered Hydro Input Shaft	1
16	710-1506		Screw, Hex Wash. Hd. Tapp .. 5/16-18 x 5.5 GR5	4		736-0253		Washer, Bell, .5 x 1.0 x .05 Used on Splined Hydro Input Shaft	1
17	710-3242		Screw, Set, 5/16 x .5	1	44	736-3019		Washer, Flat,531 x 1.062 x .134	4
18	712-0262		Nut, Hex Ctr. Lock Jam, 3/8-24 Used on Tapered Hydro Input Shaft	1	45	736-3090		Washer, Flat,26 x .72 x .06	1
	712-3059		Nut, Hex Top Lock Jam, 1/2-20 Used on Splined Hydro Input Shaft	1	46	737-3092		Fitting, Tube	1
19	712-0266		Nut, Hex Ctr. Lock Jam, 3/8-16	3	47	738-0347		Spacer, Shoulder	1
20	712-0431		Nut, Hex Flange Lock, 3/8-16 ..	4	48	738-0572		Shoulder Bolt	1
21	712-3004A		Nut, Hex Flange Lock, 5/16-18	1	49	741-0155		Bearing, Ball	2
22	712-3006		Nut, Hex, 1/4-20	1	50	741-0491		Bearing, Nylon Flange	2
23	712-3058		Nut, Hex Insert Lock, 1/2-20 ...	4	51	746-3081		Cable, Diff Lock	1
24	714-0104		Pin, Internal Cotter	1	52	747-3424		Rod, Pump Bypass	1
26	716-0104		E-Ring, .5 Dia. Shaft	1	53	747-3366		Shaft, Diff Lock	1
27	718-3097		Arm, Hydro	1	54	750-0434		Spacer,375 x .5 x 1.02	1
28	748-3099		Adapter, Pump	1	55	750-0497		Spacer,375 x .624 x .445	2
			Used on Tapered Hydro Input Shaft		56	750-3212		Spacer, Hydro,3223 x .60 x 2.44	2
	748-3093		Adapter, Pump	1	57	751-0588-8		Fuel Line	8 in.
			Used on Splined Hydro Input Shaft						

TRANSMISSION - DIFFERENTIAL

TRANSMISSION - DIFFERENTIAL

REF. NO.	PART NUMBER	DESCRIPTION	QTY	REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	611-3024	Shaft, Differential Actuator	1	33	710-0642	Screw, Hex Wash. Hd. Tapp 1/4-20 x .75	13
2	617-3001	Gear Assembly, Pinion 13T	1	34	710-1206	Screw, Hex Wash. Hd. Tapp 1/4-20 x 2.375	2
	741-3037	Bearing, Ball	1	35	710-0751	Hex Cap Screw, 1/4-20 x .62 GR5	1
3	618-3142	Hydrostatic Transmission Assy. — with Tapered Input Shaft	1	36	710-0788	Screw, Hex Wash. Hd. Tapp 1/4-20 x 1.0	6
	618-3214	Hydrostatic Transmission Assy. — with Splined Input Shaft	1	37	710-0809	Screw, Hex Wash. Hd. Tapp 1/4-20 x 1.25	6
		NOTE: For components see separate parts breakdown.		38	711-1385	Shaft, Output 9T	1
4	618-3211	Bearing Block Assembly, Needle	1	39	712-0682	Nut, Lock, 7/8-14	2
5	618-3149	Bearing Block Assembly	2	40	717-3449	Gear, Bevel 54T	1
6	618-3150	Bearing Block Assembly	2	41	718-3089	Arm, Diff. Lock Actuator	1
7	618-3203	Cover Assembly, Rear	1	42	719-3162	Housing, Differential w/Diff. Lock	1
		Includes Ref. No. 8		43	721-0261	O-Ring, 2.75 x .103	1
8	710-1633	Plug, Drain, M14 x 1.5 x .827	1	44	721-0393	Seal, Oil	1
9	735-0277	Grommet, Rubber	1	45	721-0467	Gasket	1
10	618-3163	Bearing Block Assembly	1	46	723-3014	Filter, Oil	1
11	618-3210	Hub Assembly, Wheel	2	47	736-0208	Washer, Flat, .51 x 1.5 x .07	3
12	711-1308	Axle Shaft, 15.08 Long - RH	1	48	736-0270	Washer, Belleville, .265 x .75 x .062 ...	1
13	716-0172	Retaining Ring	4	49	736-0423	Washer, Flat Shim, 1.0 x 1.56 x .010 ..	AR
14	717-1119	Gear, Spur, 14T	2	50	736-0424	Washer, Flat Shim, 1.0 x 1.56 x .020 ..	AR
15	618-3155A	Collar Assembly, Diff. Lock	1	51	736-0431	Washer, Flat Shim, 1.0 x 1.56 x .015 ..	AR
16	711-1309	Axle Shaft, 15.08 Long - LH	1	52	736-0619	Washer, Spring	1
17	716-3018	Retaining Ring	1	53	737-3022	Fitting, Filter Nipple	1
18	718-3099B	Housing, Diff. Lock	1	54	741-3083	Bearing, Needle Thrust	1
19	732-0856	Spring, Compression	1	55	735-0279	Grommet	1
20	736-0615	Washer, Thrust, 1.007 x 1.542 x .03 ...	5	56	603-0699	Plate, Trans. Support LH	1
21	619-3086	Housing, Diff. Cover	1	57	712-0273	Nut, Hex Insert Lock, 5/16-24	1
22	710-1254	Hex Cap Screw, 3/8-24 x 2.25 GR8	4	58	717-0678	Pad, Brake	2
23	717-1120	Gear, Differential 10T	4	59	717-0682	Plate, Puck	1
24	717-1173	Shaft, Cross, .5 x 3.485	1	60	732-0925	Spring, Torsion	1
25	717-1178	Shaft, Cross, Special	2	61	736-0371	Washer, Flat, .343 x .88 x .062	1
26	717-1180	Differential Pinion Block	1	62	741-0343	Pin, Brake Actuator	2
27	717-3466	Gear, Spur 60T	1	63	761-0207A	Yoke, Brake	1
28	718-3101	Block, Thrust Miter	4	64	761-0208	Bracket, Brake Anti-Rotation	1
29	736-0558	Washer, Flat, 1.187 x 1.56 x .062	3	65	761-3074	Arm, Brake Actuator	1
30	761-0215	Disc, Brake	1		759-3746	Sealant, Ultra Grey, 2 oz. Tube	1
31	703-3188A	Block, Transmission Cover	2				
32	603-0701	Plate, Trans. Support RH	1				


HYDROSTATIC TRANSMISSION



HYDROSTATIC TRANSMISSION



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	HG-50984	Shaft, Pump with Tapered Adapter End	1
	HG-51206	Shaft, Pump with Splined Adapter End	1
2	HG-2000022	Ring, Wire Retaining	4
3	HG-2000038	Ring, Retaining	1
4	HG-2000023	Spacer	1
5	HG-2000032	Bearing, Ball	1
6	HG-2000036	Seal, Lip	1
7	HG-2000037	Seal, Lip	1
8	HG-2000014	Arm, Trunnion	1
9	HG-2000015	Guide, Slot	1
10	HG-2510097	Housing Assembly	1
11	HG-50552	Bearing Assembly, Thrust Ball	2
12	HG-2000024	Washer, Block Thrust	2
13	HG-2000025	Spring, Block	2
14	HG-2510014	Kit, Pump Cylinder Block	1
15	HG-2000007	Shaft, Motor	1
16	N/A	Not Used In This Application	
17	HG-2510098	Kit, Center Section	1
18	HG-50641	Pin	2
19	HG-2000061	Gasket, Center Section	1
20	HG-50203	Swashplate, Variable	1
21	HG-2510013	Kit, Motor Cylinder Block	1
22	HG-9004100-1430	O-Ring	2
23	HG-2510083	Kit, Auxiliary Charge Pump	1
24	HG-50761	Gerotor & Housing Assembly	1
25	HG-2510050	Kit, Check Valve	1
26	HG-2510034	Kit, Check Valve w/ .044 Orifice	1
27	HG-2510081	Kit, Check Relief	1
28	HG-2510082	Kit, Auxiliary Relief Valve	1
29	HG-2510012	Kit, Bypass Valve	1
30	HG-9005110-4400	Plug, 7/16-20	2
31	HG-2510090	Kit, Auxliary Filter	1
32	HG-50969	Screw, Flange Head Cap, M8 x 60 ..	2
33	HG-9007314-0808	Screw, Socket Head Cap	8
34	HG-9005110-3100	Plug, 5/16-24	1
35	HG-50994	Cover, Filter	1
36	HG-50408	Pin	2
37	HG-2000044	Shim, Charge Pump	1
38	N/A	O-Ring-Order Seal Kit HG-2510010	
39	N/A	O-Ring-Order Seal Kit HG-2510010	
40	N/A	O-Ring-Order Seal Kit HG-2510010	
	HG-2510010	Kit, Overhaul Seal (Includes Ref. Nos. 2, 3, 4, 6, 7, 19, 22, 38, 39 & 40)	1

HYDRAULIC VALVE AND LINES




REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.
1	703-1801	Bracket, Valve Mounting	2	14	726-0197	Cable Tie	3
2	703-1802	Clamp, Side Valve	2	15	727-3056	T-Fitting, 9/16-18 Thrd.	1
3	703-1803	Clamp, Double Valve	2	16	727-3130	Tube, Hydraulic (Pump to Strng) ..	1
4	703-3154	Bracket, Lift Valve	1	17	727-3131	Tube, Hydraulic (Aux. from Strng) ..	1
5	710-0597	Screw, Hex Cap	2	18	727-3162	Tube, Hydraulic (Strng Return) ..	1
		1/4-20 x 1.0 GR5		19	727-3160	Tube, Hydraulic (Aux Return)	1
6	710-0641	Screw, Hex Cap	2	20	727-3161	Tube, Hydraulic (Return to Pump) ..	1
		1/4-20 x 2.25 GR5		21	731-3259	Knob, Lift	1
7	710-3013	Screw, Hex Cap	5	22	735-3007	Rubber Spacer	3
		1/4-20 x .50 GR5		23	741-0491	Bearing, Nylon Flange	2
8	710-3083	Screw, Hex Cap	1	24	747-3349A	Handle, Center Lift Valve	1
		5/16-18 x 1.375 GR5		25	748-3081A	Link, Lift	1
9	712-0429	Nut, Hex Insert Lock, 5/16-18	1	26	748-3082	Clamp, Handle	1
10	712-3027	Nut, Hex Flange Lock, 1/4-20	4	27	721-0493	O-Ring, .426 x .566 x .070	3
11	717-3452	Valve, Hydraulic	1	28	710-0751	Screw, Hex Cap	1
12	721-0492	O-Ring, Backup	4			1/4-20 x .62 GR5	
13	721-3021	O-Ring	6				

LOWER POWER STEERING





REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	703-3015	0716	Plate, Steering Pump Port	1	9	717-3424		Cylinder, Steering	1
2	703-3189	0716	Bracket, Cylinder Mounting	1	10	717-3442		Pump, Hydraulic Steering	1
3	710-0514		Screw, Hex Cap	2	11	723-0462		Ball Joint, 12MM x 1.75 RH	2
			3/8-16 x 1.0 GR5		12	727-3012		Fitting, 90 Degree Elbow	1
4	710-3138		Screw, Hex Cap	2	13	727-3126		Hose, Front Steering	1
			M8-1.25 x 16MM GR5		14	727-3127		Hose, Rear Steering	1
5	710-3140		Screw, Hex Cap, M6 x 14MM	4	15	727-3159		Fitting, 45 Degree	1
6	712-0431		Nut, Hex Flange Lock, 3/8-16	2	16	736-3084		Washer, Flat, .51 x 1.12 x .060 ..	1
7	712-3103		Nut, Hex Flange Lock, M12 x 1.75	2	17	721-0493		O-Ring, .426 x .566 x .070	2
8	712-3104		Nut, Hex, M12 x 1.75 RH	2	18	736-0329		Washer, Lock, 1/4"	4

HYDRAULIC STEERING PUMP




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	ET-14543-002	Screw, Hex Cap, 1.57" Lg.	1
2	ET-64455-000	Seal Kit	1
		(Includes All Parts Marked Ref. 2)	
3	ET-22991-003	Gerotor Assembly	1
4	ET-22919-005	Spacer, .240 Lg.	1
5	ET-22918-000	Drive	1
6	ET-91999-000	Plug, Manual Check	1
7	ET-285020-000	Ball, Manual Check	1
8	ET-64457-000	Bearing Kit	1
9	ET-64456-000	Spring Kit, Centering	1
10	N/A	Spool, Sleeve and Housing — Not Available as Replacement Parts. Order Complete Steering Pump	

FRONT AXLE




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0426	0637	Axle, RH Steering	1	13	719-3119		Pivot Axle	1
2	603-0427	0637	Axle, LH Steering	1	14	719-3120		Axle Carrier	1
3	710-1039		Screw, Hex Cap	1	15	721-0462		Seal, Grease, 1.31 x 1.0	1
			3/8-24 x 1.0 GR8		16	723-0462		Ball Joint, 12MM x 1.75 RH	1
4	710-3085		Screw, Hex Cap	1	17	723-0463		Ball Joint, 12MM x 1.75 LH	1
			3/8-16 x 3.5 GR5		18	736-0163		Washer, Flat, 1.03 x 1.62 x .030	2
5	711-1141		Shaft, Splined	1	19	736-0247		Washer, Flat, .406 x 1.25	1
6	712-0355		Nut, Hex Center Lock, 3/8-24	2	20	737-3000		Fitting, Lube, 3/16 Drive	3
7	712-0431		Nut, Hex Flange Lock, 3/8-16	1	21	741-0131		Bearing, Ball	1
8	712-3103		Nut, Hex Flange Lock, M12 x 1.75 ..	2	22	741-0363		Bearing, Needle	1
9	712-3104		Nut, Hex - RH, M12 x 1.75	1	23	741-0558		Bearing, Flange	4
10	712-3105		Nut, Hex - LH, M12 x 1.75	1	24	747-3348A		Tie Rod, M12 x1.75 RH & LH	1
11	716-0102		Snap Ring, 1.0 Dia. Shaft	2	25	748-3074		Steering Arm	1
12	716-0188		Retaining Ring, Internal, 2.0	1					

CENTER HYDRAULIC LIFT LINKAGE



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0434	0716	Link, LH Lift	1
2	603-0435		Shaft Assembly, Lift	1
3	603-0456	0716	Link, RH Lift	1
4	711-1206		Pin, Clevis, .5 x 3.75	1
5	712-3083		Nut, Hex Lock, 1/2-13	3
6	714-0147		Pin, Internal Cotter	2
7	716-0102		Snap Ring, 1.0 Dia. Shaft	2
8	717-3423		Cylinder, Center Lift	1
9	727-3135		Hose, Lift	2
	725-0157		Tie, Cable	1
10	731-3215		Indicatpr, Lift Position	1
11	732-0870A		Spring, Compression	1
12	736-0160		Washer, Flat, .536 x .93 x .050	1
13	736-0250		Washer, Flat, 1.0 x 1.7 x .10	1
14	738-0744A		Shoulder Screw	2
15	741-0170		Bearing, Flange w/Flats	2
16	747-3330		Rod, RH Lift	1
17	747-3331A		Rod, LH Lift	1
18	703-3426		Stop Bracket, Lift Rod	1
19	711-1378		Body, Center Check Valve	1
20	711-1379		Housing, Check Valve	1
21	721-3001		O-Ring	1
22	732-0863		Spring, Compression	1
23	732-0979		Spring, Compression	1
24	741-0862		Ball, Detent	1


DRIVESHAFT AND ENGINE CONNECTIONS



DRIVESHAFT AND ENGINE CONNECTIONS


REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	629-3065		Harness, Wire	1
	726-0154		Tie, Pushmount	4
	726-3055		Clip, Cable	2
2	651-3003		Muffler Assembly	1
3	703-2909	0716	Plate, Engine Mounting	1
4	703-2999		Shield, Muffler Heat	1
5	710-0539		Screw, Hex Cap,	4
			3/8-24 x 1.75 GR5	
6	710-0607		Screw, Hex Wash. Hd. Tapp	4
			5/16-18 x .5	
7	710-0757		Screw, Hex Cap,	1
			7/16-20 x 1.5 GR5	
8	710-3288		Screw, Hex Cap Lock	4
			1/4-20 x 1.62	
9	710-3038		Screw, Hex Cap,	6
			5/16-18 x .875 GR5	
10	710-3138		Screw, Hex Cap,	1
			M8 - 1.25 x 16MM GR5	
11	710-3209		Screw, Hex Cap,	4
			M6 - 1.0 x 10MM	
12	710-3288		Screw, Hex Cap, Lock	4
			1/4-20 x 1.62 GR5	
13	712-0429		Nut, Hex Insert Lock, 5/16-18	6
14	712-3054		Nut, Hex Lock, 3/8-24	4
15	718-3093		Shaft, Drive, 27.125 Long	1
16	725-3163		Switch, Key, w/Ground	1
17	725-3164A		Switch, Plunger	1
18	725-3166		Switch, Snap Mount	1
19	726-0205		Clamp, Hose	2
20	731-3166		Boot, Intake	1
21	731-3221		Baffle, Lower Air	1
22	731-3231		Baffle, Upper Air	1
23	736-0142		Washer, Flat, .281 x .50 x .06	4
24	703-3398		Shield, Lower Exhaust	1
25	736-3017		Washer, Flat, .417 x 1.5 x .225	1
26	746-3075		Cable, Throttle Control	1
27	746-3077		Cable, Choke Control	1
28	750-3201		Spacer, Crankshaft	1
29	751-0535-60		Hose, Fuel Line	60in.
30	751-3154		Pipe, Exhaust RH	1
31	751-3155		Pipe, Exhaust LH	1
32	756-3091A		Pulley Half	2
33	756-3099		Pulley, Center	1
34	KH-25-072-04		Stud, M8 - 1.25 x 33MM	4
35	721-0377		Gasket, Exhaust	2
36	712-3086		Nut, Hex, M8 x 1.25	4
37	725-1365		Bulb, Indicator	2
38	725-3243		Fuse, 25 Amp	2
39	721-0342		Gasket, Silicone	1
40	725-1648		Relay	1
41	736-0171		Washer, Lock, 7/16	1
42	759-3868		Cover, Fuse Box	1
43	759-3869		Box, Fuse	1
44	710-3007		Screw, Hex Wash. Hd. Tapp, #12-24 x .38	3
45	725-3191A		Switch, Plunger	1
46	719-3096		Adapter, Drive Shaft	1
47	KH-24-086-16		Screw, Hex Flange, M10 x 1.5 x 90	2

CRANKCASE AND CRANKSHAFT




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-64631	Engine, Complete	1	11	KH-12-422-09	Shim, Camshaft, .0320	AR
	KH-54-522-10	Short Block	1		KH-12-422-13	Shim, Camshaft, .0400	AR
2	KH-24-014-06	Crankshaft (Includes 3)	1		KH-12-422-07	Shim, Camshaft, .0280	AR
3	KH-52-139-09	Plug, Cup	2		KH-12-422-08	Shim, Camshaft, .0300	AR
4	KH-X-75-10	Plug, Hex Head, 3/8 NPTF	2		KH-12-422-10	Shim, Camshaft, .0340	1
5	KH-24-032-01	Seal, Oil	1		KH-12-422-11	Shim, Camshaft, .0360	AR
6	KH-12-380-17	Pin, Dowel Locating	6		KH-12-422-12	Shim, Camshaft, .0380	AR
7	KH-24-067-13	Rod, Connecting, Std	2	12	KH-24-012-10	Camshaft	1
	KH-24-067-14	Rod, Connecting, .010	2	13	KH-12-380-04	Pin, Hitch	1
8	KH-24-874-01	Piston w/Ring Set, Std	2	14	KH-M-0631005	Washer, Plain	1
	KH-24-874-02	Piston w/Ring Set, .010	2	15	KH-12-032-01	Seal, Governor Cross Shaft	1
	KH-24-874-03	Piston w/Ring Set, .020	2	16	KH-X-25-102	Washer, Plain	1
	KH-24-874-14	Piston w/Ring Set, .003	2	17	KH-24-144-01	Shaft, Governor Cross	1
9	KH-24-018-01	Retainer, Piston Pin	4	18	751-3141-12	Hose, Oil Drain	12 in.
10	KH-24-108-01	Ring Set, Std	1	19	751-3140	Drain, Oil	1
	KH-24-108-02	Ring Set, .010	1		751-3142	Cap, Oil Drain	1
	KH-24-108-03	Ring Set, .020	1	20	737-0199	Pipe, Straight	1
				21	737-0272	Elbow, 90 °	1
					KH-24-755-03	Gasket Set	1

OIL PAN/LUBRICATION




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-54-009-07	Plate, Closure Assembly (Includes 2-12, 17)	1
2	KH-24-038-06	Dipstick	1
3	KH-24-123-08	Tube, Dipstick	1
4	KH-24-043-12	Kit, Governor Gear (Includes 5) ..	1
5	KH-12-380-01	Pin, Governor Regulating	1
6	KH-52-448-02	Tab, Locking	1
7	KH-12-144-02	Shaft, Governor Gear	1
8	KH-52-032-08	Seal, Oil (PTO End)	1
9	KH-24-153-08	O-Ring	1
10	KH-24-393-10	Oil Pump Assembly	1
		(Includes 11,12)	
11	KH-24-153-01	O-Ring, Oil Pick-Up	1
12	KH-24-381-04	Pick-Up, Oil	1
13	KH-M-0631005	Washer, Plain	2
14	KH-M-0645025	Screw, Hex Flange M6 x 1 x 25 ..	2
15	KH-12-050-08	Filter, Oil	1
16	KH-24-136-01	Nipple, Oil Filter	1
17	KH-X-75-23	Plug, Pipe 1/8"	2
18	KH-24-086-16	Screw, Hex Flange M8 x 1.25 x 45	9
19	KH-25-099-24	Switch, Pressure	1
20	KH-24-086-17	Screw, Hex Flange M8 x 1.25 x 45	1

CYLINDER HEAD, VALVES AND BREATHER




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-24-755-74	Kit, Valve Cover (Includes 2-3)	1	19	KH-24-599-01	Pivot, Rocker Arm	4
2	KH-24-086-32	Screw, Shoulder	4	20	KH-M-0640034	Screw, Hex Flange M6 x 1 x 34 ..	4
3	KH-24-153-16	O-Ring, Valve Cover	1	21	KH-12-086-16	Screw, Hex Flange M10 x 1.5 x 90	8
4	KH-24-445-01	Strap, Lifting	1	22	KH-24-153-16	O-Ring, Valve Cover	1
5	KH-12-755-03	Kit, Retainer	4	23	KH-24-393-14	Cover, Fuel Pump Valve	1
6	KH-12-173-01	Cap, Valve Spring	4			(Includes 24)	
7	KH-24-089-02	Spring, Valve	4	24	KH-25-155-02	Connector 90°	2
8	KH-235011	Retainer, Spring	4	25	KH-24-086-34	Screw, Shoulder	4
9	KH-24-032-05	Seal, Valve Stem	2	26	KH-24-227-02	Cap Assembly, Oil Fill (Includes 27)	1
10	KH-24-318-09	Head Assembly, #1 Cylinder	1	27	KH-24-153-09	O-Ring	1
11	KH-24-017-01	Valve, Intake (Std.)	2	28	KH-24-402-03	Reed, Breather	1
	KH-24-017-02	Valve, Intake (.25mm)	2	29	KH-12-018-01	Retainer, Breather Reed	1
12	KH-24-016-01	Valve, Exhaust (Std.)	2	30	KH-M-0545010	Screw, Hex Flange M5 x 0.8 x 10	1
	KH-24-016-02	Valve, Exhaust (.25mm)	2	31	KH-24-050-01	Filter, Breather	1
13	KH-24-755-66	Kit, Valve Train (Includes 15,18,19)	1	32	KH-24-033-01	Kit, Breather (Includes 31-33)	1
14	KH-25-351-01	Lifter, Valve	4	33	KH-X-75-23	Plug, Allen Head 1/8 NPTF	1
15	KH-24-411-05	Rod, Push	4	34	KH-24-041-23	Gasket, Breather	1
16	KH-24-041-08	Gasket, Cylinder Head	2	35	KH-24-096-58	Cover, Breather	1
17	KH-24-318-10	Head Assembly, #2 Cylinder	1	36	KH-M0645020	Screw, Hex Flange M6 x 1.0 x 20	4
18	KH-25-186-01	Arm, Rocker	4	37	KH-X-426-9	Clamp, Breather	1
				38	KH-24-326-26	Hose, Breather	1

BLOWER HOUSING AND BAFFLES




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-24-027-20	Housing, Blower (Includes 2-4) ...	1
2	KH-24-100-02	Nut, Plastic	2
3	KH-25-139-16	Plug, Button 9/16"	1
4	KH-24-100-01	Nut, Plastic	3
5	KH-M-0551016	Screw, Hex Flange M5 x 0.8 x 16	1
6	KH-M-0545016	Screw, Hex Flange M5 x 0.8 x 16	3
7	KH-M-0545020	Screw, Hex Flange M5 x 0.8 x 20	4
8	KH-24-146-16	Plate, Backing #2 Side	1
9	KH-M-0645016	Screw, Hex Flange M6 x 1.0 x 16	6
10	KH-24-063-20	Baffle, Cyl. Barrel #2 Side	1
11	KH-24-063-17	Baffle, Valley #2 Side	1
12	KH-M-0545010	Screw, Hex Flange M5 x 0.8 x 10	2
13	KH-24-063-24	Baffle, Valley #1 Side	1
14	KH-24-063-08	Baffle, Cyl. Barrel #1 Side	1
15	KH-24-146-20	Plate, Backing #1 Side	1

IGNITION/ELECTRICAL




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-54-755-09	Kit, 15 Amp Stator (Incl. KH-24-126-71 Bracket)	1	18	KH-24-112-04	Spacer	4
2	KH-M-0548025	Screw, Hex Cap M5 x 0.8 x 25	2	19	KH-X-25-92	Washer, Plain 3/16"	4
3	KH-24-584-01	Module, Ignition	2	20	KH-M-0403025	Screw, Hex Cap M4 x 0.7 x 25	4
4	KH-M-0545020	Screw, Hex Socket Hd. M5 x 0.8 x ..	4	21	KH-24-086-18	Screw, Phillips Hd. 11-16 x 7/8" ..	2
5	KH-24-025-04	Flywheel	1	22	KH-X-25-92	Washer, Plain 3/16"	4
9	KH-X-42-15	Key	1	23	KH-25-403-03	Rectifier-regulator 15 Amp	1
10	KH-12-468-03	Washer, Plain 3/8"	1	24	KH-236602	Connector (3 Contact)	1
11	KH-12-086-14	Screw, Hex Flange M10 x 1.5 x 46 ..	1	25	759-3336	Spark Plug	2
12	KH-24-157-03	Fan	1	26	KH-235173	Clip, Cable	2
13	719-3096	Adapter, Drive Shaft	1	27	KH-X-25-63	Washer, Plain 1/4"	1
14	KH-24-086-16	Screw, Hex Flange M10 x 1.5 x 90 ..	2	28	KH-48-154-02	Clip, Cable	1
16	KH-25-086-47	Bolt, Shoulder, M6 x 1.0 x 16	4		KH-24-176-08	Harness, Wire	1
17	KH-54-755-15	Kit, Grass Screen	1		KH-24-518-12-S	Lead	1
		(Incl. 18-20 and KH-24-113-18)			KH-X-22-11	Washer, Lock, 1/4	1
					KH-X-67-3	Screw, Hex Sems 10-26 x .5	1

STARTING SYSTEM




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-M-0841080	Nut, Hex Flange M8 x 1.25"	1
2	KH-M-0839080	Screw, Hex Flange M8 x 1.25 x 80	2
3	KH-24-098-01	Starter, Solenoid Shift Assembly (Includes 4-18)	1
4	KH-24-081-04	Drive, End Cap	1
5	KH-52-100-10	Nut, Starter	2
6	KH-12-090-10	Lever, Starter Drive	1
7	KH-24-755-84	Kit, Starter repair	1
8	KH-12-239-01	Drive, Pinion	1
9	KH-52-435-02	Solenoid	1
10	KH-52-100-09	Nut, Starter	1
11	KH-12-170-04	Armature, Starter	1
12	KH-12-471-01	Frame	1
13	KH-52-221-01	Kit, Brush & Spring (Includes 15)	1
14	KH-52-323-03	Holder, Brush	1
15	KH-52-089-09	Spring, Brush	4
16	KH-52-168-01	Insulator	1
17	KH-52-211-05	Bolt	2
18	KH-24-301-01	Commutator, End Cap	1

FUEL SYSTEM




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-52-353-20	Line, Fuel 10"	2	16	KH-24-153-02	O-Ring Slow Jet	2
2	KH-X-426-9	Clamp, Hose	4	17	KH-24-337-01	Jet, Slow	1
3	KH-24-853-35	Kit, Carburetor w/Gasket	1	18	KH-24-757-02	Kit, Float Repair	1
4	KH-24-041-06	Gasket, Air Cleaner Base	1	19	KH-24-337-02	Jet, Main	1
5		Carburetor Assembly	1	20	KH-24-089-10	Spring, Idle Adjust Screw	1
6	KH-24-041-17	Gasket, Carburetor	1	21	KH-24-086-10	Screw, Idle Adjusting	1
7	KH-M0651030	Screw, Hex Flange	2	22	KH-24-757-01	Kit, Solenoid (Includes 23-28)	1
8	KH-24-050-02	Filter, Fuel	1	23	KH-24-153-06	O-Ring	1
9	KH-24-353-12	Line, Fuel 11"	1	24	KH-24-521-01	Seat, Solenoid	1
10	KH-24-757-07	Kit, Choke Repair	1	25	KH-24-153-05	O-Ring	1
11	KH-24-173-02	Cap, Choke Lever	1	26	KH-24-153-04	O-Ring	1
12	KH-24-154-01	Clip, Inlet Needle Value	1	27	KH-24-435-01	Solenoid	1
13	KH-24-462-01	Valve, Inlet Needle	1	28	KH-24-086-07	Screw, Solenoid	2
14	KH-24-086-09	Screw, Carburetor Body	4	29	KH-24-368-01	Needle, Idle	1
15	KH-24-041-09	Gasket, Carburetor Body	1	30	KH-24-089-11	Spring, Idle Needle	1
					KH-24-757-03	Kit, Carburetor Repair	1

ENGINE CONTROLS




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-M-0547050	Nut, Hex Lock M5 x 0.8	1	14	KH-41-468-03	Washer, Spring 1/4"	1
2	KH-24-089-03	Spring, Choke Return	1	15	KH-M-0545020	Screw, Hex Flange M5 x 0.8 x 20	1
3	KH-M-0645016	Screw, Hex Flange M6 x 1.0 x 16	4	16	KH-24-089-51-S	Spring, Throttle Limiter	1
4	KH-24-126-56	Bracket, Control	1	17	KH-24-089-15	Spring, Governor	1
5	KH-24-468-01	Washer, Plain 5.5 mm	3	18	KH-M-0642025	Screw, Hex Flange M6 x1.0 x 25	1
6	KH-24-090-07	Lever, Throttle Actuator	1	19	KH-24-090-14	Lever, Governor	1
7	KH-12-237-01	Clamp, Cable,	2	20	KH-M-0641060	Nut, Hex Flange M6 x 1.0"	1
8	KH-M-0545016	Screw, Hex Flange M5 x 0.8 x 16	3	21	KH-24-089-01	Spring, Linkage	1
9	KH-24-090-13	Lever, Throttle Control	1	22	KH-25-158-08	Bushing, Linkage Retaining	1
10	KH-M-0446030	Nut, Hex M4 x 0.7	1	23	KH-24-079-01	Linkage, Throttle	1
11	KH-M-0401030	Screw, Hex Cap M4 x 0.7 x 30 ...	1	24	KH-25-158-11	Bushing, Linkage Retaining	1
12	KH-24-079-02	Linkage, Choke	1	25	KH-24-126-04	Bracket Support	2
13	KH-24-090-05	Lever, Choke	1				

AIR INTAKE




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-54-755-01	Kit, Knob w/Seal (Includes 2,3) ...	1
2	KH-25-341-03	Knob, Cover	1
3	KH-24-153-15	Seal, Air Cleaner Cover Knob	1
4	KH-24-096-31	Cover, Air Cleaner	1
5	KH-12-100-01	Wing Nut	1
6	KH-24-096-01	Cover, Inner Air Cleaner	1
7	KH-24-032-03	Seal, Inner Air Cleaner	1
8	KH-24-083-02	Precleaner, Element	1
9	KH-47-083-03	Element, Air Cleaner	1
10	KH-M-0639016	Screw, Hex Flange M6 x 1.0 x 16	3
11	KH-24-126-21	Bracket, Air Cleaner Base	1
12	KH-24-094-03	Base, Air Cleaner	1
13	KH-M-0651055	Screw, Hex Flange M6 x 1.0 x 55	4
14	KH-25-155-11	Connector, Hose 45°	1
15	KH-X-426-9	Clamp, Hose	2
16	KH-25-353-08	Line, Fuel 5"	1
17	KH-24-164-29	Manifold, Intake	1
18	KH-24-041-01	Gasket, Intake Manifold	2
19	KH-24-041-06	Gasket, Air Cleaner Base	1
20	KH-24-743-08	Kit, Air Cleaner Cover	1
		(Includes 1-4, 11)	

DASH PANEL




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0586		Control Assembly, Throttle/Choke	1	12	712-0397		Wing Nut, 1/4-20 w/Bell Washer	4
2	631-0076		Boot, Tilt Steer	1	13	723-0465		Seal, Screen	2
3	631-3014		Dash Panel	1	14	725-1346		Nut, Ignition Switch, 5/8-32	1
	777120183		Graphic, Monitor Light Cover ..	1	15	725-1347		Cap, Ignition Switch	1
4	759-3476A		Key, Ignition (Set of 2)	1	16	725-3159		Hour Meter	1
5	703-3072		Screen, Dash	1	17	725-3256		Switch, PTO	1
6	703-3162		Plate, PTO Handle	1	18	726-0233		Nut, Push	4
7	710-0134		Carriage Bolt, 1/4-20 x .62	4	19	731-3209		Steering Wheel	1
8	710-0294		Screw, Hex Cap	2	20	731-3210		Cover, Steering Wheel	1
			1/4-20 x .375 GR5		21	731-3241		Handle, PTO Switch	1
9	710-1260A		Screw, Hex Wash. Hd. Tapp	2	22	736-3070		Washer, Flat, .34 x 1.5 x .10	1
			5/16-18 x .75		23	783-0462		Bracket, PTO Switch Retainer ...	1
10	710-3013		Screw, Hex Cap	3	24	629-3069		Harness, PTO Adapter	1
			1/4-20 x .50 GR5						
11	712-0237		Nut, Hex Lock, 5/16-24	1					

PEDESTAL AND CONNECTIONS




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0386A	0637	Pedestal Assembly	1	14	732-0696		Hook, Wire Rectangular	2
2	603-0587		Handle, Tilt	1	15	732-0870		Spring, Compression, .676 x 2.57	1
3	710-0136		Screw, Hex Cap	4	16	732-0932		Spring, Extension	2
			1/4-20 x 1.75 GR5		17	735-0258		Boot, Tilt Wheel Coupling	1
4	710-0597		Screw, Hex Cap	2	18	735-0269		Boot, Shaft Cover	1
			1/4-20 x 1.0 GR5		19	736-3020		Washer, Flat, .271 x .63 x .065 ..	2
5	710-1260A		Screw, Hex Wash. Hd. Tapp	6	20	738-3164		Shaft, Upper Steering	1
			5/16-18 x .75		21	741-3085		Bearing, Sleeve, 1.44 x 1.5 x .812 ..	1
6	711-1180		Shaft, Lower Steering	1	22	747-3327		Rod, Cruise Control	1
7	712-0324		Nut, Hex Insert Lock, 1/4-20	6	23	747-3328		Rod, Parking Brake	1
8	714-0104		Pin, Internal Cotter	2	24	747-3354		Rod, Cruise/Brake Pivot	1
9	716-0115		Ring, Retaining, .56 Dia Shaft	1	25	748-3067		Housing, Tilt Wheel Coupling	1
10	723-0467		Strap, Battery	1	26	748-3068		Coupling Half, Bottom	1
			(includes Ref No. 14)		27	748-3069		Coupling Half, Top	1
11	725-3255		Battery	1	28	748-3083		Index, Tilt Steering	1
12	731-3225		Lever, Park Brake	1	29	748-3084		Block, Tilt Steering	1
13	731-3226		Lever, Cruise	1	30	736-0275		Washer, Flat, .344 x .688 x .065 ..	2

SEAT ASSEMBLY



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	703-3166A	0637	Bracket, Seat Switch	1	10	726-0211		Speed Nut, U-Type, 5/16-18	4
2	703-3173	0637	Bracket, Switch Mounting	1	11	731-3240A		Base, Seat	1
3	703-3431		Track, Seat, w/Latch	1	12	731-3244		Lid, Tlbox	1
4	703-3208		Track, Seat, w/o Latch	1	13	732-1001		Spring, Compression	1
5	710-0748		Screw, Pan Torx Hd., #12-14 x .5	2	14	732-0869A		Spring, Compression	2
6	710-1636		Carriage Bolt, 5/16-18 x .62	4	15	735-0271		Bumper	2
7	710-1669		Screw, Pan Torx Hd. 5/16-18 x 1.0	4	16	747-3357A		Rod, Seat Pivot	1
8	712-3004A		Nut, Hex Flange Lock, 5/16-18	4	17	757- 3010B		Seat, High Back	1
9	714-0507		Pin, Cotter, 3/32 x .75	1		777D03268		Graphic, Reflector	1
						777D01782		Graphic, USA	1
					18	757-3009		Armrest, Seat — Set	1


HOOD, GRILLE AND SIDE PANELS



HOOD, GRILLE AND SIDE PANELS


REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	759-3865	0499	Hood w/Support Rod Assembly	1
2	703-2946	0499	Side Panel, RH	1
3	703-2947	0499	Side Panel, LH	1
4	703-2950	0499	Grille, Series 3000	
	777120314		Graphic, Warning	1
5	703-2984	0716	Support, Grille - RH	1
6	703-2985	0716	Support, Grille - LH	1
7	703-3070	0499	Bracket, Upper Hood	1
8	703-3071		Bracket, Rod Retainer	2
9	703-3101	0716	Support, Hood	1
10	710-0351		Screw, Truss Hd, Tapp, #10-16 x .5	8
11	710-0607		Screw, Hex Wash. Hd. Tapp	10
			5/16-18 x .5	
12	732-0470A		Spring, Extension	1
13	625-0053		Headlight Assembly (Lens glued to reflector)	1
	725-0963		Bulb, Headlight	2
	725-1649		Socket Assembly, Headlight	2
14	726-0139		Nut, U-type Speed, #10	2
15	726-3056		Latch, 1/4 Turn	4
16	731-3227		Mount, Side Panel/Grille RH	1
17	731-3228		Mount, Side Panel/Grille LH	1
18	731-3229		Fastener, Grille Mount	4
19	732-0936		Clip, Spring	4
20	732-0937		Spring, Compression	4
21	736-0400		Washer, Flat, .194 x .62 x .063	2
22	747-3337A		Rod, Upper Hood	1
23	747-3338		Rod, Lower Hood	1
24	777D03265		Graphic, Hood - RH	1
	777D03266		Graphic, Hood - LH	1
25	777D03275		Graphic, 3206	2

FENDER AND RUNNING BOARD




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	625-0023		Light Assembly, Rear RH	1
	725-3262		Bulb Only, Tail Light	1
	725-3263		Bulb Only, Reverse Indicator Light	1
2	625-0024		Light Assembly, Rear LH	1
	725-3262		Bulb Only, Tail Light	1
	725-3263		Bulb Only, Reverse Indicator Light	1
3	703-2977	0716	Running Board	1
	777D00432		Graphic, Direct Drive	1
	777I20094		Graphic, Starting Instructions	1
	777S30017		Graphic, Warning	1
4	703-2978	0716	Fender	1
	777D00431		Graphic, 3000 Series	1
5	710-0602		Screw, Hex Wash. Hd. Tapp	4
			5/16-18 x 1.0	
6	710-3013		Screw, Hex Cap, 1/4-20 x .5 GR5	14
7	712-0324		Nut, Hex Lock, 1/4-20	6
8	726-3057		Clip, Tail Light	4
9	731-3239		Cover, Lift Lever	1
10	731-3253		Flap, Lift Lever	1
11	735-0275		Pad. Floor LH	1
12	735-0276		Pad. Floor RH	1

FRAME AND HITCH PLATE



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0446A	0716	Frame Assembly	1
2	603-0463A	0716	Bumper, Front	1
	777D00585		Graphic	1
3	703-3546	0716	Hitch Plate	1
	777120773		Graphic, Trans. Release	1
	777S30265		Graphic, Trans. Oil	1
4	710-0623		Screw, Hex Wash. Hd. Tapp	4
			3/8-16 x .75	
5	710-0599		Screw, Hex Wash. Hd. Tapp	3
			1/4-20 x .5	
6	710-0617		Screw, Round Hd., 3/8-24	2
7	710-3131		Screw, Hex Cap	2
			1/2-13 x 1.0 GR5	
8	710-1260A		Screw, Hex Wash. Hd. Tapp	4
			5/16-18 x .75	
9	712-3027		Nut, Hex Flange Lock, 1/4-20	2
10	712-3083		Nut, Hex Lock, 1/2-13	2
11	726-0211		Speed Nut, U-Type, 5/16-18	8
12	732-3002		Spring, Extension	1
13	735-0653		Flap, Intk.	1
14	736-0342		Washer, Flat, .283 x .75 x .030	3
15	738-0704		Shoulder Screw, .312 x .18	2
16	747-3336		Rod, Front Latch	1
17	710-3038		Screw, Hex Cap, 5/16-18 x .875	2
18	711-1333		Shaft, Frame Brace	1
19	736-3008		Washer, Flat, .344 x .75 x .12	2
20	703-3417	0716	Bracket, Running Board LH	1
21	703-3418	0716	Bracket, Running Board RH	1


FUEL TANK



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	726-0205	Clamp, Hose	2
2	731-3268	Trim, Tank Protector	1
3	735-0149	Bushing, Rubber	1
4	751-0535-68	Fuel Line	68in.
5	751-3124B	Cap, Fuel	1
6	751-3144A	Tank, Fuel, 4.5 Gallon	1
7	751-3161	Sensor, Low Fuel	1
	751-3146	Grommet	1
8	751-3162A	Fitting, Fuel Pickup	1

FRONT WHEELS

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	734-3053	0499	Rim Assembly, Wheel	2
2	734-3193		Tire, Turf, 16 x 7.5 x 8.0	2
3	737-0224		Lube Fitting	2
4	741-3002		Bearing, Ball	4
5	710-3126		Screw, Hex Cap, 1/2-13 x 1.0 GR5	2
6	731-3020		Hubcap	2
7	734-0255		Valve, Tubeless Air	2
8	736-0179		Washer, Flat, .531 x 1.25 x .1	2
9	736-3095		Washer, Flat, .535 x 1.92 x .060	2



REAR WHEELS

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	734-3194		Tire, Turf, 24 x 10.5 - 12	2
2	634-3037B	0499	Rim Assembly, Wheel	2
3	734-0255		Valve, Tubeless Air	2
4	712-3050		Lug Nut, 7/16-14	8

