Cub Cadet®

Parts Manual

SERIES 3000

Model GT 3200

TABLE OF CONTENTS

DESCRIPTION	PAGE
Axle, Front	12
Baffles, Air	14
Battery	26
Brake Assembly	6
Brake Pedal and Linkage	2
Controls	
Drive Pedals and Linkage	2
Engine Control Cables	14
Cable Handles	25
Hydraulic Lift	10
Dash Panel	25
Driveshaft	14
Electrical	
Harness, Wire	14
Interlock Switches	14
Switches, Dash Panel	25
Engine Mounting	14
Engine	
Air Cleaner	24
Blower Housing	19
Breather	18
Carburetor	22
Control Bracket	23
Crankshaft	16
Cylinder Assembly	16
Cylinder Heads	18
Electrical	20
Flywheel	20
Fuel Pump/Valve Cover	18
Oil Filter	17
Oil Pump	17
Pistons	16
Starter	21
Valves	18

DESCRIPTION	PAGE
Fender and Running Board	30
Frame	32
Fuel Tank	33
Grille	28
Hood	28
Hydrostatic Transmission	8
Hydraulic Lines	10
Hydraulics, Auxiliary	35
Lift Linkage	13
Lift Valve	10
Muffler	14
Pedestal	26
PTO, Front	31
Seat	27
Side Panels	28
Steering	
Lower Steering	11
Pump, Hydraulic Steering	11
Steering Wheel	25
Upper Steering	26
Transmission	
Neutral Linkage	4
Oil Filter	6
Transmission Mounting	4
Transmission Differential	6
Wheels	34

CUB CADET LLC P.O. BOX 361131 CLEVELAND, OHIO 44136-0019 [www.cubcadet.com]

PRINTED IN U.S.A.

FORM NO. 769-04810
(2/09)

BRAKE AND CONTROL PEDALS



BRAKE AND CONTROL PEDALS

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0379		Shaft Assembly, Pedal	1
2	603-0421A		Plate, Disengagement	1
3	603-0437	0637	Cam, Clutch	1
4	603-0445A		Shaft Assembly, Brake	1
5	603-0449B		Shaft Assembly, Reverse	1
6	603-0634		Rod Assembly, Cruise	1
7	703-3012	0637	Link, Pedal Mounting	1
8	703-3020		Bracket, Rod Adjust	1
9	703-3152	0637	Bracket, Switch	2
10	603-0733	0637	Lever, Brake/Diff. Lock	1
11	703-3156A	0637	Link, Brake Pedal	1
12	710-0106		Screw, Hex Cap, 1/4-20 x 1.25 GR5	1
13	710-0599		Screw, Hex Wash. Hd. Tapp 1/4-20 x .5	5
14	710-0623		Screw, Hex Wash. Hd. Tapp 3/8-16 x .75	2
15	710-0642		Screw, Hex Wash. Hd. Tapp 1/4-20 x .75	6
16	710-3005		Screw, Hex Wash. Hd. 3/8-16 x 1.25 GR5	2
17	711-0679A		Pin, Clevis, 3/8 x 2.015	1
18	711-1530		Ferrule, Adjust.	1
19	711-04035		Stud, Actuator	1
20	712-3004A		Nut, Hex Flange Lock, 5/16-18	2
21	912-3027		Nut, Hex Flange Lock, 1/4-20	1
22	912-3058		Nut, Hex Insert Lock, 1/2-20	3
23	912-0429		Nut, Hex Insert Lock, 5/16-18	1
24	914-0104		Pin, Internal Cotter	8
25	914-0145		Pin, Internal Cotter	2
26	714-0147		Pin, Internal Cotter	5
27	915-0114		Pin, Spiral Spring, .25 x 1.5	1
28	731-3247		Pedal, Forward	1
29	731-3248		Pedal, Reverse	1
30	731-3249A		Pedal, Brake	1
31	732-0324		Spring, Compression	1
32	732-0859A		Spring, No Cut Reverse	1
33	732-0871		Spring, Torsion	1
34	732-3118		Spring, Extension, .380 OD x 1.44	2
35	936-0275		Washer, Flat, .344 x .688 x .065	2
36	936-0287		Washer, Flat, .79 x 1.24 x .060	1
37	936-0463		Washer, Flat, .25 x .62	1
38	736-0621		Washer, Wave, .785 x 1.0 x .012	1
39	736-3019		Washer, Flat, .531 x 1.06 x .134	3
40	941-0598		Bearing, Hex Flange	4
41	941-3073		Bearing, Flange	3
42	741-3074		Bearing, Flange	2
43	741-3084		Bearing, Flange	1
44	747-3319		Rod, Rear Control	1
45	747-3320		Rod, Front Control	1
46	747-3324		Rod, Rear Connecting	1
47	747-3353		Rod, Front Connecting	1
48	747-3422		Rod, Brake	1
49	748-04001		Cruise Latch	1
50	748-3080A		Plate, Cruise	1
51	603-0738		Link Assembly, Brake	1
52	736-0418A		Washer, Flat, .341 x 2.25 x .10	1
53	936-0160		Washer, Flat, .53 x .93 x .050	1
54	736-0262		Washer, Flat, .385 x .870 x .092	2
55	912-0431		Nut, Hex Flange Top Lock, 3/8-16 GRF	2

TRANSMISSION MOUNTING AND NEUTRAL LINKAGE



TRANSMISSION MOUNTING AND NEUTRAL LINKAGE

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0698		Bracket, Torque	1
2	703-3478		Plate, Hydro Neutral Return	1
3	703-3477		Link, Neutral Return Bearing	1
4	703-4093		Spring Plate, Hydro Bypass	1
5	703-3175		Bracket, Cable Retainer	1
6	703-3183		Bracket, Pedal Brace	1
7	710-0433		Screw, Hex Cap, 1/4-20 x .625 GR5 Lock	1
8	710-0514		Screw, Hex Cap, 3/8-16 x 1.0 GR5	7
9	710-0599		Screw, Hex Wash. Hd. Tapp, 1/4-20 x .5	2
10	710-0623		Screw, Hex Wash. Hd. Tapp, 3/8-16 x .75	1
11	710-0465		Screw, Hex Cap, 1/2-20 x 4.5 GR5	4
12	710-3015		Screw, Hex Cap, 1/4-20 x .75 GR5	2
13	710-3170		Ball Screw, 5/16-18 x .56	1
14	710-1506		Screw, Hex Wash. Hd. Tapp 5/16-18 x 5.5 GR5	4
15	710-3242		Screw, Set, 5/16 x .5	1
16	712-3059		Nut, Hex Top Lock Jam, 1/2-20	1
17	912-0266		Nut, Hex Ctr. Lock Jam, 3/8-16	3
18	912-0431		Nut, Hex Flange Lock, 3/8-16	4
19	712-3004A		Nut, Hex Flange Lock, 5/16-18	1
20	712-3006		Nut, Hex, 1/4-20	1
21	912-3058		Nut, Hex Insert Lock, 1/2-20	4
22	914-0104		Pin, Internal Cotter	1
23	916-0104		E-Ring, .5 Dia. Shaft	1
24	718-3097		Arm, Hydro	1
25	748-3093		Adapter, Pump	1
26	721-0459		O-Ring, .426 ID x .566 OD x .070	2
27	726-0295		Clamp, Tube	2
28	926-0324		Clamp, Hose	1
29	727-3090		Cylinder, Damper	1
30	727-3139		Tube, Hydro Pickup	1
31	727-3148		Dipstick, Transmission	1
32	731-1480		Plastic Vent	1
33	731-1481		Vent Cap	1
34	731-3297		Fan, Pump	1
35	731-3245		Holder, Dipstick	1
36	731-3250		Pedal, Diff Lock	1
37	932-0429A		Spring, Extension	1
38	735-0279		Grommet	1
39	936-0227		Washer, Flat, .390 x 1.5 x .1	3
40	936-0253		Washer, Bell, .5 x 1.0 x .05	1
41	736-3019		Washer, Flat, .531 x 1.062 x .134	4
42	736-3090		Washer, Flat, .26 x .72 x .06	1
43	737-3092		Fitting, Tube	1
44	938-0347		Spacer, Shoulder	1
45	938-0572		Shoulder Bolt	1
46	941-0155		Bearing, Ball	2
47	741-0491		Bearing, Nylon Flange	2
48	746-3081		Cable, Diff Lock	1
49	747-3424		Rod, Pump Bypass	1
50	747-3366		Shaft, Diff Lock	1
51	750-0434		Spacer, .375 x .5 x 1.02	1
52	750-0497		Spacer, .375 x .624 x .445	2
53	750-3212		Spacer, Hydro, .3223 x .60 x 2.44	2
54	751-0588-8		Fuel Line	8 in.

TRANSMISSION - DIFFERENTIAL



TRANSMISSION - DIFFERENTIAL

REF. NO.	PART NUMBER	DESCRIPTION	QTY
	918-3235	Transmission Assembly Complete - DOES NOT include Ref. Nos. 2, 3, 6, 29, 33, 36, 37 and 56.	1
1	611-3024	Shaft, Differential Actuator	1
2	617-3001	Gear Assembly, Pinion 13T	1
	941-3037	Bearing, Ball	1
3	918-3214	Hydrostatic Transmission Assy. NOTE: For components see separate parts beakdown.	1
4	710-1633	Plug, Drain, M14 x 1.5 x .827	1
5	735-0277A	Grommet, Rubber	1
6	618-3210A	Hub Assembly, Wheel	2
7	911-1308	Axle Shaft, 15.08 Long - RH	1
8	916-0172	Retaining Ring	4
9	717-1119	Gear, Spur, 14T	2
10	618-3155A	Collar Assembly, Diff. Lock	1
11	711-1309	Axle Shaft, 15.08 Long - LH	1
12	716-3018	Retaining Ring	1
13	718-3099B	Housing, Diff. Lock	1
14	732-0856	Spring, Cpmpression	1
15	736-0615	Washer, Thrust, 1.007 x 1.542 x .03	2
16	619-3086	Housing, Diff. Cover	1
17	710-1254	Hex Cap Screw, 3/8-24 x 2.25 GR8	4
18	717-1120	Gear, Differential 10T	4
19	717-1173	Shaft, Cross, .5 x 3.485	1
20	717-1178	Shaft, Cross, Special	2
21	717-1180	Differential Pinion Block	1
22	717-3466	Gear, Spur 60T	1
23	718-3101	Block, Thrust Miter	4
24	736-0558	Washer, Flat, 1.187 x 1.56 x .062	2
25	761-0215	Disc, Brake	1
26	710-1206	Screw, Hex Wash. Hd. Tapp 1/4-20 x 2.375	2
27	710-0751	Hex Cap Screw, 1/4-20 x .62 GR5	1
28	711-1385A	Shaft, Output 9T	1
29	712-0682	Nut, Lock, 7/8-14	2
30	717-3449	Gear, Bevel 54T	1
31	718-3089	Arm, Diff. Lock Actuator	1
32	721-0393	Seal, Oil	1
33	923-3014	Filter, Oil	1
34	750-04269	Spacer Washer, Flat, .51 x 1.5 x .07	1
35	736-0270	Washer, Belleville, .265 x .75 x .062	1
36	736-0619	Washer, Spring	1
37	937-3022	Fitting, Filter Nipple	1
38	735-0279	Grommet	1
39	912-0273	Nut, Hex Insert Lock, 5/16-24	1
40	917-0678	Pad, Brake	2
41	917-0682	Plate, Puck	1
42	732-0925	Spring, Torsion	1
43	736-0371	Washer, Flat, .343 x .88 x .062	1
44	941-0343	Pin, Brake Actuator	2
45	761-0207A	Yoke, Brake	1
46	761-0208	Bracket, Brake Anti-Rotation	1
47	761-3074	Arm, Brake Actuator	1
48	919-3066A	Housing, RH	1
49	619-3067	Housing LH	1
50	716-0180	Retaining Ring	2
51	921-3020A	Seal, Oil	2
52	741-3114	Bearing, Ball	2
53	941-3033A	Bearing, Ball	4
54	710-0573	Screw, Hex Cap Locking 5/16-18 x 1.25 GR5	14
55	721-0523	Seal, Oil 1.0 ID	1
56	721-0519	Seal, Gland O-Ring	1
	759-3958	Sealant, Loctite Black, 5.3 oz. Tube	1
	737-3120	Drive System Fluid Plus - Quart	5.5
	737-3121	Drive System Fluid Plus - Gallon	AR

HYDROSTATIC TRANSMISSION



HYDROSTATIC TRANSMISSION

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	HG-51206	Shaft, Pump	1
2	HG-2000022	Ring, Wire Retaining	4
3	HG-2000038	Ring, Retaining	1
4	HG-2000023	Spacer	1
5	HG-2000032	Bearing, Ball	1
6	HG-2000036	Seal, Lip	1
7	HG-2000037	Seal, Lip	1
8	HG-2000014	Arm, Trunnion	1
9	HG-2000015	Guide, Slot	1
10	HG-2510097	Housing Assembly	1
11	HG-50552	Bearing Assembly, Thrust Ball	2
12	HG-2000024	Washer, Block Thrust	2
13	HG-2000025	Spring, Block	2
14	HG-2510014	Kit, Pump Cylinder Block	1
15	HG-2000007	Shaft, Motor	1
16	N/A	Not Used In This Application	
17	HG-2510098	Kit, Center Section	1
18	HG-50641	Pin	2
19	HG-2000061	Gasket, Center Section	1
20	HG-50203	Swashplate, Variable	1
21	HG-2510013	Kit, Motor Cylinder Block	1
22	HG-9004100-1430	O-Ring	2
23	HG-2510083P	Kit, Auxiliary Charge Pump	1
24	HG-50761	Gerotor & Housing Assembly	1
25	HG-2510050	Kit, Check Valve	1
26	HG-2510034	Kit, Check Valve w/ .044 Orifice	1
27	HG-2510081	Kit, Check Relief	1
28	HG-2510082	Kit, Auxiliary Relief Valve	1
29	HG-2510012	Kit, Bypass Valve	1
30	HG-9005110-4400	Plug, 7/16-20	2
31	HG-2510090	Kit, Auxliary Filter	1
32	HG-50969	Screw, Flange Head Cap, M8 x 60	2
33	HG-9007314-0808	Screw, Socket Head Cap	8
34	HG-9005110-3100	Plug, 5/16-24	1
35	HG-50994	Cover, Filter	1
36	HG-50408	Pin	2
37	HG-2000044	Shim, Charge Pump	1
38	N/A	O-Ring-Order Seal Kit HG-2510010	
39	N/A	O-Ring-Order Seal Kit HG-2510010	
40	N/A	O-Ring-Order Seal Kit HG-2510010	
	HG-2510010	Kit, Overhaul Seal (Includes Ref. Nos. 2, 3, 4, 6, 7, 19, 22, 38, 39 & 40)	1

HYDRAULIC VALVE AND LINES



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	703-1801		Bracket, Valve Mounting	2
2	703-1802		Clamp, Side Valve	2
3	903-1803		Clamp, Double Valve	2
4	703-3154	0637	Bracket, Lift Valve	1
5	710-0597		Screw, Hex Cap 1/4-20 x 1.0 GR5	2
6	710-0641		Screw, Hex Cap 1/4-20 x 2.25 GR5	2
7	710-3013		Screw, Hex Cap 1/4-20 x .50 GR5	5
8	710-3083		Screw, Hex Cap 5/16-18 x 1.375 GR5	1
9	912-0429		Nut, Hex Insert Lock, 5/16-18	1
10	912-3027		Nut, Hex Flange Lock, 1/4-20	4
11	717-3452		Valve, Hydraulic	1
12	721-0492		O-Ring, Backup	4
13	921-3021		O-Ring	6
14	726-0197		Cable Tie	3
15	727-3056		T-Fitting, 9/16-18 Thrd.	1
16	727-3130		Tube, Hydraulic (Pump to Strng)	1
17	727-3131		Tube, Hydraulic (Aux. from Strng)	1
18	727-3162		Tube, Hydraulic (Strng Return)	1
19	727-3160		Tube, Hydraulic (Aux Return)	1
20	727-3161		Tube, Hydraulic (Return to Pump)	1
21	731-3259		Knob, Lift	1
22	935-3007		Rubber Spacer	3
23	741-0491		Bearing, Nylon Flange	2
24	747-3349A		Handle, Center Lift Valve	1
25	748-3081A		Link, Lift	1
26	748-3082		Clamp, Handle	1
27	721-0493		O-Ring, .426 x .566 x .070	3
28	710-0751		Screw, Hex Cap 1/4-20 x .62 GR5	1

LOWER POWER STEERING





REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	703-3015	0637	Plate, Steering Pump Port	1	9	717-3424		Cylinder, Steering	1
2	703-3189	0637	Bracket, Cylinder Mounting	1	10	917-3442		Pump, Hydraulic Steering	1
3	710-0514		Screw, Hex Cap ..... 3/8-16 x 1.0 GR5	2	11	723-0462		Ball Joint, 12MM x 1.75 RH	2
4	710-3138		Screw, Hex Cap ..... M8-1.25 x 16MM GR5	2	12	727-3012		Fitting, 90 Degree Elbow	1
5	710-3140		Screw, Hex Cap, M6 x 14MM	4	13	727-3126		Hose, Front Steering	1
6	912-0431		Nut, Hex Flange Lock, 3/8-16	2	14	727-3127		Hose, Rear Steering	1
7	712-3103		Nut, Hex Flange Lock, M12 x 1.75	2	15	727-3159		Fitting, 45 Degree	1
8	712-3104		Nut, Hex, M12 x 1.75 RH	2	16	736-3084		Washer, Flat, .51 x 1.12 x .060 ..	1
					17	721-0493		O-Ring, .426 x .566 x .070	2
					18	936-0329		Washer, Lock, 1/4"	4



HYDRAULIC STEERING PUMP

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	ET-14543-002	Screw, Hex Cap, 1.57" Lg.	1
2	ET-64455-000	Seal Kit ..... (Includes All Parts Marked Ref. 2	1
3	ET-22991-003P	Gerotor Assembly	1
4	ET-22919-005	Spacer, .240 Lg.	1
5	ET-22918-000	Drive	1
6	ET-9199-000	Plug, Manual Check	1
7	ET-285020-140	Ball, Manual Check	1
8	ET-64457-000	Bearing Kit	1
9	ET-64456-000	Spring Kit, Centering	1
10	N/A	Spool, Sleeve and Housing — Not Available as Replacement Parts. Order Complete Steering Pump	

FRONT AXLE



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0426	0637	Axle, RH Steering	1
2	603-0427	0637	Axle, LH Steering	1
3	710-0591		Screw, Hex Cap Lock 3/8-24 x 1.0 GR5 — Replaces 710-1039 by also ordering 736-0169	1
4	710-3085		Screw, Hex Cap 3/8-16 x 3.5 GR5	1
5	711-1141		Shaft, Splined	1
6	912-0355		Nut, Hex Center Lock, 3/8-24	2
7	912-0431		Nut, Hex Flange Lock, 3/8-16	1
8	712-3103		Nut, Hex Flange Lock, M12 x 1.75	2
9	712-3104		Nut, Hex - RH, M12 x 1.75	1
10	712-3105		Nut, Hex - LH, M12 x 1.75	1
11	916-0102		Snap Ring, 1.0 Dia. Shaft	2
12	716-0188		Retaining Ring, Internal, 2.0	1
13	719-3119A		Pivot Axle	1
14	719-3120		Axle Carrier	1
15	721-0462		Seal, Grease, 1.31 x 1.0	1
16	723-0462		Ball Joint, 12MM x 1.75 RH	1
17	723-0463		Ball Joint, 12MM x 1.75 LH	1
18	936-0163		Washer, Flat, 1.03 x 1.62 x .030	2
19	736-0247		Washer, Flat, .406 x 1.25	1
20	937-3000		Fitting, Lube, 3/16 Drive	3
21	941-0131		Bearing, Ball	1
22	941-0363		Bearing, Needle	1
23	941-0558		Bearing, Flange	4
24	747-3348A		Tie Rod, M12 x1.75 RH & LH	1
25	748-3074		Steering Arm	1
26	936-0169		Washer, Lock, 3/8	1

CENTER HYDRAULIC LIFT LINKAGE



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0434	0637	Link, LH Lift	1
2	603-0435A	0637	Shaft Assembly, Lift	1
3	603-0456	0637	Link, RH Lift	1
4	603-0803		Bracket, Downstop	1
5	703-3426		Stop Bracket, Lift Rod	1
6	703-3797		Arm, Downstop	1
7	748-3103		Disk, Detent	1
8	710-3178		Bolt, Carriage, 3/8-16 x .75	2
9	710-3013		Screw, Hex Cap, 1/4-20 x .5 GR5	2
10	711-1206		Pin, Clevis, .5 x 3.75	1
11	711-1553		Ferrule, Adjustment	1
12	711-1561		Pin, Detent Plunger	1
13	912-0431		Nut, Flange Lock, 3/8-16 GR5	2
14	712-3083		Nut, Hex Lock, 1/2-13	3
15	714-0147		Pin, Internal Cotter	2
16	916-0102		Snap Ring, 1.0 Dia. Shaft	2
17	916-0104		Ring, 'E' Retaining, .5 Dia.	1
18	716-0111		Snap Ring, .875 Dia. Shaft	1
19	717-3518		Cylinder, Center Lift	1
20	920-0236		Knob	1
	777I20243		Graphic, Height Adjust	1
21	727-3135		Hose, Lift	2
	725-0157		Tie, Cable	1
22	931-3215B		Indicator, Lift Position	1
23	732-0437		Spring, Compression	1
24	732-0870A		Spring, Compression	1
25	936-0142		Washer, Flat, .281 x .5 x .063	2
26	936-0160		Washer, Flat, .536 x .93 x .050	1
27	736-0250		Washer. Flat, 1.0 x 1.7 x .10	1
28	938-0744A		Shoulder Screw	2
29	941-0170		Bearing, Flange w/Flats	2
30	747-3330		Rod, RH Lift	1
31	747-3331A		Rod, LH Lift	1
32	747-3437		Screw, Adjustment	1
33	710-0599		Screw, Hex Wash. Hd. Tapp 1/4-20 x .5	2
34	603-0452A	4021	Front Lift bracket Assembly	1
35	912-3015		Nut, 5/8-11, Jam	2
36	712-3016		Nut, 5/8-11, Hex Nylon Lock	2
37	936-0158		Lock Washer, 5/8	2
38	747-3386		Front Lift Rod	1

DRIVESHAFT AND ENGINE CONNECTIONS



DRIVESHAFT AND ENGINE CONNECTIONS

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	929-04107		Harness, Wire	1
	926-0154		Tie, Pushmount	4
	726-3055		Clip, Cable	2
2	651-3003		Muffler Assembly	1
3	703-2909	0637	Plate, Engine Mounting	1
4	703-2999		Shield, Muffler Heat	1
5	710-0539		Screw, Hex Cap, 3/8-24 x 1.75 GR5	4
6	710-0607		Screw, Hex Wash. Hd. Tapp 5/16-18 x .5	4
7	710-0757		Screw, Hex Cap, 7/16-20 x 1.5 GR5	1
8	710-1062		Screw, Hex Cap Lock 1/4-20 x 1.25 GR5	4
9	710-3038		Screw, Hex Cap, 5/16-18 x .875 GR5	6
10	710-0237		Screw, Hex Cap, 5/16 - 24 x .625 GR5	1
11	710-3209		Screw, Hex Cap, M6 - 1.0 x 10MM	4
12	710-3288		Screw, Hex Cap, Lock 1/4-20 x 1.62 GR5	4
13	912-0429		Nut, Hex Insert Lock, 5/16-18	6
14	712-3054		Nut, Hex Lock, 3/8-24	4
15	918-3093		Shaft, Drive, 27.125 Long	1
16	725-2003		Receptacle, 12V Power	1
17	925-3164A		Switch, Plunger (Reverse)	1
18	925-04040		Switch, Snap Mount (Seat)	1
19	726-0205		Clamp, Hose	2
20	731-3166		Boot, Intake	1
21	731-3221A		Baffle, Lower Air	1
22	731-3231A		Baffle, Upper Air	1
23	936-0142		Washer, Flat, .281 x .50 x .06	4
24	703-3398		Shield, Lower Exhaust	1
25	736-3017		Washer, Flat, .417 x 1.5 x .225	1
26	746-3075		Cable, Throttle Control	1
27	746-3077		Cable, Choke Control	1
28	750-3357		Spacer, Crankshaft	1
29	751-10349-54		Hose, Fuel Line	54in.
30	751-3154		Pipe, Exhaust RH	1
31	751-3155		Pipe, Exhaust LH	1
32	756-3091A		Pulley Half	2
33	756-3099		Pulley, Center	1
34	KH-25-072-04		Stud, M8 - 1.25 x 33MM	4
35	KH-24-041-49-S		Gasket, Exhaust	2
36	712-3086		Nut, Hex, M8 x 1.25	4
37	725-3243		Fuse, 25 Amp	2
	725-04008		Fuse, 5 Amp	1
38	921-0342		Gasket, Silicone	1
39	925-1648		Relay	1
40	936-0171		Washer, Lock, 7/16	1
41	959-3868		Cover, Fuse Box	1
42	959-3869		Box, Fuse	1
43	710-3007		Screw, Hex Wash. Hd. Tapp, #12-24 x .38	3
44	925-3191A		Switch, Plunger (Brake)	1
45	719-3096		Adapter, Drive Shaft	1
46	KH-24-086-17-S		Screw, Hex Flange, M10 x 1.5 x 90	2
47	751-3199		Hose, Vacuum	1

CRANKCASE AND CRANKSHAFT



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-730104	Engine, Complete	1
	KH-24-522-340	Short Block	1
	KH-24-782-32	Miniblock	1
2	KH-24-014-06	Crankshaft (Includes 3)	1
3	KH-52-139-09	Plug, Cup	2
4	KH-25-139-57-S	Plug, Hex Head, 3/8 NPTF	2
5	KH-24-032-01	Seal, Oil	1
6	KH-24-380-13-S	Pin, Locating	6
7	KH-24-067-13	Rod, Connecting, Std	2
	KH-24-067-14	Rod, Connecting, .010	2
8	KH-24-874-08-S	Piston w/Ring Set, Std	2
	KH-24-874-20-S	Piston w/Ring Set, .010	2
	KH-24-874-21-S	Piston w/Ring Set, .020	2
	KH-24-874-16-S	Piston w/Ring Set, .003	2
9	KH-24-018-01	Retainer, Piston Pin	4
10	KH-24-108-05-S	Ring Set, Std & .003	1
11	KH-24-012-16-S	Camshaft	1

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
12	KH-12-422-09	Shim, Camshaft, .0320	AR
	KH-12-422-13	Shim, Camshaft, .0400	AR
	KH-12-422-07	Shim, Camshaft, .0280	AR
	KH-12-422-08	Shim, Camshaft, .0300	AR
	KH-12-422-10	Shim, Camshaft, .0340	1
	KH-12-422-11	Shim, Camshaft, .0360	AR
	KH-12-422-12	Shim, Camshaft, .0380	AR
13	KH-24-018-09-S	Ring, Retainer	1
14	KH-M-931010-S	Washer, Nylon	1
15	KH-28-032-09-S	Seal, Governor Cross Shaft	1
16	KH-24-468-15-S	Washer, Plain	1
17	KH-24-144-38-S	Shaft, Governor Cross	1
18	751-3141-12	Hose, Oil Drain	12 in.
19	751-10517	Drain, Oil	1
20	737-0199	Pipe, Straight	1
21	737-0272	Elbow, 90 °	1
	KH-24-755-113-S	Gasket Set	1

OIL PAN/LUBRICATION



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-54-009-07	Plate, Closure Assembly ..... (Includes 2-15)	1
2	KH-24-038-10-S	Dipstick	1
3	KH-24-755-121-S	Tube, Dipstick (Includes 2)	1
4	KH-24-043-12	Kit, Governor Gear (Includes 5) ..	1
5	KH-12-380-01	Pin, Governor Regulating	1
6	KH-24-448-02-S	Tab, Locking	1
7	KH-12-144-02	Shaft, Governor Gear	1
8	KH-52-032-08	Seal, Oil (PTO End)	1
9	KH-25-139-60-S	Plug, Pipe 1/8”	2
10	KH-24-153-08	O-Ring	1
11	KH-24-393-37-S	Oil Pump Assembly ..... (Includes 12,13)	1
12	KH-24-153-01	O-Ring, Oil Pick-Up	1
13	KH-24-381-04	Pick-Up, Oil	1
14	KH-M-0631005	Washer, Plain	2
15	KH-M-0645025	Screw, Hex Flange M6 x 1 x 25 ..	2
16	KH-12-050-08	Filter, Oil	1
17	KH-24-380-13-S	Pin, Locating	1
18	KH-24-041-29-S	Gasket, Adapter	1
19	KH-24-594-24-S	Cooler, Oil	1
20	KH-24-136-05-S	Nipple, Oil Filter	1
21	KH-25-099-24	Switch, Pressure	1
22	KH-24-086-16	Screw, Hex Flange M8 x 1.25 x 45	9
23	KH-24-086-17	Screw, Hex Flange M8 x 1.25 x 45	1

CYLINDER HEAD, VALVES AND BREATHER



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-24-755-141-S	Kit, Valve Cover (Includes 2-3)	1
2	KH-M-0651030	Screw, Hx. Flng, M6 x 1.0 x 30	8
3	KH-24-153-28-S	O-Ring, Valve Cover	2
4	KH-24-445-01	Strap, Lifting	1
5	KH-12-755-03	Kit, Retainer	4
6	KH-12-173-01	Cap, Valve Spring	4
7	KH-24-089-02	Spring, Valve	4
8	KH-235011	Retainer, Spring	4
9	KH-66-032-05	Seal, Valve Stem	2
10	KH-24-318-65-S	Kit, Cylinder Head #1	1
11	KH-24-017-01	Valve, Intake Std	2
	KH-24-017-02	Valve, Intake, .25mm	2
12	KH-24-016-01	Valve, Exhaust Std	2
	KH-24-016-02	Valve, Exhaust, .25mm	2
13	KH-24-755-66	Kit, Valve Train (Incl. 15,18,19)	1
14	KH-25-351-01	Lifter, Valve	4
15	KH-24-411-05	Rod, Push	4
16	KH-24-841-03-S	Kit, Cylinder Head Gasket (Includes 22, 25)	2
17	KH-24-318-66-S	Kit, Cylinder Head #2	1
18	KH-25-186-01	Arm, Rocker	4

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
19	KH-24-599-01	Pivot, Rocker Arm	4
20	KH-66-086-07-S	Screw, Hex Flng, M6 x 1.0 x 34	4
21	KH-24-072-09-S	Stud, Cylinder Head	8
22	KH-24-486-16-S	Washer, Flat	8
23	KH-24-559-08-S	Cover Kit, Fuel Pump Valve (Includes 2,3, 24,26)	1
24	KH-25-294-11-S	Connector, 90°	2
25	KH-24-100-10-S	Nut, Hex Flange, M8 x 1.25	8
26	KH-24-227-02	Cap Assembly, Oil Fill (Incl. 27)	1
27	KH-24-153-09	O-Ring	1
28	KH-24-402-03	Reed, Breather	1
29	KH-66-018-04-S	Retainer, Breather Reed	1
30	KH-M-0545010	Screw, Hex Flng, M5 x 0.8 x 10	1
31	KH-24-050-01	Filter, Breather	1
32	KH-24-033-01	Kit, Breather (Includes 33-35)	1
33	KH-24-041-51	Gasket, Breather	1
34	KH-24-096-86-S	Cover, Breather	1
35	KH-M-0645020	Screw, Hex Flng M6 x 1.0 x 20	4
36	KH-25-237-14-S	Clamp, Breather	1
37	KH-24-326-26	Hose, Breather	1

BLOWER HOUSING AND BAFFLES



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-24-027-163-S	Housing, Blower (Includes 2)	1
2	KH-25-313-06-S	Grommet	1
3	KH-M-0551016	Screw, Hex Flange M5 x 0.8 x 16	1
4	KH-M-0545016	Screw, Hex Flange M5 x 0.8 x 16	3
5	KH-M-0545020	Screw, Hex Flange M5 x 0.8 x 20	4
6	KH-24-146-18-S	Plate, Backing #2 Side	1
7	KH-M-0645016	Screw, Hex Flange M6 x 1.0 x 16	6
8	KH-24-063-20	Baffle, Cyl. Barrel #2 Side	1
9	KH-24-063-70-S	Baffle, Valley #2 Side	1
10	KH-M-0545010	Screw, Hex Flange M5 x 0.8 x 10	2
11	KH-24-063-59-S	Baffle, Valley #1 Side	1
12	KH-24-063-58-S	Baffle, Cyl. Barrel #1 Side	1
13	KH-24-146-20	Plate, Backing #1 Side	1

IGNITION/ELECTRICAL



REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-54-755-09	Stator Kit, 15 Amp (Incl. Ref #2)	1	16	KH-24-086-18	Screw Phillips Hd., #11-16 x .875	2
2	KH-24-126-139-S	Bracket, Stator Wire	1	17	KH-X-25-92	Washer, Plain	4
3	KH-M-0548025	Screw, Stator Mtg. M5 x .8 x 25	2	18	KH-41-403-09	Regulator - Rectifier	1
4	KH-24-584-01-S	Module, Ignition	2	19	KH-236602	Connector, Regulator-Rectifier	1
5	KH-M-545020-S	Screw, Module M5 x .8 x 20	4	20	KH-235173	Clip, Cable	1
6	KH-24-025-01	Flywheel Assembly	1	21	KH-X-25-63	Washer, Plain 1/4"	1
7	KH-X-42-15	Key	1	22	KH-48-154-02	Clip, Cable	1
8	KH-12-468-03	Washer, Flywheel Mtg. Screw .	1	23	KH-47-154-01	Clip, Cable	1
9	KH-12-086-14	Screw, Flywhl Mtg, M10x1.5 x 46	1	24	759-3336	Spark Plug	2
10	KH-24-157-07-S	Fan	1	†	KH-25-086-91-S	Screw, Set	2
11	KH-25-086-47	Bolt, Shoulder	4	†	KH-24-176-08	Harness, Wire	1
12	KH-54-755-15	Screen, Grass	1	†	KH-25-454-03-S	Tie, Wire	2
13	KH-24-112-04	Spacer	4	†	KH-24-126-137-S	Bracket, Ground Strap	1
14	KH-X-25-92	Washer, Plain	4	†	KH-25-468-07-S	Washer	1
15	KH-M-403025	Screw, Hex Hd. M4 x 0.7 x 25 .	4	†	KH-25-086-117-S	Screw, Hex Sems	1

STARTING SYSTEM



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-M-0841080	Nut, Hex Flange M8 x 1.25"	1
2	KH-M-839080	Screw, Hex Flange M8 x 1.25 x 80	2
3	KH-25-098-09-S	Starter, Solenoid Shift Assembly (Includes 4-8)	1
4	KH-25-435-05-S	Kit, Solenoid	1
5	KH-25-755-33-S	Kit, Pinion Drive (Includes 7)	1
6	KH-25-221-01-S	Kit, Brush	1
7	KH-25-141-05-S	Ring, Retainer	1
8	KH-25-086-113-S	Screw, External Torx Hd.	3

FUEL SYSTEM



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-52-353-20	Line, Fuel 10”	2
2	KH-25-237-14-S	Clamp, Hose	4
3	KH-24-853-91-S	Kit, Carburetor w/Gasket ..... (Includes 4-6)	1
4	KH-24-041-52-S	Gasket, Carburetor	1
5		Carburetor Assembly ..... Not available separately	1
6	KH-24-041-14	Gasket, Air Cleaner Base	1
7	KH-M-651025-S	Screw, Hex Flange, M6 x 1.0 x 25	2
8	KH-24-050-10-S	Filter, Fuel	1
9	KH-24-353-12	Line, Fuel 11”	1
		Not Illustrated	
	KH-24-518-24-S	Lead, Ground	1
	KH-24-757-01	Kit, Solenoid — Includes Solenoid Screw [qty. 2], O-Ring , O-Ring , O-Ring , Solenoid Assembly & Solenoid Seat.	1
	KH-24-757-02	Kit, Float Repair — Includes Carburetor Body Gasket, Float Screw, Float Assembly and Float Shaft.	1
	KH-24-757-03	Kit, Carburetor Repair — Includes Carburetor Gasket; Carburetor Body Screw; Idle Needle Spring; U-Ring; Slow Jet O-Ring; Main Jet Screw O-Ring; Solenoid O-Rings; Inlet Needle Valve Clip; Idle Needle and Inlet Needle Valve.	1
	KH-24-757-07	Kit, Choke Repair — Includes Choke Plate Screws; Choke Spring; Choke Lever; Choke Shaft; Choke Plate; Choke Bushings; and Choke Lever Cap.	1
	KH-24-757-08-S	Kit, Repair, (accelerator pump diaphragm)	1
	KH-24-757-09-S	Kit, Repair, (accelerator pump seal & bushing)	1

ENGINE CONTROLS



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-M-0547050	Nut, Hex Lock M5 x 0.8	1
2	KH-24-089-03	Spring, Choke Return	1
3	KH-M-545016-S	Screw, Hex Flange M5 x 0.8 x 16	3
4	KH-M-645016-S	Screw, Hex Flange M6 x 1.0 x 16	4
5	KH-24-126-56	Bracket, Control	1
6	KH-X-20-1-S	Washer, Lock	1
7	KH-M-541050-S	Nut, Hex Flange	1
8	KH-24-468-01	Washer , Plain 5.5mm	3
9	KH-24-090-07	Lever, Throttle Actuator	1
10	KH-12-237-01	Clamp, Cable	2
11	KH-24-090-13	Lever, Throttle Control	1
12	KH-M-446030-S	Nut, Hex M4 x 0.7	1
13	KH-M-401030-S	Screw, Hex Cap M4 x 0.7 x30	1
14	KH-24-079-21-S	Linkage, Choke	1
15	KH-24-090-05	Lever, Choke	1
16	KH-41-468-03	Washer, Spring 1/4"	1
17	KH-M-0545020	Screw, Hex Flange M5 x 0,.8 x 20	1
18	KH-24-089-51-S	Spring, Throttle Limiter	1
19	KH-24-089-46-S	Spring, Governor	1
20	KH-24-211-03-S	Screw, Round Hd. Square Neck	1
21	KH-24-090-33-S	Lever, Governor	1
22	KH-M-0641060	Nut, Hex Flange M6 x 1.0	1
23	KH-25-158-08	Bushing, Linkage Retaining	1
24	KH-24-089-01	Spring, Linkage	1
25	KH-25-158-11	Bushing, Linkage Retaining	1
26	KH-24-079-01	Linkage, Throttle	1

AIR INTAKE



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KH-24-743-08	Kit, Air Cleaner Cover (Incl 2-5, 12)	1
2	KH-54-755-01	Kit, Knob w/Seal (Incl. Ref #3,4)	1
3	KH-25-341-04-S	Knob, Cover	1
4	KH-24-153-20-S	Seal, Air Cleaner Cover Knob	1
5	KH-24-096-69-S	Cover, Air Cleaner	1
6	KH-12-100-01	Wing Nut	1
7	KH-24-096-01	Cover, Inner Air Cleaner	1
8	KH-24-032-03	Seal, Inner Air Cleaner	1
9	KH-24-083-02	Precleaner, Element	1
10	KH-47-083-03	Element, Air Cleaner	1
11	KH-24-086-53-S	Screw, Hex Flange, M6 x 1.0 x16	3
12	KH-24-126-21	Bracket, Air Cleaner Base	1
13	KH-24-094-39-S	Base, Air Cleaner	1
14	KH-24-041-06	Gasket, Air Cleaner Base	1
15	KH-15-353-02-S	Line, Fuel 17”	1
16	KH-25-237-14-S	Clamp, Hose	2
17	KH-25-155-02-S	Connector, Hose 45°	1
18	KH-24-164-55-S	Manifold, Intake (Includes19,20)	1
19	KH-24-153-27-S	O-Ring, Intake Manifold	2
20	KH-24-041-53-S	Gasket, Carburetor	1
21	KH-M-0651040-S	Screw, Hex Flange, M6 x 1.0 x 40	4
22	KH-24-126-130-S	Bracket, Air Cleaner Base	1
23	KH-M-0545010	Screw, Hex Flng, M5 x 0.8 x 10	2

DASH PANEL



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0586		Control Ass'y, Throttle/Choke	1
2	631-0076		Boot, Tilt Steer	1
3	631-04144		Dash Panel	1
	777I22466		Graphic, Monitor Light Cover	1
4	703-3072		Screen, Dash	1
5	710-0134		Carriage Bolt, 1/4-20 x .62	4
6	710-1260A		Screw, Hex Wash. Hd. Tapp 5/16-18 x .75	2
7	710-3013		Screw, Hex Cap 1/4-20 x .50 GR5	3
8	912-0237		Nut, Hex Lock, 5/16-24	1
9	912-0397		Wing Nut, 1/4-20 w/Bell Washer	4
10	925-04036C		Meter, Indicator / Hour	1
11	925-04227B		Switch, Key/Module	1
12	725-04258		Switch, PTO	1
13	925-04288		Light, Yellow LED	1
14	726-0233		Nut, Push	4
15	731-0511-37		Seal, Screen (Cut to fit screen)	2
16	731-3209		Steering Wheel	1
17	731-3210		Cover, Steering Wheel	1
18	936-04062		Washer, Flat, .34 x 1.5 x .10	1
19	936-0514		Washer, Flat, .885 x 1.85 x .06	1
20	748-0176		Bearing, Flange, .63ID x .62 Lg	1
21	925-2054A		Key, Ignition	2

PEDESTAL AND CONNECTIONS



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-04248	0637	Pedestal Assembly	1
2	603-0587		Handle, Tilt	1
	777I20861		Graphic, Tilt Steering Handle	1
3	710-0136		Screw, Hex Cap 1/4-20 x 1.75 GR5	4
4	710-0597		Screw, Hex Cap 1/4-20 x 1.0 GR5	2
5	710-1260A		Screw, Hex Wash. Hd. Tapp 5/16-18 x .75	6
6	711-1180		Shaft, Lower Steering	1
7	712-0324		Nut, Hex Insert Lock, 1/4-20	6
8	914-0104		Pin, Internal Cotter	2
9	916-0115		Ring, Retaining, .56 Dia Shaft	1
10	723-0467		Strap, Battery (Includes Ref No. 14)	1
11	925-3255		Battery	1
12	731-3225		Lever, Park Brake	1
13	731-3226		Lever, Cruise	1

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
14	732-0696		Hook, Wire Rectangular	2
15	732-0870A		Spring, Compression, .676 x 2.57	1
16	732-0932		Spring, Extension	2
17	735-0258		Boot, Tilt Wheel Coupling	1
18	735-0269		Boot, Shaft Cover	1
19	936-3020		Washer, Flat, .271 x .63 x .065	2
20	738-3164		Shaft, Upper Steering	1
21	741-3085		Bearing, Sleeve, 1.44 x 1.5 x .812	1
22	747-3327		Rod, Cruise Control	1
23	747-3328		Rod, Parking Brake	1
24	747-3354		Rod, Cruise/Brake Pivot	1
25	748-3067		Housing, Tilt Wheel Coupling	1
26	748-3068		Coupling Half, Bottom	1
27	748-3069		Coupling Half, Top	1
28	748-3083A		Index, Tilt Steering	1
29	748-3084A		Block, Tilt Steering	1
30	936-0275		Washer, Flat, .344 x .688 x .065	2
31	725-0157		Cable Tie, Harness	4

SEAT ASSEMBLY



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	703-05121	0637	Bracket, Seat Spring Support .	1
2	703-3208		Track, Seat, w/o Latch	1
3	703-3431		Track, Seat, w/Latch	1
4	703-3888	0637	Bracket, Seat	2
5	710-0759		Screw, Hex Wash. Hd. ..... 5/16-18 x .625	4
6	710-0971		Screw, Phil Pan Hd. Mach ..... 5/16-18 x 1.0	2
7	710-1636		Carriage Bolt, 5/16-18 x .62	4
8	710-1669		Screw, Pan Torx Hd. ..... 5/16-18 x 1.0	4
9	712-3004A		Nut, Hex Flange Lock, 5/16-18	4
10	914-0507		Pin, Cotter, 3/32 x .75	1
11	926-0211		Speed Nut, U-Type, 5/16-18 ...	4
12	731-3240B		Base, Seat	1
13	731-3244		Lid, Tlbx	1
14	732-1163		Spring, Compression	2
15	735-0271A		Bumper	2
16	747-3357A		Rod, Seat Pivot	1
17	757- 04031		Seat, High Back	1
18	731-05674		Cap, Spring	2

HOOD, GRILLE AND SIDE PANELS



HOOD, GRILLE AND SIDE PANELS

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	925-04001A		Headlight Assembly	1
	925-0963		Bulb, Headlight	2
	925-1649		Socket Assembly, Headlight	2
2	703-05000A	0499	Hood	1
	777S30538		Graphic, Hot Surface	1
	777X42533		Graphic, Replacement Parts	1
3	703-2946	0499	Side Panel, RH	1
	777D08867		Graphic, GT 3200	1
	777X41482		Graphic, Lift Hood	1
4	703-2947	0499	Side Panel, LH	1
	777D08867		Graphic, GT 3200	1
	777X41482		Graphic, Lift Hood	1
5	703-2950	0499	Grille, Series 3000	
	777I20314		Graphic, Warning	1
6	703-2984	0637	Support, Grille - RH	1
7	703-2985	0637	Support, Grille - LH	1
8	703-3070B	0499	Bracket, Upper Hood	1
	777S30538		Graphic, Hot Surface	1
9	703-3071		Bracket, Rod Retainer	2
10	703-3101B	0637	Support, Hood	1
11	710-0351		Screw, Truss Hd, Tapp, #10-16 x .5	6
12	710-0607		Screw, Hex Wash. Hd. Tapp 5/16-18 x .5	10
13	710-0924		Screw, Phil. Pan Hd. 1/4-20 x .75	4
14	726-3054		Nut, U Type Speed, 1/4-20	4
15	726-0139		Nut, U-type Speed, #10	2
16	726-3056		Latch, 1/4 Turn	4
17	731-3227		Mount, Side Panel/Grille RH	1
18	731-3228		Mount, Side Panel/Grille LH	1
19	732-0936		Clip, Spring	4
20	732-0937		Spring, Compression	4
21	732-1178		Spring, Hood Latch	1
22	936-0400		Washer, Flat, .194 x .62 x .063	2
23	747-3478		Rod, Upper Hood	1
24	747-3338		Rod, Lower Hood	1
25	777D09725		Graphic, Hood - RH	1
	777D09724		Graphic, Hood - LH	1
26	731-3221A		Baffle, Lower Air	1
27	703-4088	0637	Bracket, Hood Latch Support	2
28	710-0136		Screw, Hex Cap, 1/4-20 x 1.75 GR5	1
29	710-0599		Screw, Hex Wash Hd Tapp, 1/4-14 x .5	6
30	712-3051		Nut, Hex Top Lock, 1/4-20	1
31	731-3232		Roller, Hood Latch	1
32	736-0342		Washer, Flat, .283 x .75 x .030	1
33	747-04085		Rod, Hood Support	1
34	728-0117		Rivet, Pop, .125 OD	4
35	710-0651		Screw, Hex Tapp, #10-16 x .625	2

FENDER AND RUNNING BOARD



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	703-3622	4021	Running Board	1
	777S32517		Graphic, Danger Reveres Mow .	1
	777I22483		Graphic, Starting Instructions	1
	777I20859		Graphic, Height Adjustment	1
2	703-05571	4021	Fender	1
	777D07684		Graphic, 3000 Series	1
	777D08642		Graphic, Reflector LH	1
	777D08643		Graphic, Reflector RH	1
3	710-0602		Screw, Hex Wash. Hd. Tapp ..... 5/16-18 x 1.0	4
4	710-3013		Screw, Hex Cap, 1/4-20 x .5 GR5	10
5	712-0324		Nut, Hex Lock, 1/4-20	6
6	731-3239		Cover, Lift Lever	1
7	731-3253		Flap, Lift Lever	1
8	735-0275		Pad. Floor LH	1
9	735-0276		Pad. Floor RH	1

FRONT PTO



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0442	0637	Bracket, Idler	1
2	759-3867		Bracket Assembly, Brake	1
3	703-3009	0637	Bracket, PTO Mounting	1
4	703-3165	0637	Belt Guide	1
5	703-3812	0637	Bracket, Solenoid Mounting	1
6	710-0237		Screw, Hex Cap 5/16-24 x .625 GR5	2
7	710-0514		Screw, Hex Cap 3/8-16 x 1.0 GR5	2
8	710-0520		Screw, Hex Cap 3/8-16 x 1.5 GR5	1
9	710-0623		Screw, Hex Wash. Hd. Tapp 3/8-16 x .75	2
10	710-0748		Screw, Phil. Hd. Tapp #12-14 x .5	2
11	711-1196		Ferrule, Brake Adjustment	1
12	712-0324		Nut, Hex Insert Lock, 1/4-20	1
13	912-0431		Nut, Flange Lock, 3/8-16	7
14	914-0104		Pin, Internal Cotter	2
15	916-0102		Snap Ring, 1.0 Dia Shaft	1
16	725-3278		Solenoid, Vacuum Actuator	1
17	932-0470A		Spring, Extension, .530 x 4.74	1
18	738-0213		Shoulder Screw, .498 x 1.45	2
19	938-3056		Shoulder Screw	2
20	741-0491		Bearing, Nylon Flange	4
21	747-3322		Rod, PTO Brake	1
22	750-0526		Spacer, .380 x .5 x .265	2
23	951-3173		Vacuum Actuator	1
24	954-3084		V-Belt, A-Section x 37.63 (Set of two belts)	1
25	756-3092		Pulley, PTO Drive. 6.75-Double	1
26	756-3094		Pulley, Flat Idler, 4.0	1

FRAME AND HITCH PLATE



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-04253		Frame Assembly	1
2	603-04252	0637	Bumper, Front	1
	777D06086		Graphic, Series 3000	1
3	703-3546	4021	Hitch Plate	1
	777I20773		Graphic, Trans. Release	1
	777S30265		Graphic, Trans. Oil	1
4	710-0623		Screw, Hex Wash. Hd. Tapp 3/8-16 x .75	4
5	710-0599		Screw, Hex Wash. Hd. Tapp 1/4-20 x .5	3
6	710-0617		Screw, Round Hd., 3/8-24	2
7	710-3131		Screw, Hex Cap 1/2-13 x 1.0 GR5	2
8	710-1260A		Screw, Hex Wash. Hd. Tapp 5/16-18 x .75	4
9	912-3027		Nut, Hex Flange Lock, 1/4-20	2
10	712-3083		Nut, Hex Lock, 1/2-13	2
11	926-0211		Speed Nut, U-Type, 5/16-18	8
12	932-3002		Spring, Extension	1
13	735-0653		Flap, Intk.	1
14	736-0342		Washer, Flat, .283 x .75 x .030	3
15	938-0704		Shoulder Screw, .312 x .18	2
16	747-3336		Rod, Front Latch	1
17	710-3015		Screw, Hex Cap, 1/4-20 x .75 GR5	2
18	647-04010		Shaft, Tank Constraint	1
19	936-0329		Washer, Lock, 1/4	2
20	703-3417	4021	Bracket, Running Board LH	1
21	703-3418	4021	Bracket, Running Board RH	1

FUEL TANK



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	726-0205	Clamp, Hose	2
2	731-3268-4	Trim, Tank Protector	4 in.
3	935-0149	Bushing, Rubber	1
4	751-10349-54	Fuel Line	54in.
5	951-3124D	Cap, Fuel	1
6	651-3002A	Tank Assembly, Fuel, Includes Ref. Nos. 3,5,7 and 8	1
7	751-3161	Sensor, Low Fuel	1
	735-0699	Grommet	1
8	751-3162A	Fitting, Fuel Pickup	1

FRONT WHEELS

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	934-3078A	0499	Rim Assembly, Wheel	2
2	734-3193A	0901	Tire, Turf, 16 x 7.5 x 8.0	2
3	737-0224		Lube Fitting	2
4	941-3002		Bearing, Ball	4
5	710-3126		Screw, Hex Cap, 1/2-13 x 1.0 GR5	2
6	931-3020		Hubcap	2
7	934-0255		Valve, Tubeless Air	2
8	936-0179		Washer, Flat, .531 x 1.25 x .1	2
9	936-3095		Washer, Flat, .535 x 1.92 x .060	2



REAR WHEELS

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	734-3194A	0901	Tire, Turf, 24 x 10.5 - 12	2
2	634-3053	0499	Rim Assembly, Wheel	2
3	934-0255		Valve, Tubeless Air	2
4	712-3050		Lug Nut, 7/16-14	8



AUXILIARY HYDRAULICS



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	747-3350A		Handle Ass'y. (Includes Ref. 29)	1
2	903-1803		Clamp, Double Valve	1
3	703-3154	0637	Bracket, Lift Valve	1
4	703-3442	0637	Bulkhead, Fitting	1
5	710-0528		Screw, Hex Cap, 5/16-18 x 1.25 GR5	1
6	710-3025		Screw, Hex Cap, 5/16-18 x .625 GR5	2
7	710-3013		Screw, Hex Cap, 1/4-20 x .5 GR5	3
8	710-1058		Screw, Hex Cap, 1/4-20 x 4.0 GR2	4
9	710-3015		Screw, Hex Cap, 1/4-20 x .75 GR5	1
10	711-3294		Fitting, Union	1
11	912-0291		Nut, Hex Lock, 1/4-20 GRA	2
12	912-0429		Nut, Hex Nylon Insert Lock, 5/16-18 GR5	3
13	712-3035		Nut, Hex Jam, 9/16-18 GR5	4
14	717-3452		Valve, Hydro	1
15	921-3021		O-Ring	5
16	721-0492		O-Ring	5
17	727-3141		Tube, Hydraulic (Up)	1
18	727-3142		Tube, Hydraulic (Down)	1
19	727-3145		Fitting, Bulkhead	2
20	727-3023		Coulpling, Male	1
21	727-3170		Fitting, Pipe Nipple	2
22	727-3024		Cap, Protective Coupling	1
23	727-3014		Coupling, Female	1
24	731-3022		Cap, Protective Coupling	1
25	935-3007		Pad, Bumper	1
26	741-0491		Bearing, Nylon Flange	2
27	748-3082		Clamp, Handle	1
28	748-3081A		Link, Lift	1
29	731-3259		Grip, Handle	1