

FAST START

GUIDE


FAST START

GUIDE

Read and understand all instruction, warning and danger labels.

1


PTO



Place **PTO (Blade Engage) Lever** in **Off** position.


OFF ON

2




Move **Control Levers** out to neutral position.

3




Engage **Parking Brake Lever**.

NO
↑
PARK
BRAKE
(P)
↓
OFF



4



Off On


Pull **Choke** up to full choke position.

5



Move **Throttle** to **Rabbit** (fast) position.

6



Insert key and turn to **Start** position. Release after engine starts.

Didn't Start?

Is the battery connected? Fresh gas in the unit?
See Operator's Manual for additional troubleshooting tips.

Stopping the Unit

- Put **PTO** (blade engage) lever in the **Off** position.
- Move **Drive Control** levers to neutral position.
- Engage **Parking Brake**.
- Move **Throttle Control** Lever to **Turtle** (slow) position.
- Turn key counterclockwise to Stop position and remove.



IMPORTANT: READ OPERATOR'S MANUAL THOROUGHLY AND FOLLOW THE SAFE OPERATION PRACTICES BEFORE OPERATING .

