

Cub Cadet®

ILLUSTRATED PARTS MANUAL



Z-Force S 48, 54 & 60-inch Cutting Decks

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

To The Owner

Thank You

Thank you for purchasing a Cub Cadet Zero-Turn Tractor. It was carefully engineered to provide excellent performance when properly operated and maintained.

All information in this manual is relative to the most recent product information available at the time of printing. Please be aware that this Illustrated Part's Manual may cover a range of product specifications for various models.

Components listed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and equipment without notice and without incurring obligation.

Throughout this manual, all references to *right* (RH) and *left* (LH) are observed from the operating position.

Table of Contents

Axles	16	Labels	33-35
Battery	8	Meter, Systems Indicator	8
Consoles	10	Muffler	10
Engine, Kawasaki FR651-S05	36-49	PTO Switch	8
Engine, Kawasaki FR691-S05	50-62	Seat	14
Engine, Kawasaki FR730-S05	64-77	Solenoid	8
Mower Deck, 48-inch	22	Steering Linkage	18
Mower Deck, 54-inch	24	Steering Assembly	20
Mower Deck, 60-inch	26	Steering Wheel	16
Pedal Controls	18	Switches, Interlock	8
Drive System (48-inch)	4	Throttle Control	10
Drive System (54 & 60-inch)	6	Transmission (48-inch)	4
Electrical Schematic	32	Transmission (54 & 60-inch)	6
Engine Accessories	10	Transmission, RH	28
Frame	14	Transmission, LH	30
Fuel Tank	12-13	Wheels, Front & Rear	9
Deck Lift Handle/Linkage	3		

Record Product Information

To ease in ordering replacement parts, please locate the model plate on the equipment and record the information in the provided area to the right. You can locate the model plate by looking beneath the seat.

MODEL NUMBER

--	--	--	--	--	--	--	--	--	--	--

SERIAL NUMBER


--	--	--	--	--	--	--	--	--	--	--

Painted Parts

When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXXX-0637). Please refer to the table below for current color codes:

0637	Black
4021	Yellow (Cub Cadet)
0499	Beige (Cub Cadet)


0685	Blue (Cub Cadet)
0691	Black Jack (Cub Cadet Commercial)



Ref	Part Number	Description
1	738-04489	Shoulder Screw, .625 x .830
2	747-05353A	Lift Rod
3	02005535	Spacer, .632 x .877 x .548
4	603-04867	Rock Shaft Assembly
5	603-04881	Foot Lift Pivot Assembly
6	603-04880	Lift Pedal Assembly
7	603-04771	Deck Lift Adjustment Bracket
8	703-07489A	Lift Link Bracket
9	703-07540A	Index Plate
10	703-07552A	Pedal Link Plate
11	703-07554	Mid Link Plate
12	703-07639	Front Hanger Rod Bracket Mount
13	703-07663A	Deck Up Stop Bracket
14	703-07672	Deck Lift Square Spacer
15	703-08215	Mid-Angled Link Plate
16	710-0514	Hex Screw, 3/8-16 x 1.00
17	710-0528	Hex Screw, 5/16-18 x 1.25
18	710-1008	Hex Washer Screw, 3/8-16 x 1.875
19	710-3011	Hex Screw, 3/8-16 x 2.25
20	710-3032	Hex Screw, 1/2-13 x 1.25

Ref	Part Number	Description
21	711-05500A	Lock Pin, .375 x 1.90
22	712-04065	Flange Lock Nut, 3/8-16
23	912-3048	Jam Nut, 1/2-13
24	712-3083	Hex Lock Nut, 1/2-13
25	914-0145	Click Pin, .092 x 1.64
26	916-0231	E-Type Ring, .750
27	917-04074	Adjustable Deck Gear
28	731-06848	Spacer, .791 x .950 x 1.35
29	936-0119	Lock Washer, 5/16
30	736-0343	Flat Washer, .330 x 1.25 x .120
31	738-04337A	Shoulder Spacer, .9790 x .2025
32	738-04428	Shoulder Spacer, 3/8-16 x .562 x .360
33	738-1014	Shoulder Screw, .500 x 1.25 x 3/8-16
34	741-04499	Hex Flange Bearing, .752
35	750-04584	Spacer, .375 x .625 x 1.340
36	731-08265	Spacer, .790 x .950 x .730
37	750-05362	Spacer, .632 x .877 x .281
38	712-0459	Flange Lock Nut, 7/16-20
39	912-3000	Hex Lock Nut, 3/8-16
40	732-04829	Torsion Spring, .75

Drive System, 48" Deck




Drive System, 48" Deck

Ref.	Part Number	Description
1	603-04770	Brake Shaft Assembly
2	603-04773	Brake Handle Assembly
3	918-04868A	LH Transmission Assembly
4	918-04869A	RH Transmission Assembly
5	703-07318C	Idler Bracket
6	703-07367	RH Mount Bracket
7	703-07368	LH Mount Bracket
8	703-07484	Idler Mount Plate
9	703-07593	Shaft Mount Bracket
10	710-0176	Hex Screw, 5/16-18 x 2.75
11	710-05278	Hex Screw, 5/16-18 x 2.25
12	710-04484	Hex Washer Screw, 5/16-18 x .750
13	710-0514	Hex Screw, 3/8-16 x 1.00
14	710-3011	Hex Screw, 3/8-16 x 2.25
15	710-3038	Hex Screw, 5/16-18 x .875
16	911-0832	Ferrule, 3/8-24 x .375
17	711-1530	Ferrule, .325 x .312
18	712-04063	Flange Lock Nut, 5/16-18
19	712-04064	Flange Lock Nut, 1/4-20
20	712-04065	Flange Lock Nut, 3/8-16
21	914-0104	Cotter Pin, .072 x 1.13
22	914-0507	Cotter Pin, 3/32 x .750
23	731-04735	Selector Handle

Ref.	Part Number	Description
24	932-0209	Extension Spring, .48 x 2.03
25	732-04229	Extension Spring, .75 x 6.02
26	732-0437	Compression Spring, .34 x 1.0
27	732-04688A	Transmission Bypass Lever Wire
28	732-0963	Extension Spring, .50 x 6.37
29	732-0994	Extension Spring, .500 x 7.0
30	936-0175	Spring Washer, .265 x .562 x .025
31	936-0314	Thrust Washer, .375 x .70 x .030
32	738-04392	Shoulder Spacer, .884 x .190
33	738-04192B	Rod, .405 x 14.00
34	938-0533	Shoulder Screw, .498 x 1.635
35	741-0491	Flange Bearing, .500 x .34
36	747-05139A	Disengage Brake Rod
37	747-05277A	LH Keeper Rod
38	747-05278A	RH Keeper Rod
39	750-05347	Transmission Spacer, 9.40
40	954-04250	Belt
41	756-04224	Flat Idler Pulley, 2.75
42	912-0411	Hex Lock Nut, 5/16-24
43	936-0264	Flat Washer, .330 x .630 x .064
44	714-04040	Bow-Tie Cotter Pin
45	712-0459	Flange Lock Nut, 7/16-20


Drive System, 54" & 60" Deck



Drive System, 54" & 60" Deck


Ref.	Part Number	Description
1	02001111	Hose Clamp, 1/2"
2	603-04757	Brake Shaft Assembly
3	603-04773	Brake Handle Assembly
4	918-05005A	RH Transmission Assembly
5	918-05006A	LH Transmission Assembly
6	931-04223	Expansion Tank Assembly
7	961-04053	LH Brake Assembly
8	961-04054	RH Brake Assembly
9	703-07318C	Idler Bracket
10	703-07367	RH Mount Bracket
11	703-07368	LH Mount Bracket
12	703-07484	Idler Mount Plate
13	703-07593	Shaft Mount Bracket
14	710-0176	Hex Screw, 5/16-18 x 2.75
15	710-05278	Hex Screw, 5/16-24 x 2.25
16	710-04484	Hex Washer Screw, 5/16-18 x .750
17	710-0514	Hex Screw, 3/8-16 x 1.00
18	710-0599	Hex Washer Screw, 1/4-20 x .500
19	710-3011	Hex Screw, 3/8-16 x 2.25
20	710-3038	Hex Screw, 5/16-18 x .875
21	911-0832	Ferrule, 3/8-24 x .375
22	711-1530	Ferrule, .325 x .312
23	712-04063	Flange Lock Nut, 5/16-18
24	712-04064	Flange Lock Nut, 1/4-20
25	712-04065	Flange Lock Nut, 3/8-16
26	914-0104	Cotter Pin, .072 x 1.13
27	914-0507	Cotter Pin, 3/32 x .750

Ref.	Part Number	Description
28	917-0678	Brake Pad
29	731-04735	Selector Handle
30	932-0209	Extension Spring, .48 x 2.03
31	732-0335	Compression Spring, .405 x 1.17
32	732-04229	Extension Spring, .75 x 6.02
33	732-04688A	Transmission Bypass Lever Wire
34	732-0963	Extension Spring, .50 x .637
35	732-0994	Extension Spring, .500 x 7.0
36	936-0175	Spring Washer, .265 x .562 x .025
37	936-0314	Thrust Washer, .375 x .70 x .030
38	738-04392	Shoulder Spacer, .884 x .190
39	738-04192B	Rod, .405 x 14.00
40	938-0533	Shoulder Screw, .498 x 1.635
41	741-0491	Flange Bearing, .500 x .34
42	747-05139A	Disenage Brake Rod
43	747-05277A	LH Rod Keeper
44	747-05278A	RH Rod Keeper
45	750-05346	Transmission Spacer, 10.5
46	751-11531	Fuel Hose, 1/2 x 12.00
47	954-04250	Belt
48	756-04224	Flat Idler Pulley, 2.75
49	761-04061	Brake Disc
50	912-0411	Hex Lock Nut, 5/16-24
51	936-0264	Flat Washer, .330 x .630 x .064
52	714-04040	Bow-Tie Cotter Pin
53	712-0459	Flange Lock Nut, 7/16-20




Ref	Part Number	Description
1	02003037	Electrical Conduit Clip, ½
2	925-05189	Harness Assembly (<i>Not Shown</i>)
3	710-0599	Hex Washer Screw, ¼-20 x 0.500
4	712-0271	Sems Nut, ¼-20
5	712-04064	Flange Lock Nut, ¼-20
6	725-0157	Cable Tie, ¾ x .05 x 7.4
7	925-04022B	Hour Meter/Service Minder
8	925-04175	Electric PTO Switch
9	925-04227B	Key Switch

Ref	Part Number	Description
10	725-04363	Interlock Switch
11	725-04439	Solenoid
12	725-05208	Seat Switch
13	925-1745A	Universal Key Switch
14	925-1707D	Battery
15	783-0349	Battery Tray
16	726-0475	Clamp, 1.0
17	738-04237A	Shoulder Screw, #10-32 x .500
18	747-05505	Battery Rod




Ref.	Part Number	Description
1	634-04128	Wheel Assy., 18 x 9.5-8 (48" Decks)
—	N/A	Wheel Assy., 20 x 10.00 x 10 (54" & 60" Decks)
—	934-0255	Valve, Tubeless
—	934-0246A-0499	Rim, Only (54" & 60" Decks)
—	734-1873-0901	Tire Only 20 x 10 x 8 (54" & 60" Decks)
2	918-04317	Wheel Hub Assembly (48" only)
3	634-04629	Complete Wheel Assy., 13 x 5.0-6
4	710-04652	Hex Screw, 1/2-20 x 7.25
5	710-3119	Hex Screw, 3/8-16 x .750 (48" Only)
6	712-3050	Lug Nut, 7/16-14
7	912-3058	Hex Lock Nut, 1/2-20
8	936-0227	Flat Washer, .390 x 1.500 x .134 (48" Only)
9	750-05351	Spacer, .51 x .75 x 1.25
10	750-05572	Spacer, .76 x 1.23 x 1.57

Engine Connections




Ref.	Part Number	Description
1	710-05361	Hex Screw, M10-1.5 x .500 x 8.8
2	703-07543B	Hitch Bracket
3	703-07570	Bumper Bracket
4	703-07583B	RH Lower Console
5	703-07584	RH Upper Console
6	703-07585	LH Upper Console
7	703-07588B	LH Lower Console
8	703-07627A	Parking Brake Lock Bracket
9	703-07658	Muffler Mount Bracket
10	703-08000	Belt Keeper Bracket
11	703-08313B	Left Tank Support Bracket
12	703-08314B	Right Tank Support Bracket
13	703-08599	Tank Support Bracket RH
14	703-08598	Tank Support Bracket LH
15	710-0227	Hex Washer Screw, #8-18 x 0.500
16	710-04043	Hex Flange Screw, 5/16-18
17	710-04048	Hex Flange, 5/16-18 x 1.0
18	710-04484	Hex Washer Screw, 5/16-18 x .750
19	710-1315	Tap Screw, 3/8-16 x 1.25
20	710-05070	Screw, 1/4-20 x .5
21	710-05074	Screw, 1/4-20 x 1.0
22	726-0475	Clamp, 1.0
23	710-3217	Machine Screw, #8-32 x 0.375
24	712-0142	Hex Nut, #8-32
25	712-0271	Sems Nut, 1/4-20
26	712-04063	Flange Lock Nut, 5/16-18
27	712-04064	Flange Lock Nut, 1/4-20
28	912-3005	Flange Lock Nut, 3/8-16
29	756-04415	Electric PTO Engine Pulley
30	726-0205	Hose Clamp, .490
31	726-0272	Clamp, 5/16
32	731-06593	Throttle Knob
33	751-10291A	Oil Drain Extension Hose
34	746-04057	Choke Cable
35	946-1086	Throttle Cable, 39.0 x .62
36	751-10349	Fuel Hose, 1/4
37	737-04138	Oil Drain
38	751-11471	Kohler Twin Muffler
39	751-11424A	Long Muffler Deflector

Fuel Tank




Ref.	Part Number	Description
1	735-04065	Fuel Tank Bushing
2	735-04081	Rubber Grommet
3	951-04287A	Fuel Tank
4	751-11986B	Fuel Pickup Fitting
5	751-12118	Rollover Valve
6	951-12193A	Fuel Cap
7	951-12559	Utility Bin
8	751-12089-51	Vent Hose



Ref.	Part Number	Description
1	735-04065	Fuel Tank Bushing
2	735-04081	Rubber Grommet
3	951-04287A	Fuel Tank
4	751-11986B	Fuel Pickup Fitting
5	751-12118	Rollover Valve
6	951-12193A	Fuel Cap
7	710-04043	Hex Flange Screw, 5/16-18
8	712-04063	Flange Lock Nut, 5/16-18
9	951-10589	Carbon Cannister
10	951-10590	Cannister Filter Vent
11	951-10610	Cannister Adapter Bracket
12	751-10750	Low Perm Fuel Host 7/32 Yellow
13	951-12559	Utility Bin
14	751-12089-51	Vent Hose 3/16 Red


Seat & Frame



*54/60" Deck Units Only.

Ref.	Part Number	Description
1	603-04717C	Frame Assembly (46" & 48" Decks)
	603-04862A	Frame Assembly (54" & 60" Decks)
2	703-07315A	Floor Board
3	603-04805	Seat Box Assembly
4	703-07473A	Transmission Cover
5	710-04484	Hex Washer Screw, 5/16-18 x .750
6	710-05070	Screw, 1/4-20 x .5
7	710-05074	Screw, 1/4-20 x 1.0
8	710-3015	Hex Screw, 1/4-20 x .75
9	712-04092	Speed Nut, U-Type 1/4-20
10	935-0199A	Rubber Bumper
11	750-05373	Spacer, .281 x .750 x .680
12	712-04064	Flange Lock Nut, 1/4-20 (54/60" Deck Units only)
13	703-07668C	Seat Base
14	710-04043	Hex Washer Screw, 5/16-18
15	712-04063	Flange Lock Nut, 5/16-18
16	732-04561	Comp. Spring, 1.71 x 3.735 x .238
17	938-0296	Shoulder Screw, 5/16-18 x .437 x .268
18	757-04136	Seat w/ Armrests

Steering Column & Axles




Steering Column & Axles

Ref.	Part Number	Description
1	02004124	Socket Head Screw, 5/16-18 x 1.00
2	603-04924	Caster Bracket Assembly
3	603-04949	Upper Steering Column Assembly
4	603-04767	Tilt Release Pedal Assembly
5	603-04772	Front Bumper Frame Assembly
6	631-04008A	Steering Wheel Assembly
7	703-07349	Lower Steering Wheel Column
8	703-07352	Lower Column Cover
9	703-07424	Tilt Steering Pedal
10	703-07486	Front Frame Brace
11	703-07611	Damper Pivot Lower Bracket
12	703-07613A	Tilt Action Lever
13	703-07624A	Steering Mount Box Plate
14	710-0376	Hex Screw, 5/16-18 x 1.00
15	710-0395	Hex Screw, 5/16-18 x 2.25
16	710-0411	Hex Screw, 3/8-16 x 4.00
17	710-04484	Hex Washer Screw, 5/16-18 x .750
18	710-05070	Screw, 1/4-20 x .5
19	710-0514	Hex Screw, 3/8-16 x 1.00
20	710-0528	Hex Screw, 5/16-18 x 1.25
21	710-1260A	Hex Washer Screw, 5/16-18 x 750
22	710-1880	Hex Screw, 5/16-18 x .75
23	710-3085	Hex Screw, 3/8-16 x 3.50
24	710-3119	Hex Screw, 3/8-16 x .750
25	711-05281	Pivot Gear Steering Shaft
26	712-04063	Flange Lock Nut, 5/16-18

Ref.	Part Number	Description
27	712-04065	Flange Lock Nut, 3/8-16
28	912-3009	Hex Lock Nut, 5/16-18
29	914-0507	Cotter Pin, 3/32 x .750
30	916-0231	E-Ring, .750
31	717-04692	13-Tooth Variable Spur Gear
32	717-04696	12-Tooth Variable Gear
33	917-04998	Steering Shaft
34	719-04544	RH Flange Bearing Caster Pivot Axle
35	719-04545	LH Flange Bearing Caster Pivot Axle
36	927-04320	Locking Damper Cylinder, 80MM
37	731-04532B	Steering Wheel Cover
38	731-07358B	Column Cover
39	931-3020	Hubcap
40	748-04139	Steering Shaft Block
41	736-0242	Bell Washer, .340 x .872 x .060
42	736-0343	Flat Washer, .330 x 1.25 x .120
43	936-0447	Wave Washer, 1.5 x 1.0 x .029
44	936-0504	Wave Washer, .510 x .750 x .017
45	736-3040	Flat Washer, .406 x 1.92 x .060
46	736-3078	Flat Washer, .344 x 1.00 x .063
47	738-0143	Shoulder Bolt, 3/8-16 x .496 x .336
48	938-0148	Shoulder Screw, 3/8-16 x .50 x .66
49	741-0338	Flange Bearing, 3/4 x .52
50	741-04488	Flange Bearing, 1.0001 x 1.25
51	948-0209	Flange Bearing, .630 x 1.50

Steering Linkage & Pedal Controls




Steering Linkage & Pedal Controls

Ref.	Part Number	Description
1	02003170	Spacer, 344 x .500 x .375
2	603-04752	Forward Pedal Assembly
3	603-04849	Reverse Pedal Rod
4	603-04850	Forward Bracket Assembly
5	918-04846B	Steering Assembly
6	703-07465	Reverse Bearing Bracket
7	703-07466B	Control Bracket
8	703-07567	Steering Link Plate
9	703-07642D	Pedal Mount Bracket
10	703-07675A	Reverse Pedal Bracket
11	703-07786A	Pedal Mount Plate Support Bracket
12	710-0106	Hex Head Screw, 1/4-20 x 1.25
13	710-0206	Hex Screw, 1/4-20 x .875
14	710-04484	Hex Washer Screw, 5/16-18 x .750
15	710-0599	Hex Washer Screw, 1/4-20 x .500
16	710-0604A	Hex Washer Screw, 5/16-18 x .625
17	710-0703	Carriage Screw, 1/4-20 x .75
18	710-0932	Carriage Screw, 1/4-20 x 1.00
19	710-3005	Hex Screw, 3/8-16 x 1.25
20	710-3119	Hex Screw, 3/8-16 x .750
21	711-0173	Clevis Pin, .375 x .969
22	711-05270	Rod, 3/8 x 5.0
23	711-05274	Neutral Adjustment Hub
24	711-05364	Adjustment Ferrule, 1/4-28 x 1.000
25	712-04064	Flange Lock Nut, 1/4-20

Ref.	Part Number	Description
26	712-04065	Flange Lock Nut, 3/8-16
27	912-0411	Hex Lock Nut, 5/16-24
28	912-3000	Hex Lock Nut, 3/8-16
29	912-3001	Jam Nut, 3/8-24
30	714-04040	Bow-Tie Cotter Pin, 72
31	914-0507	Cotter Pin, 3/32 x .750
32	723-04080	Female Ball-Joint
33	731-07616	Pivot Arm, LH
	731-07615	Pivot Arm, RH
34	932-04262	Extension Spring, .429 x 2.515
35	735-04113	Reverse Foot Pad
36	936-0142	Flat Washer, .281 x .500 x .063
37	936-0176	Flat Washer, .265 x .938 x .120
38	736-04299	Flat Washer, .281 x .50 x .04
39	936-0864	Thrust Washer, .375 x .812 x .060
40	738-0322A	Shoulder Screw, .625 x .217
41	738-04409	Shoulder Screw, .500 x .434
42	738-04427	Shoulder Screw, 375 x .48
43	738-0509	Shoulder Screw, .500 x 1.825
44	941-0225	Hex Flange Bearing
45	741-04280	Ball Bearing, .25 x .6875 x .25
46	741-3065B	Hex Flange Bearing, .628
47	747-05311	Hydro Control Rod
48	747-05397	Hydro Link Rod

Steering Assembly




Steering Assembly

Ref.	Part Number	Description
1	603-04776	Cam Plate Assembly
2	603-04777	Neutral Bracket
3	617-04047	LH Steering Gear Assembly
4	617-04048	RH Steering Gear Assembly
5	741-04203	Flange Bearing, .5 x .700
6	715-04071	Dowel Pin, 3/16 x 1/2
7	919-04261B	Upper Steering Housing
8	710-0642	Hex Washer Screw, 1/4-20 x 0.750
9	710-0778	Hex Washer Screw, 1/4-20 x 1.500
10	710-0788	Hex Washer Screw, 1/4-20 x 1.000
11	710-3015	Hex Screw, 1/4-20 x .75
12	912-0291	Flange Lock Nut, 1/4-20
13	712-04065	Flange Lock Nut, 3/8-16
14	916-0114	Retaining Ring, .56
15	717-04318	Pinion Gear, 7-Tooth
16	717-04730	Synchro Rack Gear
17	917-04732A	Steering Gear, 53-Tooth
18	718-04644	Hydro Steering Cam
19	721-04186	O-Ring, .625 x .07
20	732-04523	Compression Spring, .531 x 1.25
21	936-0274	Flat Washer, 1.01 x 1.75 x .172
22	736-04237	Flat Washer, .508 x 1.325 x .040
23	736-04498	Flat Washer, .260 x .455 x .048

Ref.	Part Number	Description
24	736-0615	Thrust Washer, 1.007 x 1.542 x .03
25	911-04587A	Steering Shaft
26	938-0145	Shoulder Screw, 3/8-16 x .500 x .835
27	741-04204	Sleeve Bearing, .437 x .3425
28	741-04206A	Sleeve Bearing, .623 x .5025 x .800
29	741-04235	Flange Bearing, .625 x .875
30	741-04257	Rack Caster Bearing
31	741-04280	Ball Bearing, .25 x .6875 x .25
32	741-0747	Ball Bearing, .5625 x 1.375 x .4375
33	750-05369	Spacer, .260 x .375 x .75
34	647-04191	Arm Asm, Lh, Hydro, Vert
35	647-04192	Arm Asm, Rh, Hydro, Vert
36	647-04222	Cam Asm, Lh, Painted
37	647-04224	Cam Asm, Rh, Painted
38	715-0120	Pin, Spirol, 3/16 X 1.00, Hd
39	916-0102	Ring, Snap, 1.0 Dia Shaft
40	917-04330	Gear, Steering, 26t
41	718-04757	Tube, Cam, Speed
42	732-04711	Spr, Wave, M, 24.22x32x1.98, Gap
43	936-0256	Wash, Flat, .635x.930x.033, Ht
44	741-04231	Brg, Sleeve, 1.2 Od X 1.00 Id
45	919-04262B	Lower Steering Housing


48" Deck



Ref.	Part Number	Description
1	00011861	Hex Screw, 3/8-16 x 2.50
2	737-3004	Grease Fitting, 1/4-28 x .788
3	00014270	Carriage Bolt, 3/8-16 x 2.00
4	737-04345	Straight Grease Fitting, 1/4-28
5	736-3052	Washer, .406 x 1.00 x .105
6	710-3022	Hex Screw, 3/8-16 x 2.75
7	750-05553	Spacer, .812 x 1.47 x .218
8	01003269	Washer, .438 x 1.75 x .250
9	01009253	Washer, .390 x 1.50 x .122
10	02000762	Flange Hex TT Screw, 5/16-18 x 1.00
11	02002629	Hook Ext. Spring, .75 x 7.89 x .14
12	02004195	45-Degree Spring Mount Bracket
13	02005017	Hi-Lift Blade, 17.0
14	96606	Retainer Hook Bracket
15	918-04426	Deck Spindle Assembly
16	703-07616A	48" Plate Idler
17	703-07641	Spring Mount Plate
18	710-0514	Hex Screw, 3/8-16 x 1.00
19	710-05173A	Hex Screw, 3/4-16 x 6.00
20	710-0599	Hex Washer TT Screw, 1/4-20 x .500
21	710-3157A	Hex Head Screw, 7/16-20 x 3.25
22	710-3168	Carriage Bolt, 3/8-16 x 1.00
23	712-04065	Flange Lock Nut, 3/8-16
24	712-3078	Flange Lock Nut, 3/4-16
25	917-04552	Electric PTO Clutch
26	932-0594A	Extension Spring, .91 x 7.33
27	936-0171	Lock Washer, 7/16
28	736-3040	Flat Washer, .406 x 1.92 x .060
29	738-04392	Shoulder Spacer, .884 x .190


Ref.	Part Number	Description
30	747-04530	Belt Keeper Rod
31	747-04938	Belt Keeper Rod
32	748-3065A	Deck Spindle Spacer
33	750-05420	Spindle Spacer, .76 x 2.0 x 1.1
34	954-04044A	Hi-Performance Belt
35	756-04129B	Idler Pulley
36	756-3089	V-Type Pulley
37	00022560	Centerlock Flange Nut, 3/8-16
38	710-3178	Carriage Bolt, 3/8-16 x .75
39	01006693P	Fab Deck Deflector Chute
40	01006748	Deflector Chute Bracket
41	01008225	Push Nut Retainer,
42	01008644	Fab Deck Chute Finger Guard
43	02001235	Micro Chute Baffle
44	980-00106A	48" Welded Deck
45	703-07346A	48" Standard Baffle
46	703-07664A	48" LH Belt Cover
47	703-07685A	48" RH Belt Cover
48	710-04484	Hex Washer Screw, 5/16-18 x .750
49	710-3168	Carriage Bolt, 3/8-16 x .75
50	912-0641	Hex Nut, M16-1.5
51	921-04041	Water Nozzle Adapter
52	732-04797	Torsion Spring
53	734-04155	Deck Wheel, 5.0
54	936-0760	Lock Washer, 17 x 23.8 x 1.95
55	737-04003D	Water Deck Nozzle
56	938-3056	Shoulder Bolt, 3/8-16 x .496 x 2.50
57	747-3384	Chute Deflector Rod

54" Deck




Ref.	Part Number	Description	Ref.	Part Number	Description
1	00010958	Washer, .532 x 1.06 x .094	37	710-0560	Carriage Bolt, $\frac{3}{8}$ -18 x 1.75
2	737-3004	Grease Fitting, $\frac{1}{4}$ -28 x .788	38	710-3157A	Hex Screw, $\frac{7}{16}$ -20 x 3.50
3	00022560	Counterlock Flange Nut, $\frac{3}{8}$ -16	39	710-3178	Carriage Bolt, $\frac{3}{8}$ -16 x .75
4	737-04345	Straight Grease Fitting, $\frac{1}{4}$ -28	40	712-04065	Flange Lock Nut, $\frac{3}{8}$ -16
5	750-3193	Spacer, .390 x .620 x 3.04	41	912-0641	Hex Nut, M16-1.5
6	750-05553	Spacer, .812 x 1.47 x .218	42	912-3058	Nut, Hexlk, 1/2-20, Gr2, Nylon
7	01006693P	Fab Deck Deflector Chute	43	712-3078	Flange Lock Nut, $\frac{3}{4}$ -16
8	01006748	Deflector Chute Bracket	44	917-04754	Electric PTO Clutch
9	01006961	Hex Screw, $\frac{1}{2}$ -20 x 7.50	45	921-04041	Water Nozzle Adapter
10	01008049	Carriage Bolt, $\frac{3}{8}$ -16 x 4.00	46	731-3005	Front Roller
11	01008644	Fab Deck Chute Finger Guard	47	732-04797	Torsion Spring
12	02001235	Deck Chute Baffle	48	932-0594A	Extension Spring, .91 x 7.33
13	02002629	Hook Ext. Spring, .75 x 7.89 x .14	49	936-0133	Washer, .411 x 1.25 x 1.00
14	02003712	Hook Ext. Spring, .94 x 7.57 x .14	50	936-0171	Lock Washer, $\frac{7}{16}$
15	02004447	Idler Pulley, 4.88	51	936-0326	Flat Washer, .390 x 1.500 x .134
16	02005018	Hi-Lift Blade, 19.0	52	936-0760	Lock Washer, 17 x 23.8 x 1.95
17	02005079	Idler Pulley, 5.06	53	736-3040	Flat Washer, .406 x 1.92 x .060
18	96606	Retainer Hook	54	736-3052	Washer, .406 x 1.00 x .105
19	903-04791	54" Welded Deck	55	737-04003D	Water Deck Nozzle
20	603-04839	54" Idler Assembly	56	738-04376	Shoulder Spacer, .854 x .280
21	918-04426	Deck Spindle Assembly	57	738-04462	Shoulder Bolt, $\frac{3}{8}$ -16 x .74 x 2.47
22	634-3159	Deck Wheel	58	747-3384	Chute Deflector Rod
23	703-07010	Deck Idler Arm	59	748-3065A	Deck Spindle Spacer
24	703-07641	Spring Mount Plate	60	750-05420	Spindle Spacer, .76 x 2.0 x 1.1
25	703-07687A	54" RH Belt Cover	61	750-05496	Spacer, .760 x 2.00 x 1.69
26	703-07688A	54" LH Belt Cover	62	954-04137A	V-Belt
27	703-07787	Spindle Reinforcement Plate	63	954-04262	Belt
28	703-07845A	Standard Baffle	64	756-04129B	Idler Pulley, 4.25
29	710-0411	Hex Screw, $\frac{3}{8}$ -16 x 4.00	65	756-04459A	V-Type Pulley
30	710-0431	Carriage Bolt, $\frac{3}{8}$ -16 x 1.50	66	956-1209	V-Type Pulley
31	710-04484	Hex Washer Screw, $\frac{5}{16}$ -18 x .750	67	750-04409	Bearing Spacer
32	710-04605	Flange Hex TT Screw, $\frac{5}{16}$ -18 x 1.50	68	921-3018A	Oil Seal
33	710-05110A	Hex Screw, $\frac{3}{4}$ -16 x 8.0	69	703-07632A	Spring Mount Bracket
34	710-0514	Hex Screw, $\frac{3}{8}$ -16 x 1.00	70	941-04089	Cone Bearing, .750"
35	710-05173A	Hex Screw, $\frac{3}{4}$ -16 x 6.0	71	941-04091	Bearing Cup, .750"
36	710-0599	Hex Washer TT Screw, $\frac{1}{4}$ -20 x .500			

60" Deck



Ref.	Part Number	Description	Ref.	Part Number	Description
1	00010958	Washer, .532 x 1.06 x .094	36	603-04839	60" Idler Assembly
2	01008225	Retainer Nut	37	703-07010	Deck Idler Arm
3	737-3004	Grease Fitting, 1/4-28 x .788	38	703-07516A	Standard Baffle
4	00022560	Counterlock Flange Nut, 3/8-16	39	703-07632A	Spring Mount Bracket
5	00030276	Carriage Bolt, 3/8-16 x 1.50	40	703-07641	Spring Mount Plate
6	737-04345	Straight Grease Fitting, 1/4-28	41	703-07687A	60" RH Belt Cover
7	710-0560	Carriage Bolt, 3/8-18 x 1.75	42	703-07688A	60" LH Belt Cover
8	710-3178	Carriage Bolt, 3/8-16 x .75	43	703-07787	Spindle Reinforcement Plate
9	96606	Retainer Hook	44	710-3157A	Hex Screw, 7/16-20 x 3.50
10	750-3193	Spacer, .390 x .620 x 3.04	45	710-05110A	Hex Screw, 3/4-16 x 8.0
11	736-3052	Washer, .406 x 1.00 x .105	46	710-0514	Hex Screw, 3/8-16 x 1.00
12	936-0133	Washer, .411 x 1.25 x 1.00	47	710-0599	Hex Washer TT Screw, 1/4-20 x .500
13	710-04484	TT Screw, 5/16-18 x .750	48	956-1209	V-Type Pulley
14	750-05553	Spacer, .812 x 1.47 x .218	49	710-3034	Carriage Bolt, 3/8-16 x 1.25
15	732-04797	Torsion Spring	50	712-04065	Flange Lock Nut, 3/8-16
16	01005376	V- Belt	51	912-0641	Hex Nut, M16-1.5
17	01006693P	Fab Deck Deflector Chute	52	712-3078	Flange Lock Nut, 3/4-16
18	01006748	Deflector Chute Bracket	53	917-04754	Electric PTO Clutch
19	01006961	Hex Screw, 1/2-20 x 7.50	54	921-04041	Water Nozzle Adapter
20	01008049	Carriage Bolt, 3/8-16 x 4.00	55	731-3005	Front Roller
21	01008644	Fab Deck Chute Finger Guard	56	932-0594A	Extension Spring, .91 x 7.33
22	750-05496	Spacer, .760 x 2.00 x 1.69	57	936-0171	Lock Washer, 7/16
23	710-04605	Flange Hex TT Screw, 5/16-18 x 1.50	58	936-0326	Flat Washer, .390 x 1.500 x .134
24	912-3058	Nut, Hexlk, 1/2-20, Gr2, Nylon	59	936-0760	Lock Washer, 17 x 23.8 x 1.95
25	710-05173A	Hex Screw, 3/4-16 x 6.00	60	736-3040	Flat Washer, .406 x 1.92 x .060
26	02002299	Nylock Nut, 1/2-20	61	737-04003D	Water Deck Nozzle
27	02002629	Hook Ext. Spring, .75 x 7.89 x .14	62	738-04462	Shoulder Bolt, 3/8-16 x .74 x 2.47
28	02003712	Hook Ext. Spring, .94 x 7.57 x .14	63	738-04376	Shoulder Spacer, .854 x .280
29	02004447	Idler Pulley, 4.88	64	747-3384	Chute Deflector Rod
30	02005019	Hi-Lift Blade, 21.0	65	748-3065A	Deck Spindle Spacer
31	02005079	Idler Pulley, 5.06	66	750-05420	Spindle Spacer, .76 x 2.0 x 1.1
32	02005195	Deck Chute Baffle	67	954-04262	Belt
33	918-04426	Deck Spindle Assembly	68	756-04129B	Idler Pulley, 4.25
34	634-3159	Deck Wheel	69	756-04458A	V-Type Pulley
35	980-00100A	60" Welded Deck			

RH Transmission 918-05005A




* Parts Included in Seal Kit

Ref	Part Number	Description
1	HG-71821	Kit, Housing, Main, RH
2	HG-72226	Kit, Cover, Side, RH
7	HG-53246	Hex Cap Screw, 1/4-20 x 1.125
11	HG-9005110-5600	Plug, 9/16-18
22	HG-51448	Plate, Bypass
23	HG-52114	Oil Filter
26	HG-52162	Seal, Plug, 1.25 x .25
27	HG-52137	Hex Cap Screw, 3/8-16 x 1.5
30	HG-51626	Seal, Lip .375 x .75 x .25
31	HG-51628	Ring, Ret .375 External
32	HG-52136	Rod, Bypass
33	HG-51627	Ring, Ret .75 Internal
34	HG-52742	Arm, Bypass
35	HG-51630	Ring, Retaining .375 External
40	HG-51048	Trunnion, Swashplate
41	HG-51140	Seal, Lip 12 x 32 x 7
45	736-0371	Washer, .34 x .88 x .06
46	HG-51812	Hex Cap Screw, 5/16-24 x 1.00
55	HG-50951	Washer, 1.23 x 1.56 x .04
56	HG-51161	Seal, Lip 17 x 40 x 7
57	HG-50329	Ring, Retaining
60	HG-51462	Bearing Thrust
64	HG-71579	Cylinder Block Assembly
65	HG-50551P	Thrust Ball Bearing, 30 x 52 x 13
69	HG-70723	Block 7 Piston Assembly
70	HG-44371	Washer, .63 x 1.0 x .05
71	HG-44145	Retaining Ring, .625
72	HG-52149	Gear, 16t
73	HG-53136	Motor Shaft
74	HG-51069	Washer, .72 x 1.16 x .04
80	HG-50132	Washer, .5 x 1.0 x .03
81	HG-52148	Gear, 43t

Ref	Part Number	Description
82	HG-52583	Gear, 11t
83	HG-51083	Jack Shaft
90	HG-50859	Retaining Ring, 2.06 Internal
91	HG-52108	Gear, 54t
92	HG-53336	Spacer, .75 x 1.32 x .257
93	HG-44121P	Ball Bearing, .75 x 40 x 12
95	HG-53656	Ball Bearing, 1.0 x 52 x 15
96	HG-53699	Seal, Lip 25 x 52 x 10
97	HG-71404	Kit, Hub, 4 Bolt
99	HG-53768	Nut, 3/4-16, Hex Lock
105	HG-50752	Hex Cap Screw, 1/4-20 x .75
106	HG-53655	Guard, Filter, RH
111	HG-71393	Fitting, 9/16-18 SAE .5 Barb
120	TBD	Fan 7", 10 Blade
121	TBD	Disc, Pulley
122	HG-44133	Nut, 1/2-20, Hex Jam
123	HG-51076	Hex Cap Screw, 1/4-20 x .875
140	HG-52527	Spacer, .320 x 1.005 x .179
141	HG-51946	Neutral Left Arm
142	HG-71341	Hex Cap Screw, 5/16-24
146	HG-51950	Washer, .343 x 1.5 x .062
147	HG-52401	Extension Spring, .57 x 2"
158	HG-53501	Axle Cap
160	HG-53138	Seal, Lip, .625 x .875 x .25
201	HG-71580	Kit, Center Section, RH
207	TBD	Kit, Fan & Pulley
209	HG-71459	Hub Puller, 4 Bolt
210	HG-71443	Kit, Input Shaft
211	HG-71592	Kit, RTN, Bidirectional
212	HG-71570	Kit, Shaft, Axle
NS	HG-71410	Kit, Seal

LH Transmission 918-05006A




* Parts Included in Seal Kit

Ref	Part Number	Description
1	HG-71822	Kit, Housing, Main, LH
2	HG-72227	Kit, Cover, Side, LH
7	HG-53246	Hex Cap Screw, 1/4-20 x 1.125
11	HG-9005110-5600	Plug, 9/16-18
13	HG-50928	Sealant
22	HG-51448	Plate, Bypass
23	HG-52114	Oil Filter
26	HG-52162	Seal, Plug, 1.25 x .25
27	HG-52137	Hex Cap Screw, 3/8-16 x 1.5
30	HG-51626	Seal, Lip .375 x .75 x .25
31	HG-51628	Ring, Ret .375 External
32	HG-52136	Rod, Bypass
33	HG-51627	Ring, Ret .75 Internal
34	HG-52742	Arm, Bypass
35	HG-51630	Ring, Retaining .375 External
40	HG-51048	Trunnion, Swashplate
41	HG-51140	Seal, Lip 12 x 32 x 7
45	736-0371	Washer, .34 x .88 x .06
46	HG-51812	Hex Cap Screw, 5/16-24 x 1.00
55	HG-50951	Washer, 1.23 x 1.56 x .04
56	HG-51161	Seal, Lip 17 x 40 x 7
57	HG-50329	Ring, Retaining
60	HG-51462	Bearing, Thrust
64	HG-71579	Cylinder Block Assembly
65	HG-50551P	Thrust Ball Bearing, 30 x 52 x 13
69	HG-70723	Block 7 Piston Assembly
70	HG-44371	Washer, .63 x 1.0 x .05
71	HG-44145	Retaining Ring, .625
72	HG-52149	Gear, 16t
73	HG-53136	Motor Shaft
74	HG-51069	Washer, .72 x 1.16 x .04
80	HG-50132	Washer, .5 x 1.0 x .03

Ref	Part Number	Description
81	HG-52148	Gear, 43t
82	HG-52583	Gear, 11t
83	HG-51083	Jack Shaft
90	HG-50859	Retaining Ring, 2.06 Internal
91	HG-52108	Gear, 54t
92	HG-53336	Spacer, .75 x 1.32 x .257
93	HG-44121P	Ball Bearing, .75 x 40 x 12
95	HG-53656	Ball Bearing, 1.0 x 52 x 15
96	HG-53699	Seal, Lip 25 x 52 x 10
97	HG-71404	Kit, Hub, 4 Bolt
99	HG-53768	Nut, 3/4-16, Hex Lock
105	HG-50752	Hex Cap Screw, 1/4-20 x .75
106	HG-53644	Guard, Filter, LH
111	HG-71393	Fitting, 9/16-18 SAE .5 Barb
120	TBD	Fan 7", 10 Blade
121	TBD	Disc, Pulley
122	HG-44133	Nut, 1/2-20, Hex Jam
123	HG-51076	Hex Cap Screw, 1/4-20 x .875
140	HG-52527	Spacer, .320 x 1.005 x .179
141	HG-51945	Neutral Right Arm
142	HG-71341	Hex Cap Screw, 5/16-24
146	HG-51950	Washer, .343 x 1.5 x .062
147	HG-52401	Extension Spring, .57 x 2"
158	HG-53501	Axle Cap
160	HG-53138	Seal, Lip, .625 x .875 x .25
201	HG-71581	Kit, Center Section, LH
207	TBD	Kit, Fan & Pulley
209	HG-71459	Hub Puller, 4 Bolt
210	HG-71443	Kit, Input Shaft
211	HG-71588	Kit, RTN, Bidirectional
212	HG-71570	Kit, Shaft, Axle
NS	HG-71410	Kit, Seal


Electrical Schematic



33



Z-Force S 54 Labels




35



Kawasaki FR651V-AS05 Cylinder/Crankcase

E0110-A630A




Kawasaki FR651V-AS05 Cylinder/Crankcase

Ref.	Part Number	Description
11004	KM-11004-7026	Head Gasket
11008	KM-11008-7039	Complete Cylinder Head, #1
11008A	KM-11008-7040	Complete Cylinder Head, #2
11022	KM-11022-7019	Rocker Case, #1
11022A	KM-11022-7020	Rocker Case, #2
11061	KM-11061-7083	Rocker Case Gasket
11061A	KM-11061-7084	Breather Gasket
13272	KM-13272-7004	Breather Plate
14091	KM-14091-7064	Breather Cover
16126	KM-16126-7020	Breather Valve
32154	KM-32154-7019	Pipe
32155	KM-32155-7003	Breather Pipe
49015	KM-49015-7106	Crankcase Cover
49120	KM-49120-7129	Complete Crankcase
59071	KM-59071-2079	Joint
92043	KM-92043-1263	Pin
92049	KM-92049-7001	Oil Seal, RVC2, 6 X 11 X 10.2
92049A	KM-92049-7005	Oil Seal, So 8 X 14 X 5 HS
92049B	KM-92049-7010	Oil Seal, Sd 35 X 48 X 8 R HS
92049C	KM-92049-7028	Oil Seal, 38 X 62 X 8 MTCLV
92066	KM-92066-7023	Plug
92066A	KM-92066-7026	Plug
92153	KM-92153-7043	Bolt, 6 X 12
92153A	KM-92153-7054	Bolt, 8 X 50
130	KM-130AA0625	Flanged Bolt, 6 X 25
130A	KM-130CA1050	Flanged Bolt, 10 X 50
130B	KM-130CA1065	Flanged Bolt, 10 X 65
172	KM-172BA0818	Stud Bolt , 8 X 18
214	KM-214AA0408	Pan Screw +-, 4 X 8
670	KM-670B2011	O-Ring, 11mm


Kawasaki FR651V-AS05 Piston/Crankshaft

E0120-A398A




Ref.	Part Number	Description
13001	KM-13001-7027	Engine Piston
13002	KM-13002-7006	Piston Pin
13008	KM-13008-7005	Piston Ring Set
13025	KM-13025-7009	Piston Ring Set L, 0.5
13029	KM-13029-7010	Engine Piston L, 0.5
13031	KM-13031-7084	Complete Crankshaft
13251	KM-13251-7025	Connecting Rod Assembly
92033	KM-92033-7016	Snap Ring
92151	KM-92151-7017	Bolt, 6 X 35

E0140-A447A



Ref.	Part Number	Description
13272	KM-13272-7011	Rotor Plate
14075	KM-14075-7013	Oil Gauge Cap Assembly
16154	KM-16154-7010	Outer Rotor Pump
16154A	KM-16154-7011	Inner Rotor Pump
49065	KM-49065-7006	Oil Filter
49065A	KM-49065-7007	Oil Filter
59231	KM-59231-7016	Filler
92066	KM-92066-7003	Plug
92066A	KM-92066-7028	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7008	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12
555	KM-555A0420	Spring Pin, 4 X 20
670	KM-670D2016	O-Ring, 16mm

E0130-A176A




Kawasaki FR651V-AS05 Valve & Camshaft

Ref.	Part Number	Description
11055	KM-11055-7009	Bracket
12004	KM-12004-7008	Intake Valve
12005	KM-12005-7009	Exhaust Valve
12009	KM-12009-7001	Valve Spring Retainer
12011	KM-12011-2056	Collet
12016	KM-12016-2066	Rocker Arm
12032	KM-12032-7001	Tappet
13070	KM-13070-7017	Governor Guide
13116	KM-13116-7007	Push Rod
13271	KM-13271-7007	Plate
13271A	KM-13271-7021	Governor Plate
42036	KM-42036-7010	Sleeve
49078	KM-49078-7002	Engine Valve Spring, IN
49118	KM-49118-7022	Complete Camshaft
92033	KM-92033-7001	Snap Ring
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring
92152	KM-92152-7020	Collar
92153	KM-92153-7100	Bolt, 6 X 29.5
92200	KM-92200-2151	Washer, 8.1 X 18 X 0.5
92200A	KM-92200-7009	Washer, 16 X 42 X 0.91
92200B	KM-92200-7048	Washer, 16.3 X 30 X 2.28
130	KM-130AA0814	Flanged Bolt, 8 X 14
312	KM-312AA0600	Hex Nut, 6mm

Kawasaki FR651V-AS05 Cooling Equipment


E0150-A873A



Ref.	Part Number	Description
13070	KM-13070-7019	Cooling Air Guide
13272	KM-13272-7006	Fan Plate
14037	KM-14037-70089H	Screen
23062	KM-23062-7005	Complete Bracket
49089	KM-49089-7079	Engine Shroud
49089A	KM-49089-7080	Engine Shroud
59041	KM-59041-7014	Fan
59066	KM-59066-7063	Fan Housing
92009	KM-92009-2303	Screw
92026	KM-92026-7007	Spacer
92151	KM-92151-7012	Bolt, 6 X 12
92153	KM-92153-7007	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12

Kawasaki FR651V-AS05 Electric Equipment

E0160-B284A




Ref.	Part Number	Description
13272	KM-13272-7012	Plate
21066	KM-21066-7017	Voltage Regulator
21171	KM-21171-0711	Ignition Coil Assembly
21193	KM-21193-7038	Flywheel Assembly
26011	KM-26011-7025	Lead Wire, L = 95
26031	KM-26031-7040	Harness
26031A	KM-26031-7041	Harness
26031B	KM-26031-7044	Harness
59031	KM-59031-7017	Charging Coil
92009	KM-92009-2303	Screw

Ref.	Part Number	Description
92009A	KM-92009-2308	Screw
92066	KM-92066-7026	Plug
92070	KM-BPR4ES	Spark Plug, BPR4ES (NGK)
92072	KM-92072-7003	Band
92151	KM-92154-7003	Bolt, 12 X 30
92171	KM-92171-7008	Clamp
92172	KM-92172-7018	Screw, 5 X 20
92200	KM-92200-7002	Washer
130	KM-130AA0620	Flanged Bolt, 6 X 20
510	KM-510A5100	Woodruff Key

Kawasaki FR651V-AS05 Control Equipment

E0170-A652A




Ref.	Part Number	Description
13107	KM-13107-7047	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-7022	Link
39129	KM-39129-7035	Governor Spring
49103	KM-49103-7014	Governor Arm
49103A	KM-49103-7015	Governor Arm
49113	KM-49113-7050	Complete Control Panel
92145	KM-92145-7057	Spring
92145A	KM-92145-7058	Spring
92150	KM-92150-2182	Bolt, 5 X 18

Ref.	Part Number	Description
92153	KM-92153-0009	Bolt, 6 X 12
92153A	KM-92153-7033	Bolt, 6 X 35
92153B	KM-92153-7043	Bolt, 6 X 12
92170	KM-92170-7001	Clamp
92172	KM-92172-7035	Screw, 5 X 30
214	KM-214AA0408	Pan Screw +-, 4 X 8
311	KM-311AA0600	Hex Nut, 6mm
312	KM-312AA0500	Hex Nut, 5mm
411	KM-411AA0600	Plain Washer, 6mm

Kawasaki FR651V-AS05 Carburetor

E0180-A778A




Ref.	Part Number	Description
11061	KM-11061-7009	Chamber Gasket
11061A	KM-11061-7010	Screw Gasket
11061B	KM-11061-7085	Manifold Gasket
11061C	KM-11061-7087	Insulator Gasket
11061D	KM-11061-7088	Insulator/Manifold Gasket
13107	KM-13107-7018	Shaft
15004	KM-15004-7062	Carburetor Assembly
16014	KM-16014-7010	Pilot Air Screw
16020	KM-16020-7003	Float Chamber
16025	KM-16025-7017	Throttle Valve
16030	KM-16030-7003	Float Valve
16031	KM-16031-7002	Float
16041	KM-16041-7050	Choke Carburetor Shaft
16041A	KM-16041-7051	Throttle Carburetor Shaft
16073	KM-16073-7013	Insulator
16186	KM-16186-7006	Choke Valve Assembly

Ref.	Part Number	Description
21188	KM-21188-7002	Solenoid
39074	KM-39074-7001	Throttle Lever Assembly
49121	KM-49121-7018	Main Nozzle
59076	KM-59076-7019	Intake Manifold
92009	KM-92009-2083	Screw
92009A	KM-92009-2349	Screw
92009B	KM-92009-2402	Screw
92063	KM-92063-7141	Main Jet, #122
92063A	KM-92063-7142	Main Jet, #124
92063B	KM-92063-7149	Main Jet, #120
92081	KM-92081-2234	Spring
92093	KM-92093-2100	Seal
92093A	KM-92093-7003	Seal
92145	KM-92145-2122	Spring
130	KM-130AA0630	Flanged Bolt, 6 X 30
172	KM-172BA06115	Stud Bolt, 6 X 115

Kawasaki FR651V-AS05 Air Filter/Muffler


E0190-B094A



Ref.	Part Number	Description
11011	KM-11011-7054	Air Filter Case
11013	KM-11013-7049	Air Filter Element
11060	KM-11060-7016	Muffler Gasket
11061	KM-11061-7086	Carburetor/Intake Pipe Gasket
11065	KM-11065-7023	Cap
16060	KM-16060-7038	Intake Pipe
42036	KM-42036-7017	Breather Sleeve
92009	KM-92009-2303	Screw
92015	KM-92015-1367	Nut
92171	KM-92171-7007	Clamp
92173	KM-92173-7003	Clamp
92192	KM-92192-7146	Tube, 12.6 x 18.6 x 118
92192A	KM-99999-7082	Air Filter Tube
92210	KM-92210-7027	Nut, M8
461	KM-461DA0800	Spring Washer, 8mm


Kawasaki FR651V-AS05 Fuel Tank/Fuel Valve

E0200-A679A




Ref.	Part Number	Description
42036	KM-42036-7015	Sleeve
49019	KM-49019-7005	Fuel Filter
49040	KM-49040-7008	Fuel Pump
92009	KM-92009-2303	Screw
92170	KM-92170-2009	Clamp
92171	KM-92171-7008	Clamp
92192	KM-92192-7145	Tube, 6.35 X 12.7 X 185
92192A	KM-92192-7148	Tube, 6.4 X 12.7 X 150
92192B	KM-92192-7188	Tube, 6.35 X 12.7 X 390

E0210-A457A



Ref.	Part Number	Description
16146	KM-16146-7027	Cover Assembly
16146A	KM-16146-7028	Cover Assembly
21080	KM-21080-7006	Armature
21163	KM-21163-0714	Electric Starter
27012	KM-27012-7004	Hook
32085	KM-99999-0309	Stopper
59051	KM-59051-7034	Spur Gear
92093	KM-92093-7007	Seal
92145	KM-92145-7060	Spring
92154	KM-92154-7001	Bolt
92210	KM-92210-7017	Nut
92210A	KM-99999-0309	Nut
130	KM-130AA0840	Flanged Bolt, 8 x 40


F0290-B469A



Ref.	Part Number	Description
56033	KM-56033-7001	Manual Label
56070	KM-56070-7001	Warning Label

Kawasaki FR691V-AS05 Valve/Camshaft


E0130-A176A



Ref.	Part Number	Description
11055	KM-11055-7009	Bracket
12004	KM-12004-7008	Intake Valve
12005	KM-12005-7009	Exhaust Valve
12009	KM-12009-7001	Valvespring Retainer
12011	KM-12011-2056	Collet
12016	KM-12016-2066	Rocker Arm
12032	KM-12032-7001	Tappet
13070	KM-13070-7017	Governor Guide
13116	KM-13116-7007	Push Rod
13271	KM-13271-7007	Plate
13271A	KM-13271-7021	Governor Plate
42036	KM-42036-7010	Sleeve

Ref.	Part Number	Description
49078	KM-49078-7002	Engine Valve Spring, IN
49118	KM-49118-7022	Complete Camshaft
92033	KM-92033-7001	Snap Ring
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring
92152	KM-92152-7020	Collar
92153	KM-92153-7100	Bolt, 6 X 29.5
92200	KM-92200-2151	Washer, 8.1 X 18 X 0.5
92200A	KM-92200-7009	Washer, 16 X 42 X 0.91
92200B	KM-92200-7048	Washer, 16.3 X 30 X 2.28
130	KM-130AA0814	Flanged Bolt, 8 X 14
312	KM-312AA0600	Hex Nut, 6mm


E0120-A398A



Ref.	Part Number	Description
13001	KM-13001-7027	Engine Piston
13002	KM-13002-7006	Piston Pin
13008	KM-13008-7005	Piston Ring Set
13025	KM-13025-7009	Piston Ring Set, L ,0.5
13029	KM-13029-7010	Engine Piston, L, 0.5
13031	KM-13031-7084	Complete Crankshaft
13251	KM-13251-7025	Connecting Rod Assembly
92033	KM-92033-7016	Snap Ring
92151	KM-92151-7017	Bolt, 6 X 35

Kawasaki FR691V-AS05 Cylinder/Crankcase

E0110-A630A




Kawasaki FR691V-AS05 Cylinder/Crankcase

Ref.	Part Number	Description
11004	KM-11004-7026	Head Gasket
11008	KM-11008-7039	Complete Cylinder Head, #1
11008A	KM-11008-7040	Complete Cylinder Head, #2
11022	KM-11022-7019	Rocker Case, #1
11022A	KM-11022-7020	Rocker Case, #2
11061	KM-11061-7083	Rocker Case Gasket
11061A	KM-11061-7084	Breather Gasket
13272	KM-13272-7004	Breather Plate
14091	KM-14091-7064	Breather Cover
16126	KM-16126-7020	Breather Valve
32154	KM-32154-7019	Pipe
32155	KM-32155-7003	Breather Pipe
49015	KM-49015-7106	Crankcase Cover
49120	KM-49120-7129	Complete Crankcase
59071	KM-59071-2079	Joint
92043	KM-92043-1263	Pin
92049	KM-92049-7001	Oil Seal, RVC 26 x 11 x 10.2
92049A	KM-92049-7005	Oil Seal, SO 8 x 14 x 5 HS
92049B	KM-92049-7010	Oil Seal, SD 35 x 48 x 8 RHS
92049C	KM-92049-7028	Oil Seal, 38 x 62 x 8 MTCLV
92066	KM-92066-7023	Plug
92066A	KM-92066-7026	Plug
92153	KM-92153-7043	Bolt, 6 x 12
92153A	KM-92153-7054	Bolt, 8 x 50
130	KM-130AA0625	Flanged Bolt, 6 x 25
130A	KM-130CA1050	Flanged Bolt, 10 x 50
130B	KM-130CA1065	Flanged Bolt, 10 x 65
172	KM-172BA0818	Stud Bolt, 8 x 18
214	KM-214AA0408	Pan Screw +-, 4 x 8
670	KM-670B2011	O-Ring, 11mm


Kawasaki FR691V-AS05 Cooling Equipment

E0150-A873A



Ref.	Part Number	Description
13070	KM-13070-7019	Cooling Air Guide
13272	KM-13272-7006	Fan Plate
14037	KM-14037-70089H	Screen
23062	KM-23062-7005	Complete Bracket
49089	KM-49089-7079	Engine Shroud
49089A	KM-49089-7080	Engine Shroud
59041	KM-59041-7014	Fan
59066	KM-59066-7063	Fan Housing
92009	KM-92009-2303	Screw
92026	KM-92026-7007	Spacer
92151	KM-92151-7012	Bolt, 6 X 12
92153	KM-92153-7007	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12


E0140-A447A



Ref.	Part Number	Description
13272	KM-13272-7011	Rotor Plate
14075	KM-14075-7013	Oil Gauge Cap Assembly
16154	KM-16154-7010	Outer Pump Rotor
16154A	KM-16154-7011	Inner Pump Rotor
49065	KM-49065-7006	Oil Filter
49065A	KM-49065-7007	Oil Filter
59231	KM-59231-7016	Filler
92066	KM-92066-7003	Plug
92066A	KM-92066-7028	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7008	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12
555	KM-555A0420	Spring Pin, 4 X 20
670	KM-670D2016	O-Ring, 16mm

Kawasaki FR691V-AS05 Control Equipment

E0170-A652A




Ref.	Part Number	Description
13107	KM-13107-7047	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-7022	Link
39129	KM-39129-7035	Governor Spring
49103	KM-49103-7014	Governor Arm
49103A	KM-49103-7015	Governor Arm
49113	KM-49113-7050	Complete Control Panel
92145	KM-92145-7057	Spring
92145A	KM-92145-7058	Spring
92150	KM-92150-2182	Bolt, 5 X 18

Ref.	Part Number	Description
92153	KM-92153-0009	Bolt, 6 X 12
92153A	KM-92153-7033	Bolt, 6 X 35
92153B	KM-92153-7043	Bolt, 6 X 12
92170	KM-92170-7001	Clamp
92172	KM-92172-7035	Screw, 5 X 30
214	KM-214AA0408	Pan Screw +-, 4 X 8
311	KM-311AA0600	Hex Nut, 6mm
312	KM-312AA0500	Hex Nut, 5mm
411	KM-411AA0600	Plain Washer, 6mm

Kawasaki FR691V-AS05 Electric Equipment

E0160-B284A




Ref.	Part Number	Description
13272	KM-13272-7012	Plate
21066	KM-21066-7017	Voltage Regulator
21171	KM-21171-0711	Ignition Coil Assembly
21193	KM-21193-7038	Flywheel Assembly
26011	KM-26011-7025	Lead Wire, L = 95
26031	KM-26031-7040	Harness
26031A	KM-26031-7041	Harness
26031B	KM-26031-7044	Harness
59031	KM-59031-7017	Charging Coil
92009	KM-92009-2303	Screw

Ref.	Part Number	Description
92009A	KM-92009-2308	Screw
92066	KM-92066-7026	Plug
92070	759-3339	Spark Plug
92072	KM-92072-7003	Band
92151	KM-92154-7003	Bolt, 12 X 30
92171	KM-92171-7008	Clamp
92172	KM-92172-7018	Screw, 5 X 20
92200	KM-92200-7002	Washer
130	KM-130AA0620	Flanged Bolt, 6 X 20
510	KM-510A5100	Woodruff Key

Kawasaki FR691V-AS05 Air Filter/Muffler


E0190-B094A



Ref.	Part Number	Description
11011	KM-11011-7054	Air Filter Case
11013	KM-11013-7049	Air Filter Element
11060	KM-11060-7016	Muffler Gasket
11061	KM-11061-7086	Carburetor/Pipe Intake Gasket
11065	KM-11065-7023	Cap
16060	KM-16060-7038	Intake Pipe
42036	KM-42036-7017	Breather Sleeve
92009	KM-92009-2303	Screw
92015	KM-92015-1367	Nut
92171	KM-92171-7007	Clamp
92173	KM-92173-7003	Clamp
92192	KM-92192-7146	Tube, 12.6 X 18.6 X 118
92192A	KM-99999-7082	Air Filter Tube
92210	KM-92210-7027	Nut, M8
461	KM-461DA0800	Spring Washer, 8mm

Kawasaki FR691V-AS05 Carburetor

E0180-A778A




Ref.	Part Number	Description
11061	KM-11061-7009	Chamber Gasket
11061A	KM-11061-7010	Screw Gasket
11061B	KM-11061-7085	Manifold Gasket
11061C	KM-11061-7087	Insulator Gasket
11061D	KM-11061-7088	Insulator/Manifold Gasket
13107	KM-13107-7018	Shaft
15004	KM-15004-7063	Carburetor Assembly
16014	KM-16014-7010	Pilot Air Screw
16020	KM-16020-7003	Float Chamber
16025	KM-16025-7017	Throttle Valve
16030	KM-16030-7003	Float Valve
16031	KM-16031-7002	Float
16041	KM-16041-7050	Choke Carburetor Shaft
16041A	KM-16041-7051	Throttle Carburetor Shaft
16073	KM-16073-7013	Insulator
16186	KM-16186-7006	Choke Valve Assembly

Ref.	Part Number	Description
21188	KM-21188-7002	Solenoid
39074	KM-39074-7001	Throttle Lever Assembly
49121	KM-49121-7018	Main Nozzle
59076	KM-59076-7019	Intake Manifold
92009	KM-92009-2083	Screw
92009A	KM-92009-2349	Screw
92009B	KM-92009-2402	Screw
92063	KM-92063-7141	Main Jet, #122
92063A	KM-92063-7142	Main Jet, #124
92063B	KM-92063-7149	Main Jet, #120
92081	KM-92081-2234	Spring
92093	KM-92093-2100	Seal
92093A	KM-92093-7003	Seal
92145	KM-92145-2122	Spring
130	KM-130AA0630	Flanged Bolt, 6 X 30
172	KM-172BA06115	Stud Bolt, 6 X 115

Kawasaki FR691V-AS05 Carburetor


E0210-A452A



Ref.	Part Number	Description
16146	KM-16146-7027	Cover Assembly
16146A	KM-16146-7028	Cover Assembly
21080	KM-21080-7006	Armature
21163	KM-21163-0714	Electric Starter
27012	KM-27012-7004	Hook
32085	KM-99999-0309	Stopper
59051	KM-59051-7034	Spur Gear
92093	KM-92093-7007	Seal
92145	KM-92145-7060	Spring
92154	KM-92154-7001	Bolt
92210	KM-92210-7017	Nut
92210A	KM-99999-0309	Nut
130	KM-130AA0840	Flanged Bolt, 8 X 40

Kawasaki FR691V-AS05 Fuel Tank/Fuel Valve


E0200-A679A




Ref.	Part Number	Description
42036	KM-42036-7015	Sleeve
49019	KM-49019-7005	Fuel Filter
49040	KM-49040-7008	Fuel Pump
92009	KM-92009-2303	Screw
92170	KM-92170-2009	Clamp
92171	KM-92171-7008	Clamp
92192	KM-92192-7145	Tube, 6.35 X 12.7 X 185
92192A	KM-92192-7148	Tube, 6.4 X 12.7 X 150
92192B	KM-92192-7188	Tube, 6.35 X 12.7 X 390

Kawasaki FR691V-AS05 Engine Labels

56033




56070



Ref.	Part Number	Description
56033	KM-56033-7001	Manual Label
56070	KM-56070-7001	Warning Label

[illegible]


Kawasaki FR730V-AS05 Cylinder/Crankcase




Kawasaki FR730V-AS05 Cylinder/Crankcase

Ref.	Part Number	Description
11004	KM-11004-7026	Head Gasket
11008	KM-11008-7039	Complete Cylinder Head, #1
11008A	KM-11008-7040	Complete Cylinder Head, #2
11022	KM-11022-7019	Rocker Case, #1
11022A	KM-11022-7020	Rocker Case, #2
11061	KM-11061-7083	Rocker Case Gasket
11061A	KM-11061-7094	Breather Gasket
13272	KM-13272-7004	Breather Plate
14091	KM-14091-7064	Breather Cover
16126	KM-16126-7020	Breather Valve
32154	KM-32154-7019	Pipe
32155	KM-32155-7003	Breather Pipe
49015	KM-49015-7106	Crankcase Cover
49015A	KM-49015-7106	Crankcase Cover
49120	KM-49120-7134	Complete Crankcase
49120A	KM-49120-7142	Complete Crankcase
59071	KM-59071-2079	Joint
92004	KM-92004-7024	Stud, 8 x 30
92043	KM-92043-1263	Pin
92049	KM-92049-7001	Oil Seal, RVC 26 x 11 x 10.2
92049A	KM-92049-7005	Oil Seal, SO 8 x 14 x 5 HS
92049B	KM-92049-7010	Oil Seal, SD 35 x 48 x 8 R HS
92049C	KM-92049-7028	Oil Seal, 38 x 62 x 8MTCLV
92066	KM-92066-7023	Plug
92066A	KM-92066-7026	Plug
92104	KM-92104-7001	Liquid Gasket, TB1217H
92153	KM-92153-7043	Bolt, 6 x 12
92153A	KM-92153-7054	Bolt, 8 x 50
130	KM-130AA0625	Flanged Bolt, 6 x 25
130A	KM-130CA1050	Flange Bolt, 10 x 50
130B	KM-130CA1065	Flange Bolt, 10 x 65
214	KM-214AA0408	Pan Screw, 4 x 8
670	KM-670B2011	O-Ring, 11MM

Kawasaki FR730V-AS05 Piston/Crankshaft




Ref.	Part Number	Description
13001	KM-13001-7027	Engine Piston
13002	KM-13002-7006	Piston Pin
13008	KM-13008-7005	Piston Ring Set
13025	KM-13025-7009	Piston Ring Set L, 0.5
13029	KM-13029-7010	Engine Piston L, 0.5
13031	KM-13031-7084	Complete Crankshaft
13251	KM-13251-7025	Connecting Rod Assembly
92033	KM-92033-7016	Snap Ring
92033A	KM-92033-7018	Snap Ring
92151	KM-92151-7017	Bolt, 6 x 35



Ref.	Part Number	Description
13272	KM-13272-7011	Rotor Plate
14075	KM-14075-7013	Oil Gauge Cap Assembly
16154	KM-16154-7010	Outer Rotor Pump
16154A	KM-16154-7011	Inner Rotor Pump
49065	KM-49065-7006	Oil Filter
49065A	KM-49065-7007	Oil Filter
59231	KM-59231-7016	Filler
92066	KM-92066-7003	Plug
92066A	KM-92066-7028	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7008	Bolt
92153A	KM-92153-7043	Bolt, 6 x 12
555	KM-555A0420	Spring Pin, 4 x 20
670	KM-670D2016	O-Ring, 16mm


Kawasaki FR730V-AS05 Valve & Camshaft




Kawasaki FR730V-AS05 Valve & Camshaft

Ref.	Part Number	Description
11055	KM-11055-7009	Bracket
12004	KM-12004-7008	Intake Valve
12005	KM-12005-7009	Exhaust Valve
12009	KM-12009-7001	Valve Spring Retainer
12011	KM-12011-2056	Collet
12016	KM-12016-2066	Rocker Arm
12032	KM-12032-7001	Tappet
13070	KM-13070-7017	Governor Guide
13116	KM-13116-7007	Push Rod
13271	KM-13271-7007	Plate
13271A	KM-13271-7021	Governor Plate
42036	KM-42036-7010	Sleeve
49078	KM-49078-7002	Engine Valve Spring, IN
49118	KM-49118-7022	Complete Camshaft
92033	KM-92033-7001	Snap Ring
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring
92152	KM-92152-7020	Collar
92153	KM-92153-7100	Bolt, 6 x 29.5
92200	KM-92200-2151	Washer, 8.1 x 18 x 0.5
92200A	KM-92200-7009	Washer, 16 x 42 x 0.91
92200B	KM-92200-7048	Washer, 16.3 x 30 x 2.28
130	KM-130AA0814	Flanged Bolt, 8 x 14
312	KM-312AA0600	Hex Nut, 6mm

Kawasaki FR730V-AS05 Cooling Equipment




Ref.	Part Number	Description
13070	KM-13070-7019	Cooling Air Guide
13272	KM-13272-7006	Fan Plate
14037	KM-14037-70089H	Screen
23062	KM-23062-7005	Complete Bracket
23062A	KM-23062-7022	Complete Bracket
49089	KM-49089-7079	Engine Shroud
49089A	KM-49089-7080	Engine Shroud
59041	KM-59041-7014	Fan
59066	KM-59066-7063	Fan Housing
59066A	KM-59066-7063	Fan Housing
92009	KM-92009-2303	Screw
92026	KM-92026-7007	Spacer
92151	KM-92151-7012	Bolt, 6 x 12
92153	KM-92153-7007	Bolt
92153A	KM-92153-7043	Bolt, 6 x 12



Ref.	Part Number	Description
13272	KM-13272-7012	Plate
21066	KM-21066-7017	Voltage Regulator
21171	KM-21171-0711	Ignition Coil Assembly
21171	KM-21171-0711	Ignition Coil Assembly
21193	KM-21193-7038	Flywheel Assembly
26011	KM-26011-7025	Lead Wire, L = 95
26031	KM-26031-7040	Harness
26031A	KM-26031-7041	Harness
26031B	KM-26031-7044	Harness
59031	KM-59031-7017	Charging Coil
92009	KM-92009-2303	Screw

Ref.	Part Number	Description
92009A	KM-92009-2308	Screw
92066	KM-92066-7026	Plug
92070	KM-BPR4ES	Spark Plug, BPR4ES (NGK)
92072	KM-92072-7003	Band
92151	KM-92154-7003	Bolt, 12 x 30
92154	KM-92154-7003	Bolt, 12 x 30
92171	KM-92171-7008	Clamp
92172	KM-92172-7018	Screw, 5 x 20
92200	KM-92200-7002	Washer
130	KM-130AA0620	Flanged Bolt, 6 x 20
510	KM-510A5100	Woodruff Key


Kawasaki FR730V-AS05 Control Equipment



Ref.	Part Number	Description
13107	KM-13107-7047	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-7022	Link
39129	KM-39129-7035	Governor Spring
49103	KM-49103-7014	Governor Arm
49103A	KM-49103-7015	Governor Arm
49113	KM-49113-7050	Complete Control Panel
92145	KM-92145-7057	Spring
92145A	KM-92145-7058	Spring
92150	KM-92150-2182	Bolt, 5 x 18

Ref.	Part Number	Description
92151	KM-92151-7014	Bolt, 5 x 30
92153	KM-92153-0009	Bolt, 6 x 12
92153A	KM-92153-7033	Bolt, 6 x 35
92153B	KM-92153-7043	Bolt, 6 x 12
92170	KM-92170-7001	Clamp
214	KM-214AA0408	Pan Screw, 4 x 8
311	KM-311AA0600	Hex Nut, 6mm
312	KM-312AA0500	Hex Nut, 5mm
411	KM-411AA0600	Plain Washer, 6mm


Kawasaki FR730V-AS05 Carburetor



Ref.	Part Number	Description
11061	KM-11061-7009	Chamber Gasket
11061A	KM-11061-7010	Screw Gasket
11061B	KM-11061-7087	Insulator Gasket
11061C	KM-11061-7088	Insulator/Manifold Gasket
11061D	KM-11061-7093	Manifold Gasket
13107	KM-13107-7018	Shaft
15004	KM-15004-7052	Carburetor Assembly
16014	KM-16014-7010	Pilot Air Screw
16020	KM-16020-7003	Float Chamber
16025	KM-16025-7017	Throttle Valve
16030	KM-16030-7003	Float Valve
16031	KM-16031-7002	Float
16041	KM-16041-7050	Choke Carburetor Shaft
16041A	KM-16041-7056	Throttle Carburetor Shaft
16073	KM-16073-7013	Insulator


Ref.	Part Number	Description
16186	KM-16186-7006	Choke Valve Assembly
21188	KM-21188-7002	Solenoid
49121	KM-49121-7018	Main Nozzle
59076	KM-59076-7019	Intake Manifold
92009	KM-92009-2083	Screw
92009A	KM-92009-2349	Screw
92063	KM-92063-7141	Main Jet, #122
92063A	KM-92063-7142	Main Jet, #124
92063B	KM-92063-7149	Main Jet, #120
92081	KM-92081-2234	Spring
92093	KM-92093-2100	Seal
92093A	KM-92093-7003	Seal
92145	KM-92145-2122	Spring
130	KM-130AA0630	Flanged Bolt, 6 x 30
172	KM-172BA06115	Stud Bolt, 6 x 115

Kawasaki FR730V-AS05 Air Filter/Muffler




Ref.	Part Number	Description
11011	KM-11011-7054	Air Filter Case
11013	KM-11013-7049	Air Filter Element
11060	KM-11060-7016	Muffler Gasket
11061	KM-11061-7086	Carburetor/Intake Pipe Gasket
16060	KM-16060-7038	Intake Pipe
42036	KM-42036-7017	Breather Sleeve
92009	KM-92009-2303	Screw
92015	KM-92015-1367	Nut
92066	KM-92066-0095	Plug
92170	KM-92170-2042	Clamp
92171	KM-92171-7007	Clamp
92173	KM-92173-7003	Clamp
92192	KM-92192-7146	Tube, 12.6 x 18.6 x 118
92192A	KM-92192-7165	Tube
92210	KM-92210-7027	Nut, M8
461	KM-461DA0800	Spring Washer, 8mm

Kawasaki FR730V-AS05 Fuel Tank/Fuel Valve



Ref.	Part Number	Description
42036	KM-42036-7015	Sleeve
49019	KM-49019-7005	Fuel Filter
49040	KM-49040-7008	Fuel Pump
92009	KM-92009-2303	Screw
92170	KM-92170-2009	Clamp
92171	KM-92171-7008	Clamp
92192	KM-92192-7148	Tube, 6.4 x 12.7 x 150
92192A	KM-92192-7172	Tube, 6.35 x 12.7 x 185
92192B	KM-92192-7188	Tube, 6.35 x 12.7 x 390

Kawasaki FR730V-AS05 Starter



Ref.	Part Number	Description
16146	KM-16146-7027	Cover Assembly
16146A	KM-16146-7030	Cover Assembly
21080	KM-21080-7006	Armature
21163	KM-21163-0714	Electric Starter
27012	KM-27012-7008	Hook
32085	KM-99999-0309	Stopper
59051	KM-59051-7034	Spur Gear
92093	KM-92093-7007	Seal
92145	KM-92145-7060	Spring
92154	KM-92154-7001	Bolt
92210	KM-92210-7017	Nut
92210A	KM-99999-0309	Nut
130	KM-130AA0840	Flanged Bolt, 8 x 40

56033



56070



Ref.	Part Number	Description
56033	KM-56033-7001	Manual Label
56070	KM-56070-7001	Warning Label

[illegible]

[illegible]



To order replacement parts, call a Customer Support Representative at (800) 965-4CUB.
Locate your nearest Cub Cadet dealer at (877) 282-8684
or visit www.cubcadet.com to find the nearest Cub Cadet dealer in your area.

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
