

Cub Cadet®

ILLUSTRATED PARTS MANUAL



RZT-S 42, 46, 50 & 54-inch Cutting Decks

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

To The Owner

Thank You

Thank you for purchasing a Cub Cadet Zero-Turn Tractor. It was carefully engineered to provide excellent performance when properly operated and maintained.

All information in this manual is relative to the most recent product information available at the time of printing. Please be aware that this Illustrated Part's Manual may cover a range of product specifications for various models.

Components listed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and equipment without notice and without incurring obligation.

Throughout this manual, all references to *right* (RH) and *left* (LH) are observed from the operating position.

Table of Contents

Drive System	4	42" Deck	20
Frame & Electrical	6	46" Deck	22
Engine Accessories (Kawasaki)	8	50" Deck	24
Engine Accessories (Kohler)	9	54" Deck	26
Deck Lift	10	LH Transmission 618-06996	28
Operator's Platform	11	RH Transmission 618-06997	30
Fuel Tank	12	Electrical Schematic	32
Fuel Tank (CA Models)	13	Labels	33
Seat Adjustment	14	Kawasaki FR691V-AS05	36
Front Axle	15	Kohler KT725-3012	50
Steering Column & Pedal Controls	16	Kohler KT730-3012	66
Steering Linkage	18	Kohler KT735-3013	82

Record Product Information

To ease in ordering replacement parts, please locate the model plate on the equipment and record the information in the provided area to the right. You can locate the model plate by looking beneath the seat.

MODEL NUMBER

--	--	--	--	--	--	--	--	--	--	--

SERIAL NUMBER

--	--	--	--	--	--	--	--	--	--	--


Painted Parts

When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXX-0637). Please refer to the table below for current color codes:

0637	Black	0685	Blue (Cub Cadet)
4021	Yellow (Cub Cadet)	0691	Black Jack (Cub Cadet Commercial)
0499	Beige (Cub Cadet)		


This page left intentionally blank.

Drive System




Ref.	Part Number	Description
1	918-04317	Wheel Hub Assembly
2	618-06996	Transmission Assembly, LH
3	618-06997	Transmission Assembly, RH
4	634-04293	Complete Wheel, 18 x 8.5-8 (42" & 46)
5	703-08570	Transmission Mounting Bracket
6	703-08605	Idler Bracket
7	703-08613A	Spring Mounting Bracket
8	703-08614A	Transmission Bracket
9	703-08615A	Transmission Bracket
10	710-0176	Hex Screw, 5/16-18 x 2.75
11	710-04389	Screw, TT, 5/16-18 x 2.25
12	710-04092	Hex Screw, 7/16-20 x 1.75
13	710-04484	Hex Washer Screw, 5/16-18 x .750
14	710-1315	Hex Washer Screw, 3/8-16 x 1.250
15	710-0514	Hex Screw, 3/8-16 x 1.00
16	710-3119	Hex Screw, 3/8-16 x .75
17	712-04063	Flange Lock Nut, 5/16-18
18	711-06112	Keeper Rod, .25 x 1.535
19	912-3020	Jam Lock Nut, 3/8-16
20	712-0459	Flange Lock Nut, 7/16-20
21	712-3050	Lug Nut, 7/16-14
22	714-04040	Bow-Tie Cotter Pin
23	732-04229	Extension Spring, .75 Dia. x 6.02
24	936-0227	Flat Washer, .390 x 1.50 x .134
25	738-04162C	Shoulder Spacer, .884 x .190
26	738-04192B	Rod, .405 Dia. x 14.0 LG
27	603-04173-0499	Rim Only, (42" & 26")
28	734-04246-0901	Tire Only, 18 x 8.5-8 (42" & 46")
29	603-04175-0499	Rim Only, (50" & 54")
30	734-1729-0901	Tire Only, 18 x 9.5-8 (50" & 54")
31	747-05657A	Bypass Rod
32	750-04561	Tube, .51 ID x .75 OD x 10.2
33	954-04317A	Belt, A-Type x 67.0
34	756-05042	Idler Pulley, 4.25 Dia.
35	634-04128-0911	Complete Wheel, 18 x 9.5-8 (50" & 54")
36	934-0255	Valve Tubeless
37	748-05029	Shoulder Spacer
38	783-08389	Pulley Cap
39	747-05653	Engine Keeper Rod (42")
	747-06044	Engine Keeper Rod (46", 50" & 54")

Frame & Electrical



Ref	Part Number	Description
1	603-05156	Muffler Shield Assembly
2	703-05383B	Retainer Plate
3	603-05024	Frame Assembly
4	703-08555	Transmission Mounting Bracket
5	703-08558	Rear Bumper
6	703-08671A	Muffler Mounting Shield Bracket, RH
7	703-08695	Muffler Mounting Shield Bracket, LH
8	703-09083	Muffler Shield
9	710-04484	Hex Washer Screw, 5/16-18 x .750
10	710-1652	Hex Washer Screw, 1/4-20 x .625
11	710-3005	Hex Screw, 3/8-16 x 1.25
12	703-09195	Lower Heat Shield
13	747-05685	Battery Rod
14	712-04065	Flange Lock Nut, 3/8-16
15	726-04072A	Clip, .250 Dia. x .500 LG
16	738-04058	Shoulder Spacer, .38 x 1.0 x .70
17	712-04064	Flange Lock Nut, 1/4-20
18	925-06154	Hour Meter/Service Minder
19	925-3233	Electric PTO Switch
20	725-06102A	Key Switch
21	725-04363	Interlock Switch
22	725-06153	Solenoid
23	925-05013	Seat Switch
24	625-05000	Key, Assembly
25	925-1707D	Battery
26	736-0607	Lock Washer, 5/16
27	738-04237A	Shoulder Screw, #10-32 x .500
—	725-06074	Harness Assembly

Engine Accessories (Kawasaki)




Ref.	Part Number	Description
1	710-0227	Hex Washer Screw, #8-18 x .500
2	710-05070	Screw, 1/4-20 x .50
3	710-1315	Tap Screw, 3/8-16 x 1.25
4	710-1376	Hex Screw, M8-1.25 x 16
5	710-3217	Screw, #8-32 x .375
6	712-0142	Hex Nut, #8-32
7	712-04064	Flange Lock Nut, 1/4-20
8	912-3005	Flange Lock Nut, 3/8-16
9	726-0205	Hose Clamp, .490 Dia.
10	731-09637	Throttle Control Knob

Ref.	Part Number	Description
11	936-0300	Flat Washer, .406 x .875 x .059
12	737-04138	Oil Drain
13	946-05131	Throttle Cable
14	946-1085A	Choke Cable
15	751-10349-28	Fuel Hose, 1/4
16	951-10517A	Oil Drain
17	751-11053A	Deflector, Muffler, Long
18	751-11471A	Muffler, Kawasaki Twin
19	751-3141-14	Oil Drain Hose
20	756-04494	Engine Pulley

Ref.	Part Number	Description
1	710-0227	Hex Washer Screw, #8-18 x .500
2	710-04683A	Hex Washer Screw, 3/8-16 x 1.00
3	710-05070	Screw, 1/4-20 x .50
4	710-1314A	Socket Head Screw, 5/16-18 x .750
5	710-3217	Screw, #8-32 x .375
6	712-0142	Hex Nut, #8-32
7	712-04064	Flange Lock Nut, 1/4-20
8	710-1652	Hex Washer Screw, 1/4-20 x .625
9	726-0205	Hose Clamp, .490 Dia.

Ref.	Part Number	Description
10	731-1999	Choke Plug
11	731-09637	Throttle Control Knob
12	946-05145	Throttle/Choke Control Cable
13	751-11053A	Muffler Deflector Long
14	751-10291A	Oil Drain Hose
15	751-10349-28	Fuel Hose, 1/4
16	751-10528A	Twin Muffler
17	756-04494	Engine Pulley


Deck Lift



Ref	Part Number	Description
1	603-05107A	Deck Lift Plate, RH
2	603-05108A	Deck Lift Plate, LH
3	603-05137	Deck Lift Shift Assembly
4	647-04267	Brake Rod Assembly
5	703-08591A	Lift Link Plate
6	703-08644	Rod Support Mounting Bracket
7	703-09621	Deck Lift Handle
8	710-3008	Hex Cap Screw, 5/16-18 x .75
9	710-3168	Carriage Bolt, 3/8-16 x 1.00
10	911-0832	Ferrule, 3/8-24 x .375
11	712-0229	Push Nut, 3/8
12	712-04063	Flange Lock Nut, 5/16-18
13	712-04065	Flange Lock Nut, 3/8-16
14	712-05046	Hex Nut, 1/2-13
15	714-04040	Bow-Tie Cotter Pin
16	714-04043	Bow-Tie Cotter Pin
17	916-0231	E-Type Ring, .750


Ref	Part Number	Description
18	720-04139B	Grip, .50 ID
19	726-05009	End Cap
20	731-05297	Spacer, .76 ID x .750 LG
21	731-08782	Deck Lift Bracket
22	732-04587	Extension Spring, .63 Dia. x 4.95 LG
23	936-0314	Washer, .375 x .700 x .030
24	736-3078	Flat Washer, .344 x 1.00 x .063
25	738-04278	Shoulder Screw, .500 x 1/4-20
26	738-05029	Shoulder Spacer, .854 x .232
27	938-0507B	Shoulder Screw, .500 Dia. x .434
28	741-3084	Flange Bearing, .751 x 1.125 x .375
29	747-05552B	Deck Lift Rod
30	747-05592A	Brake Rod
31	748-04069	Deck Lift pivot Cup
32	750-05658	Nylon Sleeve, .55 ID x 4.50 LG
33	710-04683A	Screw, 3/8-16 x 1.00

Operator's Platform




Ref.	Part Number	Description
1	703-08720A	Rear Tank Bracket
2	703-09332A	Rear Seatbox Brace
3	703-08762C	Height Index Bracket
4	703-09320	Seat Frame
5	703-09186B	Seatbox Plate
6	710-0376	Hex Cap Screw, 5/16-18 x 1.00
7	710-04484	Hex Washer Screw, 5/16-18 x .750
8	710-05109	Hex Washer Screw, 5/16-14 x 1.00
9	710-05424	Self Tapping Screw, 5/16-18 x .750
10	710-0607	Hex Washer Screw, 5/16-18 x .50
11	728-05012	Nut, 5/16-18
12	931-08687A	LJ Console
13	931-09459	RH Console
14	731-09477	Plastic Plug
15	738-04549A	Shoulder Screw, 1/4-20

Fuel Tank




Ref.	Part Number	Description
1	951-05137	Fuel Tank
2	935-0149	Fuel Tank Bushing
3	735-04081	Rubber Grommet
4	751-10442	Fuel Pickup Fitting
5	751-12118	Rollover Valve
6	951-12179B	Fuel Cap
7	751-12089-51	Vent Hose




Ref.	Part Number	Description
1	951-05137	Fuel Tank
2	703-08769	Carbon Canister Bracket
3	710-04484	Hex Washer Screw, 5/16-18 x .750
4	710-3008	Hex Screw, 5/16-18 x .75
5	712-04063	Flange Lock Nut, 5/16-18
6	936-3008	Flat Washer, .344 x .750 x .120
7	951-10589	Carbon Canister
8	951-10590	Cannister Filter Vent
9	951-10610	Cannister Adapter Bracket
10	751-10750-28	Low Perm Fuel Hose 7/32 Yellow
11	751-10749-30	Vent Hose, Carb
12	935-0149	Fuel Tank Bushing
13	735-04081	Rubber Grommet
14	751-10442	Fuel Pickup Fitting
15	751-12118	Rollover Valve
16	951-12426A	Fuel Cap

Seat Adjustment




Ref.	Part Number	Description
1	703-08734	Seat Bracket
2	710-04482A	Hex Flange Bolt, 3/8-16 x .875
3	710-04484	Hex Washer Screw, 5/16-18 x .750
4	712-04063	Flange Lock Nut, 5/16-18
5	732-04563	Compression Spring, .68 x 1.065 x .055
6	732-04849	Compression Spring, 1.50 x 3.90 x .200
7	757-04131	Seat
8	938-0296	Shoulder Screw, 5/16-18 x .437 x .268
9	783-06049	Seat Mount Bracket
10	783-06050	Seat Adjustment Lever
11	783-06448	Clip



Ref.	Part Number	Description
1	603-05059C	Caster Wheel Bracket
2	903-05106	Front Axle
3	710-0216	Hex Cap Screw, 3/8-16 x .75
4	710-04652	Bolt, 1/2-20 x 7.25
5	710-04656	Screw, 3/8-16 x 2.75
6	710-05398	Socket Head Screw, 5/16-18 x 1.00
7	710-06041	Hex Cap Screw, 5/16-18 x .75
8	710-06045	Hex Flange Screw, 3/8-16 x 2.25
9	710-3119	Hex Screw, 3/8-16 x .75
10	711-06081A	Pivot Gear Steering Shaft
11	712-04217	Flange Lock Nut, 3/8-16
12	912-3009	Hex Lock Nut, 5/16-18
13	912-3058	Hex Lock Nut, 1/2-20

Ref.	Part Number	Description
14	717-04952	12-Tooth Variable Gear
15	717-05133	13-Tooth Variable Spur Gear
16	731-09291A	Axle Cover, RH
17	731-09320A	Axle Cover, LH
18	736-05033A	Wave Washer, 1.25 x 1.00 x .300
19	738-05093	Shoulder Spacer, 1.75 x .180
20	738-04549A	Shoulder Screw, 1/4-20
21	750-04775A	Spacer, .51 ID x .75 OD x 5.825
22	750-04792	Hub, .76 x 1.23 x .92 LG
23	634-04711-0931	Wheel Assembly, 13 x 5-6
24	710-04483	Self Tapping Screw, 1/4-20 x .50
25	703-08642A	Floor Board
26	710-06093	Hex Flange Screw, 3/8-16 x 2.00

Steering Column & Pedal Controls




Steering Column & Pedal Controls

Ref.	Part Number	Description
1	603-04931A	Support Bracket Assembly, RH
2	603-05040	Brake Pedal Assembly
3	603-04938	Steering Column Assembly
4	647-04269A	Brake Pedal Assembly
5	647-04270A	Drive Pedal Assembly
6	703-09147	Tilt Steering Pedal
7	703-08604	Speed Bracket, LH
8	703-08606	Speed Bracket, RH
9	703-08620A	Steering Support Bracket
10	703-08621A	Lower Steering Wheel Column
11	703-08622	Lower Column Cover
12	703-08646A	Drive Pedal
13	703-08656	Support Bracket, LH
14	703-08675	Brake Pedal
15	703-08678A	Return to Neutral Link
16	703-08690	Reverse Pedal Bracket
17	703-08694A	Reverse Pedal
18	703-08754A	Forward pedal Bracket
19	710-0106	Hex Head Screw, 1/4-20 x 1.25
20	710-0433	Hex Head Screw, 1/4-20 x .625
21	710-04484	Hex Washer Screw, 5/16-18 x .750
22	710-05070	Screw, 1/4-20 x .5
23	710-0538	Hex Screw, 5/16-18 x .625
24	914-0474	Cotter Pin, .125 x .75
25	710-1245B	Hex Screw, 5/16-24 x .875
26	710-3005	Hex Screw, 3/8-16 x 1.25
27	710-3008	Hex Screw, 5/16-18 x .75
28	711-05068A	Clevis Pin, 5/16 x 4.135
29	711-05670	Clevis Pin, .224 Dia. x .625
30	712-04063	Flange Lock Nut, 5/16-18
31	712-04064	Flange Lock Nut, 1/4-20


Ref.	Part Number	Description
32	712-04065	Flange Lock Nut, 3/8-16
33	714-04040	Bow-Tie Cotter Pin, 72
34	916-0231	E-Ring, .750
35	717-04954	Steering Shaft
36	717-04960	14-Tooth Spur Gear
37	731-07358B	Column Cover
38	731-04039	Steering Wheel Cover
39	732-04748	Extension Spring, .70 OD x 3.035 LG
40	732-04949	Torsion Spring, 1.00 ID x .22
41	735-04117	Reverse Pedal Pad
42	735-04118A	Forward Pedal Pad
43	735-04136	Brake Pedal Pad
44	936-0192	Flat Washer, .535 x .930 x .090
45	736-0242	Bell Washer, .340 x .872 x .060
46	936-0264	Flat Washer, .330 x .630 x .064
47	936-0314	Thrust Washer, .375 x .700 x .030
48	736-3092	Flat Washer, .265 x 1.00 x .030
49	938-0296	Shoulder Screw, 5/16-18 x .437 x .268
50	938-0380	Shoulder Bolt, 3/8-16 x .500 x .270
51	738-04483	Shoulder Spacer, .375 x .625 x .20
52	738-04552A	Shoulder Spacer, 1.50 x .38 x .38
53	738-0929	Shoulder Screw, 3/8-16 x .496 x 1.445
54	941-0225	Hex Flange Bearing
55	741-04543	Hex Flange Bearing, 7/16
56	741-0495	Flange Bearing, .63 ID x .695 OD x .06
57	747-05654A	Front Brake Rod
58	948-0209	Flange Bearing, .63 ID x 1.50
59	748-04203	Cruise Latch
60	750-05635	Spacer, .385 ID x .875 OD x .458
61	631-04008A	Steering Wheel Assembly

Steering Linkage



Ref.	Part Number	Description
1	603-04976A	Steering Plate Assembly, RH
2	603-04980A	Steering Plate Assembly, LH
3	617-05018P	Steering Gear Assembly, RH
4	617-05017P	Steering Gear Assembly, LH
5	703-08600	Control Link
6	703-08882	Speed Cam Plate, LH
7	703-08883	Speed Cam Plate, RH
8	710-0276	Carriage Screw, 5/16-18 x 1.00
9	710-04484	Hex Washer Screw, 5/16-18 x .750
10	710-0520	Hex Screw, 3/8-16 x 1.50
11	710-3220	Hex Screw, 1/4-20 x 1.00
12	712-0266A	Nut, Jamlock, 3/8-16
13	712-04063	Flange Lock Nut, 5/16-18
14	712-04064	Flange Lock Nut, 1/4-20
15	712-04065	Flange Lock Nut, 3/8-16
16	712-04339	Nut, 5/16-18, Centerlock
17	712-0711	Jam Nut, 3/8-24
18	723-04080	Female Ball-Joint
19	726-0201	Speed Nut, .3125 ID
20	726-0233	Push Nut, .25 ID x .50 OD
21	936-0211	Flat Washer, .285 x 1.25 x .060
22	736-04639	Washer, .355 x 1.25 x .048
23	736-3010	Flat Washer, .407 x .812 x .135
24	937-3000	Grease Fitting, 3/16
25	738-05046	Shoulder Screw, 3/8-16 x .625 x .875
26	738-1014	Shoulder Screw, .500 x 1.25 x 3/8-16
27	741-04425	Ball Bearing, .25 x .625
28	747-05591A	Hydro Link, RH
29	747-05606A	Hydro Link, LH
30	747-06130	Drag Link, .375 Dia.
31	950-0535	Spacer, .380 ID x .625 OD x .21


42" Deck



Ref.	Part Number	Description
1	903-05125	42" Deck Assembly
2	918-04822A	Spindle Assembly
3	631-05191	Chute Deflector Assembly
4	683-05124	Deck Lift Bracket
5	703-08336C	Pivot Idler Bracket
6	703-09583	Bracket Belt Guard
7	710-1260A	Hex Washer Screw, 5/16-18 x .750
8	710-0573	Hex Cap Screw, 5/16-18 x 1.25
9	710-1652	Hex Washer Screw, 1/4-20 x .625
10	710-3005	Hex Cap Screw, 3/8-16 x 1.25
11	710-3144	Hex Cap Screw, 3/8-16 x 2.00
12	710-3157A	Screw, 7/16-20 x 3.25
13	710-3178	Carriage Screw, 3/8-16 x .75
14	712-0229	Push Nut, 3/8
15	712-04065	Flange Lock Nut, 3/8-16
16	712-0417A	Hex Flange Nut, 5/8-18
17	710-0376	Hex Cap Screw, 5/16-18 x 1.00
18	714-0162	Cotter Pin, 5/32 x 1.25
19	917-04074	Deck Adjustment Gear
20	917-05121	Electric PTO Clutch
21	921-04041	Water Nozzle Adapter
22	731-08698	Belt Cover
23	932-3127	Compression Spring, .66 x 1.9
24	732-04960	Extension Spring, .94 Dia. x 7.57
25	734-04155	Deck Ball Wheel, 5.0

Ref.	Part Number	Description
26	712-04063	Flange Lock Nut, 5/16-18
27	736-0262	Flat Washer, .385 x .870 x .092
28	736-0322	Flat Washer, .450 x 1.25 x .164
29	720-05010	Cap, .290 x .500
30	731-07487	Deck Wash Nozzle
31	738-04162C	Shoulder Spacer, .884 x .190
32	938-3056	Shoulder Screw, .5 x 2.5 x 3/8-16
33	942-04312	Blade, 2 in 1, 21.23
34	747-05608	Deck Spring Rod
35	747-06292	Deck Hanger Rod
36	738-04278	Shoulder Screw, .500 x 1/4-20
37	954-04033A	V-Belt
38	756-05042	Idler Pulley, 4.25 Dia.
39	756-04511B	Idler Pulley, 5.00 Dia.
40	748-05029	Shoulder Spacer
41	783-08389	Pulley Cap
42	936-0351	Washer, .760 x 1.50 x .030
43	738-1186A	Spindle Shaft
44	941-0919A	Ball Bearing
45	750-04936	Spacer, .792 x 1.060 x 1.860
46	956-1227	Deck Pulley
47	711-04847B	Hinge Pin
48	732-04372	Torsion Spring
49	783-06074A	Chute Bracket


46" Deck



Ref.	Part Number	Description
1	903-05123	46"Deck Assembly
2	918-05078	Spindle Assembly
3	631-05191	Chute Deflector Assembly
4	683-05124	Deck Lift Bracket
5	703-08612A	Idler Bracket
6	710-1260A	Hex Washer Screw, 5/16-18 x .750
7	710-3085	Hex Cap Screw, 3/8-16 x 3.50
8	710-05376	Carriage Screw, 3/8-16 x 1.75
9	710-0573	Hex Cap Screw, 5/16-18 x 1.25
10	710-1652	Hex Washer Screw, 1/4-20 x .625
11	710-3157A	Screw, 7/16-20 x 3.25
12	710-3178	Carriage Screw, 3/8-16 x .75
13	712-0229	Push Nut, 3/8
14	712-04065	Flange Lock Nut, 3/8-16
15	712-0417A	Hex Flange Nut, 5/8-18
16	710-0376	Hex Cap Screw, 5/16-18 x 1.00
17	714-0162	Cotter Pin, 5/32 x 1.25
18	917-04074	Deck Adjustment Gear
19	917-05122A	Electric PTO Clutch
20	921-04041	Water Nozzle Adapter
21	731-08698	Belt Cover
22	932-3127	Compression Spring, .66 x 1.9
23	732-04927	Extension Spring, 1.25 OD x 1.751
24	734-04155	Deck Ball Wheel, 5.0
25	712-04063	Flange Lock Nut, 5/16-18
26	736-0262	Flat Washer, .385 x .870 x .092

Ref.	Part Number	Description
27	736-0322	Flat Washer, .450 x 1.25 x .164
28	736-3052	Flat Washer, .406 x 1.00 x .105
29	720-05010	Cap, .290 x .500
30	731-07487	Deck Wash Nozzle
31	938-3056	Shoulder Screw, .5 x 2.5 x 3/8-16
32	942-04244A	Blade, 2 in 1, 23.25
33	747-05608	Deck Spring Rod
34	747-06292	Deck Hanger Rod
35	738-04278	Shoulder Screw, .500 x 1/4-20
36	954-04325	V-Belt
37	756-05042	Idler Pulley, 4.25 Dia.
38	756-04511B	Idler Pulley, 5.00 Dia.
39	703-09583	Bracket Belt Guard
40	783-08389	Pulley Cap
41	936-0351	Washer, .760 x 1.50 x .030
42	938-1128	Spindle Shaft
43	941-0919A	Ball Bearing
44	750-04936	Spacer, .792 x 1.060 x 1.860
45	750-1343	Spacer, .8 x 1.1 x 2.26
46	756-04356	Deck Pulley
47	711-04847B	Hinge Pin
48	732-04372	Torsion Spring
49	783-06074A	Chute Bracket
50	738-05013A	Shoulder Spacer
51	748-05029	Shoulder Spacer


50" Deck



Ref.	Part Number	Description
1	603-04947	Belt Cover, RH
2	603-04948	Belt Cover, LH
3	903-05121	50" Deck Assembly
4	918-04125B	Spindle Assembly
5	683-05124	Deck Lift Bracket
6	703-05825C	Idler Arm
7	703-09583	Bracket Belt Guard
8	703-3279	Stop Bracket
9	703-3511B	Finger Guard
10	710-0347	Hex Cap Screw, 3/8-16 x 1.75
11	710-04484	Hex Washer Screw, 5/16-18 x .750
12	710-0573	Hex Cap Screw, 5/16-18 x 1.25
13	710-3005	Hex Cap Screw, 3/8-16 x 1.25
14	710-3144	Hex Cap Screw, 3/8-16 x 2.00
15	710-3157A	Screw, 7/16-20 x 3.25
16	710-3168	Carriage Screw, 3/8-16 x 1.00
17	710-3178	Carriage Screw, 3/8-16 x .75
18	711-06092	J-Hook
19	712-04065	Flange Lock Nut, 3/8-16
20	712-0417A	Hex Flange Nut, 5/16-18
21	714-0162	Cotter Pin, 5.32 x 1.25
22	748-05029	Shoulder Spacer
23	917-04074	Deck Adjustment Gear
24	917-05122A	Electric PTO Clutch
25	921-04041	Water Nozzle Adapter
26	731-05679A	Front Roller
27	731-07487	Deck Wash Nozzle
28	932-3127	Compression Spring, .66 x 1.9
29	732-04927	Extension Spring, 1.25 OD x 1.751
30	710-1260A	Hex Washer Screw, 5/16-18 x .750

Ref.	Part Number	Description
31	734-04155	Deck Ball Wheel, 5.0
32	736-0262	Flat Washer, .385 x .870 x .092
33	736-0322	Flat Washer, .450 x 1.25 x .164
34	736-0407	Bell Washer, .45 x 1.0 x .062
35	738-04162C	Shoulder Spacer, .884 x .190
36	738-04278	Shoulder Screw, .500 x 1/4-20
37	938-3056	Shoulder Screw, .5 x 2.5 x 3/8-16
38	942-04053C	Blade, 2 in 1, 17.9
39	747-05608	Deck Spring Rod
40	747-06292	Deck Hanger Rod
41	954-05008	V-Belt
42	756-05042	Idler Pulley, 4.25 Dia
43	756-04511B	Idler Pulley, 5.00 Dia.
44	756-04216	V-Type Pulley, 5.39
45	783-08389	Pulley Cap
46	631-05162	Discharge Chute Assembly
47	710-1652	Hex Washer Screw, 1/4-20 x .625
48	712-0229	Push Nut, 3/8
49	783-04414A	Center Skirt
50	783-04415	RH Skirt
51	711-04565	Hinge Pin
52	732-04372	Torsion Spring
53	703-09623	Chute Bracket
54	736-0315	Flat Washer, .76 x 1.50 x .12
55	738-1010A	Spindle Shaft, 5.75
56	941-0919A	Ball Bearing
57	748-0160A	Spacer, .79 x 1.25 x .175
58	750-1000	Spacer, .80 x 1.10 x 1.32
59	750-1349A	Spacer, .79 x 1.82 x .55


54" Deck



Ref.	Part Number	Description
1	903-05144	54" Deck Assembly
2	603-05152	Deck Lift Bracket
3	918-06978	Spindle Assembly
4	703-09637	Idler Arm
5	710-0347	Hex Cap Screw, 3/8-16 x 1.75
6	710-0376	Hex Cap Screw, 5/16-18 x 1.00
7	710-04379A	Hex Cap Screw, 7/16-20 x 3.50
8	710-0573	Hex Cap Screw, 5/16-18 x 1.25
9	710-1260A	Hex Washer Screw, 5/16-18 x .750
10	710-3130	Hex Cap Screw, 3/8-16 x 3.25
11	712-04063	Flange Lock Nut, 5/16-18
12	712-04065	Flange Lock Nut, 3/8-16
13	712-0417A	Hex Flange Nut, 5/16-18
14	714-0162	Cotter Pin, 5.32 x 1.25
15	917-04074	Deck Adjustment Gear
16	717-05209	Electric PTO Clutch
17	921-04041	Water Nozzle Adapter
18	731-07487	Deck Wash Nozzle
19	731-09968	Belt Cover, RH
20	731-09969	Belt Cover, LH
21	732-04927	Extension Spring, 1.25 OD x 1.751
22	932-3127	Compression Spring, .66 x 1.9
23	734-04155	Deck Ball Wheel, 5.0
24	736-0322	Flat Washer, .450 x 1.25 x .164

Ref.	Part Number	Description
25	738-04278	Shoulder Screw, .500 x 1/4-20
26	738-05081	Shoulder Spacer
27	938-3056	Shoulder Screw, .5 x 2.5 x 3/8-16
28	942-05056	Blade, 18.67
29	747-05608	Deck Spring Rod
30	747-06292	Deck Hanger Rod
31	748-05029A	Shoulder Spacer
32	954-04329	V-Belt
33	756-04511B	Idler Pulley, 5.00 Dia.
34	756-05042	Idler Pulley, 4.25 Dia
35	783-08027	Belt Guard Bracket
36	783-08389	Pulley Cap
37	631-05168	Chute Assembly
38	710-05073	Screw, Sems, 1/4-20 x .50
39	732-04659	Torsion Spring
40	747-06290	Hinge Pin
41	783-08504	Chute Bracket
42	738-1186A	Spindle Shaft, 6.11 Long
43	941-0919A	Ball Bearing
44	750-04936	Spacer, .792 x 1.060 x 1.860
45	750-06152	Spacer, .792 x 1.060 x 1.782
46	756-05038	Deck Pulley
47	783-08435	Bearing Shield

LH Transmission 618-06996




LH Transmission 618-06996

Ref.	Part Number	Description
1	HG-71030L	Kit, Housing, Main, LH
2	HG-71031L	Kit, Housing, Side, LH
4	HG-70723	Kit, Block, 7 Piston
5	HG-52527	Spacer, .320 x 1.005 x .150
6	HG-70331	Kit, Block, 10cc Cylinder
7	HG-9005110-5600	Plug, 9/16-18
9	HG-53246	Screw, Hex Washer
15	HG-51625	Rod, Bypass
16	HG-51627	Ring, Ret .375 External
18	HG-51628	Ring, Retaining .375 External
19	HG-51048	Trunnion, Swashplate
24	736-0371	Washer, .34 x .88 x .06
27	HG-2003014	Spring, Block
28	HG-2003017	Washer, .59 x .79 x .04
29	HG-51062	Shaft, Input
30	HG-50315	Ball Bearing 17 x 40 x 12
31	HG-2000022	Ring, Reatining
32	HG-50951	Washer, 1.23 x 1.57 x .04
33	HG-51161	Seal, Lip 17 x 40 x 7
34	HG-50329	Ring Retaining Internal
35	HG-50551P	Thrust Bearing, 30 x 52 x 13
36	HG-44371	Washer, .63 x 1.00 x .05
37	HG-44145	Ring, Reatining, Motor Shaft
38	HG-51130	Gear, 13T Pinion
39	HG-52579	Shaft, Motor

Ref.	Part Number	Description
40	HG-51069	Washer, .71 x 1.16 x .04
41	HG-50132	Washer
42	HG-51129	Gear, 10T/48T
43	HG-51043	Gear, 10T Jackshaft
44	HG-51083	Pin, Jackshaft
45	HG-52531	Ring, Spiral Retaining-87
46	HG-52541	Gear, Bull 52T
47	HG-52532	Washer, 1.018 x 1.571 x .105
48	HG-52542	Buahing, Sleeve (Inboard)
49	HG-52545	Shaft, Axle, 1.00 x 11.70 DD
50	HG-51517	Bushing, 1.003 x 1.571 x .625
51	HG-51518	Seal, Lip, TC4, 1.00 x 1.577 x .27
52	HG-70853	Kit, Seals & Rings
53	HG-70868L	Kit, Expansion Plate LH
54	HG-72135	Kit, Fan & Pulley
55	HG-71892	Kit, Brake Arm
57	HG-71529	Kit, Center Section LH
59	HG-71006	Kit, Bypass Arm
61	HG-71497	Kit, Filter
131	HG-71341	Socket Cap Screw, 5/16-24 x 7/8
135	HG-51605	Spring, Extension
138	HG-71510	Kit, Breather
140	HG-51945	Arm, Left Return
200	HG-71588	Kit, RTN Bidirectional

RH Transmission 618-06997




Items Not Shown:
52 HG-70853 Seal Kit

RH Transmission 618-06997

Ref.	Part Number	Description	Ref.	Part Number	Description
1	HG-71030R	Kit, Housing, Main, RH	40	HG-51069	Washer, .71 x 1.16 x .04
2	HG-71031R	Kit, Housing, Side, RH	41	HG-50132	Washer
4	HG-70723	Kit, Block, 7 Piston	42	HG-51129	Gear, 10T/48T
5	HG-52527	Spacer, .320 x 1.005 x .150	43	HG-51043	Gear, 10T Jackshaft
6	HG-70331	Kit, Block, 10cc Cylinder	44	HG-51083	Pin, Jackshaft
7	HG-9005110-5600	Plug, 9/16-18	45	HG-52531	Ring, Spiral Retaining-87
9	HG-53246	Screw, Hex Washer	46	HG-52541	Gear, Bull 52T
14	HG-51628	Ring, Retaining .375 External	47	HG-52532	Washer, 1.018 x 1.571 x .105
15	HG-51625	Rod, Bypass	48	HG-52542	Bushing, Sleeve (Inboard)
16	HG-51627	Ring, Ret .375 External	49	HG-52545	Shaft, Axle, 1.00 x 11.70 DD
19	HG-51048	Trunnion, Swashplate	50	HG-51517	Bushing, 1.003 x 1.571 x .625
24	736-0371	Washer, .34 x .88 x .06	51	HG-51518	Seal, Lip, TC4, 1.00 x 1.577 x .27
27	HG-2003014	Spring, Block	52	HG-70853	Kit, Seals & Rings
28	HG-2003017	Washer, .59 x .79 x .04	53	HG-70868R	Kit, Expansion Plate RH
29	HG-51062	Shaft, Input	54	HG-72135	Kit, Fan & Pulley
30	HG-50315	Ball Bearing 17 x 40 x 12	55	HG-71893	Kit, Brake Arm
31	HG-2000022	Ring, Reatining	57	HG-71530	Kit, Center Section RH
32	HG-50951	Washer, 1.23 x 1.57 x .04	59	HG-71357	Kit, Bypass Arm
33	HG-51161	Seal, Lip 17 x 40 x 7	61	HG-71497	Kit, Filter
34	HG-50329	Ring Retaining Internal	131	HG-71341	Socket Cap Screw, 5/16-24 x 7/8
35	HG-50551P	Thrust Bearing, 30 x 52 x 13	135	HG-51605	Spring, Extension
36	HG-44371	Washer, .63 x 1.00 x .05	138	HG-71510	Kit, Breather
37	HG-44145	Ring, Reatining, Motor Shaft	140	HG-51946	Arm, Neutral Right
38	HG-51130	Gear, 13T Pinion	200	HG-71592	Kit, RTN Bidirectional
39	HG-52579	Shaft, Motor			

Electrical Schematic



777I25034



777D17303



777D17302



777D13929



777D16533



777D17287



777X46957 42"

Cub Cadet RZT S 42	
COMMON PARTS	ITEM NUMBER
Blade(s)	942-04319 (X2)
Extreme Blade(s)	942-04308-X (X2)
Deck belt(s)	954-0433A
Drive belt(s)	954-0437A
Spark Plug(s)	759-3336 (X2)
Air Filter	KH-32-483-0F-S1
Oil Filter	KH-12-050-01-S
Fuel Filter	KH-25-050-22-S1
Amount of oil & weight	58 oz / 10W-30
Battery Voltage	12 Volts
ACCESSORIES	ITEM NUMBER
Deck	15870002100
Mower Kit	15A30006100
Tire Chains	490-241-0021
Light Kit	15A70032100
Hiding Mower Cover	490-290-0013
Oil Siphon	490-850-0008
Blade Removal Tool	490-850-0005
Tire Sealant	490-325-0020
Oil Filter Wrench	490-800-0045
American Wax-Sink Spray	490-000-0062
Carburetor & Choke Cleaner	490-000-0028
32 oz. STA-BIL Fuel Additive	22216



777X46958 46"

Cub Cadet RZT S 46	
COMMON PARTS	ITEM NUMBER
Blade(s)	942-04319A (X2)
Extreme Blade(s)	942-04290-X (X2)
Deck belt(s)	954-04329
Drive belt(s)	954-0437A
Spark Plug(s)	759-3336 (X2)
Air Filter	KH-32-483-0F-S1
Oil Filter	KH-12-050-01-S
Fuel Filter	KH-25-050-22-S1
Amount of oil & weight	58 oz / 10W-30
Battery Voltage	12 Volts
ACCESSORIES	ITEM NUMBER
Deck	15870002100
Mower Kit	15A30006100
Tire Chains	15A70032100
Light Kit	490-241-0021
Hiding Mower Cover	15A70032100
Oil Siphon	490-290-0013
Blade Removal Tool	490-850-0008
Tire Sealant	490-325-0020
Oil Filter Wrench	490-800-0045
American Wax-Sink Spray	490-000-0062
Carburetor & Choke Cleaner	490-000-0028
32 oz. STA-BIL Fuel Additive	22216




777X46961 50" (Kaw.)
777X46960 50" (Koh.)

Cub Cadet RZT S 50	
COMMON PARTS	ITEM NUMBER
Blade(s)	942-04053C (X3)
Extreme Blade(s)	942-04053-X (X3)
Deck belt(s)	954-0500B
Drive belt(s)	954-0437A
Spark Plug	KM-BPRAES
Air Filter	KM-9999-0384
Oil Filter	KM-8066-7007
Fuel Filter	KM-49019-0014
Amount of oil & weight	70 oz / 10W-30
Battery Voltage	12 Volts
ACCESSORIES	ITEM NUMBER
Deck	15870002100
Mower Kit	15A30006100
Tire Chains	15A70032100
Light Kit	490-241-0022
Hiding Mower Cover	15A70032100
Oil Siphon	490-290-0013
Blade Removal Tool	490-850-0008
Tire Sealant	490-325-0020
Oil Filter Wrench	490-800-0045
American Wax-Sink Spray	490-000-0062
Carburetor & Choke Cleaner	490-000-0028
32 oz. STA-BIL Fuel Additive	22216




777X47207 54" (Kaw.)
777X47206 54" (Koh.)


Cub Cadet RZT S 54	
COMMON PARTS	ITEM NUMBER
Blade(s)	942-05056 (X3)
Deck belt(s)	954-05321
Drive belt(s)	954-0437A
Spark Plug(s)	KM-BPRAES (X2)
Air Filter	KM-9999-0384
Oil Filter	KM-8066-7007
Fuel Filter	KM-49019-0014
Amount of oil & weight	70 oz / 10W-30
Battery Voltage	12 Volts
ACCESSORIES	ITEM NUMBER
Deck	15A70043100
Mower Kit	15A70042100
Blade Removal Tool	490-850-0008
Tire Sealant	490-325-0020
Oil Filter Wrench	490-800-0045
American Wax-Sink Spray	490-000-0062
Carburetor & Choke Cleaner	490-000-0028
32 oz. STA-BIL Fuel Additive	22216



777I25048 (Kaw.)
Eff. to 11.1.13
777I25181 (Kaw.)
Eff. from 11.1.13



777I25049 (Koh.)
Eff. to 11.1.13
777I25182 (Koh.)
Eff. from 11.1.13



777S35331



777I23785



Labels

777D15397



777D15399



777S35296




777D15400



777D19178




777S35297



777D17127




777I25013



[illegible]

Kawasaki FR691V-AS05 Valve/Camshaft


E0130-A176A



Ref.	Part Number	Description
11055	KM-11055-7009	Bracket
12004	KM-12004-0705	Intake Valve
12005	KM-12005-0720	Exhaust Valve
12009	KM-12009-7001	Valvespring Retainer
12011	KM-12011-2056	Collet
12016	KM-12016-2066	Rocker Arm
12032	KM-12032-7001	Tappet
13070	KM-13070-7017	Governor Guide
13116	KM-13116-7007	Push Rod
13271	KM-13271-7007	Plate
13271A	KM-13271-7021	Governor Plate
42036	KM-42036-7010	Sleeve

Ref.	Part Number	Description
49078	KM-49078-7002	Engine Valve Spring, IN
49118	KM-49118-7022	Complete Camshaft
92033	KM-92033-7001	Snap Ring
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring
92152	KM-92152-1689	Collar
92153	KM-92153-7100	Bolt, 6 X 29.5
92200	KM-92200-2151	Washer, 8.1 X 18 X 0.5
92200A	KM-92200-7009	Washer, 16 X 42 X 0.91
92200B	KM-92200-7048	Washer, 16.3 X 30 X 2.28
130	KM-130AA0814	Flanged Bolt, 8 X 14
312	KM-312AA0600	Hex Nut, 6mm


E0120-A398A



Ref.	Part Number	Description
13001	KM-13001-7027	Engine Piston
13002	KM-13002-7006	Piston Pin
13008	KM-13008-7005	Piston Ring Set
13025	KM-13025-7009	Piston Ring Set, L ,0.5
13029	KM-13029-7010	Engine Piston, L, 0.5
13031	KM-13031-0747	Complete Crankshaft
13251	KM-13251-7025	Connecting Rod Assembly
92033	KM-92033-7016	Snap Ring
92151	KM-92151-7017	Bolt, 6 X 35

Kawasaki FR691V-AS05 Cylinder/Crankcase

E0110-A630A




Kawasaki FR691V-AS05 Cylinder/Crankcase

Ref.	Part Number	Description
11004	KM-11004-7026	Head Gasket
11008	KM-11008-7039	Complete Cylinder Head, #1
11008A	KM-11008-7040	Complete Cylinder Head, #2
11022	KM-11022-7019	Rocker Case, #1
11022A	KM-11022-7020	Rocker Case, #2
11061	KM-11061-7083	Rocker Case Gasket
11061A	KM-11061-7094	Breather Gasket
13272	KM-13272-7004	Breather Plate
14091	KM-14091-7064	Breather Cover
16126	KM-16126-7020	Breather Valve
32154	KM-32154-7019	Pipe
32155	KM-32155-7003	Breather Pipe
49015	KM-49015-7106	Crankcase Cover
49120	KM-49120-7129	Complete Crankcase
59071	KM-59071-2079	Joint
92043	KM-92043-1263	Pin
92049	KM-92049-7001	Oil Seal, RVC 26 x 11 x 10.2
92049A	KM-92049-7019	Oil Seal, SO 8 x 14 x 5 HS
92049B	KM-92049-7010	Oil Seal, SD 35 x 48 x 8 RHS
92049C	KM-92049-7028	Oil Seal, 38 x 62 x 8 MTCLV
92066	KM-92066-7023	Plug
92066A	KM-92066-7026	Plug
92153	KM-92153-7043	Bolt, 6 x 12
92153A	KM-92153-7054	Bolt, 8 x 50
130	KM-130AA0625	Flanged Bolt, 6 x 25
130A	KM-130CA1050	Flanged Bolt, 10 x 50
130B	KM-130CA1065	Flanged Bolt, 10 x 65
172	KM-172BA0818	Stud Bolt, 8 x 18
214	KM-214AA0408	Pan Screw +-, 4 x 8
670	KM-670B2011	O-Ring, 11mm


Kawasaki FR691V-AS05 Cooling Equipment

E0150-A873A



Ref.	Part Number	Description
13070	KM-13070-7019	Cooling Air Guide
13272	KM-13272-7006	Fan Plate
14037	KM-14037-70089H	Screen
23062	KM-23062-7005	Complete Bracket
49089	KM-49089-7079	Engine Shroud
49089A	KM-49089-7080	Engine Shroud
59041	KM-59041-7014	Fan
59066	KM-59066-7063	Fan Housing
92009	KM-92009-2303	Screw
92026	KM-92026-7007	Spacer
92151	KM-92151-7012	Bolt, 6 X 12
92153	KM-92153-7007	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12


E0140-A447A



Ref.	Part Number	Description
13272	KM-13272-7011	Rotor Plate
14075	KM-14075-7013	Oil Gauge Cap Assembly
16154	KM-16154-7010	Outer Pump Rotor
16154A	KM-16154-7011	Inner Pump Rotor
49065	KM-49065-7006	Oil Filter
49065A	KM-49065-7007	Oil Filter
59231	KM-59231-0712	Filler
92066	KM-92066-7003	Plug
92066A	KM-92066-7028	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7008	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12
555	KM-555A0420	Spring Pin, 4 X 20
670	KM-670D2016	O-Ring, 16mm

Kawasaki FR691V-AS05 Control Equipment


E0170-A652A



Ref.	Part Number	Description
13107	KM-13107-7047	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-7022	Link
39129	KM-39129-7035	Governor Spring
49103	KM-49103-7014	Governor Arm
49103A	KM-49103-7015	Governor Arm
49113	KM-49113-7050	Complete Control Panel
92145	KM-92145-7057	Spring
92145A	KM-92145-7058	Spring
92150	KM-92150-2182	Bolt, 5 X 18

Ref.	Part Number	Description
92153	KM-92153-0009	Bolt, 6 X 12
92153A	KM-92153-7033	Bolt, 6 X 35
92153B	KM-92153-7043	Bolt, 6 X 12
92170	KM-92170-7001	Clamp
92172	KM-92172-7035	Screw, 5 X 30
214	KM-214AA0408	Pan Screw +-, 4 X 8
311	KM-311AA0600	Hex Nut, 6mm
312	KM-312AA0500	Hex Nut, 5mm
411	KM-411AA0600	Plain Washer, 6mm

E0160-B284A




Ref.	Part Number	Description
13272	KM-13272-7012	Plate
21066	KM-21066-7017	Voltage Regulator
21171	KM-21171-0711	Ignition Coil Assembly
21193	KM-21193-7038	Flywheel Assembly
26011	KM-26011-7025	Lead Wire, L = 95
26031	KM-26031-7040	Harness
26031A	KM-26031-7041	Harness
26031B	KM-26031-1625	Harness
59031	KM-59031-7017	Charging Coil
92009	KM-92009-2303	Screw

Ref.	Part Number	Description
92009A	KM-92009-2308	Screw
92066	KM-92066-7026	Plug
92070	759-3339	Spark Plug
92072	KM-92072-7003	Band
92151	KM-92154-7003	Bolt, 12 X 30
92171	KM-92171-7008	Clamp
92172	KM-92172-7018	Screw, 5 X 20
92200	KM-92200-7002	Washer
130	KM-130AA0620	Flanged Bolt, 6 X 20
510	KM-510A5100	Woodruff Key

Kawasaki FR691V-AS05 Air Filter/Muffler


E0190-B094A



Ref.	Part Number	Description
11011	KM-11011-7065	Air Filter Case
11013	KM-99999-0384	Air Filter Element
11060	KM-11060-7016	Muffler Gasket
11061	KM-11061-7086	Carburetor/Pipe Intake Gasket
11065	KM-11065-7037	Cap
16060	KM-16060-7038	Intake Pipe
42036	KM-42036-7017	Breather Sleeve
92009	KM-92009-2303	Screw
92015	KM-92015-1367	Nut
92171	KM-92173-1001	Clamp
92173	KM-92173-7003	Clamp
92192	KM-92192-7146	Tube, 12.6 X 18.6 X 118
92192A	KM-99999-7082	Air Filter Tube
92210	KM-92210-7027	Nut, M8
461	KM-461DA0800	Spring Washer, 8mm

Kawasaki FR691V-AS05 Carburetor


E0180-A778A



Ref.	Part Number	Description
11061	KM-11061-7009	Chamber Gasket
11061A	KM-11061-7010	Screw Gasket
11061B	KM-11061-7093	Manifold Gasket
11061C	KM-11061-7087	Insulator Gasket
11061D	KM-11061-7088	Insulator/Manifold Gasket
13107	KM-13107-7018	Shaft
15004	KM-15004-0829	Carburetor Assembly
16014	KM-16014-7010	Pilot Air Screw
16020	KM-16020-7003	Float Chamber
16025	KM-16025-7017	Throttle Valve
16030	KM-16030-7003	Float Valve
16031	KM-16031-7002	Float
16041	KM-16041-0007	Choke Carburetor Shaft
16041A	KM-16041-7051	Throttle Carburetor Shaft
16073	KM-16073-7013	Insulator
16186	KM-16186-7006	Choke Valve Assembly

Ref.	Part Number	Description
21188	KM-21188-7002	Solenoid
39074	KM-39074-7001	Throttle Lever Assembly
49121	KM-49121-7018	Main Nozzle
59076	KM-59076-7019	Intake Manifold
92009	KM-92009-2083	Screw
92009A	KM-92009-2349	Screw
92009B	KM-92009-2402	Screw
92063	KM-92063-7141	Main Jet, #122
92063A	KM-92063-7142	Main Jet, #124
92063B	KM-92063-7149	Main Jet, #120
92081	KM-92081-2234	Spring
92093	KM-92093-2100	Seal
92093A	KM-92093-7003	Seal
92145	KM-92145-2122	Spring
130	KM-130AA0630	Flanged Bolt, 6 X 30
172	KM-172BA06115	Stud Bolt, 6 X 115


E0210-A452A



Ref.	Part Number	Description
16146	KM-16146-7027	Cover Assembly
16146A	KM-16146-7028	Cover Assembly
21080	KM-21080-7006	Armature
21163	KM-21163-0727	Electric Starter
27012	KM-27012-7004	Hook
32085	KM-99999-0309	Stopper
59051	KM-59051-7034	Spur Gear
92093	KM-92093-7007	Seal
92145	KM-92145-7060	Spring
92154	KM-92154-7001	Bolt
92210	KM-92210-7017	Nut
92210A	KM-99999-0309	Nut
130	KM-130AA0840	Flanged Bolt, 8 X 40

Kawasaki FR691V-AS05 Fuel Tank/Fuel Valve


E0200-A679A




Ref.	Part Number	Description
42036	KM-42036-7015	Sleeve
49019	KM-49019-0014	Fuel Filter
49040	KM-49040-7008	Fuel Pump
92009	KM-92009-2303	Screw
92170	KM-92170-2009	Clamp
92171	KM-92171-7008	Clamp
92192	KM-92192-7172	Tube, 6.35 X 12.7 X 185
92192A	KM-92192-7148	Tube, 6.4 X 12.7 X 150
92192B	KM-92192-7188	Tube, 6.35 X 12.7 X 390

Kawasaki FR691V-AS05 Engine Labels

56033




56070



Ref.	Part Number	Description
56033	KM-56033-7001	Manual Label
56070	KM-56070-7001	Warning Label


[illegible]

Kohler KT725-3012 Crankcase



Ref.	Part Number	Description
1	KH-24-126-243-S	Lifting Strap
2	KH-24-380-16-S	Locating Pin
3	KH-24-032-19-S	Oil Seal, 1.78 x 1.26
4	KH-24-018-01-S	Piston Pin Retainer
5	KH-25-108-01-S	Piston Ring Set (STD)
—	KH-25-108-02-S	Piston Ring Set (.08)
—	KH-25-108-03-S	Piston Ring Set (.25)
—	KH-25-108-04-S	Piston Ring Set (.50)
6	KH-25-874-13-S	Piston Kit w/ Ring (STD) (Inc. 4 & 5)
—	KH-25-874-15-S	Piston Kit w/ Ring (.08)
—	KH-25-874-16-S	Piston Kit w/ Ring (.25)
—	KH-25-874-17-S	Piston Kit w/ Ring (.50)
7	KH-24-067-30-S	Connecting Rod (STD)
—	KH-24-067-31-S	Connecting Rod (U/S .010) (25mm)
8	KH-24-018-09-S	Ring Retainer
9	KH-24-468-15-S	Flat Washer, 11/32"
10	KH-28-032-09-S	Governor Cross Shaft Seal
11	KH-24-144-38-S	Governor Cross Shaft
12	KH-M-931010-S	Flat Washer, 9 mm
13	KH-25-086-398-S	Thread Forming Screw
14	KH-12-153-07	O-Ring
15	KH-25-153-09-S	O-Ring
16	KH-32-010-07-S	Camshaft Assembly
17	KH-32-038-12-S	Dipstick Assembly
18	KH-32-123-14-S	Oil Fill Tube Assembly


Kohler KT725-3012 Head/Valve/Breather




Kohler KT725-3012 Head/Valve/Breather

Ref.	Part Number	Description
1	KH-32-841-02-S	Cylinder Head Gasket Kit (Inc. Head Mounting Hardware)
2	KH-62-086-08-S	Flange Screw, M10 x 1.5 x 90
3	KH-32-017-01-S	Intake Valve
4	KH-32-016-01-S	Exhaust Valve
5	KH-275067	Spacer (.010")
6	KH-12-755-03	Retainer Kit
7	KH-25-032-14-S	Valve Band Seal
8	KH-25-173-28-S	Valve Spring Cap
9	KH-32-089-05-S	Valve Spring
10	KH-25-599-01-S	Rocker Arm Pivot
11	KH-32-019-02-S	Tappet
12	KH-32-072-04-S	Rocker Stud
13	KH-32-100-05-S	Hex Nut Assembly (Inc. #14)
14	KH-25-086-168-S	Set Screw
15	KH-32-146-09-S	Guide Plate
16	KH-32-186-03-S	Rocker Arm
17	KH-32-411-04-S	Push Rod
18	KH-25-086-374-S	Pan Head Screw
19	KH-25-096-09-S	Rocker Cover
20	KH-12-402-02	Breather Reed
21	KH-32-050-06-S	Breather Filter
22	KH-32-468-01-S	Sealing Washer
23	KH-M-547050-S	Lock Nut, M5 x 8
24	KH-25-096-11-S	Rocker Cover
25	KH-32-318-21-S	Cylinder Head Assembly Kit, #1 (Inc. Exhaust Mounting Hardware)
26	KH-32-318-22-S	Cylinder Head Assembly Kit, #2 (Inc. Exhaust Mounting Hardware)
27	KH-25-326-62-S	Breather Hose
28	KH-32-096-16-S	Breather Cover
29	KH-32-072-05-S	Stud
30	KH-16-096-02-S	Breather Media Cover
31	KH-66-018-04-S	Reed Retainer
32	KH-25-086-400-S	Thread Forming Screw

Kohler KT725-3012 Oil Pan/Lubrication




Ref.	Part Number	Description
1	KH-24-086-17-S	Flange Screw, M8 x 1.25 x 45
2	KH-25-032-06-S	Oil Seal, 2.38 x 1.45
3	KH-25-139-57-S	Square Head Pipe Plug, 3/8
4	KH-32-199-17-S	Oil Pan Assembly
5	KH-12-144-02	Governor Gear Shaft
6	KH-12-380-01	Governor Regulating Pin
7	KH-24-448-02-S	Locking Tab
8	KH-32-310-02-S	Governor Gear Kit
9	KH-32-393-18-S	Oil Pump Assembly
10	KH-25-086-414-S	Button Head Screw
11	KH-12-050-01-S	Oil Filter
12	KH-32-089-06-S	Compression Spring
13	KH-32-162-06-S	Oil Screen
14	KH-25-099-27-S	Oil Pressure Switch




Ref.	Part Number	Description
1	KH-52-139-09-S	Cup Plug
2	KH-32-014-327-S	Crankshaft

Kohler KT725-3012 Ignition/Electrical



Ref.	Part Number	Description
1	KH-12-132-02-S	Spark Plug
2	KH-25-086-402-S	Thread Forming Screw
3	KH-237878	15 Amp Stator Kit
4	KH-25-086-361-S	Hex Flange Screw
5	KH-25-340-04-S	Square Key
6	KH-25-468-09-S	Flat Washer
7	KH-20-146-05-S	Fan Mounting Plate
8	KH-32-018-03-S	Flywheel Fan Retainer
9	KH-32-157-04-S	Fan
10	KH-32-162-03-S	Grass Screen
11	KH-25-086-473-S	Thread Forming Screw
12	KH-25-155-41-S	Connector
13	KH-25-454-03-S	Wire Tie
14	KH-32-025-25-S	Flywheel Assembly
15	KH-32-584-06-S	Ignition Module
16	KH-32-176-34-S	Wiring Harness
17	KH-32-518-02-S	Jumper Lead
18	KH-41-403-10-S	Rectifier Regulator

Kohler KT725-3012 Blower Housing & Baffles




Kohler KT725-3012 Blower Housing & Baffles

Ref.	Part Number	Description
1	KH-25-086-473-S	Thread Forming Screw
2	KH-25-086-450-S	Hi-Low Screw
3	KH-25-086-397-S	Thread Forming Screw
4	KH-32-146-15-S	Backing Plate
5	KH-32-063-19-S	Valley Baffle, #1 Cylinder
6	KH-32-063-20-S	Valley Baffle, #2 Cylinder
7	KH-25-086-400-S	Thread Forming Screw
8	KH-25-086-406-S	Thread Forming Screw
9	KH-32-063-17-S	Left Barrel Baffle
10	KH-32-063-18-S	Right Barrel Baffle
11	KH-32-027-17-S	Blower Housing
12	KH-32-445-01-S	Lift Strap
13	KH-25-086-449-S	Screw, M5-2.42
14	KH-32-314-06-S	Fixed Guard


[illegible]

Ref.	Part-Number	Description
1	KH-25-086-397-S	Thread Forming Screw
2	KH-24-089-03	Choke Return Spring
3	KH-32-089-03-S	Speed Control Spring
4	KH-24-089-55-S	Governor Spring
5	KH-25-158-08	Linkage Retaining Bushing
6	KH-25-158-11	Throttle Linkage Bushing
7	KH-32-090-07-S	Governor Spring Lever
8	KH-32-090-08-S	Speed Control Lever
9	KH-32-090-09-S	Speed Setting Lever
10	KH-32-090-12-S	Choke Lever
11	KH-24-112-27-S	Control Assembly Spacer
12	KH-24-468-01	Flat Washer, 5.5mm
13	KH-25-086-429-S	Thread Forming Screw
14	KH-25-086-398-S	Thread Forming Screw
15	KH-32-079-01-S	Throttle Linkage
16	KH-32-126-04-S	Control Bracket
17	KH-41-468-03	Spring Washer, 1/4
18	KH-32-089-07-S	Linkage Spring
19	KH-M-547050-S	Lock Nut, M5 x .8
20	KH-12-237-01	Cable Clamp
21	KH-25-086-405-S	Thread Forming Screw
22	KH-24-090-69-S	Governor Lever
23	KH-24-211-03-S	Bolt, M6 x 1.0 x 25
24	KH-M-641060-S	Flange Nut, M6 x 1.0
25	KH-24-079-22-S	Choke Linkage
26	KH-24-089-25-S	Governor Spring

Kohler KT725-3012 Air Intake/Filtration




Ref.	Part Number	Description
1	KH-25-173-09-S	Masking Cap
2	KH-32-094-13-S	Air Cleaner Base Assembly
3	KH-32-883-09-S1	Air Filter Element
4	KH-25-153-15-S	O-Ring
5	KH-32-083-10-S	Pre-Cleaner Element
6	KH-32-041-04-S	Air Cleaner Base Gasket
7	KH-32-096-20-S	Air Cleaner Cover Assembly



Ref.	Part Number	Description
1	KH-32-098-04-S	Starter Assembly
2	KH-M-851080-S	Flange Screw, M8 x 1.25 x 80


Kohler KT725-3012 Fuel System



Ref.	Part Number	Description
1	KH-25-072-25-S	Stud
2	KH-25-086-398-S	Thread Forming Screw
3	KH-M-641060-S	Flange Nut, M6 x 1.0
4	KH-25-050-22-S1	Fuel Filter
5	KH-24-153-27-S	Intake Port O-Ring
6	KH-25-111-81-S	Fuel Line, 24"
7	KH-25-237-37-S	Spring Hose Clamp
8	KH-47-154-01-S	Cable Clip
9	KH-24-086-12	Tap Screw, M6 x 1.7 x 18

Ref.	Part Number	Description
10	KH-24-393-16	Fuel Pump
11	KH-25-086-400-S	Thread Forming Screw
12	KH-32-326-08-S	Pulse Pump Hose
13	KH-32-853-43-S	Carburetor Kit
14	KH-24-164-91-S	Intake Manifold Kit
15	KH-M-651040-S	Flange Screw, M6 x 1.0 x 40
16	KH-24-041-52-S	Carburetor Gasket
17	KH-25-139-60-S	Pipe Plug, 1/8


Kohler KT725-3012 Labels



Artwork is representative.
Actual labels may differ depending on model and specification number.


Ref.	Part Number	Description
1	KH-25-113-70-S	Clear Laminate Decal
2	KH-25-454-05-S	Tie
3	KH-32-113-108-S	Decal, 22 HP

Kohler KT730-3012 Crankcase



Ref.	Part Number	Description
1	KH-24-126-243-S	Oil Fill Tube Bracket
2	KH-24-380-16-S	Locating Pin
3	KH-24-032-19-S	Oil Seal, 1.78 x 1.26
4	KH-24-018-01-S	Piston Pin Retainer
5	KH-25-108-01-S	Piston Ring Set (STD)
—	KH-25-108-02-S	Piston Ring Set (.08)
—	KH-25-108-03-S	Piston Ring Set (.25)
—	KH-25-108-04-S	Piston Ring Set (.50)
6	KH-25-874-13-S	Piston Kit w/ Ring (STD) (Inc. 4 & 5)
—	KH-25-874-15-S	Piston Kit w/ Ring (.08)
—	KH-25-874-16-S	Piston Kit w/ Ring (.25)
—	KH-25-874-17-S	Piston Kit w/ Ring (.50)
7	KH-24-067-30-S	Connecting Rod (STD)
—	KH-24-067-31-S	Connecting Rod (U/S .010) (25mm)
8	KH-24-018-09-S	Ring Retainer
9	KH-24-468-15-S	Flat Washer, 11/32"
10	KH-28-032-09-S	Governor Cross Shaft Seal
11	KH-24-144-38-S	Governor Cross Shaft
12	KH-M-931010-S	Flat Washer, 9 mm
13	KH-25-086-398-S	Thread Forming Screw
14	KH-12-153-07	O-Ring
15	KH-25-153-09-S	O-Ring
16	KH-32-010-07-S	Camshaft Assembly
17	KH-32-038-12-S	Dipstick Assembly
18	KH-32-123-14-S	Oil Fill Tube Assembly


Kohler KT730-3012 Head/Valve/Breather




Kohler KT730-3012 Head/Valve/Breather

Ref.	Part Number	Description
1	KH-32-841-02-S	Cylinder Head Gasket Kit (Inc. Head Mounting Hardware)
2	KH-62-086-08-S	Flange Screw, M10 x 1.5 x 90
3	KH-32-017-01-S	Intake Valve
4	KH-32-016-01-S	Exhaust Valve
5	KH-275067	Spacer (.010")
6	KH-12-755-03	Retainer Kit
7	KH-25-032-14-S	Valve Band Seal
8	KH-25-173-28-S	Valve Spring Cap
9	KH-32-089-05-S	Valve Spring
10	KH-25-599-01-S	Rocker Arm Pivot
11	KH-32-019-02-S	Tappet
12	KH-32-072-04-S	Rocker Stud
13	KH-32-100-05-S	Hex Nut Assembly (Inc. #14)
14	KH-25-086-168-S	Set Screw
15	KH-32-146-09-S	Guide Plate
16	KH-32-186-03-S	Rocker Arm
17	KH-32-411-04-S	Push Rod
18	KH-25-086-374-S	Pan Head Screw
19	KH-25-096-09-S	Rocker Cover
20	KH-12-402-02	Breather Reed
21	KH-32-050-06-S	Breather Filter
22	KH-32-468-01-S	Sealing Washer
23	KH-M-547050-S	Lock Nut, M5 x 8
24	KH-25-096-11-S	Rocker Cover
25	KH-32-318-21-S	Cylinder Head Assembly Kit, #1 (Inc. Exhaust Mounting Hardware)
26	KH-32-318-22-S	Cylinder Head Assembly Kit, #2 (Inc. Exhaust Mounting Hardware)
27	KH-25-326-62-S	Breather Hose
28	KH-32-096-16-S	Breather Cover
29	KH-32-072-05-S	Stud
30	KH-16-096-02-S	Breather Media Cover
31	KH-66-018-04-S	Reed Retainer
32	KH-25-086-400-S	Thread Forming Screw

Kohler KT730-3012 Oil Pan/Lubrication




Ref.	Part Number	Description
1	KH-24-086-17-S	Flange Screw, M8 x 1.25 x 45
2	KH-25-032-06-S	Oil Seal, 2.38 x 1.45
3	KH-25-139-57-S	Square Head Pipe Plug, 3/8
4	KH-32-199-17-S	Oil Pan Assembly
5	KH-12-144-02	Governor Gear Shaft
6	KH-12-380-01	Governor Regulating Pin
7	KH-24-448-02-S	Locking Tab
8	KH-32-310-02-S	Governor Gear Kit
9	KH-32-393-18-S	Oil Pump Assembly
10	KH-25-086-414-S	Button Head Screw
11	KH-12-050-01-S	Oil Filter
12	KH-32-089-06-S	Compression Spring
13	KH-32-162-06-S	Oil Screen
14	KH-25-099-27-S	Oil Pressure Switch




Ref.	Part Number	Description
1	KH-52-139-09-S	Cup Plug
2	KH-32-014-327-S	Crankshaft

Kohler KT730-3012 Ignition/Electrical



Ref.	Part Number	Description
1	KH-12-132-02-S	Spark Plug
2	KH-25-086-402-S	Thread Forming Screw
3	KH-237878	15 Amp Stator Kit
4	KH-25-086-361-S	Hex Flange Screw
5	KH-25-340-04-S	Square Key
6	KH-25-468-09-S	Flat Washer
7	KH-20-146-05-S	Fan Mounting Plate
8	KH-32-018-03-S	Flywheel Fan Retainer
9	KH-32-157-04-S	Fan
10	KH-32-162-03-S	Grass Screen
11	KH-25-086-473-S	Thread Forming Screw
12	KH-25-155-41-S	Connector
13	KH-25-454-03-S	Wire Tie
14	KH-32-025-25-S	Flywheel Assembly
15	KH-32-584-06-S	Ignition Module
16	KH-32-176-34-S	Wiring Harness
17	KH-32-518-02-S	Jumper Lead
18	KH-41-403-10-S	Rectifier Regulator


Kohler KT730-3012 Blower Housing & Baffles



Kohler KT730-3012 Blower Housing & Baffles


Ref.	Part Number	Description
1	KH-25-086-473-S	Thread Forming Screw
2	KH-25-086-450-S	Hi-Low Screw
3	KH-25-086-397-S	Thread Forming Screw
4	KH-32-146-15-S	Backing Plate
5	KH-32-063-19-S	Valley Baffle, #1 Cylinder
6	KH-32-063-20-S	Valley Baffle, #2 Cylinder
7	KH-25-086-400-S	Thread Forming Screw
8	KH-25-086-406-S	Thread Forming Screw
9	KH-32-063-17-S	Left Barrel Baffle
10	KH-32-063-18-S	Right Barrel Baffle
11	KH-32-027-17-S	Blower Housing
12	KH-32-445-01-S	Lift Strap
13	KH-25-086-449-S	Screw, M5-2.42
14	KH-32-314-06-S	Fixed Guard

Kohler KT730-3012 Engine Controls




Ref.	Part-Number	Description
1	KH-25-086-397-S	Thread Forming Screw
2	KH-24-089-03	Choke Return Spring
3	KH-32-089-03-S	Speed Control Spring
4	KH-24-089-55-S	Governor Spring
5	KH-25-158-08	Linkage Retaining Bushing
6	KH-25-158-11	Throttle Linkage Bushing
7	KH-32-090-07-S	Governor Spring Lever
8	KH-32-090-08-S	Speed Control Lever
9	KH-32-090-09-S	Speed Setting Lever
10	KH-32-090-12-S	Choke Lever
11	KH-24-112-27-S	Control Assembly Spacer
12	KH-24-468-01	Flat Washer, 5.5mm
13	KH-25-086-429-S	Thread Forming Screw
14	KH-25-086-398-S	Thread Forming Screw
15	KH-32-079-01-S	Throttle Linkage
16	KH-32-126-04-S	Control Bracket
17	KH-41-468-03	Spring Washer, 1/4
18	KH-32-089-07-S	Linkage Spring
19	KH-M-547050-S	Lock Nut, M5 x .8
20	KH-12-237-01	Cable Clamp
21	KH-25-086-405-S	Thread Forming Screw
22	KH-24-090-69-S	Governor Lever
23	KH-24-211-03-S	Bolt, M6 x 1.0 x 25
24	KH-M-641060-S	Flange Nut, M6 x 1.0
25	KH-24-079-22-S	Choke Linkage
26	KH-24-089-25-S	Governor Spring

Kohler KT730-3012 Air Intake/Filtration




Ref.	Part Number	Description
1	KH-25-173-09-S	Masking Cap
2	KH-32-094-13-S	Air Cleaner Base Assembly
3	KH-32-883-09-S1	Air Filter Element
4	KH-25-153-15-S	O-Ring
5	KH-32-083-10-S	Pre-Cleaner Element
6	KH-32-041-04-S	Air Cleaner Base Gasket
7	KH-32-096-20-S	Air Cleaner Cover Assembly



Ref.	Part Number	Description
1	KH-32-098-04-S	Starter Assembly
2	KH-M-851080-S	Flange Screw, M8 x 1.25 x 80


Kohler KT730-3012 Fuel System



Ref.	Part Number	Description
1	KH-25-072-25-S	Stud
2	KH-25-086-398-S	Thread Forming Screw
3	KH-M-641060-S	Flange Nut, M6 x 1.0
4	KH-25-050-22-S1	Fuel Filter
5	KH-24-153-27-S	Intake Port O-Ring
6	KH-25-111-81-S	Fuel Line, 24"
7	KH-25-237-37-S	Spring Hose Clamp
8	KH-47-154-01-S	Cable Clip
9	KH-24-086-12	Tap Screw, M6 x 1.7 x 18

Ref.	Part Number	Description
10	KH-24-393-16	Fuel Pump
11	KH-25-086-400-S	Thread Forming Screw
12	KH-32-326-08-S	Pulse Pump Hose
13	KH-32-853-34-S	Carburetor Kit
14	KH-24-164-91-S	Intake Manifold Kit
15	KH-M-651040-S	Flange Screw, M6 x 1.0 x 40
16	KH-24-041-52-S	Carburetor Gasket
17	KH-25-139-60-S	Pipe Plug, 1/8


Kohler KT730-3012 Labels



Artwork is representative.
Actual labels may differ depending on model and specification number.


Ref.	Part Number	Description
1	KH-25-113-70-S	Clear Laminate Decal
2	KH-25-454-05-S	Tie
3	KH-32-113-107-S	Decal, 23 HP

Kohler KT735-3013 Crankcase



Ref.	Part Number	Description
1	KH-24-126-243-S	Oil Fill Tube Bracket
2	KH-24-380-16-S	Locating Pin
3	KH-24-032-19-S	Oil Seal, 1.78 x 1.26
4	KH-24-018-01-S	Piston Pin Retainer
5	KH-25-108-01-S	Piston Ring Set (STD)
—	KH-25-108-02-S	Piston Ring Set (.08)
—	KH-25-108-03-S	Piston Ring Set (.25)
—	KH-25-108-04-S	Piston Ring Set (.50)
6	KH-25-874-13-S	Piston Kit w/ Ring (STD) (Inc. 4 & 5)
—	KH-25-874-15-S	Piston Kit w/ Ring (.08)
—	KH-25-874-16-S	Piston Kit w/ Ring (.25)
—	KH-25-874-17-S	Piston Kit w/ Ring (.50)
7	KH-24-067-30-S	Connecting Rod (STD)
—	KH-24-067-31-S	Connecting Rod (U/S .010) (25mm)
8	KH-24-018-09-S	Ring Retainer
9	KH-24-468-15-S	Flat Washer, 11/32"
10	KH-28-032-09-S	Governor Cross Shaft Seal
11	KH-24-144-38-S	Governor Cross Shaft
12	KH-M-931010-S	Flat Washer, 9 mm
13	KH-25-086-398-S	Thread Forming Screw
14	KH-12-153-07	O-Ring
15	KH-25-153-09-S	O-Ring
16	KH-32-010-07-S	Camshaft Assembly
17	KH-32-038-12-S	Dipstick Assembly
18	KH-32-123-14-S	Oil Fill Tube Assembly


Kohler KT735-3013 Head/Valve/Breather




Kohler KT735-3013 Head/Valve/Breather

Ref.	Part Number	Description
1	KH-32-841-02-S	Cylinder Head Gasket Kit (Inc. Head Mounting Hardware)
2	KH-62-086-08-S	Flange Screw, M10 x 1.5 x 90
3	KH-32-017-01-S	Intake Valve
4	KH-32-016-01-S	Exhaust Valve
5	KH-275067	Spacer (.010")
6	KH-12-755-03	Retainer Kit
7	KH-25-032-14-S	Valve Band Seal
8	KH-25-173-28-S	Valve Spring Cap
9	KH-32-089-05-S	Valve Spring
10	KH-25-599-01-S	Rocker Arm Pivot
11	KH-32-019-02-S	Tappet
12	KH-32-072-04-S	Rocker Stud
13	KH-32-100-05-S	Hex Nut Assembly (Inc. #14)
14	KH-25-086-168-S	Set Screw
15	KH-32-146-09-S	Guide Plate
16	KH-32-186-03-S	Rocker Arm
17	KH-32-411-04-S	Push Rod
18	KH-25-086-374-S	Pan Head Screw
19	KH-25-096-09-S	Rocker Cover
20	KH-12-402-02	Breather Reed
21	KH-32-050-06-S	Breather Filter
22	KH-32-468-01-S	Sealing Washer
23	KH-M-547050-S	Lock Nut, M5 x 8
24	KH-25-096-11-S	Rocker Cover
25	KH-32-318-21-S	Cylinder Head Assembly Kit, #1 (Inc. Exhaust Mounting Hardware)
26	KH-32-318-22-S	Cylinder Head Assembly Kit, #2 (Inc. Exhaust Mounting Hardware)
27	KH-25-326-62-S	Breather Hose
28	KH-32-096-16-S	Breather Cover
29	KH-32-072-05-S	Stud
30	KH-16-096-02-S	Breather Media Cover
31	KH-66-018-04-S	Reed Retainer
32	KH-25-086-400-S	Thread Forming Screw

Kohler KT735-3013 Oil Pan/Lubrication




Ref.	Part Number	Description
1	KH-24-086-17-S	Flange Screw, M8 x 1.25 x 45
2	KH-25-032-06-S	Oil Seal, 2.38 x 1.45
3	KH-25-139-57-S	Square Head Pipe Plug, 3/8
4	KH-32-199-17-S	Oil Pan Assembly
5	KH-12-144-02	Governor Gear Shaft
6	KH-12-380-01	Governor Regulating Pin
7	KH-24-448-02-S	Locking Tab
8	KH-32-310-02-S	Governor Gear Kit
9	KH-32-393-18-S	Oil Pump Assembly
10	KH-25-086-414-S	Button Head Screw
11	KH-12-050-01-S	Oil Filter
12	KH-32-089-06-S	Compression Spring
13	KH-32-162-06-S	Oil Screen
14	KH-25-099-27-S	Oil Pressure Switch




Ref.	Part Number	Description
1	KH-52-139-09-S	Cup Plug
2	KH-32-014-327-S	Crankshaft

Kohler KT735-3013 Ignition/Electrical



Ref.	Part Number	Description
1	KH-12-132-02-S	Spark Plug
2	KH-25-086-402-S	Thread Forming Screw
3	KH-237878	15 Amp Stator Kit
4	KH-25-086-361-S	Hex Flange Screw
5	KH-25-340-04-S	Square Key
6	KH-25-468-09-S	Flat Washer
7	KH-20-146-05-S	Fan Mounting Plate
8	KH-32-018-03-S	Flywheel Fan Retainer
9	KH-32-157-04-S	Fan
10	KH-32-162-03-S	Grass Screen
11	KH-25-086-473-S	Thread Forming Screw
12	KH-25-155-41-S	Connector
13	KH-25-454-03-S	Wire Tie
14	KH-32-025-25-S	Flywheel Assembly
15	KH-32-584-06-S	Ignition Module
16	KH-32-176-34-S	Wiring Harness
17	KH-32-518-02-S	Jumper Lead
18	KH-41-403-10-S	Rectifier Regulator


Kohler KT735-3013 Blower Housing & Baffles



Kohler KT735-3013 Blower Housing & Baffles


Ref.	Part Number	Description
1	KH-25-086-473-S	Thread Forming Screw
2	KH-25-086-450-S	Hi-Low Screw
3	KH-25-086-397-S	Thread Forming Screw
4	KH-32-146-15-S	Backing Plate
5	KH-32-063-19-S	Valley Baffle, #1 Cylinder
6	KH-32-063-20-S	Valley Baffle, #2 Cylinder
7	KH-25-086-400-S	Thread Forming Screw
8	KH-25-086-406-S	Thread Forming Screw
9	KH-32-063-17-S	Left Barrel Baffle
10	KH-32-063-18-S	Right Barrel Baffle
11	KH-32-027-17-S	Blower Housing
12	KH-32-445-01-S	Lift Strap
13	KH-32-314-06-S	Fixed Guard

Kohler KT735-3013 Engine Controls




Ref.	Part-Number	Description
1	KH-25-086-397-S	Thread Forming Screw
2	KH-24-089-03	Choke Return Spring
3	KH-32-089-03-S	Speed Control Spring
4	KH-24-089-55-S	Governor Spring
5	KH-25-158-08	Linkage Retaining Bushing
6	KH-25-158-11	Throttle Linkage Bushing
7	KH-32-090-07-S	Governor Spring Lever
8	KH-32-090-08-S	Speed Control Lever
9	KH-32-090-09-S	Speed Setting Lever
10	KH-32-090-12-S	Choke Lever
11	KH-24-112-27-S	Control Assembly Spacer
12	KH-24-468-01	Flat Washer, 5.5mm
13	KH-25-086-429-S	Thread Forming Screw
14	KH-25-086-398-S	Thread Forming Screw
15	KH-32-079-01-S	Throttle Linkage
16	KH-32-126-04-S	Control Bracket
17	KH-41-468-03	Spring Washer, 1/4
18	KH-32-089-07-S	Linkage Spring
19	KH-M-547050-S	Lock Nut, M5 x .8
20	KH-12-237-01	Cable Clamp
21	KH-25-086-405-S	Thread Forming Screw
22	KH-24-090-69-S	Governor Lever
23	KH-24-211-03-S	Bolt, M6 x 1.0 x 25
24	KH-M-641060-S	Flange Nut, M6 x 1.0
25	KH-24-079-22-S	Choke Linkage
26	KH-24-089-25-S	Governor Spring

Kohler KT735-3013 Air Intake/Filtration




Ref.	Part Number	Description
1	KH-25-173-09-S	Masking Cap
2	KH-32-094-13-S	Air Cleaner Base Assembly
3	KH-32-883-09-S1	Air Filter Element
4	KH-25-153-15-S	O-Ring
5	KH-32-083-10-S	Pre-Cleaner Element
6	KH-32-041-04-S	Air Cleaner Base Gasket
7	KH-32-096-20-S	Air Cleaner Cover Assembly



Ref.	Part Number	Description
1	KH-32-098-04-S	Starter Assembly
2	KH-M-851080-S	Flange Screw, M8 x 1.25 x 80


Kohler KT735-3013 Fuel System



Ref.	Part Number	Description
1	KH-25-072-25-S	Stud
2	KH-25-086-398-S	Thread Forming Screw
3	KH-M-641060-S	Flange Nut, M6 x 1.0
4	KH-24-050-13-S	Fuel Filter
5	KH-24-153-27-S	Intake Port O-Ring
6	KH-25-111-81-S	Fuel Line, 24"
7	KH-25-237-37-S	Spring Hose Clamp
8	KH-47-154-01-S	Cable Clip
9	KH-24-086-12	Tap Screw, M6 x 1.7 x 18

Ref.	Part Number	Description
10	KH-24-393-16	Fuel Pump
11	KH-25-086-400-S	Thread Forming Screw
12	KH-32-326-08-S	Pulse Pump Hose
13	KH-32-853-34-S	Carburetor Kit
14	KH-24-164-91-S	Intake Manifold Kit
15	KH-M-651040-S	Flange Screw, M6 x 1.0 x 40
16	KH-24-041-52-S	Carburetor Gasket
17	KH-25-139-60-S	Pipe Plug, 1/8

Kohler KT735-3013 Labels



Artwork is representative.
Actual labels may differ depending on model and specification number.

Ref.	Part Number	Description
1	KH-25-113-70-S	Clear Laminate Decal
2	KH-25-454-05-S	Tie
3	KH-32-113-106-S	Decal, 24 HP

[illegible]

[illegible]



To order replacement parts, call a Customer Support Representative at (800) 965-4CUB.
Locate your nearest Cub Cadet dealer at (877) 282-8684
or visit www.cubcadet.com to find the nearest Cub Cadet dealer in your area.

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
