

Cub Cadet.


ILLUSTRATED PARTS MANUAL



Log Splitter — LS 33 CC & LS 27 CC

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019


Cub Cadet LS 27 CC




Ref.	Part Number	Description
1.	718-0769A	Hydraulic Cylinder
2.	727-04166	Hydraulic Tube
3.	710-1018	Hex Cap Screw, 1/2-20 x 2.75
4.	737-0192	90 Degree Solid Adapter
5.	718-0481A	Control Valve
6.	737-0153	Return Elbow
7.	737-0238	Nipple Pipe, 1/2-14
8.	710-1806	Hex Cap Screw, 1/2-13 x 3.25
9.	719-0550A	Wedge Assembly
10.	712-3058	Hex Lock Nut, 1/2-20
11.	712-0711	Hex Jam Nut, 3/8-24
12.	710-0459A	Hex Cap Screw, 3/8-24 x 1.5
13.	781-0351	Adjustable Gib
14.	736-0116	Flat Washer, .635 x.93 x.06
15.	712-3022	Hex Lock Nut, 1/2-13
16.	681-04071A	Beam Assembly
17.	710-3056	Hex Screw, 5/16-18 x 3.25
18.	710-0654A	Hex Washer Screw, 3/8-16 x 1.0
19.	781-1048A	Dislodger Bracket
20.	781-0790	Back Plate
21.	737-04093	Inlet Filter
22.	727-0443	Return Hose, 3/4" ID x 44" Lg.
23.	726-0132	Hose Clamp, 5/8"
24.	737-0316	Filter Housing
25.	723-0405	Oil Filter
26.	734-0873	Hub Cap
27.	714-0162	Cotter Pin
28.	712-0359	Slotted Nut, 3/4-16
29.	634-0187	Wheel Assembly
30.	736-0351	Flat Washer, .760 ID x.500 OD
31.	737-0312	Adapter, 3/4-14
32.	781-0526A	Hose Guard
33.	737-0348A	Vented Dipstick
34.	711-1587	Clevis Pin
35.	781-0690	Lock Rod
36.	714-0470	Cotter Pin
37.	726-0214	Push Cap
38.	732-0583	Compression Spring
39.	781-04180	Log Tray Bracket

Ref.	Part Number	Description
40.	710-04484	TT Screw, 5/16-18 x .750
41.	712-04065	Flange Lock Nut, 3/8-16
42.	781-04179	Log Tray
43.	681-04040A	Frame Assembly
44.	710-0521	Hex Bolt, 3/8-16 x 3"
45.	719-0353	Coupling Shield
46.	714-0122	Square Key, 3/16" x.75
47.	718-04145	Flexible Coupling
48.	712-04063	Flange Lock Nut, 5/16-18
49.	781-0097	Rear Coupling Support Bracket
50.	781-1045	Beam Support
51.	727-04130	Hose
52.	718-04127	Gear Pump
53.	737-0329	45 Degree Elbow Fitting
54.	727-0502	High Pressure Hydraulic Hose
55.	781-0788	Tongue Assembly
56.	747-1261	Latch Rod
57.	710-0521	Hex Head Screw, 3/8-16 x 3
58.	732-3127	Compression Spring
59.	710-04065	Flange Lock Nut, 3/8-16
60.	781-0538A	Hose Guard
61.	710-3085	Hex Cap Screw, 3/8-16 x 3.50
62.	736-0185	Flat Washer, .375 x.738 x .063
63.	747-04539	Hydraulic Valve Control
64.	681-04030	Hitch Coupling Assembly
65.	713-0433A	Chain
66.	781-04002	Fender
67.	713-04036	Valve Handle Link
68.	720-04088	Grip
69.	710-0376	Hex Screw, 5/16-18 x 1.00
70.	681-04029	Adjustable Assembly Stand
71.	715-0111	Cotter Pin, 3/32 x 1.00
72.	710-0650	TT Screw, 5/16-18 x 0.875"
73.	711-04585	Clevis Pin
74.	625-0062	Light Kit
75.	681-0164	Light Bracket, LH
—	781-1027A	Light Bracket, RH
76.	712-3008	Jam Nut, 3/8-16
77.	715-0120	Spirol Pin, 3/16 x 1.00

Cub Cadet LS 27 CC (Honda GCV160LA)




Ref.	Part Number	Description
1	12000-ZL8-425	Cylinder Assy.
3	12209-ZM0-003	Seal, Valve Stem
4	12311-ZL8-D00	See Part Details - Pri; Cover, Head
4	12311-ZL8-000	See Part Details - Sup; Cover, Head
5	12355-ZL8-000	Cover, Breather
6	14711-Z0J-000	Pri; Valve, In. (Rocknel)
7	14721-ZL8-000	Valve, Ex.
8	14751-ZL8-000	Spring, Valve
9	14771-Z0J-000	Retainer, Valve Spring
10	90013-883-000	Bolt, Flange (6x12) (Ct200)
11	90014-952-000	Bolt, Flange (6x14) (Ct200)
12	91201-ZL8-003	Oil Seal (25.4x62x6)
13	98079-56846	Spark Plug (Bpr6es) (NGK)




Ref.	Part Number	Description
1	11300-Z0L-821	Pan Assy., Oil (Sae)
3	15625-Z2L-801	Gasket, Oil Filler Cap
7	15650-Z0L-000	Gauge Assy., Oil Level
8	16508-ZM0-010	Pri; Shaft, Governor Holder
9	16510-ZM0-010	Pri; Governor Assy.
10	16511-ZL8-000	Weight, Governor
11	16512-ZM0-000	Holder, Governor Weight
12	16513-ZE1-000	Pin, Governor Weight
13	16531-ZE1-000	Slider, Governor
14	16541-ZM0-000	Shaft, Governor Arm
15	90014-952-000	Bolt, Flange (6x14) (Ct200)

Ref.	Part Number	Description
16	90121-952-000	Bolt, Flange (6x25) (Ct200)
17	90131-883-000	Sup; Bolt, Drain Plug (12x15)
17	90131-896-650	Pri; Bolt, Drain Plug
18	90451-ZE1-000	Washer, Thrust (6mm)
19	90602-ZE1-000	Pri; Clip, Governor Holder
20	91202-ZM0-V31	Oil Seal (28x41.25x6)
23	94101-06800	Washer, Plain (6mm)
24	94109-12000	Washer, Drain Plug (12mm)
25	94251-08000	Pin, Lock (8mm)
26	94301-08200	Pin, Dowel (8x20)

Cub Cadet LS 27 CC (Honda GCV160LA)




Cub Cadet LS 27 CC (Honda GCV160LA)




Ref.	Part Number	Description
1	13010-Z0L-014	Ring Set, Piston (Std). (Teikoku)
2	13101-Z2A-010	Piston
3	13111-ZE0-000	Pin, Piston
4	13200-Z0J-000	Rod Assy., Connecting.
5	90001-ZE1-000	Bolt, Connecting Rod.
6	90551-ZE0-000	Clip, Piston Pin (13mm)

Cub Cadet LS 27 CC (Honda GCV160LA)




Ref.	Part Number	Description
1	14320-ZL8-010	Pulley, Camshaft.
2	14324-ZL8-000	Shaft, Cam Pulley
3	14400-Z0J-014	Belt, Timing (84hu7 G-200)
4	14431-Z0J-000	Arm, In. Valve Rocker
5	14441-Z0J-000	Pri; Arm, Ex. Valve Rocker
6	14461-ZL8-000	Shaft, Rocker Arm
7	90012-333-000	Screw, Tappet Adjusting
8	90206-001-000	Nut, Tappet Adjusting.
9	91301-ZM0-V31	O-ring (6.8x1.9) (Arai).

Cub Cadet LS 27 CC (Honda GCV160LA)



Ref.	Part Number	Description
1	28400-ZL8-023ZA	Pri; Starter Assy., Recoil *nh1*
3	28461-ZL8-003	Grip, Starter.
4	28462-ZL8-003	Rope, Recoil Starter.
5	90201-ZM0-000	Nut, Flange (6mm).


Cub Cadet LS 27 CC (Honda GCV160LA)



Ref.	Part Number	Description
3	16854-ZH8-000	Rubber, Supporter (107mm)
5	16950-ZM0-003	Petcock Assy.
6	16952-ZA8-800	Filter, Fuel
7	17511-Z0L-000	Tank, Fuel
8	17514-Z0L-000	Seal, Fuel Filler Neck
9	17516-Z0L-000	Clip, Tank Mounting.
10	17532-Z0L-000	Rubber A, Tank Mounting
11	17533-Z0L-000	Rubber B, Tank Mounting
12	17534-Z0L-000	Nut, Tank Mounting
13	17620-Z0J-800	Cap Assy., Fuel Tank.
14	17636-Z0L-000	Gauge, Fuel Level

Ref.	Part Number	Description
16	17701-Z0L-810	Tube, Fuel Tank
17	17702-ZM0-800	Tube, Fuel
19	19610-Z0L-850ZA	Cover, Fan *nh1* (Black)
20	19619-ZL8-300	Collar, Fan Cover
21	91501-Z0L-800	Collar, Fuel Petcock
23	90043-ZL8-000	Bolt, Stud (H=42.5mm)
26	93891-05010-08	Screw-washer (5x10)
29	95002-02080	Clip, Tube (B8)
30	95002-02100	Clip, Tube (B10)
33	95002-70000	Clip, Tube (C11)


Cub Cadet LS 27 CC (Honda GCV160LA)



Ref.	Part Number	Description
1	16010-883-015	Gasket Set.
2	16013-ZL1-003	Float Set
3	16015-887-782	Chamber Set, Float
5	16024-ZE1-811	Screw Set, Drain
6	16028-ZE0-005	Screw Set
8	16100-Z0L-861	Carburetor Assy..
9	16155-ZM0-013	Valve, Float
10	16166-ZM0-003	Nozzle, Main
13	16211-ZL8-000	Insulator, Carburetor


Ref.	Part Number	Description
14	16212-ZL8-000	Gasket, Insulator
15	16221-883-800	Gasket, Carburetor
16	16228-ZL8-000	Gasket, Carburetor
19	19650-ZM0-000	Guide, Air
20	93500-05006-0H	Screw, Pan (5x6)
22	99101-124-0600	Jet, Main (#60)
22	99101-124-0620	Jet, Main (#62)
22	99101-124-0650	Jet, Main (#65)

Cub Cadet LS 27 CC (Honda GCV160LA)




Ref.	Part Number	Description
1	15721-ZM0-000	Tube, Breather
2	17211-ZL8-023	Pri; Element, Air Cleaner
3	17220-ZM0-000	Case Assy., Air Cleaner
4	17228-ZM0-000	Gasket, Air Cleaner
5	17231-Z0L-030	Pri; Cover, Air Cleaner
6	90003-ZM0-000	Bolt, Flange (6x86) (Ct200)
7	95701-06014-08	Bolt, Flange (6x14)

Cub Cadet LS 27 CC (Honda GCV160LA)




Ref.	Part Number	Description
1	06180-Z0J-000	Arrester Kit, Spark
2	18310-ZM0-000	Muffler.
3	18321-Z0L-000	Protector, Muffler
4	18348-Z0L-000	Cap, Muffler
5	18350-ZL8-000	Arrester, Spark
6	18356-ZL8-000	Plate, Arrester Number
7	18381-ZL8-305	Gasket, Muffler
8	90004-ZL8-000	Bolt, Flange (6x79) (Ct200)
9	90013-883-000	Bolt, Flange (6x12) (Ct200)
10	90055-ZE1-000	Screw, Tapping (4x6)
11	90055-ZE1-000	Screw, Tapping (4x6)

Cub Cadet LS 27 CC (Honda GCV160LA)




Ref.	Part Number	Description
2	13331-357-000	Key, Special Woodruff
3	19612-Z0L-000	Plate, Side
4	30500-Z0J-003	Coil Assy., Ignition (Phelon)
7	31110-Z0J-013	Flywheel Comp. (Phelon)
17	90013-883-000	Bolt, Flange (6x12) (Ct200)
19	90022-888-010	Bolt, Flange (6x20) (Ct200)
20	90201-878-003	Pri; Nut, Special (14mm)

Cub Cadet LS 27 CC (Honda GCV160LA)




Ref.	Part Number	Description
1	16551-ZM0-010	Arm, Governor
2	16555-Z0L-800	Rod, Governor
3	16561-ZM0-V30	Spring, Governor
4	16562-ZM0-000	Spring, Throttle Return
6	16580-Z0L-800	Base, Control
8	16613-893-000	Grommet, Choke Rod
9	16674-Z0L-800	Rod, Choke
11	35120-Z0L-801	Switch Assy., Engine Stop
12	51125-Z0L-003	Holder, Wire
12	90681-959-003	Clip A, Cable (Nifco)
13	90015-ZE5-010	Bolt, Governor Arm
14	90016-ZE8-000	Bolt, Flange (6x45)
15	94050-06000	Nut, Flange (6mm)

Cub Cadet LS 27 CC (Honda GCV160LA)



Ref.	Part Number	Description
1	87101-ZM0-010	Pri; Emblem (Gcv160 5.5)
3	87114-ZH7-821	Label, Warning
4	87528-ZL8-000	Mark, Choke


777D09480



777S32605




777S32597




777S32061



777|22692




777122037



777I20798


USE SAE
10W30 OIL



777120349

DO NOT STEP


Cub Cadet LS 33 CC



Ref.	Part Number	Description
1.	781-04180	Log Tray Bracket
2.	710-0376	Hex Screw, 5/16-18 x 1.00
3.	781-04179	Log Tray Bracket
4.	710-04484	TT Screw, 5/16-18 x .750
5.	719-0550A	Wedge Assembly
6.	712-3022	Lock Nut, 1/2-13
7.	710-1018	Hex Cap Screw, 1/2-20 x 2.75
8.	710-1806	Hex Cap Screw, 1/2-13 x 3.25
9.	781-0351	Adjustable Gib
10.	712-0711	Hex Jam Nut, 3/8-24
11.	710-0459A	Hex Cap Screw, 3/8-24 x 1.5
12.	781-0790	Back Plate
13.	712-3058	Hex Lock Nut, 1/2-20
14.	737-04093	Inlet Filter
15.	710-0654A	Hex Washer Screw, 3/8-16 x 1.0
16.	781-0525	Dislodger
17.	712-3008	Jam Nut, 3/8-16
18.	681-04030	2-inch Hitch Coupler
19.	713-0433A	Chain
20.	681-04080	Beam Assembly
21.	714-0211	Cotter Pin
22.	718-0313A	Hydraulic Cylinder 31/33 Ton
23.	711-1135	Clevis Pin
24.	727-04166	Hydraulic Tube
25.	727-0443	Return Hose, 3/4" ID x 44"
26.	781-0526A	Hose Guard
27.	726-0132	Hose Clamp, 5/8"
28.	737-0153	Return Elbow
29.	737-0192	90 Degree Solid Male Adapter
30.	737-0235	3/4" Hose Adapter
31.	718-0481A	Control Valve
32.	737-0316	Filter Housing
33.	723-0405	Oil Filter
34.	727-0502	High Pressure Hydraulic Hose
35.	781-0538A	Hose Guard
36.	714-0470	Cotter Pin, 1/8"
37.	738-0805	Hinge Pin, 1/2 x 4.8" Lg.
38.	726-0214	Push Cap
39.	732-0583	Compression Spring 4"
40.	736-0116	Flat Washer, .635 ID x .93 OD
41.	781-0690	Locking Rod


Ref.	Part Number	Description
42.	737-0348A	Vented Dipstick
43.	781-04002	Fender
44.	720-04088	Grip
45.	625-0062	Tail Light Assembly
46.	681-04041A	Frame Assembly, 7.0 Gal
47.	736-0242	Bell Washer, 340 x .872 x .060
48.	712-0292	Tin Nut Clip, 1/4-20
49.	710-3180	Hex Cap Screw, 5/16-18 x 1.75
50.	710-3226	Hex Cap Screw, 5/16-18 x 5.50
51.	781-1100	Front Support Bracket Coupling
52.	736-0185	Flat Washer, .375 x .738 x .063
53.	711-0396	Spacer, .385 x .623 x .750
54.	710-0347	Hex Cap Screw, 3/8-16 x 1.75
55.	710-3085	Hex Cap Screw, 3/8-16 x 3.50
56.	719-0315	Coupling Shield
57.	714-0114	Key
58.	712-04063	Hex Flange Lock Nut, 5/16-18
59.	718-04135	Flex Coupling
60.	681-04029	Adjustable Jack Stand
61.	681-0110	Support Beam Assembly
62.	781-0097	Rear Coupling Support Bracket
63.	737-0264	Adapter, 7/8-14
64.	718-04128	Pump
65.	747-04539	Hydraulic Valve Control
66.	727-0451	Suction Hose
67.	710-0521	Hex Cap Screw, 3/8-16 x 3.0
68.	712-04065	Flange Lock Nut, 3/8-16
69.	736-0169	Lock Washer, 3/8
70.	781-0680A	Tube
71.	710-0411	Hex Cap Screw, 3/8-16 x 4.0
72.	634-0187	Wheel Assembly
73.	736-0351	Flat Washer, .76" ID x 1.5" OD
74.	712-0359	Slotted Nut, 3/4-16
75.	714-0162	Cotter Pin, 5/32" x 1-1/4"
76.	734-0873	Hub Cap
77.	681-04049	Light Bracket Assembly LH
—	781-04116	Light Bracket RH
78.	711-04585	Clevis Pin
79.	713-04036	Valve Handle Link
80.	714-0111	Cotter Pin
81.	710-0650	TT Screw, 5/16-18 x .875

Cub Cadet LS 33 CC (Kohler CS 8.5T)



Ref.	Part Number	Description
1	KH-63-014-12-S	Crankshaft
2	KH-63-340-01-S	Key, Straight (6.3m)


Cub Cadet LS 33 CC (Kohler CS 8.5T)



Ref.	Part Number	Description
1	KH-63-032-03-S	Oil Seal
2		Crankcase
3	KH-63-874-13-S	Piston w/ Ring Set (.50) (Incl. 4, 5)
	KH-63-874-14-S	Piston w/ Ring Set (.25)
	KH-63-874-15-S	Kit, Piston w/ Ring Set (Std)
4	KH-63-018-04-S	Ring, Retainer
5	KH-63-108-15-S	Ring Set (Std)
	KH-63-108-14-S	Ring Set (.25)
	KH-63-108-13-S	Ring Set (.50)
6	KH-63-067-03-S	Connecting Rod (Includes 7)
7	KH-63-211-03-S	Bolt, Conn Rod
8	KH-63-139-01-S	Plug, Drain
9	KH-63-041-01-S	Gasket, Plug
10	KH-63-380-13-S	Pin, Dowel
11	KH-63-030-04-S	Bearing, G.r.
12	KH-63-030-02-S	Bearing


Ref.	Part Number	Description
13	KH-63-041-34-S	Gasket, C.P.
14	KH-63-144-13-S	Shaft, Governor
15	KH-63-009-09-S	Closure Plate
16	KH-63-032-05-S	Oil Seal, G.R.
17	KH-63-086-60-S	Screw, Flange
18	KH-63-468-01-S	Washer
19	KH-63-043-08-S	Governor Gear Assembly
20	KH-63-018-01-S	Snap Ring
21	KH-63-241-01-S	Collar
22	KH-63-144-01-S	Shaft, Governor Cross
23	KH-63-468-03-S	Washer
24	KH-63-154-01-S	Clip
25	KH-63-422-08-S	Shim
26	KH-63-012-03-S	Camshaft
27	KH-63-144-14-S	Balance Shaft

Cub Cadet LS 33 CC (Kohler CS 8.5T)



Ref.	Part Number	Description
1	KH-63-139-12-S	Plug, Oil Level
2	KH-63-153-01-S	O-Ring, Plug
3	KH-63-086-14-S	Screw
4	KH-63-237-01-S	Clamp
5	KH-63-099-15-S	Switch, Oil Level
6	KH-63-139-02-S	Plug, Oil
7	KH-63-112-01-S	Spacer / Oil Level Guage


Cub Cadet LS 33 CC (Kohler CS 8.5T)



Ref.	Part-Number	Description
1	KH-63-326-05-S	Hose, Breather
2	KH-63-086-14-S	Screw
3	KH-63-096-13-S	Cover, Valve
4	KH-63-041-36-S	Gasket, Valve Cover
5	KH-63-033-03-S	Breather Assembly
6	KH-63-086-01-S	Screw, Cyl Head
7	KH-63-041-37-S	Gasket, Breather
8	KH-63-318-05-S	Cylinder Head
9	KH-63-380-03-S	Pin, Dowel
10	KH-63-041-35-S	Gasket, Cyl Head
11	KH-63-100-12-S	Nut
12	KH-63-599-01-S	Pivot, Rocker Arm

Ref.	Part-Number	Description
13	KH-63-186-03-S	Arm, Rocker
14	KH-63-086-32-S	Screw, Valve Adj
15	KH-63-316-03-S	Plate, Guide
16	KH-63-462-01-S	Valve, Cotter
17	KH-63-173-01-S	Cap, Valve Spring
18	KH-63-089-25-S	Spring, Valve
19	KH-63-032-01-S	Seal, Valve Stem
20	KH-63-411-03-S	Push Rod
21	KH-63-016-04-S	Valve, Exhaust
22	KH-63-017-04-S	Valve, Intake
23	KH-63-351-01-S	Lifter,-Valve


Cub Cadet LS 33 CC (Kohler CS 8.5T)



Ref.	Part Number	Description
1	KH-63-100-20-S	Nut, Flywheel
2	KH-63-468-25-S	Washer, Flywheel
3	KH-63-025-08-S	Flywheel
4	KH-63-340-02-S	Key, Woodruff
5	KH-63-086-13-S	Screw
6	KH-63-755-12-S	Assembly, Ignition Module (Incl. 7)
7	KH-63-173-02-S	Cap Assembly
8	66-132-01-S	Spark Plug


Ref.	Part Number	Description
9	KH-63-352-01-S	Oil Light
10	KH-63-086-14-S	Screw
11	KH-63-237-05-S	Clamp
12	KH-63-100-05-S	Nut, Stop Switch
13	KH-63-099-02-S	Stop Switch
14	KH-63-086-15-S	Screw, Stop Switch
15	KH-63-099-03-S	Oil Switch Assembly
16	KH-63-431-02-S	Sleeve, Wire

Cub Cadet LS 33 CC (Kohler CS 8.5T)




Ref.	Part Number	Description
1	KH-63-027-04-S	Kit, Blower Housing
2	KH-63-063-03-S	Baffle, Cylinder
3	KH-63-086-14-S	Screw

Cub Cadet LS 33 CC (Kohler CS 8.5T)



Ref.	Part Number	Description
1	KH-63-086-62-S	Screw, Guard
2	KH-63-165-01-S	Retractable Starter (Includes 3-9)
3	KH-63-081-01-S	Housing Assembly
4	KH-63-166-01-S	Handle
5	KH-63-089-07-S	Spring, Starter
6	KH-63-093-01-S	Pulley
7	KH-63-757-03-S	Kit, Pawl Repair (Includes 8)
8	KH-63-086-18-S	Screw
9	KH-63-160-01-S	Rope, Starting
10	KH-63-109-05-S	Starter Cup


Cub Cadet LS 33 CC (Kohler CS 8.5T)



Ref.	Part Number	Description
1	KH-63-100-15-S	Nut, Air Cleaner
2	KH-63-853-10-S	Kit, Carb w/ gaskets (Incl. 3-5)
3	KH-63-041-39-S	Gasket, Air Cleaner Base
4	KH-63-053-10	Carburetor
5	KH-63-041-38-S	Gasket, Carburetor
6	KH-63-173-07-S	Cap, Carburetor Adjusting
7	KH-63-089-28-S	Screw, Float Bowl
8	KH-63-164-03-S	Manifold, Intake
9	KH-63-072-07-S	Stud, Carburetor
10	KH-63-462-05-S	Valve, Fuel Shut-off (Includes 11-14)
11	KH-63-050-03-S	Cup, Filter
12	KH-63-041-40-S	Gasket, Fuel Strainer
13	KH-63-050-04-S	Filter, Screen
14	KH-63-153-07-S	O-Ring
15	KH-63-154-07-S	Clip

Ref.	Part Number	Description
16	KH-63-353-02-S	Fuel Line
17	KH-63-126-11-S	Bracket, Fuel Valve
18	KH-63-086-14-S	Screw
19	KH-63-353-03-S	Fuel Line
20	KH-63-126-10-S	Bracket, Tank
21	KH-63-468-26-S	Washer
22	KH-63-086-21-S	Screw
23	KH-63-139-04-S	Plug
24	KH-63-065-03-S	Tank, Fuel
25	KH-63-444-02-S	Strainer
26	KH-63-173-03-S	Cap, Fuel Tank
—	KH-63-032-23-S	Seal, Fuel Tank Cap
—	KH-63-113-06-S	Decal, Caution
—	KH-63-757-08-S	Kit, Float Repair
—	KH-63-757-10-S	Kit, Carburetor Repair


Cub Cadet LS 33 CC (Kohler CS 8.5T)



Ref.	Part Number	Description
1	KH-63-086-47-S	Screw
2	KH-63-237-13-S	Clamp
3	KH-63-079-04-S	Choke Link
4	KH-63-089-29-S	Spring, Linkage
5	KH-63-086-14-S	Screw
6	KH-63-079-03-S	Linkage, Throttle
7	KH-63-089-28-S	Spring, Linkage
8	KH-63-090-09-S	Lever, Governor
9	KH-63-211-02-S	Bolt
10	KH-63-468-04-S	Washer


Ref.	Part Number	Description
11	KH-63-100-01-S	Nut
12	KH-63-089-27-S	Spring, Governor
14	KH-63-090-10-S	Lever, Throttle
14	KH-63-154-04-S	Clip
15	KH-63-089-03-S	Spring, Compression
16	KH-63-086-03-S	Screw, Pan Head
17	KH-63-086-46-S	Screw
18	KH-63-237-08-S	Bowden Clamp
—	KH-63-113-23-S	Decal, Choke/throttle

Cub Cadet LS 33 CC (Kohler CS 8.5T)



Ref.	Part Number	Description
1	KH-63-100-19-S	Nut
2	KH-63-096-14-S	Cover, A/C
3	KH-63-100-21-S	Nut, Wing A/C
4	KH-63-083-11-S	Element, A/C
5	KH-63-083-12-S	Pre-cleaner/element
6	KH-63-032-18-S	Seal, A/C
7	KH-63-086-20-S	Screw
8	KH-63-041-39-S	Gasket, A/C 8.5
9	KH-63-086-35-S	Screw, Hex Flange
10	KH-63-126-12-S	Bracket, A/C
11	KH-63-100-15-S	Nut A/C
12	KH-63-094-07-S	Base, A/C
—	KH-63-113-03-S	Decal, A/C

Cub Cadet LS 33 CC (Kohler CS 8.5T)



Ref.	Part Number	Description
1	KH-63-755-16-S	Muffler Guard Kit
2	KH-63-086-62-S	Screw, Guard
3	KH-63-189-02-S	Spark Arrestor
4	KH-63-100-03-S	Nut, Exhaust
5	KH-63-041-42-S	Gasket, Exhaust
6	KH-63-086-10-S	Screw, Hex Flange
7	KH-63-468-05-S	Washer
8	KH-63-072-01-S	Stud
9	KH-63-068-03-S	Muffler


777D09477

33 TON
COMMERCIAL GRADE
LOG SPLITTER

Cub Cadet

- HORIZONTAL/VERTICAL OPERATION
- CAST IRON WEDGE
- DIAMOND PLATE FENDERS
- LIGHT KIT
- WHEELED JACK STAND
- COIL-WRAPPED HOSES

777S32595



777S32559

CONTROL VALVE

LOG DISLODGER

RETRACT WEDGE, LODGED wood will be automatically removed. LUBRICATE BEAM BEFORE EACH USE.

REVERSE

NEUTRAL

FORWARD

REFER TO OPERATOR'S MANUAL FOR DETAILS.

⚠ DANGER

1. READ OPERATOR'S MANUAL
2. KEEP HANDS AWAY FROM WEDGE AND MOVING PARTS.
3. PERSON FAMILIAR WITH LOG SPLITTER MUST BE SAME PERSON WHO OPERATES CONTROL VALVE.
4. KEEP BYSTANDERS, HELPERS AND CHILDREN AT LEAST 10 FEET AWAY.

777S32597


⚠ WARNING - TO AVOID INJURY AND/OR PROPERTY DAMAGE

MOVING LOG SPLITTER BY HAND

- Hitch with 2" ball. Latch securely.
- If coupler adjustment is needed, refer to owner's manual.
- Lock beam in horizontal position.
- Lock jack stand in down position.
- Do not attempt to move log splitter up or down a slope by hand.

TOWING LOG SPLITTER

- Lock beam in horizontal position.
- Attach coupler to Class 1 or higher.
- Hitch with 2" ball. Latch securely.
- If coupler adjustment is needed, refer to owner's manual.
- Attach safety chains to tow vehicle.
- Do not tow faster than 45 mph.
- High speed may cause loss of control.
- Check local, state and federal requirements before towing on any public road.



777I20739

UP
DOWN

ADD OIL BEFORE OPERATING

Maintain fluid level within the ranges specified on the dipstick. Do not overfill! Check when fluid is cold and with unit level. Never run below this level. Pump will be ruined. Change hydraulic fluid every 100 hours of use. Change hydraulic filter every 50 hours of use. Use only a 10 micron hydraulic filter.

HYDRAULIC FLUID ONLY
DEXRON III or 10 WEIGHT AW

Order Part Number Hydraulic Filter 723-9405

777S32062

OPERATOR'S INSTRUCTIONS

READ OPERATOR'S MANUAL

VERTICAL POSITION

LOCK

⚠ DANGER

HYDRAULIC FLUID ONLY

DEXRON III or 10 WEIGHT AW

Order Part Number Hydraulic Filter 723-9405

777I20349

DO NOT STEP



To order replacement parts, call the Customer Dealer Referral Line at 1-877-282-8684
or visit www.cubcadet.com to find the nearest Cub Cadet dealer in your area.

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
