




Part's Manual

BIG COUNTRY 

6x4 Utility Vehicle

Model 641



CUB CADET LLC P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

PRINTED IN U.S.A.

FORM NO. 769-00686D

1/04

MODEL 641


TABLE OF CONTENTS

DESCRIPTION	PAGE	DESCRIPTION	PAGE
Axle, Front Suspension	5	Fenders.....	5, 7
Axle, Center Suspension	13	Fuel System	2, 3
Axle, Rear Suspension	13	Hood	5
Bed	7	Labels	38
Bed Lift	7	Pedal, Brake	11
Brake, Parking	11	Pedal, Throttle	11
Bumper	5	Schematic, Electrical	34, 35
Cables	15	Seats	2
Chain Guide	9	Shifter Assembly	13
Clutch, Main	9	Steering (Lower)	3
Dash Panel	11	Steering (Upper)	3
Electrical System	36	Transmission Accessories	9
Engine & Transmission Cradle	9	Transmission, <i>Tuff Torq</i> Model KT35	
Engine Accessories	9	Transaxle Case Assembly	27
Engine, <i>Honda</i> Model GX20K1		Input Shaft Assembly	28
Cylinder Head.....	16	Reduction Assembly	29
Cylinder Barrel.....	17	Range Shift Assembly	30
Crankcase Cover.....	18	Differential Gear Assembly	31
Crankshaft	18	Differential lock Assembly	32
Piston.....	19	Brake Assembly	33
Camshaft	20	Trim Panels	3
Fan Cover	21	Wheels, Front & Rear	5, 13
Carburetor	22		
Flywheel	23		
Ignition Coil	24		
Starter Motor.....	25		
Control	26		

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part, numbered 700-xxxx, is painted Cub Yellow, the part number to order would be 700-xxxx-0498.


Cub Yellow: 0498
Cub Beige: 0499
Powder Black: 0637

SEATS AND FUEL TANK



REF. NO.	PART NUMBER	DESCRIPTION	QTY	REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	607-0034	Bracket Assembly, Fuel Tank	1	16	735-0271	Bumper	6
2	631-04097	Tank Assembly, Fuel (Incl. valve, grommets, cap. switch & fitting)	1	17	738-0140	Shoulder Screw, .435 x.178-5/16 x.56	4
	751-10064	Fuel Tank Only		18	707-04062A	Plate, Seat, RH	1
3	710-3008	Hex Screw, 5/16-18 x .75	1	19	710-0376	Hex Screw, 5/16-18 x 1.0	4
4	711-1768	Hold-down Rod, Fuel Tank	1	20	649-04002	Tube, Grab Handle	2
5	712-0265	Sems Nut, 5/16-18	1	21	710-0216	Hex Screw, 3/8-16 x.75	8
6	712-3027	Nut, Flange Lock, 1/4-20	1	22	712-0130	Nut, Hex Lock Nylon, 3/8-16	8
7	721-04006	Gasket, Fuel Tank (11")	1	23	725-2068	Low Fuel Sensor	1
8	726-0205	Clamp, Hose	1	24	751-3174	Fuel Return Fitting	1
9	736-0159	Washer, .349 x .879 x .063	1	25	737-04010	Fuel Tank Shut Off Valve	1
10	751-0852	Cap, Fuel	1	26	751-0535	Fuel Line Hose	20
11	707-04061A	Plate, Seat, LH	1	27	737-0296	Vent	1
12	712-3004A	Nut, Flange Lock, 5/16-18, Gr5	8	28	735-0699	Grommet	1
13	750-0258	Spacer, Seat	6	29	741-04006	Fuel Tank Grommet	2
14	757-0389	Track Assembly, Seat	1	30	735-04001	Floor Mat	1
15	757-04008A	Seat	2	31	726-0465	Retainer Clip	17


STEERING



STEERING

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	631-04103	Dash Assembly	1
2	707-04252	Hood Mounting Plate	2
3	731-2952	Panel, Airbox Cover	1
4	710-0564	Hex Screw, 1/4-20 x 2.75	2
5	710-3015	Hex Screw, 1/4-20 x .75, Gr5	1
6	712-0324	Hex Lock Nut, Nylon, 1/4-20	1
7	712-0397	Wing Nut, 1/4-20	2
8	721-04070	Trim, Bulb Seal, 1/4	1
9	723-3069	Foot Pad, Abrasive	4
10	728-0173	Rivet, Pop.,187	10
11	728-04004	Rivet, Pop.,188	4
12	731-04033A	Container, Bulkhead	1
13	731-2953A	Panel, Shift Cover	1
14	731-2648	Console, Cup Holder	1
15	735-04038	Handle, Latch	2
16	736-0195	Flat Washer, 349 x.875 x.04	2
17	736-0173	Washer, Flat,.28 x.74 x.063	2
18	736-0400	Washer, Flat,.194 x.62 x.063	4
19	736-0463	Washer, Flat,.25 x.630 x.0515	1
20	707-04278	Plate, Console Support	1
21	710-0599	Screw, Self-tapping, 1/4-20 x.5	4
22	617-0075A	Gear Assembly, Steering	1
23	707-04074	Steering Bracket, Sector Clamp	1
24	707-0417	Bracket, Steering Mounting	1
25	710-0514	Hex Screw, 3/8-16, 1.00, Gr5	4
26	710-0520	Hex Screw, 3/8-16, 1.50, Gr5	3
27	712-0431	Nut, Flange Lock, 3/8-16	6
28	735-0801	Grommet, Steering Shaft	1
29	741-0763	Bushing, Rubber	1
30	631-04008	Wheel, Steering	1
31	710-1880	Hex Screw, 5/16-18,.75, Gr5, Patch	1
32	710-3008	Hex Screw, 5/16-18, .75, Gr5	4
33	711-04231	Shaft, Steering, 5/8 Spline	1
34	711-1774	Collar, .75	2
35	712-0130	Nut, Hex Lock Nylon, 3/8-16	1
36	712-3004A	Nut, Flange Lock, 5/16-18	4
37	731-04532	Cover, Steering Wheel	1
38	731-0954	Bellow, Steering, 4.75 Lg	1
39	736-0275	Washer, Flat,.344 x.688 x.065	1
40	741-04000	Bearing, Flange,.75 ID, Self-Aligning	2
41	651-04003	Pump Assembly, Fuel	1
42	710-0106	Hex Screw, 1/4-20 x 1.25	2
43	712-3027	Flange Lock Nut, 1/4-20	2
44	722-0160	Bushing,.96OD x.50	2
45	726-0470	Cable Tie	1
46	751-0535	Fuel Line Hose	52
47	793-00003	Fuel Filter	1
48	726-0205	Clamp, Hose	6



FRONT END



FRONT END

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-04004	Axle Assembly, Right-front (Incl. Ref 12 - 15)	1
—	607-04005	Axle Assembly, Left-front (Incl. Ref 12 - 15)	1
2	710-0347	Hex Screw, 3/8-16 x 1.75	2
3	710-04012	Hex Screw, 1/2-13 x 7.0, Gr5	2
4	710-04120	Hex Screw, 5/8-11 x 11.13, Gr5	2
5	710-3011	Hex Screw, 3/8-16 x 2.25	2
6	712-0130	Nut, Hex Lock, Nylon, 3/8-16, Gr5	10
7	712-3016	Nut, Hex Lock, Nylon, 5/8-11, Gr5	2
8	712-3022	Nut, Hex Lock, 1/2-13	2
9	607-04106	Steering Control Knuckle, RH	1
—	607-04105	Steering Control Knuckle, LH	1
10	732-04176	Shock Absorber, 2.9 Stroke	2
11	750-1388	Tube, .875 x .50 x 4.75	2
12	737-04006	Grease Fitting	2
13	741-0758	Bearing, .63 ID x 1.19 OD	4
14	741-0762	Bushing, Steering	4
15	750-1357	Spacer, .645 ID x 1.063 OD	2
16	607-0037	Front Bumper Assembly	1
17	710-0514	Hex Screw, 3/8-16 x 1.0	10
18	736-0300	Flat Washer, .406 x .875 x .059	4
19	710-3181	Hex Screw, 1/2-13 x 1.50, Gr5	2
20	731-04029	Dust Cap	2
21	736-04019	Flat Washer, .531 x 1.25 x .181	2
22	634-04039	Wheel Ass'y, 22 x 11 x 10, RH, All Terr.	1
	634-04040	Wheel Ass'y, 22 x 11 x 10, LH, All Terr.	1
23	731-04516	Panel, Right Fender, Camo	1
24	731-04517	Panel, Left Fender, Camo	1
25	731-04748	Panel, Hood, Dark Camo	1
26	710-0376	Hex Screw 5/16-18 x 1.00 Gr 5	14
27	710-3008	Hex Screw, 5/16-18 x .75	2
28	728-04004	Pop Rivet	6
29	735-04003	Mud Flap	2
30	736-0356	Washer, Bell, .39 x 1.38 x .062	14
31	736-0400	Flat Washer, .194 x .62 x .063	6
32	625-04017	Head lamp Assembly	2
33	707-04165	Bracket, Hood Mounting	1
34	711-04139	Rod, Hood Mounting	1
35	712-0324	Nut, Hex Lock, 1/4-20	4
36	714-0101	Cotter Pin, Internal, 1.42	1
37	736-3020	Washer, Flat, .271 x .63 x .065	4
38	710-3015	Hex Screw, 1/4-20 x .75	4
39	607-04062	Dash Support Frame Assembly	1
40	607-04065	Upper Dash Frame Assembly	1
41	712-0703A	Insert Nut, 5/16-18	12
42	710-0216	Hex Screw, 3/8-16 x .75	6
43	710-0599	Screw, Self-tapping, 1/4-20 x .5	7
44	731-04016	Suspension Bumper	2
45	712-0431	Flange Lock Nut, 3/8-16	10
46	607-04010	Brush Guard	1
47	736-3050	Flat Washer, .406ID x .810OD x .051	4


REAR FENDERS AND CARGO BED



REAR FENDERS AND CARGO BED

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-04028	Tailgate Assembly	1
2	607-04035	Bed Assembly	1
3	710-0599	Screw, Self-tapping, 1/4-20 x 0.500	12
4	736-3020	Flat Washer,.271 x.630 x.065	8
5	714-0104	Cotter Pin,.072 Dia x 1.13	8
6	720-04036	Plug Cap	4
7	731-04016	Bumper, Extension Suspension	6
8	732-0306	Compression Spring, .406 x .531 x	4
9	735-0271	Bumper, .62Dia x .3	4
10	736-0162	Washer, Flat, .64 ID x 1.0 x .12	2
11	736-3008	Washer, Flat, .344 x .750 x .120	2
12	736-3010	Washer, Flat,.407 x.812 x.135	4
13	710-3233	Screw, Hex, 1/2-13 x 2.5	2
14	746-0968	Cable, Lift 16.16 LG	2
15	747-1116	Handle, Deck Release	4
16	748-0331	Spacer, Shoulder .625 Dia x .324 Dia	2
17	707-04060	Bracket, Bed Latch Base	1
18	710-04166	Stud, Ball 5/16-18	2
19	710-3025	Hex Screw, 5/16-18 x .625, Gr5	1
20	712-0264	Nut, Acorn 1/4-20 w/o Lock	2
21	712-0324	Nut, Hex Lock, 1/4-20	10
22	712-0703A	Nut, Insert 5/16-18	19
23	726-04005	Latch	1
24	728-0123	Pop Rivet, 3/16	4
25	731-04174	Handle, Bag w/Screw	1
26	732-04109	Spring, Gas .91 Stroke	1
27	736-0176	Washer, Flat .265 x .938 x .120	2
28	736-0231	Washer, Flat.344 x 1.125 x.120	2
29	712-3022	Hex Lock Nut, 1/2-13	2
30	710-0703	Hex Screw, 1/4-20 x.75	8
31	731-04518	Fender, Rear RH, Camo	1
32	731-04519	Fender, Rear LH, Camo	1
33	736-04008	Rubber Washer,.310 x 1.0 x.125	8
34	710-0376	Hex Screw, 5/16-18 x 1.0	8
35	736-0356	Bell Washer,.39 x 1.38 x.062	8
36	731-04523	Bed Skirt Panel, LH, Camo	1
37	731-04522	Bed Skirt Panel, RH, Camo	1
38	735-04035	Rear Mud Flap	2
39	728-04004	Pop Rivet,.188	8
40	741-0761	Rubber Bushing, Bed Pivot	2
41	731-04011	Bumper, Compression Suspension	8
42	712-04006	Hex Lock Nut, M10-1.25	8


ENGINE AND TRANSMISSION



ENGINE AND TRANSMISSION


REF. NO.	PART NUMBER	DESCRIPTION	QTY	REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	607-0029A	Frame Ass'y, Engine/Trans. Support	1	34	736-0278	Washer, Flat, .33 x .678 x .030	3
2	710-0344	Hex Screw, 3/8-16 x 1.5, Gr5	1	35	737-04013	Valve, Oil Drain	1
3	710-04019	Hex Screw, 3/8-24 x 3, Gr5	1	36	751-0544	Arrestor, Spark 1-1/4	1
4	710-3144	Hex Screw, 3/8-16 x 2.00	4	37	751-0854A	Muffler, Honda GXV	1
5	710-04025	Hex Screw, M10-1.5 x 60mm, Gr8	1	38	852H636740	Engine, <i>Honda</i> GX620K1	1
6	710-04028	Hex Screw, M16-2 x 40mm	4	39	607-04016	Shift Ass'y, Interlock (Incl. 40-48)	1
7	710-0514	Hex Screw, 3/8-16 x 2.25, Gr5	4	40	607-04018	Interlock Shift Bracket	1
8	710-1260A	Hex Screw, 5/16-18 x .75	4	41	607-04017	Interlock Shift Plate	1
9	712-0130	Nut, Hex Lock, 3/8-16	5	42	607-04015	Brake Clutch Lever	1
10	732-1186	Spring, Extension, .795 x 5.42	2	43	712-3005	Hex Flange Lock Nut, 3/8-16	2
11	736-0133	Washer, Flat, .411 x 1.25 x .10	9	44	732-0814	Extension Spring	1
12	736-04005	Washer, Flat, .395 x 1.12 x .14	1	45	736-0105	Bell Washer, .375 x .870 x .063	1
13	618-0686A	Clutch Assembly, Engine	1	46	736-0326	Flat Washer, .510 x 1.0 x .125	1
14	618-0687	Clutch Assembly, Transmission	1	47	738-0213	Shoulder Screw	2
15	736-04009	Washer, 1.03 x 1.625 x .12	1	48	741-0491	Flange Bearing	4
16	738-04002A	Spacer, Drive, .39 ID x 1.00 OD	1	49	618-0685	Transmission, <i>Tuff Torq</i> Model KT 35	1
17	754-0646	V-type Belt, Cogged, 1.19	1	50	707-0369	Lever, Transmission	1
18	651-04000A	Filter Ass'y, Air Cleaner (Incl. 19-27)	1	51	710-0693	Hex Screw, 3/8-16 x 4.50, Gr5	1
19	726-0476	Hose Clamp	4	52	710-0805	Hex Screw, 5/16-18 x 1.50, Gr5	1
20	751-3206	Air Cleaner Canister	1	53	710-3001	Hex Screw, 3/8-16 x .880, Gr5	1
21	751-3208	Air Cleaner Cap	1	54	712-3005	Lock Nut, Hex Flange 3/8-16	2
22	751-3197	Dust Ejector Valve	1	55	712-0429	Nut, Hex Lock, 5/16-18	1
23	751-3207	Air Cleaner Element (Not Shown)	1	56	750-3235	Spacer, .505 x .75 x 3.31	1
24	751-0856	Air Intake Hose	1	57	711-04024	Pin, .625 x 1.37	2
25	751-0851	Air Filter Hose	1	58	716-0106A	E-Ring, .625	4
26	707-04067A	Air Intake Bracket	1	59	738-0509	Shoulder Screw, .50 x 1.825	1
27	710-1376	Hex Screw, M8-1.25	2	60	736-3084	Flat Washer, .510 x 1.12 x .060	1
28	707-0375	Support, Upper Transmission	1	61	731-04078A	Chain Roller	1
29	710-04022	Hex Screw, M8-1.25	2	62	718-04033	Rotary Adjuster	1
30	710-0473	Screw, Machine #10-24 x .50	2	63	710-0599	Self Tapping Screw, 1/4-20 x .50	1
31	710-3206A	Hex Screw, M8-1.25 x 25, Gr8	3	64	710-3118	Hex Screw, 3/8-16 x 1.00	1
32	735-0226	Grommet, Rubber.66 ID x 1.25 OD	1	-	737-3119	Oil, Shell TTF-SB	*
33	736-0119	Washer, Lock, 5/16	2				

PEDALS AND DASH



PEDALS AND DASH


REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	731-04755	Instrument Dash Cover	1
2	725-3284	Key Switch	1
3	731-1346	Nut, Ignition Switch, 5/8-32	1
4	731-1347	Cap, Ignition Switch	1
5	725-2003	Power Receptacle, 12V	1
6	726-0293	Nut, Retainer, 1/8	2
7	731-04010	Switch Plug Panel	4
8	731-04023	Plug, Horn Switch	1
9	731-04676	Dash Panel	1
10	725-04022	Hour Indicator Meter	1
11	607-0021	Lever, Parking Brake	1
12	607-04077	Pedal Assembly, Brake	1
13	607-04082	Pedal Assembly, Throttle	1
14	607-04083	Pedal Arm Assembly, Throttle	1
15	710-04030	Screw, Hi-Lo, 1/4-20 x .5	2
16	736-0463	Washer, Flat .25 x .630 x .0515	2
17	710-1237	Screw, Self-tapping, #10-32 x .625	2
18	710-3168	Bolt, Carriage, 3/8-16 x 1.0	2
19	711-04067	Pin, Clevis.50 x 3.25	3
20	711-1765	Rod, Brake Lock	1
21	712-0431	Nut, Flange Lock, 3/8-16	2
22	735-3049	Pad, Brake Pedal	1
23	714-0147	Pin, Cotter,.125 x 1.75	2
24	714-0127	Pin, Cotter, 1/16	2
25	732-1187	Spring, Extension, .637 x 2.972	1
26	720-04001	Knob, Ball	1
27	721-3049	Cover, Protective	1
28	725-1657A	Snap Mount Switch, Interlock	1
29	710-0528	Hex Screw, 5/16-18 x 1.25	2
30	712-3010	Hex Nut, 5/16-18	2
31	714-0101	Cotter Pin	1



SHIFTER ASSEMBLY AND REAR/CENTER SUSPENSION


REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	647-0069B	Lever Assembly, Transmission	1
2	647-0071A	Shifter Assembly, Differential Lock	1
3	711-04068	Pin, Clevis, .50 x 5.375	1
4	714-0115	Pin, Cotter	1
5	711-04017	Pin, Clevis, .375 x 2.0	1
6	712-0711	Nut, Jam, 3/8-24	1
7	714-0104	Pin, Cotter, .072 x 1.13	2
8	719-3013	Clevis, Adjustment	1
9	720-04002	Knob, Ball	1
10	720-0434	Knob, Ball	1
11	732-1187	Spring, Extension, .637 x 2.972	1
12	746-04004	Control Cable, Differential Lock	1
13	747-04010A	Shifter Rod, Transmission	1
14	607-0042A	Axle Support Assembly, Rear Weld	1
15	710-0298	Screw, Hex, 5/8-18 x 3.5, Gr5	2
16	710-3011	Screw, 3/8-16 x 2.25	4
17	710-0347	Screw, 3/8-16 x 1.75	4
18	711-1764	Axle Shaft, Rear Drive	1
19	712-0130	Nut, Hex Lock, 3/8-16	8
20	712-0413	Jam Nut, Lock, 5/8-18	4
21	713-04007	Sprocket	1
22	716-0401	Retaining Ring, External, 1.14	4
23	732-04176	Shock Absorber, 2.9Stroke	4
24	736-0424	Washer, Flat, 1.06 x 1.56 x .020	8
25	736-3046A	Washer, Flat, 1.010 x 1.86 x .060	16
26	737-3000	Lube Fitting, 3/16	8
27	741-04030	Bearing Flange, 1.0 x 1.125 x 1.0	16
28	741-0759	Ball Bearing, Internal Axle	4
29	741-0760	Ball Bearing, External Axle	4
30	750-04004	Spacer, .63 x 1.0 x 2.594	8
31	607-0043A	Axle Support Assembly, Center Weld	2
32	623-0026A	Weld Coupling Assembly	2
33	710-3119	Screw, Hex, 3/8-16 x .75, Gr5	12
34	710-0298	Screw, Hex, 5/8-18 x 3.5, Gr5	4
35	710-3229	Screw, Hex, 7/16-14 x 2.75, Gr5	4
36	711-1763	Axle Shaft, Drive Center	2
37	712-0290	Nut, Hex Lock, 7/16-14	4
38	713-04005	Sprocket, Hub, 1.75 - 23T	2
39	750-1389	Spacer, 1.78 x 1.88	2
40	607-04084	Frame Assembly, Complete	1
41	713-0605	Chain, 60-97 Pitch	2
42	710-04009	Hex Screw, 7/16-20 x 1.5, Gr5	20
43	634-04071	Wheel Ass'y, 25 x 11 x 10, RH, All Terr.	2
	634-04072	Wheel Ass'y, 25 x 11 x 10 LH, All Terr.	2
44	741-04002	Bushing, .504 x .628 x .50	4
45	710-0378	Hex Screw, 5/16-18 x 2.50	2
46	707-04006	Belt Guard	1
47	710-0759	Screw, 5/16-18 x .625	2
48	712-3009	Hex Lock Nut, 5/16-18	2

CABLES




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	710-04027	Screw, Shoulder, .375 x .375	1
2	711-0813	Pin, Clevis, 5/16 x 2.5	1
3	712-3025	Nut, Jam, 5/16-24, Gr5	6
4	712-3009	Nut, Hex Lock, 5/16-18	1
5	714-0104	Pin, Cotter, .072 x 1.13	2
6	726-0470	Cable Tie, Tree Mount	1
7	732-0470A	Extension Spring	1
8	736-0159	Washer, .349 x .879 x .063	1
9	736-0271	Washer, Spring, .317 x .879 x .063	1
10	746-04000	Cable, Control, Brake	1
11	746-04002	Cable, Control, Choke	1
12	746-04006	Cable, Control, Clutch Brake	1
13	746-04042	Cable, Control, Throttle	1
14	746-04125	Cable, Control, Brake	1

ENGINE — CYLINDER HEAD




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	11911-ZJ1-840	Hanger, Engine	2
2	12204-ZE2-306	Guide, Valve (OS)	2
3	12205-ZJ1-405	Guide, Ex. Valve (OS)	2
4	12210-ZJ1-840	Cylinder Head (#1)	1
5	12216-ZE2-300	Clip, Valve Guide	4
6	12220-ZJ1-840	Cylinder Head (#2)	1
7	12251-ZJ1-841	Gasket, Cylinder Head	2
8	12311-ZJ1-840	Cover, Head	1
9	12314-ZJ1-840	Cover, Head Filler	1
10	12391-ZE2-020	Gasket, Cylinder Head Cover	2
11	15611-MB0-000	Cap, Oil Filler	1
12	15625-ZJ1-840	Gasket, Oil Filler Cap	1
13	17101-ZJ1-840	Manifold, In	1
14	17151-ZJ1-841	Gasket, In. Manifold	2
15	18333-ZE3-800	Gasket, Ex. Pipe	2
16	19682-ZJ1-840	Shroud, Head	2
17	90011-ZJ1-841	Bolt, Socket (8x45)	4
18	90014-ZE2-000	Bolt, Head Cover	2
19	90014-952-000	Bolt, Flange (6x14)	2
20	90018-ZJ1-840	Bolt, Stud (8x22)	4
21	90441-ZE2-010	Washer, Head Cover	2
22	94050-08000	Nut, Flange (8mm)	4
23	94301-12200	Pin A, Dowel (12x20)	4
24	95701-08020-00	Bolt, Flange (8x20)	2
25	95701-10080-00	Bolt, Flange (10x80)	8
26	98079-52876	Spark Plug (BPR2ES) (NGK)	2

ENGINE — CYLINDER BARREL




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	12000-ZJ1-841	Cylinder Assembly	1
2	12356-ZJ1-000	Cover, Breather	1
3	12358-ZJ1-000	Gasket, Breather Cover	1
4	12372-ZE2-300	Valve, Breather	1
5	15558-ZJ1-010AH	Valve, Drain (14x1.5)	1
6	16541-ZJ1-840	Shaft, Governor Arm	1
8	31511-ZJ1-000	Clamp, Wire	1
10	37240-ZG3-E01	Switch, Oil Pressure	1
11	90002-ZG5-004	Screw-washer (4x8)	1
12	90029-888-000	Bolt, Flange (6x16)	2
13	90031-ZE1-000	Bolt, Flange (6x32)	2
14	91001-ZJ1-841	Bearing, Needle (8x12.7x11.1)	1
15	91002-ZJ1-841	Bearing, Needle (8x12x10)	1
16	91201-ZE9-003	Oil Seal (8x14x5)	1
17	91201-ZJ1-841	Oil Seal (38x58x9)	1
18	91302-MB6-830	O-ring (13x3.0)	1
20	92800-14000	Bolt, Drain Plug (14mm)	2
22	94102-08800	Washer, Plain (8mm)	3
23	94109-14000	Washer, Drain Plug (14mm)	2
24	94251-08000	Pin, Lock (8mm)	2
26	96140-60030-10	Bearing, Radial Ball (6003)	1

ENGINE — CRANKCASE COVER




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	11300-ZJ1-840	Cover Assembly, Crankcase (Q-type)	1
2	11381-ZJ1-840	Gasket, Case Cover	1
4	15120-ZJ1-000	Cover Assembly, Oil Pump	1
5	15124-ZJ1-003	Rotor, Oil Pump (Outer)	1
6	15232-ZJ1-000	Spring, Relief Valve	1
7	15348-ZJ1-840	Cover, Oil Filter	1
8	15400-POH-305PE	Filter, Oil	1
10	15411-ZJ1-840	Base, Oil Filter	1
11	15427-ZJ1-000	Screen, Oil Filter	1
12	15655-ZJ1-840	Dipstick, Oil	1
13	16510-ZJ1-840	Governor Assembly	1
14	16511-ZJ1-840	Weight, Governor	3
15	16512-ZJ1-840	Holder, Governor Weight	1
16	16513-ZE2-000	Pin, Governor Weight	3
17	16531-ZE2-000	Slider, Governor	1
20	90015-883-000	Bolt, Flange (6x28)	3
21	90018-PN3-000	Holder, Oil Filter	1
22	90473-147-000	Washer (6x16)	1
23	90602-ZE1-000	Clip, Governor Holder	1
24	91202-ZJ1-841	Oil Seal (38x58x9)	1
25	91320-MJ6-003	O-ring (11.8x2.4)	2
26	94101-06800	Washer, Plain (6mm)	1
27	94301-08140	Pin A, Dowel (8x14)	2
28	95701-06020-00	Bolt, Flange (6x20)	3
29	95701-08050-00	Bolt, Flange (8x50)	9
30	96211-12000	Ball, Steel (#12) (3/8)	1
31	96600-06016-00	Bolt, Socket (6x16)	2
32	13310-ZJ1-840	Crankshaft	1

ENGINE — PISTON




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	13010-ZJ1-841	Ring Set, Piston (Std)	2
	13011-ZJ1-841	Ring Set, Piston (OS 0.25)	2
	13012-ZJ1-841	Ring Set, Piston (OS 0.50)	2
	13013-ZJ1-841	Ring Set, Piston (0.75)	2
2	13101-ZJ1-840	Piston (Std)	2
	13102-ZJ1-840	Piston (OS 0.25)	2
	13103-ZJ1-840	Piston (OS 0.50)	2
	13104-ZJ1-840	Piston (0.75)	2
3	13111-ZJ1-840	Pin, Piston	2
4	13200-ZJ1-841	Rod Assembly, Connecting	2
6	90001-ZN1-000	Bolt, Connecting Rod (6x37)	4
7	94601-18000	Clip, Piston Pin (18mm)	4

ENGINE — CAMSHAFT




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	12209-ZE8-003	Seal, Valve Stem	2
2	14100-ZJ1-842	Camshaft Assembly	1
3	14410-ZJ1-840	Rod, Push	4
4	14431-ZE2-010	Arm, Valve Rocker	4
5	14451-ZE1-013	Pivot, Rocker Arm	4
6	14568-ZJ1-841	Spring, Weight Return	1
7	14576-ZJ1-840	Pin, Decompression	1
8	14711-ZE3-000	Valve, In	2
9	14721-ZE3-000	Valve, Ex	2
10	14730-ZJ1-840	Lifter Ass'y., Valve	1
11	14751-ZE2-003	Spring, Valve	4
12	14760-ZJ1-840	Shaft, Valve Lifter	1
13	14764-ZJ1-840	Spring, Valve Lifter	2
14	14771-ZE2-000	Retainer, In. Valve Spring	2
15	14773-ZE2-000	Retainer, Ex. Valve Spring	2
16	14775-ZE2-010	Seat, Valve Spring	2
17	14781-ZE2-000	Rotator, Valve	2
18	14791-ZE2-010	Plate, Push Rod Guide	2
19	90005-896-000	Bolt, Flange (5x16)	1
20	90012-ZE0-010	Bolt, Pivot (8mm)	4
21	90206-ZE1-000	Nut, Pivot Adj	4
22	90446-357-000	Washer, Thrust (17.2mm)	1
23	90602-ZE1-000	Clip, Governor Holder	2
24	94301-08120	Pin A, Dowel (8x12)	1
25	94101-06800	Washer, Plain (6mm)	4
26	94305-60282	Pin, Spring (6x28)	1
27	95701-06025-00	Bolt, Flange (6x25)	1

ENGINE — FAN COVER




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	16715-ZJ1-840	Cover, Fuel Pump	1
5	19611-ZJ1-860ZB	Cover, Fan (Bright Red)	1
6	19612-ZJ1-840	Plate, R. Side	1
7	19614-ZJ1-840	Plate, L. Side	1
8	19631-ZJ1-840	Shroud, R	1
9	19632-ZJ1-840	Shroud, L	1
14	33713-GC2-000	Collar B, Taillight	6
16	80101-310-000	Rubber, Rr. Fender Cushion	1
17	90013-883-000	Bolt, Flange (6x12) (Ct200)	10
18	90018-ZE1-000	Bolt, Flange (6x23)	2
19	90042-ZJ1-840	Bolt, Stud (6x71)	4
20	90313-ZJ1-840	Nut, Square (5mm)	2
23	93913-25580	Screw, Tapping (5x20)	2
25	94050-06000	Nut, Flange (6mm)	4
27	95701-06008-00	Bolt, Flange (6x8)	2

ENGINE — CARBURETOR




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	12357-ZJ1-840	Tube, Breather	1
2	15772-551-000	Clip, Breather Tube	1
3	16010-ZG8-000	Gasket Set	1
4	16011-KCK-910	Valve Set, Float	1
5	16013-ZV4-005	Float Set	1
6	16015-ZJ1-841	Chamber Set, Float	1
7	16016-ZJ1-010	Screw Set	1
8	16024-124-760	Screw Set, Drain	1
9	16028-ZG8-000	Screw Set	1
10	16100-ZJ1-841	Carburetor Assembly. (Bg22g A)	1
11	16148-141-881	Cap, Choke Lever Dust	1
12	16150-ZJ1-841	Jet Set (#52)	1
13	16166-ZJ0-000	Nozzle, Main	1
14	16178-548-004	O-ring (5.8x1.9)	1
15	16198-ZJ1-840	Tube, Drain	1
16	16200-ZJ1-841	Valve Assembly., Solenoid	1
17	16211-ZJ0-830	Insulator, Carburetor	1
18	16221-ZJ1-840	Gasket, Carburetor	2
19	17228-ZG8-003	Gasket, Air Cleaner	1
20	17410-ZJ1-840	Elbow, Air Cleaner	1
21	90314-ZJ1-840	Nut, Insert (6mm)	2
22	90682-959-661	Clip B, Cable	1
23	91402-ZJ1-841	Clip, Purse Lock	1
24	93892-04014-08	Screw-washer (4x14)	4
	93892-04014-18	Screw-washer (4x14)	4
25	93892-05012-08	Screw-washer (5x12)	2
26	95002-02080	Clip, Tube (B8)	1
27	95801-06120-00	Bolt, Flange (6x120)	2
28	99201-ZG8-1100	Jet Set, Main (#110)	1

ENGINE — FLYWHEEL




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	19511-ZJ1-000	Fan, Cooling	1
2	19513-ZJ1-000	Plate, Cooling Fan Setting	1
4	28452-ZJ1-811	Grid, Screen	1
6	28454-ZJ1-801	Holder, Screen Grid	1
7	31110-ZJ1-840	Flywheel	1
10	90201-ZG3-000	Nut, Flange (20mm)	1
11	90401-ZG3-000	Washer (20mm)	1
12	90741-ZE2-000	Key, Special Woodruff (25x18)	1
14	95701-08016-00	Bolt, Flange (8x16)	1
17	95701-08016-00	Bolt, Flange (8x16)	1

ENGINE — IGNITION COIL




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	30500-ZJ1-841	Coil Assembly., R. Ignition	1
2	30518-ZJ1-000	Grommet, Ignition Wire	2
3	30550-ZJ1-841	Coil Assembly., L. Ignition	1
4	30700-ZJ1-841	Cap Assembly., Noise Suppressor	2
6	31630-ZJ1-801	Coil Assembly., Charge (12V/20A)	1
7	31740-ZJ1-841	Diode Assembly., Engine Stop	1
8	63312-ZA7-000	Grommet, Tool	1
10	90031-ZE1-000	Bolt, Flange (6x32)	6
11	90031-ZE1-000	Bolt, Flange (6x32)	2
15	95701-06008-00	Bolt, Flange (6x8)	1
16	32763-PA0-000	Clamp, Wire	1

ENGINE — STARTER MOTOR




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	30201-PH9-004	Ring, Snap (Denso)	1
2	30202-PZ1-003	Collar Set, Clutch Stop	1
3	31200-ZJ1-841	Motor Assembly., Starter	1
4	31203-PH9-004	Lever, Pinion Drive	1
5	31204-ZJ1-H01	Switch Assembly., Magnet	1
6	31206-ZG4-801	Armature	1
7	31207-ZJ1-H01	Clutch, Overrunning	1
8	31211-PH9-004	Brush	4
9	31212-PH9-004	Spring, Brush	4
10	31213-P64-N01	Cover	1
11	31214-PH9-004	Bolt, Through	2
12	31216-ZJ1-H01	Yoke	1
13	31220-PH9-004	Nut, Hex. (8mm)	1
14	31223-PA0-006	Nut, Flange (5mm)	2
15	31231-PH9-004	Holder, Brush	1
16	31233-PH9-004	Insulator, Brush Holder	1
17	31234-ZJ1-H01	Cover, Terminal	1
18	91002-ZG4-801	Bearing A	2
19	94001-08000-0S	Nut, Hex. (8mm)	1
20	94111-08000	Washer, Spring (8mm)	1
21	94301-10120	Pin, Dowel (10x12)	2
22	95701-08110-00	Bolt, Flange (8x110)	2

ENGINE — CONTROL




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	16263-883-W10	Joint, Rod	1
2	16500-ZJ1-861	Control Assembly	1
3	16534-ZJ1-840	Spring, Starter	1
4	16551-ZJ1-840	Arm, Governor	1
5	16555-ZJ1-840	Rod, Governor	1
6	16561-ZJ4-830	Spring, Governor	1
7	16562-ZJ1-840	Spring, Throttle Return	1
8	16576-891-000	Holder, Cable	2
10	16584-883-300	Spring, Control Adjusting	2
11	16592-ZJ1-000	Spring, Cable Return	2
12	16617-ZJ1-840	Holder, Cable	2
14	16611-ZJ1-840	Rod, Choke Control	1
18	90014-952-000	Bolt, Flange (6x14)	2
21	92301-05016-0A	Bolt, Slot (5x16)	2
23	92301-05025-0A	Bolt, Slot (5x25)	1
24	92301-04006-0H	Bolt, Recessed (4x6)	2
25	93500-05025-0A	Screw, Pan (5x25)	1
26	94050-06000	Nut, Flange (6mm)	1

TRANSMISSION — TRANSAXLE CASE ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-194855-24020	Sealant	1
2	TT-192162-24111	Housing, Transaxle, Left	1
3	TT-192162-24121	Housing, Transaxle, Right	1
4	TT-194855-24150	Washer, 36 x 45.5 x 1.2	1
5	TT-192162-24190	Seal, TC 30 40 8	1
6	TT-194859-24252	Vent Valve	1
7	TT-194859-24262	Cap, Vent Valve	1
8	TT-194859-24270	Body, Vent Valve	1
9	TT-192162-24291	Cap, Oil	1
10	TT-22351-080020	Pin, 8 x 20	2
11	TT-23491-140002	Plug, 14	1
12	TT-24311-000160	Packing, P 16	1
13	TT-24311-000180	Packing, P 18	1
14	TT-192162-24160	Bolt, 28 x 10 x 9	16

TRANSMISSION — INPUT SHAFT ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-192162-24680	Washer 20 x 35 x 1.6	1
2	TT-192162-25212	Input Shaft	1
3	TT-192162-25340	Shifter	1
4	TT-192162-25250	Spring 29.5	1
5	TT-192162-25370	Gear 19H Kit	1
6	TT-192162-25360	Gear 19H, Input	1
7	TT-192162-25260	Needle 24 x 28 x 17	1
8	TT-192162-25280	Sprocket 11 Kit	1
9	TT-192162-25230	Sprocket 11, Input	1
10	TT-24161-202417	Needle 20 x 24 x 17	1
11	TT-192162-25290	Sleeve 20 x 30 x 13	1
12	TT-1E6190-54160	Washer 17.2 x 30 x 1.5	1
13	TT-24101-062034	Bearing 6203	1
14	TT-192159-31410	Bearing 6204R SH2	1
15	TT-24190-080001	Ball, 1/4	2

TRANSMISSION — REDUCTION ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-192162-25460	Reduction Shaft Assembly	1
2	TT-192162-25420	Sprocket, 27	1
3	TT-192162-25480	Shaft, Reduction	1
4	TT-194855-25460	Chain, 40 x 34	1
5	TT-192162-24190	Gear, 46H, Reduction	1
6	TT-192159-31410	Bearing, 6204R, SH2	2
7	TT-22242-000260	Ring, 26	1

TRANSMISSION — RANGE SHIFT ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-192162-27111	Arm, Shift	1
2	TT-192162-27680	Plate	1
3	TT-192162-28300	Block, Shift	1
4	TT-194855-52111	Switch	1
5	TT-22242-000140	Ring, 14	1
6	TT-24311-000125	Packing, P 12.5	2
7	TT-26476-080202	Tapping Screw, 8 x 20	1

TRANSMISSION — DIFFERENTIAL GEAR ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-192162-31460	Gear, 63H, Final	1
2	TT-192162-31510	Differential, Gear Kit	1
3	TT-192162-31520	Gear (RR, Differential)	1
4	TT-194855-31550	Shaft, Differential Pinion	1
5	TT-192157-31580	Differential Side Gear, RH	1
6	TT-192162-31610	Washer, Differential Gear	2
7	TT-194525-31810	Pinion, Differential	2
8	TT-194515-31850	Washer, Differential Pinion	2
9	TT-192162-32100	Differential, Case Kit	1
10	TT-192162-32110	Case (R, Differential)	1
11	TT-192162-32120	Case (L, Differential)	1
12	TT-22117-080000	Washer, 8	10
13	TT-24101-060084	Bearing, 6008	2
14	TT-26106-080402	Bolt, 8 x 40	10
15	TT-26716-080002	Nut, 8	10
16	TT-192162-33612	Shaft, LH	1
17	TT-192162-33622	Shaft, RH	1

TRANSMISSION — DIFFERENTIAL LOCK ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-194235-27270	Seal, TC4 20 35 7	1
2	TT-192162-33100	Differential Lock Kit	1
3	TT-192162-33120	Fork, Differential Lock	1
4	TT-192162-33131	Shaft, Differential Lock	1
5	TT-194300-33160	Spring, Differential Lock	1
6	TT-194300-33200	Spacer, 20 x 32 x 3.2	2
7	TT-22242-000200	Ring, 20	1
8	TT-22351-080032	Pin, 8.0A x 32	1
9	TT-22351-080040	Pin, 8.0A x 40	1
10	TT-194854-33110	Slider, Differential Lock	1
11	TT-192162-33140	Arm, Differential Lock	1
12	TT-192162-33150	Bracket, Differential Lock	1
13	TT-22360-120000	Pin, 12	1
14	TT-22487-120200	Pin, 12 x 20	1
15	TT-26476-080202	Tapping Screw, 8 x 20	2

TRANSMISSION — BRAKE ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-192162-36300	Plate Kit	1
2	TT-192162-36320	Steel Plate	6
3	TT-194555-36511	Friction Plate, 175	4
4	TT-192162-36310	Cover, Brake	2
5	TT-192162-36330	Actuator, LH	1
6	TT-192162-36340	Actuator, RH	1
7	TT-192162-36400	Cam Lever Complete, LH	1
8	TT-192162-36360	Cam Lever Shaft	1
9	TT-192162-36410	Cam Lever, Complete, RH	1
10	TT-192162-36360	Cam Lever Shaft	1
11	TT-192162-36390	Washer, 42 x 54.6 x 1	2
12	TT-22242-000250	Ring, 25	2
13	TT-22312-080160	Pin, 8 x 16	4
14	TT-24101-060064	Bearing, 6006	2
15	TT-24190-160001	Ball, 1/2	12
16	TT-24311-000210	Packing, P 21	2
17	TT-24421-304708	Seal, TC304708	2
18	TT-26476-080302	Tapping Screw, 8 x 30	20


ELECTRICAL SCHEMATIC




ELECTRICAL SCHEMATIC




ELECTRICAL SYSTEM



ELECTRICAL SYSTEM




Relay Center



Fuse Box

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	16606	Bracket, Retainer Hook	1
2	629-04008	Connection Assembly	1
3	629-04001	Harness Assembly, Utility Starter	1
4	629-04060	Harness Assembly, Ground	2
5	710-04030	Screw, Self-tapping 1/4-20	2
6	710-0599	Screw, Self-tapping, 1/4-20 x 0.500	3
7	710-0703	Screw, Hex Carriage, 1/4-20 x .75	2
8	710-0788	Screw, Self-tapping, 1/4-20 x 1.000	2
9	710-1260A	Screw, 5/16-18 x .75	1
10	710-3009	Screw, #10-24 x 0.75	4
11	712-0271	Nut, Hex Sems, 1/4-20	2
12	721-3049	Cover, Protection	1
13	723-3064	Strap, Battery	1
14	725-0157†	Cable, Tie 3/16 x .05 x 7.4	2
15	725-04008	Fuse, 5 Amp	1
16	725-04172	Harness, Utility Wire, Main	1
17	725-04067	Harness, Motor Wire	1
18	725-1657A	Switch, Interlock	1
19	725-1738	Battery, 300 CCA	1
20	726-0470	Cable Tie, 19" x 8.39"	7
21	726-0465	Clip, Retainer, Panel	2
22	726-04002†	Double Tube Clamp	1
23	736-0329	Lock Washer, 1/4	2

†Not Shown



CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019