




PART'S MANUAL

BIG COUNTRY 

6x4 Utility Vehicle

Model 642



CUB CADET LLC P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

PRINTED IN U.S.A.


FORM NO. 769-00897

9/2003

MODEL 642


TABLE OF CONTENTS

DESCRIPTION	PAGE	DESCRIPTION	PAGE
Air Filter	27	Fenders	16
Alternator	19	Frame	4
Axle, Front Suspension	6	Fuel System	22
Axle, Center Suspension	7	Hitch, Front.....	3
Axle, Rear Suspension	8	Hood	15
Bed	9	Labels.....	53
Bed Lift	17	Oil Filter	30
Brake, Parking	21	Pedal, Brake	26
Brush Guard	2	Pedal, Throttle	26
Bumper	2	Schematic, Electrical	48, 49
Cables	24	Seats	14
Chain Guide	5	Shifter Assembly	20
Clutch, Main	18	Steering (Lower).....	10
Dash Panel	13	Steering (Upper).....	11
Electrical System	50	Transmission Accessories.....	40
Electrical Rear Outlet	52	Transmission, <i>Tuff Torq</i> Model KT35	
Engine & Transmission Cradle	18	Transaxle Case Assembly	41
Engine Accessories	27	Input Shaft Assembly	42
Engine, <i>Honda</i> Model GX20K1		Reduction Assembly	43
Cylinder Head	28	Range Shift Assembly	44
Cylinder Barrel	29	Differential Gear Assembly	45
Crankcase Cover	30	Differential lock Assembly	46
Crankshaft.....	31	Brake Assembly	47
Piston	32	Trim Panels	12
Camshaft.....	33	Wheels, Front & Rear	25
Fan Cover	34		
Carburetor	35		
Flywheel	36		
Ignition Coil	37		
Starter Motor	38		
Control.....	39		




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-0037	Front Bumper Assembly	1
2	710-3001	Screw, Hex, 3/8-16 x .88	6
3	712-0431	Nut, Flange Lock, 3/8-16	6
4	736-04006	Washer, Flat, .444 x 1.0 x .057	6
5	607-04010	Guard, Brush	1
6	710-0514	Screw, Hex 3/8-16 x 1.00 GR 5	4
7	712-0431	Nut, Flangelock 3/8-16	4
8	736-3050	Flat Washer,.406 ID x 810 OD x.051	4

FRONT HITCH




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-0024	Hitch, Assembly	1
2	710-3008	Screw, 5/16-18 x .75 GR 5	5
3	712-3004A	Nut, Flangelock 5/16-18 GR 5	5
4	607-04011	Hitch	1
5	607-0026A	Mating Assembly	Ref

FRAME




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-0044C	Frame Assembly, Complete	1
2	607-04065	Frame Assembly, Upper Dash	1
3	710-0216	Screw, Hex, 3/8-16 x .75	4
4	710-0599	Screw, Self-tapping, 1/4-20 x 0.500	15
5	712-0431	Nut, Flange Lock, 3/8-16	4
6	712-0703A	Nut, Insert, 5/16-18	26
7	713-0605	Chain, 60-97 Pitch	2
8	731-04016	Bumper, Compression Extension	6
9	736-3050	Washer, Flat, .406 x 812 x .51	4
10	741-0761	Rubber Bushing, Bed Pivot	2
11	735-04040	Bumper	4
12	712-04052	Nut Hex, Flange Lock	8
13	707-04246	Plate, Spacer	4

CHAIN GUIDE



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	738-0509	Shoulder Screw, .50 x 1.825	1
2	736-3084	Washer, Flat, .510 x 1.12 x .060	2
3	736-0262	Washer, Flat, .385 x .870 x .092	1
4	731-04078	Roller, Chain	1
5	718-04033	Adjuster, Rotary	1
6	710-0599	Screw, Self-tapping, 1/4-20 x .5	1
7	710-0514	Hex Screw, 3/8-16 x 1.0	1


AXLE (FRONT SUSPENSION)



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-04004	Axle Assembly, Right-front	1
	737-04006	Grease Fitting	1
	741-0758	Bearing, .63 ID x 1.19 OD	2
	741-0762	Bushing, Steering	2
	750-1357	Spacer, .645 ID x 1.063 OD	1
—	607-04005	Axle Assembly, Left-front	1
	737-04006	Grease Fitting	1
	741-0758	Bearing, .63 ID x 1.19 OD	2
	741-0762	Bushing, Steering	2
	750-1357	Spacer, .645 ID x 1.063 OD	1
2	710-04023	Hex Screw, M10-1.25 x 65mm	2
3	710-04012	Hex Screw, 1/2-13 x 6.50, Gr5	2
4	710-04120	Hex Screw, 5/8-11 x 11.13, Gr5	2
5	712-04006	Nut, Hex Lock, Nylon, M10 -1.25	4
6	712-3016	Nut, Hex Lock, Nylon, 5/8-11, Gr5	2
7	712-3022	Nut, Hex Lock, 1/2-13	2
8	723-0618	Steering Control Knuckle, RH	1
—	723-0619	Steering Control Knuckle, LH	1
9	732-04176	Shock Absorber, 2.9 Stroke	2
10	750-1388	Tube, .875 x .50 x 4.75	2
11	710-04024	Hex Screw, M10-1.25 x 50mm	2
12	726-0465	Clip, Retainer	23
13	735-04001	Floor Mat	2


*.5 oz. per pivot arm

AXLE (CENTER SUSPENSION)




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-0043A	Axle Support Assembly, Center Weld	2
2	623-0026A	Weld Coupling Assembly	2
3	710-0216	Screw, Hex, 3/8-16 x .75, Gr5	12
4	710-0298	Screw, Hex, 5/8-18 x 3.5, Gr5	4
5	710-04023	Screw, M10-1.25 x .65, Gr8	2
6	710-04024	Screw, M10-1.25 x .50, Gr8	2
7	710-3229	Screw, Hex, 7/16-14 x 2.75, Gr5	4
8	711-1763	Axle Shaft, Drive Center	2
9	712-0290	Nut, Hex Lock, 7/16-14	4
10	712-04006	Nut, Nylon Lock, M10-1.25	4
11	712-0413	Nut, Jam Lock, 5/8-18, Gr5	2
12	713-04005	Sprocket, Hub, 1.75 - 23T	2
13	716-0401	Retaining Ring, External, 1.14	2
14	732-04176	Shock Absorber, 2.9 Stroke	2
15	736-0169	Washer, Lock, 3/8 , Regular Duty	12
16	736-0237	Washer, Flat, .65 x 1.25 x .075	4
17	736-0424	Washer, Flat, 1.06 x 1.56 x .020	4
18	736-3046A	Washer, Flat, 1.010 x 1.86 x .060	8
19	737-3000	Lube Fitting, 3/16	4
20	741-04030	Bearing, 1.0 x 1.125 x 1.0	8
21	741-0759	Ball Bearing, Internal Axle	2
22	741-0760	Ball Bearing, External Axle	2
23	750-04004	Spacer, .63 x 1.0 x 2.594	4
24	750-1389	Spacer, 1.78 x 1.88	2

AXLE (REAR SUSPENSION)



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-0042A	Axle Support Assembly, Rear Weld	1
2	710-0298	Screw, Hex, 5/8-18 x 3.5, Gr5	2
3	710-04023	Screw, M10-1.25 x .65, Gr8	1
4	710-04024	Screw, M10-1.25 x .50, Gr8	1
5	711-1764	Axle Shaft, Rear Drive	1
6	712-04006	Nut, Nylon Lock, M10 x 1.25	2
7	712-0413	Jam Nut, Nylon Lock, 5/8-18	2
8	713-04007	Sprocket	1
9	716-0401	Retaining Ring, External, 1.14	2
10	732-04176	Shock Absorber, 2.9Stroke	2
11	736-0237	Washer, Flat, .65 x 1.25 x .075	4
12	736-0424	Washer, Flat, 1.06 x 1.56 x .020	4
13	736-3046A	Washer, Flat, 1.010 x 1.86 x .060	8
14	737-3000	Lube Fitting, 3/16	4
15	741-04030	Bearing, 1.0 x 1.125 x 1.0	8
16	741-0759	Ball Bearing, Internal Axle	2
17	741-0760	Ball Bearing, External Axle	2
18	750-04004	Spacer, .63 x 1.0 x 2.594	4


BED



NOTE: Bed shown inverted for clarity.


REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-04028	Tailgate Assembly	1
2	607-04035	Bed Assembly, Utility	1
3	710-0489	Screw, Hex, 1/5-13 x 2.0, Gr5	2
4	710-0599	Screw, Self-tapping, 1/4-20 x 0.500	8
5	712-3022	Nut, Hex Lock, 1/2-13	2
6	714-0104	Cotter Pin,.072Dia x 1.13LG	8
7	731-04016	Bumper, Extension Suspension	4
8	732-0306	Compression Spring,.406 x.531 x 1.75 LG	4
9	735-0271	Bumper,.62Dia x.3	4
10	736-0162	Washer, Flat,.64 ID x 1.0 x.12	2
11	736-3008	Washer, Flat,.344 x.750 x.120	2
12	736-3010	Washer, Flat,.407 x.812 x.135 HDN	4
13	746-0968	Cable, Lift 16.16 LG	2
14	747-1116	Handle, Deck Release	4
15	748-0331	Spacer, Shoulder.625 Dia x.324 Dia	2

STEERING (LOWER)




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	617-0075A	Gear Assembly, Steering	1
2	707-04074	Steering Bracket, Sector Clamp	1
3	707-0417	Bracket, Steering Mounting	1
4	710-0514	Hex Screw, 3/8-16, 1.00, Gr5	4
5	710-0520	Hex Screw, 3/8-16, 1.50, Gr5	2
6	712-0431	Nut, Flange Lock, 3/8-16	6
7	735-0801	Grommet, Steering Shaft	1
8	741-0763	Bushing, Rubber	1

STEERING (UPPER)




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	623-0027	Shaft Assembly, Steering	1
2	710-0520	Hex Screw, 3/8-16, 1.50, Gr5	1
3	710-3008	Hex Screw, 5/16-18, .75, Gr5	4
4	711-1774	Collar, .75	2
5	712-04001	Nut, Hex, M16-2, Class 8	1
6	712-3009	Nut, Hex Lock, 5/16-18	4
7	712-3017	Nut, Hex, 3/8-16, Gr8	1
8	731-0954	Bellow, Steering, 4.75 Lg	1
9	731-2848	Steering Wheel, Three-spoke	1
10	731-3210	Cover, Steering Wheel, Soft Grip	1
11	736-0169	Washer, Lock, 3/8, Regular Duty	1
12	736-0262	Washer, Flat, .385 ID x .870 OD x .092	4
13	741-04000	Bearing, Flange, .75 ID, Self-Aligning	2

TRIM PANELS




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	631-04095	Dash Assembly	1
2	710-04064	Machine, Screw, 1/4-20 x .75	8
3	710-04066	Screw, 1/4-20 x 3.0	2
4	710-0599	Screw, Self-tapping, 1/4-20 x 0.500	1
5	712-04013	Nut, Retainer, 1/4-20	2
6	712-0397	Wing Nut, 1/4-20 (w/ Bell Washer)	2
7	731-04033A	Tool Box	1
8	731-2648	Console, Cup Holder	1
9	731-2952	Panel, Airbox Cover	1
10	731-2953A	Panel, Shift Cover	1
11	736-0195	Washer, Flat, .3125 x .875 x .04	2
12	736-04004	Flat Washer, .350 x 1.25 x .06	3
13	736-04017	Washer, Rubber, .375 x 1.5 x 1.25	2
14	736-3020	Washer, Flat, .271 x .630 x .065	8

DASH PANEL




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	625-04009	Instrument Panel	1
2	725-04000	Switch, Key	1
3	725-04006	Rocker Switch, Headlight	1
4	725-1346	Ignition Switch Nut, 5/8-32	1
5	725-1347	Ignition Switch Cap	1
6	725-2003	Receptacle, Power, 12v	1
7	726-0293	Nut, Retainer 1/8	2
8	731-04010	Switch	3
9	731-04023	Plug	1
10	731-04270	Dash Panel	1
11	725-04014	Switch, Horn	1
-	725-04015	Horn, Assembly 12V (Shown on Page 11)	-

SEATS




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-0023	Plate Assembly, Seat, LH	1
2	712-3004A	Nut, Flange Lock, 5/16-18, Gr5	8
3	757-0389	Track Assembly, Seat	1
4	757-04008	Seat	2
5	607-0022	Plate Assembly, Seat, RH	1
6	750-04023	Spacer, Seat	4
7	649-04002	Tube Assembly, Grab Handle	2
8	710-0216	Hex Screw, 3/8-16 x .75, Gr5	8
9	712-0431	Nut, Flange Lock, 3/8-16	12
10	738-0140	Shoulder Screw, .435 x .178-5/16 x .56	4
11	710-3025	Hex Screw, 5/16-18 x .625, Gr5	2
12	735-0271	Bumper .62 Dia x .3	3
13	710-0376	Hex Screw 5/16-18 x 1.00 Gr 5	2

HOOD




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	707-04165	Mounting Bracket, Hood	1
2	710-3015	Hex Screw, 1/4-20, .75, Gr5	4
3	711-04139	Rod Mounting Hood	1
4	712-0324	Nut, Nylon Hex Lock, 1/4-20, Gr8	4
5	714-0101	Cotter Pin	1
6	731-04552	Panel, Hood	1
7	736-3020	Washer, Flat, .271 x .630 x .065	4
—	631-04055	Panel Assembly, Hood	—

FENDERS




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	731-04556	Panel, Front Fender, RH	1
2	731-04557	Panel, Front Fender, LH	1
3	731-04552	Panel, Hood	1
4	710-0376	Hex Screw, 5/16-18 x 1.0 Gr5	22
5	710-0703	Hex Screw, 1/4-20 x .75	8
6	710-3008	Hex Screw, 1/4-20	2
7	710-0324	Hex Lock Nut, Nylon, 1/4-20	8
8	728-04004	Pop Rivet	14
9	731-04553	Panel, Bed Skirt, LH	1
10	731-04559	Panel, Rear Fender, LH	1
11	731-04558	Panel, Rear Fenders, RH	1
12	731-04555	Panel Bed Skirt, RH	1
13	735-04035	Mud Flap, Rear	2
14	735-04003	Mud Flap	2
15	736-04008	Washer, Rubber, .310 x 1.0 x .125	8
16	736-04004	Flat Washer, .350 x 1.25 x .06	22
17	736-0119	Lock Washer, 5/16	22
18	736-3020	Flat Washer, .271 x .630 x .065	8
19	736-0275	Flat Washer, .344 x .688 x .0652	2
20	736-0400	Flat Washer, .194 x .62 OD x .063	14
21	625-04017	Headlight Assembly	2

BED LIFT




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	711-04006	Clevis Pin 3.0"	1
2	711-04007	Clevis Pin 2.25"	1
3	714-04003	Internal Cotter Pin	2
4	725-04012	Cargo Box Switch	1
5	725-04020	Actuator, Electric Bed Lift	1
6	725-1543	Fuse 30 Amp	1
7	725-1718	Relay 12V 40A (2)	2

ENGINE & TRANSMISSION CRADLE



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-0029A	Frame Assembly, Engine/Trans. Support	1
2	710-0344	Hex Screw, 3/8-16 x 1.5, Gr5	1
3	710-04019	Hex Screw, 3/8-24 x 3, Gr5	1
4	710-04024	Hex Screw, M10-1.25 x .50, Gr8	4
5	710-04025	Hex Screw, M10-1.5 x 60mm, Gr8	1
6	710-04028	Hex Screw, M16-2 x 40mm	4
7	710-0514	Hex Screw, 3/8-16 x 2.25, Gr5	4
8	710-1260a	Hex Screw, 5/16-18 x .75	4
9	712-0375	Nut, Hex Lock, 3/8-16	5
10	712-04006	Nut, Nylon Lock, M10-1.25	4
11	732-1186	Spring, Extension, .795 x 5.42	2
12	736-0133	Washer, Flat, .411 x 1.25 x .10	9
13	736-04005	Washer, Flat, .395 x 1.12 x .14	1
14	618-0686A	Clutch Assembly, Engine	1
15	618-0687	Clutch Assembly, Transmission	1
16	736-04009	Washer, 1.03 x 1.625 x .12	1
17	738-04002	Spacer, Drive, .39 ID x 1.00 OD	1
18	754-0646	V-type Belt, Cogged, 1.19	1


ALTERNATOR



*4 x 2 Only


REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-04041	Pulley Assembly Alternator	1
2	707-04179	Bracket, Mount Front	1
3	707-04189	Bracket, Support Rear	1
4*	707-04220	Bracket, Support (4x2 only)	1
5	710-0489	Screw, 1/2-13 x 2.00 GR5	1
6	710-1681	Screw, M8- 1.25 - 20	2
7	710-3001	Hex Screw, 3/8-16 x .880, Gr5	4
8*	710-3131	Hex Screw, 1/2-13 GR8(4x2 Only)	1
9	712-0431	Nut, Flange Lock, 3/8-16	4
10	712-3022	Nut, Hex Lock, 1/2-13	2
11	725-04148	Harness, Aux, Alternator	1
12	725-04161	Alternator, Aux 65 Amp	1
13	725-04163	Harness, Alternator Regulator	1
14	736-0242	Washer, Bell, .340 x .872 x .060	1
15	754-0465	V-Belt 3/8 x 35.68 LG	1
16	756-04097	Pulley, 2.65 OD	1

SHIFTER ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	647-0069B	Lever Assembly, Transmission	1
2	647-0071A	Shifter Assembly, Differential Lock	1
3	711-04017	Pin, Clevis, .375 x 2.0	1
4	711-04068	Pin, Clevis, .5 x 5.375	1
5	712-3001	Nut, Jam, 3/8-24	1
6	714-0104	Pin, Cotter, .072 x 1.13	2
7	714-0115	Pin, Cotter, 1/8 x 1.0	1
8	719-3013	Clevis, Adjustment	1
9	720-04002	Knob, Ball	1
10	720-0434	Knob, Ball	1
11	732-1187	Spring, Extension, .637 x 2.972	1
12	746-04004	Control Cable, Differential Lock	1
13	747-04010A	Shifter Rod, Transmission	1

PARKING BRAKE




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-0021	Lever Assembly, Parking Brake	1
2	710-04030	Screw, Hi-Lo, 1/4-20 x .5	2
3	711-04067	Pin, Clevis	1
4	711-1765	Rod, Brake Lock	1
5	714-0101	Pin, Cotter	1
6	714-0127	Pin, Cotter 1/16 x .75	2
7	720-04001	Knob, Ball	1
8	721-3049	Cover, Protective	1
9	725-1657A	Snap Mount Switch, Interlock	1
10	732-1187	Spring, Extension, .637 x 2.972	1
11	736-0463	Washer, Flat .25 x .630 x .0515	2

FUEL SYSTEM




FUEL SYSTEM




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	651-04003	Pump Assembly, Fuel	1
2	707-0381	Support Plate, Console	1
3	710-0106	Hex Screw, 1/4-20 x 1.25, Gr5	2
4	712-0324	Nut, Nylon Hex Lock, 1/4-20, Gr8	2
5	722-0160	Bushing, .96 OD x .50	2
6	726-0205	Clamp, Hose	6
7	726-0470	Cable Tie, 19 x 8.39	1
8	736-3020	Washer, Flat, .271 x .630 x .065	4
9	751-0535	Hose, Fuel Line	5
10	793-00003	Filter, Fuel	2
11	721-04006	Gasket, Fuel Tank, 11.5	2
12	725-2068	Switch, Fuel Level Gauge	1
13	735-0699	Grommet, 1.58 OD x 1.21 ID x .5	2
14	737-04009	Fitting, Elbow, .190 ID	1
15	737-04010	Valve, Fuel Tank	1
16	741-04006	Grommet, 1.06 OD x .362	1
17	751-0850	Tank, Fuel	1
18	751-0853	Gauge, Fuel Tank	1
19	751-0852	Cap, Fuel, 3.5	1
20	607-0034	Bracket Assembly, Fuel Tank	1
21	710-3008	Hex Screw, 5/16-18 x .75	4
22	736-0119	Washer, Lock, 5/16	2
23	736-0278	Washer, Flat, .330 x .687 x .030	4
24	736-0159	Washer, .349 x .879 x .063	1
25	712-0265	Sems Nut, 5/16-18	1
26	726-0470	Cable Tie, Tree Mount	1
27	711-1768	Hold-down Rod, Fuel Tank	1
28	712-3027	Nut, Flange Lock, 1/4-20	1
—	631-0223	Tank Assembly, Fuel (Incl. Refs 12-19)	1

CABLES




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	710-04027	Screw, Shoulder, .375 x .375	1
2	711-0813	Pin, Clevis, 5/16 x 2.5	1
3	712-3025	Nut, Jam 5/16-18	6
4	712-3009	Nut, Hex Lock, 5/16-18	1
5	714-0104	Pin, Cotter, .072 x 1.13	2
6	726-0470	Tie, Cable 19 x 8.39 Tree Mount	1
7	732-0470A	Extension Spring,.530 OD x 4.75 LG	1
8	736-0159	Washer, .349 x .879 x .063	1
9	736-0271	Washer, Spring.317 ID x.625 OD	1
10	746-04000	Cable, Control Brake	2
11	746-04002	Cable, Control, Choke	1
12	746-04006	Cable, Control Brake Clutch	1
13	746-04042	Cable, Control, Throttle	1
14	707-04006	Guard, Belt	1
15	710-0378	Screw, Hex 5/16-18 x 2.5	2
16	710-0759	Screw, Flange 5/16-18 x.625	2
17	712-3009	Nut, Hexlock 5/16-18	2

WHEELS




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	710-04009	Hex Screw, 7/16-20 x 1.5, Gr5	20
2	710-3181	Hex Screw, 1/2-13 x 1.5, Gr5	2
3	736-04019	Washer, Flat, .531 x 1.25 x .181	2
4	731-04029	Dust Cover	2
5	634-04035	Wheel Assembly, RH 22 x 11 x 10 EMT (AT)	1
5	634-04036	Wheel Assembly, LH 22 x 11 x 10 EMT (AT)	1
6	634-04108	Wheel Assembly, RH 25 x 11 x 10 EMT (AT)	2
6	634-04109	Wheel Assembly, LH 25 x 11 x 10 EMT (AT)	2

PEDALS




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-0038	Pedal Assembly, Brake	1
2	607-0039	Pedal Assembly, Throttle	1
3	611-0157	Shaft Assembly, Pedal Pivot	2
4	710-0528	Hex Screw, 5/16-18, 1.25, Gr5	2
5	710-0875	Screw, Self-tapping, 1/4-20 x .75	2
6	712-3010	Nut, Hex Lock, 5/16-18, Gr5	2
7	712-3061	Lock Nut, Nylon, 3/8-24	1
8	735-04000	Pad, Pedal Brake	1

ENGINE ACCESSORIES




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	651-04000A	Filter Assembly, Air Cleaner	1
-	751-3206	Filter, Air Cleaner Housing	1
-	751-3207	Filter, Air Cleaner Element	1
-	751-3208	Filter, Air Cleaner Cap	1
-	751-3197	Filter, Air Cleaner Dust Valve	1
2	707-0375	Support, Upper Transmission	1
3	710-04022	Hex Screw, M8-1.25	2
4	710-0473	Screw, Machine #10-24 x .50	2
5	710-3005	Hex Screw, 3/8-16 x 1.25	
6	710-3206A	Hex Screw, M8-1.25 x 25, Gr8	3
7	732-04039	Spring, Extension, .315 OD x 2.125	1
8	735-0226	Grommet, Rubber .66 ID x 1.25 OD	1
9	736-0119	Washer, Lock, 5/16	2
10	736-0278	Washer, Flat, .33 x .678 x .030	2
11	736-3050	Washer, Flat, .406 x .812 x .051	1
12	737-04013	Valve, Oil Drain	1
13	751-0544	Arrestor, Spark 1-1/4	1
14	751-0854	Muffler, Honda GXV	1
15	852H636740	Engine, <i>Honda</i> GX620K1	1

ENGINE — CYLINDER HEAD




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	11911-ZJ1-840	Hanger, Engine	2
2	12204-ZE2-306	Guide, Valve (OS)	2
3	12205-ZJ1-405	Guide, Ex. Valve (OS)	2
4	12210-ZJ1-840	Cylinder Head (#1)	1
5	12216-ZE2-300	Clip, Valve Guide	4
6	12220-ZJ1-840	Cylinder Head (#2)	1
7	12251-ZJ1-841	Gasket, Cylinder Head	2
8	12311-ZJ1-840	Cover, Head	1
9	12314-ZJ1-840	Cover, Head Filler	1
10	12391-ZE2-020	Gasket, Cylinder Head Cover	2
11	15611-MB0-000	Cap, Oil Filler	1
12	15625-ZJ1-840	Gasket, Oil Filler Cap	1
13	17101-ZJ1-840	Manifold, In	1
14	17151-ZJ1-841	Gasket, In. Manifold	2
15	18333-ZE3-800	Gasket, Ex. Pipe	2
16	19682-ZJ1-840	Shroud, Head	2
17	90011-ZJ1-841	Bolt, Socket (8x45)	4
18	90014-ZE2-000	Bolt, Head Cover	2
19	90014-952-000	Bolt, Flange (6x14)	2
20	90018-ZJ1-840	Bolt, Stud (8x22)	4
21	90441-ZE2-010	Washer, Head Cover	2
22	94050-08000	Nut, Flange (8mm)	4
23	94301-12200	Pin A, Dowel (12x20)	4
24	95701-08020-00	Bolt, Flange (8x20)	2
25	95701-10080-00	Bolt, Flange (10x80)	8
26	98079-52876	Spark Plug (BPR2ES) (NGK)	2

ENGINE — CYLINDER BARREL




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	12000-ZJ1-841	Cylinder Assembly	1
2	12356-ZJ1-000	Cover, Breather	1
3	12358-ZJ1-000	Gasket, Breather Cover	1
4	12372-ZE2-300	Valve, Breather	1
5	15558-ZJ1-010AH	Valve, Drain (14x1.5)	1
6	16541-ZJ1-840	Shaft, Governor Arm	1
8	31511-ZJ1-000	Clamp, Wire	1
10	37240-ZG3-E01	Switch, Oil Pressure	1
11	90002-ZG5-004	Screw-washer (4x8)	1
12	90029-888-000	Bolt, Flange (6x16)	2
13	90031-ZE1-000	Bolt, Flange (6x32)	2
14	91001-ZJ1-841	Bearing, Needle (8x12.7x11.1)	1
15	91002-ZJ1-841	Bearing, Needle (8x12x10)	1
16	91201-ZE9-003	Oil Seal (8x14x5)	1
17	91201-ZJ1-841	Oil Seal (38x58x9)	1
18	91302-MB6-830	O-ring (13x3.0)	1
20	92800-14000	Bolt, Drain Plug (14mm)	2
22	94102-08800	Washer, Plain (8mm)	3
23	94109-14000	Washer, Drain Plug (14mm)	2
24	94251-08000	Pin, Lock (8mm)	2
26	96140-60030-10	Bearing, Radial Ball (6003)	1

ENGINE — CRANKCASE COVER




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	11300-ZJ1-840	Cover Assembly, Crankcase (Q-type)	1
2	11381-ZJ1-840	Gasket, Case Cover	1
4	15120-ZJ1-000	Cover Assembly, Oil Pump	1
5	15124-ZJ1-003	Rotor, Oil Pump (Outer)	1
6	15232-ZJ1-000	Spring, Relief Valve	1
7	15348-ZJ1-840	Cover, Oil Filter	1
8	15400-POH-305PE	Filter, Oil	1
10	15411-ZJ1-840	Base, Oil Filter	1
11	15427-ZJ1-000	Screen, Oil Filter	1
12	15655-ZJ1-840	Dipstick, Oil	1
13	16510-ZJ1-840	Governor Assembly	1
14	16511-ZJ1-840	Weight, Governor	3
15	16512-ZJ1-840	Holder, Governor Weight	1
16	16513-ZE2-000	Pin, Governor Weight	3
17	16531-ZE2-000	Slider, Governor	1
20	90015-883-000	Bolt, Flange (6x28)	3
21	90018-PN3-000	Holder, Oil Filter	1
22	90473-147-000	Washer (6x16)	1
23	90602-ZE1-000	Clip, Governor Holder	1
24	91202-ZJ1-841	Oil Seal (38x58x9)	1
25	91320-MJ6-003	O-ring (11.8x2.4)	2
26	94101-06800	Washer, Plain (6mm)	1
27	94301-08140	Pin A, Dowel (8x14)	2
28	95701-06020-00	Bolt, Flange (6x20)	3
29	95701-08050-00	Bolt, Flange (8x50)	9
30	96211-12000	Ball, Steel (#12) (3/8)	1
31	96600-06016-00	Bolt, Socket (6x16)	2

ENGINE — CRANKSHAFT




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	13310-ZJ1-840	Crankshaft	1

ENGINE — PISTON




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	13010-ZJ1-841	Ring Set, Piston (Std)	2
	13011-ZJ1-841	Ring Set, Piston (OS 0.25)	2
	13012-ZJ1-841	Ring Set, Piston (OS 0.50)	2
	13013-ZJ1-841	Ring Set, Piston (0.75)	2
2	13101-ZJ1-840	Piston (Std)	2
	13102-ZJ1-840	Piston (OS 0.25)	2
	13103-ZJ1-840	Piston (OS 0.50)	2
	13104-ZJ1-840	Piston (0.75)	2
3	13111-ZJ1-840	Pin, Piston	2
4	13200-ZJ1-841	Rod Assembly, Connecting	2
6	90001-ZN1-000	Bolt, Connecting Rod (6x37)	4
7	94601-18000	Clip, Piston Pin (18mm)	4

ENGINE — CAMSHAFT




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	12209-ZE8-003	Seal, Valve Stem	2
2	14100-ZJ1-842	Camshaft Assembly	1
3	14410-ZJ1-840	Rod, Push	4
4	14431-ZE2-010	Arm, Valve Rocker	4
5	14451-ZE1-013	Pivot, Rocker Arm	4
6	14568-ZJ1-841	Spring, Weight Return	1
7	14576-ZJ1-840	Pin, Decompression	1
8	14711-ZE3-000	Valve, In	2
9	14721-ZE3-000	Valve, Ex	2
10	14730-ZJ1-840	Lifter Ass'y., Valve	1
11	14751-ZE2-003	Spring, Valve	4
12	14760-ZJ1-840	Shaft, Valve Lifter	1
13	14764-ZJ1-840	Spring, Valve Lifter	2
14	14771-ZE2-000	Retainer, In. Valve Spring	2
15	14773-ZE2-000	Retainer, Ex. Valve Spring	2
16	14775-ZE2-010	Seat, Valve Spring	2
17	14781-ZE2-000	Rotator, Valve	2
18	14791-ZE2-010	Plate, Push Rod Guide	2
19	90005-896-000	Bolt, Flange (5x16)	1
20	90012-ZE0-010	Bolt, Pivot (8mm)	4
21	90206-ZE1-000	Nut, Pivot Adj	4
22	90446-357-000	Washer, Thrust (17.2mm)	1
23	90602-ZE1-000	Clip, Governor Holder	2
24	94301-08120	Pin A, Dowel (8x12)	1
25	94101-06800	Washer, Plain (6mm)	4
26	94305-60282	Pin, Spring (6x28)	1
27	95701-06025-00	Bolt, Flange (6x25)	1

ENGINE — FAN COVER




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	16715-ZJ1-840	Cover, Fuel Pump	1
5	19611-ZJ1-860ZB	Cover, Fan (Bright Red)	1
6	19612-ZJ1-840	Plate, R. Side	1
7	19614-ZJ1-840	Plate, L. Side	1
8	19631-ZJ1-840	Shroud, R	1
9	19632-ZJ1-840	Shroud, L	1
14	33713-GC2-000	Collar B, Taillight	6
16	80101-310-000	Rubber, Rr. Fender Cushion	1
17	90013-883-000	Bolt, Flange (6x12) (Ct200)	10
18	90018-ZE1-000	Bolt, Flange (6x23)	2
19	90042-ZJ1-840	Bolt, Stud (6x71)	4
20	90313-ZJ1-840	Nut, Square (5mm)	2
23	93913-25580	Screw, Tapping (5x20)	2
25	94050-06000	Nut, Flange (6mm)	4
27	95701-06008-00	Bolt, Flange (6x8)	2

ENGINE — CARBURETOR




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	12357-ZJ1-840	Tube, Breather	1
2	15772-551-000	Clip, Breather Tube	1
3	16010-ZG8-000	Gasket Set	1
4	16011-KCK-910	Valve Set, Float	1
5	16013-ZV4-005	Float Set	1
6	16015-ZJ1-841	Chamber Set, Float	1
7	16016-ZJ1-010	Screw Set	1
8	16024-124-760	Screw Set, Drain	1
9	16028-ZG8-000	Screw Set	1
10	16100-ZJ1-841	Carburetor Assembly. (Bg22g A)	1
11	16148-141-881	Cap, Choke Lever Dust	1
12	16150-ZJ1-841	Jet Set (#52)	1
13	16166-ZJ0-000	Nozzle, Main	1
14	16178-548-004	O-ring (5.8x1.9)	1
15	16198-ZJ1-840	Tube, Drain	1
16	16200-ZJ1-841	Valve Assembly., Solenoid	1
17	16211-ZJ0-830	Insulator, Carburetor	1
18	16221-ZJ1-840	Gasket, Carburetor	2
19	17228-ZG8-003	Gasket, Air Cleaner	1
20	17410-ZJ1-840	Elbow, Air Cleaner	1
21	90314-ZJ1-840	Nut, Insert (6mm)	2
22	90682-959-661	Clip B, Cable	1
23	91402-ZJ1-841	Clip, Purse Lock	1
24	93892-04014-08	Screw-washer (4x14)	4
	93892-04014-18	Screw-washer (4x14)	4
25	93892-05012-08	Screw-washer (5x12)	2
26	95002-02080	Clip, Tube (B8)	1
27	95801-06120-00	Bolt, Flange (6x120)	2
28	99201-ZG8-1100	Jet Set, Main (#110)	1

ENGINE — FLYWHEEL




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	19511-ZJ1-000	Fan, Cooling	1
2	19513-ZJ1-000	Plate, Cooling Fan Setting	1
4	28452-ZJ1-811	Grid, Screen	1
6	28454-ZJ1-801	Holder, Screen Grid	1
7	31110-ZJ1-840	Flywheel	1
10	90201-ZG3-000	Nut, Flange (20mm)	1
11	90401-ZG3-000	Washer (20mm)	1
12	90741-ZE2-000	Key, Special Woodruff (25x18)	1
14	95701-08016-00	Bolt, Flange (8x16)	1
17	95701-08016-00	Bolt, Flange (8x16)	1

ENGINE — IGNITION COIL




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	30500-ZJ1-841	Coil Assembly., R. Ignition	1
2	30518-ZJ1-000	Grommet, Ignition Wire	2
3	30550-ZJ1-841	Coil Assembly., L. Ignition	1
4	30700-ZJ1-841	Cap Assembly., Noise Suppressor	2
6	31630-ZJ1-801	Coil Assembly., Charge (12V/20A)	1
7	31740-ZJ1-841	Diode Assembly., Engine Stop	1
8	63312-ZA7-000	Grommet, Tool	1
10	90031-ZE1-000	Bolt, Flange (6x32)	6
11	90031-ZE1-000	Bolt, Flange (6x32)	2
15	95701-06008-00	Bolt, Flange (6x8)	1
16	32763-PA0-000	Clamp, Wire	1

ENGINE — STARTER MOTOR




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	30201-PH9-004	Ring, Snap (Denso)	1
2	30202-PZ1-003	Collar Set, Clutch Stop	1
3	31200-ZJ1-841	Motor Assembly., Starter	1
4	31203-PH9-004	Lever, Pinion Drive	1
5	31204-ZJ1-H01	Switch Assembly., Magnet	1
6	31206-ZG4-801	Armature	1
7	31207-ZJ1-H01	Clutch, Overrunning	1
8	31211-PH9-004	Brush	4
9	31212-PH9-004	Spring, Brush	4
10	31213-P64-N01	Cover	1
11	31214-PH9-004	Bolt, Through	2
12	31216-ZJ1-H01	Yoke	1
13	31220-PH9-004	Nut, Hex. (8mm)	1
14	31223-PA0-006	Nut, Flange (5mm)	2
15	31231-PH9-004	Holder, Brush	1
16	31233-PH9-004	Insulator, Brush Holder	1
17	31234-ZJ1-H01	Cover, Terminal	1
18	91002-ZG4-801	Bearing A	2
19	94001-08000-0S	Nut, Hex. (8mm)	1
20	94111-08000	Washer, Spring (8mm)	1
21	94301-10120	Pin, Dowel (10x12)	2
22	95701-08110-00	Bolt, Flange (8x110)	2

ENGINE — CONTROL



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	16263-883-W10	Joint, Rod	1
2	16500-ZJ1-861	Control Assembly	1
3	16534-ZJ1-840	Spring, Starter	1
4	16551-ZJ1-840	Arm, Governor	1
5	16555-ZJ1-840	Rod, Governor	1
6	16561-ZJ4-830	Spring, Governor	1
7	16562-ZJ1-840	Spring, Throttle Return	1
8	16576-891-000	Holder, Cable	2
10	16584-883-300	Spring, Control Adjusting	2
11	16592-ZJ1-000	Spring, Cable Return	2
12	16617-ZJ1-840	Holder, Cable	2
14	16611-ZJ1-840	Rod, Choke Control	1
18	90014-952-000	Bolt, Flange (6x14)	2
21	92301-05016-0A	Bolt, Slot (5x16)	2
23	92301-05025-0A	Bolt, Slot (5x25)	1
24	92301-04006-0H	Bolt, Recessed (4x6)	2
25	93500-05025-0A	Screw, Pan (5x25)	1
26	94050-06000	Nut, Flange (6mm)	1


TRANSMISSION ACCESSORIES



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	607-04016	Shift Assembly, Interlock	1
2	618-0685	Transmission, <i>Tuff Torq</i> Model KT 35	1
3	707-0369	Lever, Transmission	1
4	710-0693	Hex Screw, 3/8-16 x 4.50, Gr5	1
5	710-0805	Hex Screw, 5/16-18 x 1.50, Gr5	1
6	710-3001	Hex Screw, 3/8-16 x .880, Gr5	1
7	712-3005	Lock Nut, Hex Flange 3/8-16	2
8	712-3009	Nut, Hex Lock, 5/16-18	1
9	736-0278	Washer, Flat, .330 x .687 x .030	1
10	750-3235	Spacer, .505 x .75 x 3.31	1
11	711-04024	Pin, .625 x 1.37	2
12	716-0106	E-Ring, .625	4
—	737-3119	Oil, Shell TTF-SB	*


* Transmission Capacity is 189 oz.

TRANSMISSION — TRANSAXLE CASE ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-194855-24020	Sealant	1
2	TT-192162-24111	Housing, Transaxle, Left	1
3	TT-192162-24121	Housing, Transaxle, Right	1
4	TT-194855-24150	Washer, 36 x 45.5 x 1.2	1
5	TT-192162-24190	Seal, TC 30 40 8	1
6	TT-194859-24252	Vent Valve	1
7	TT-194859-24262	Cap, Vent Valve	1
8	TT-194859-24270	Body, Vent Valve	1
9	TT-192162-24291	Cap, Oil	1
10	TT-22351-080020	Pin, 8 x 20	2
11	TT-23491-140002	Plug, 14	1
12	TT-24311-000160	Packing, P 16	1
13	TT-24311-000180	Packing, P 18	1
14	TT-192162-24160	Bolt, 28 x 10 x 9	16

TRANSMISSION — INPUT SHAFT ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-194855-24020	Sealant	1
2	TT-192162-24111	Housing, Transaxle, Left	1
3	TT-192162-24121	Housing, Transaxle, Right	1
4	TT-194855-24150	Washer, 36 x 45.5 x 1.2	1
5	TT-192162-24190	Seal, TC 30 40 8	1
6	TT-194859-24252	Vent Valve	1
7	TT-194859-24262	Cap, Vent Valve	1
8	TT-194859-24270	Body, Vent Valve	1
9	TT-192162-24291	Cap, Oil	1
10	TT-22351-080020	Pin, 8 x 20	2
11	TT-23491-140002	Plug, 14	1
12	TT-24311-000160	Packing, P 16	1
13	TT-24311-000180	Packing, P 18	1
14	TT-192162-24160	Bolt, 28 x 10 x 9	16
15	TT-24190-080001	Ball, 1/4	2

TRANSMISSION — REDUCTION ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-192162-25460	Reduction Shaft Assembly	1
2	TT-192162-25420	Sprocket, 27	1
3	TT-192162-25480	Shaft, Reduction	1
4	TT-194855-25460	Chain, 40 x 34	1
5	TT-192162-24190	Gear, 46H, Reduction	1
6	TT-192159-31410	Bearing, 6204R, SH2	2
7	TT-22242-000260	Ring, 26	1

TRANSMISSION — RANGE SHIFT ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-192162-27111	Arm, Shift	1
2	TT-192162-27680	Plate	1
3	TT-192162-28300	Block, Shift	1
4	TT-194855-52111	Switch	1
5	TT-22242-000140	Ring, 14	1
6	TT-24311-000125	Packing, P 12.5	2
7	TT-26476-080202	Tapping Screw, 8 x 20	1

TRANSMISSION — DIFFERENTIAL GEAR ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-192162-31460	Gear, 63H, Final	1
2	TT-192162-31510	Differential, Gear Kit	1
3	TT-192162-31520	Gear (RR, Differential)	1
4	TT-194855-31550	Shaft, Differential Pinion	1
5	TT-192157-31580	Differential Side Gear, RH	1
6	TT-192162-31610	Washer, Differential Gear	2
7	TT-194525-31810	Pinion, Differential	2
8	TT-194515-31850	Washer, Differential Pinion	2
9	TT-192162-32100	Differential, Case Kit	1
10	TT-192162-32110	Case (R, Differential)	1
11	TT-192162-32120	Case (L, Differential)	1
12	TT-22117-080000	Washer, 8	10
13	TT-24101-060084	Bearing, 6008	2
14	TT-26106-080402	Bolt, 8 x 40	10
15	TT-26716-080002	Nut, 8	10
16	TT-192162-33612	Shaft, LH	1
17	TT-192162-33622	Shaft, RH	1

TRANSMISSION — DIFFERENTIAL LOCK ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-194235-27270	Seal, TC4 20 35 7	1
2	TT-192162-33100	Differential Lock Kit	1
3	TT-192162-33120	Fork, Differential Lock	1
4	TT-192162-33131	Shaft, Differential Lock	1
5	TT-194300-33160	Spring, Differential Lock	1
6	TT-194300-33200	Spacer, 20 x 32 x 3.2	2
7	TT-22242-000200	Ring, 20	1
8	TT-22351-080032	Pin, 8.0A x 32	1
9	TT-22351-080040	Pin, 8.0A x 40	1
10	TT-194854-33110	Slider, Differential Lock	1
11	TT-192162-33140	Arm, Differential Lock	1
12	TT-192162-33150	Bracket, Differential Lock	1
13	TT-22360-120000	Pin, 12	1
14	TT-22487-120200	Pin, 12 x 20	1
15	TT-26476-080202	Tapping Screw, 8 x 20	2


TRANSMISSION — BRAKE ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	TT-192162-36300	Plate Kit	1
2	TT-192162-36320	Steel Plate	6
3	TT-194555-36511	Friction Plate, 175	4
4	TT-192162-36310	Cover, Brake	2
5	TT-192162-36330	Actuator, LH	1
6	TT-192162-36340	Actuator, RH	1
7	TT-192162-36400	Cam Lever Complete, LH	1
8	TT-192162-36360	Cam Lever Shaft	1
9	TT-192162-36410	Cam Lever, Complete, RH	1
10	TT-192162-36360	Cam Lever Shaft	1
11	TT-192162-36390	Washer, 42 x 54.6 x 1	2
12	TT-22242-000250	Ring, 25	2
13	TT-22312-080160	Pin, 8 x 16	4
14	TT-24101-060064	Bearing, 6006	2
15	TT-24190-160001	Ball, 1/2	12
16	TT-24311-000210	Packing, P 21	2
17	TT-24421-304708	Seal, TC304708	2
18	TT-26476-080302	Tapping Screw, 8 x 30	20



ELECTRICAL SCHEMATIC




ELECTRICAL SYSTEM



ELECTRICAL SYSTEM


REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	16606	Bracket, Retainer Hook	1
2	629-04008	Connection Assembly	1
3	629-04001	Harness Assembly, Utility Starter	1
4	629-04060	Harness Assembly, Ground	2
5	710-04030	Screw, Self-tapping 1/4-20	2
6	710-0599	Screw, Self-tapping, 1/4-20 x 0.500	3
7	710-0703	Screw, Hex Carriage, 1/4-20 x .75	2
8	710-0788	Screw, Self-tapping, 1/4-20 x 1.000	2
9	710-1260A	Screw, 5/16-18 x .75	1
10	710-3009	Screw, #10-24 x 0.75	4
11	712-0271	Nut, Hex Sems, 1/4-20	2
12	721-3049	Cover, Protection	1
13	723-3064	Strap, Battery	1
14	725-0157	Cable, Tie 3/16 x.05 x 7.4	2
15	725-04008	Fuse, 5 Amp	1
16	725-04065	Harness, Utility Wire	1
17	725-04067	Harness, Motor Wire	1
18	725-01657A	Switch, Interlock	1
19	725-1738	Battery, 300 CCA	1
20	726-0470	Cable Tie, 19" x 8.39"	7
21	726-3046	Clip, Ratchet.250 Dia.	2
22	726-3008	Heat Shield Cable Clip	1
23	736-0329	Lock Washer, 1/4	2

ELECTRICAL OUTLET REAR



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	710-0473	Screw, Machine #10-24 x .50	2
2	712-0272	Nut, Hex #10-24	2
3	725-04009	Fuse, 15 AMP	1
4	725-04016	Switch, Power Recepticle	1
5	725-04017	Recepticle, Power 12V/15A	1
6	725-04018	Recepticle, Plug	1
7	725-04085	Terminal, #10 Ring	2

LABELS



NOTES
