




ILLUSTRATED PARTS MANUAL



TANK S

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

To The Owner

Thank You

Thank you for purchasing a Cub Cadet Zero-Turn Tractor. It was carefully engineered to provide excellent performance when properly operated and maintained.

All information in this manual is relative to the most recent product information available at the time of printing. Please be aware that this Illustrated Part's Manual may cover a range of product specifications for various models.

Components listed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and equipment without notice and without incurring obligation.

Throughout this manual, all references to *right* (RH) and *left* (LH) are observed from the operating position.

Table of Contents

Battery	12	Front Axle	16
Bumper	21	Fuel Tank	5
Choke Control	24/25	Hydro Controls	6
Consoles/Control Panels, U.S.	10	Hydro Hoses & Motors	8
Consoles/Control Panels, Aus.	11	Labels	68
Deck Assembly, 60"	28	Lift Lever	10
Deck Assembly, 72"	30	Meter, Hour	12
Deck Lift Assembly	22	Muffler	24/26
Deck Spindle Assembly, 60"	32	Pedal Controls, Drive	19
Deck Spindle Assembly, 72"	34	Pedal Controls, Brake	20
Electrical	12	PTO Knob	12
Electrical Schematic	67	ROPS	4
Engine, Kawasaki FX850V-AS00-S	36	Seat	4
Engine, Kawasaki FXT00V-BS04-R	52	Steering Controls	14
Engine Accessories, 60"	24	Steering Wheel/Steering Column	18
Engine Accessories, 72"	26	Throttle Control	24/25
Frame	3	Wheels, Front & Rear	13

Record Product Information

To ease in ordering replacement parts, please locate the model plate on the equipment and record the information in the provided area to the right. You can locate the model plate by looking beneath the seat.

MODEL NUMBER

--	--	--	--	--	--	--	--	--	--	--

SERIAL NUMBER


--	--	--	--	--	--	--	--	--	--	--

Painted Parts

When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXX-0637). Please refer to the table below for current color codes:

0637	Black
4021	Yellow (Cub Cadet)
0499	Beige (Cub Cadet)


0685	Blue (Cub Cadet)
0691	Black Jack (Cub Cadet Commercial)



Ref	Part Number	Description
1	00005765	Carriage Bolt, 3/8-16 x 1.25
2	00012152	Nylock Nut, 1/4-20
3	00012169	Washer. .344 x .688 x .063
4	00022560	Flange Counterlock Nut, 3/8-16
5	700-0599	Hex Flange Screw, 1/4-20 x .500
6	710-0641	Hex Screw, 1/4-20 x 2.25
7	711-0761	Clevis Pin, 1/2 x 2.500
8	01008225	Push Nut, .335 x .780 x .015
9	01010119	Flange Top Lock Nut, 1/2-13
10	02000673	Hair Pin, 1/2 x 1.625 x .125
11	02002655	Spacer, .510 x .750 x 1.25


Ref	Part Number	Description
12	02003074	Hitch Pin, .120 X 3.00
13	02003505	Flat Screw, 1/4-20 X .750
14	02003563	Carriage Bolt, 1/2-13 X 3.00
15	02003749	Wear Plate, 1.125 x 5.0
16	02005357	Cylinder Mount Bracket
17	603-04668	Front Axle Brakcet Assembly
18	680-00094	Index Lift Housing Assembly
19	680-00123	Frame Assembly
20	703-07098	Manifold Mount Bracket
21	710-3168	Carriage Bolt, 3/8-16 x 1.00
22	935-0199A	Rubber Bumper, .62 x .22

Seat Assembly




Ref.	Part Number	Description
1	00002528	Hex Screw, $\frac{3}{8}$ -16 x 2.00
2	912-3017	Nut, $\frac{3}{8}$ -16
3	712-0161	Nylock Nut, #10-24
4	00012158	Wsdher, .406 x .813 x .063
5	00012168	Lock Washer, .312 x .583 x .083
6	00012180	Hex Screw, $\frac{5}{16}$ -18 x 1.00
7	00013116	Hex Screw, $\frac{5}{16}$ -18 x 1.25
8	00022547	Counter Lock Nut, $\frac{5}{16}$ -18
9	00022560	Flange Counter Lock Nut, $\frac{3}{8}$ -16
10	710-0599	Hex Screw, $\frac{1}{4}$ -20 x .500
11	712-3004A	Flange Counter Lock Nut, $\frac{5}{16}$ -18
12	736-3052	Washer, .406 x 1.00 x .105
13	912-3027	Flange Top Lock Nut, 1/4-20
14	01008140P	LH Torsion Spring, .725 x 1.07 x .09
15	01009459	Shoulder Bolt, $\frac{5}{16}$ -18 x .37 x 1.50
16	02002091	Shoulder Bolt, $\frac{3}{8}$ -16 x .50 x .75
17	02002963	Bump Stop w/ Washer

Ref.	Part Number	Description
18	02002964	Flat Head Screw, #10-24 x .750
19	02003732	Lever Latch Bracket
20	02003738	Mount Latch Bracket
21	02003745	Center Adjust Stud, .375 x 1.125
22	02004228	Suspension Seat w/ Seat Belt
23	680-00087	Wide Assembly Floor Panel
24	680-00096	Seat Mount Bracket Assembly
25	680-00110	Folding ROPS Assembly
26	703-07490	Seat Support Lock Bracket
27	703-07491	Seat Link Pivot Mount Bracket
28	710-0260A	Carriage Bolt, $\frac{5}{16}$ -18 x .62
29	710-3015	Hex Screw, $\frac{1}{4}$ -20 x .75
30	712-04190	Nut
31	912-0429	Hex Lock Nut, $\frac{5}{16}$ -18
32	735-04159	Grommet, .38 x .75 x .75
33	749-04613	Link Tube
34	750-3119	Spacer, .406 x 1.00 x .38




Ref.	Part Number	Description
1	725-0157	Cable Tie
2	01000215	Hose Clamp
3	951-3124E	Fuel Cap
4	01007425	Fuel Fitting
5	02001908	Fuel Hose Assembly
6	02002253	Fuel Tank Grommet
7	02003842	Fuel Tank
8	02005013	Hex Screw, 3/8-16 x .50

Hydro Controls




Ref.	Part Number	Description
1	00006168	Washer, .438 x 1.00 x .078
2	712-04065	Nylock Nut, 3/8-16
3	725-0157	Cable Tie
4	00012529	Reel Return Line Sleeve, 1.59
5	00020628	Key, .188 x .188 x .875
6	710-3005	Hex Screw, 3/8-16 x 1.25
7	01007309	Counterlock Nut, 3/8-24
8	02000296	Grommet, .54 x .78
9	02001151	Elbow Fitting, 5/8 x 1/2
10	02001715	Hydro Adapter, 8 x 10
11	02001975	Hydro Adapter, 8 x 8
12	02002392	Hose Clamp
13	02003193P	Gear Pump, 3.0
14	02003368P	Steering Cylinder
15	02003930	Hydro Cylinder, 1.50 x 2.75
16	02004642	Elbow Fitting, 40RB-40RS
17	02004643	Elbow Fitting, 40RS-60RB
18	02004644	Elbow Fitting, 60RB-60RS
19	02004645	Elbow Fitting, 60RS-80RB
20	02004687	Fitting, 40RB-40RS
21	02004696	Dual Action Lift Hydro Valve
22	02004837	Elbow Fitting
23	02005325	Hydro Steering Valve
24	02005462	Anti-Abrasion Sleeve
25	718-04563	Hydro Manifold, 8 x 6
26	918-3132	Oil Radiator
27	727-04275	Hose Assy. (Tank-Pump)
28	727-04281	Hose Assy. (Lift Valve-Manifold)
29	727-04286	Hose Assy. (Exchanger-Tank)
30	727-04303	Steering Valve Pump Hose Assy.
31	727-04304	Lift Valve Steering Valve Hose Assy.
32	727-04305	Steering Ext. Steering Valve Hose Assy.
33	727-04306	Steering Retractor Steering Valve Hose Assy.
34	727-04307	Manifold Steering Valve Hose Assy.
35	727-04309	Cylinder Retractor Lift Valve Hose Assy.
36	727-04310	Cylinder Extension Lift Valve Hose Assy.
37	727-04311	Exchanger Manifold Hose Assy.
38	727-04317	Elbow Fitting
39	737-04260	Elbow, 1/2 x 3/8
40	756-04381	Pulley

Hydro Hose & Pump Assembly




Ref.	Part Number	Description
1	00006168	Washer, .438 x 1.00 x .078
2	00020628	Key, .188 x .188 x .875
3	00022560	Flange Counter Lock Nut, 3/8-16
4	00030261	Hydro Oil Tank Cap
5	00030276	Carriage Bolt, 3/8-16 x 1.50
6	710-3178	Carriage Bolt, 3/8-16 x .75
7	710-3034	Carriage Bolt, 3/8-16 x 1.25
8	738-0940	Oil Drain Plug, w/ Seal
9	01006949	Motor Back-Up Plate
10	01007309	Counter Lock Nut, 3/8-24
11	01007791	Socket Cap Screw, 1/2-13 x 3.50
12	01009775	Hydro Wheel Motor Spacer
13	02000401	Extension Spring, .74 x 2.7 x .075
14	02000841	Socket Cap Screw, 1/4-20 x .750
15	02001160	Elbow Fitting, 9/16 x 1/2
16	02001169	Pump Fan Shroud
17	02001179	Pump Motor Hose Assembly
18	02001715	Hydro Adapter, 8 x 10
19	02001872P	Pilot Hydro Hose Assembly
20	02002003	Elbow Hydro Adapter, 8 x 8
21	02002257	Hydro Filter
22	02002392	Hose Clamp
23	02003381P	RH Hydro Pump
24	02005160	Fitting, 3/4 x 1/2
25	680-00056	Hydro Tank Assembly
26	680-00059	Wide Motor Frame
27	703-07750	Brake Cable Bracket
28	710-3005	Hex Screw, 3/8-16 x 1.25
29	712-3083	Hex Lock Nut, 1/2-13
30	918-04710	LH Hydro Pump
31	918-04717	LH Hydro Motor w/ Brake
32	918-04718	RH Hydro Motor w/ Brake
33	727-04284	Hose Assy. (Wheel Pump-Manifold)
34	756-04381	Pulley

Control Group, U.S.




Ref.	Part Number	Description
1	00012152	Nylock Nut, ¼-20
2	00014608	Nylock Nut, #10-32
3	00022560	Flange Counter Lock Nut, ¾-16
4	00030906	Machine Screw, #10-32 x .625
5	710-3178	Carriage Bolt, ¾-16 x .75
6	710-0599	Hex Flange Screw, ¼-20 x .500
7	936-0160	Washer, .536 x .930 x .050
8	01002511	Jam Nut, ¾-16
9	01004546	Spacer, .500 x .750 x .700
10	01008225	Push Nut, .335 x .780 x .015
11	01008531P	Flange Screw, #10-32 x .500
12	01009362	Screw, ¼-20 x .750
13	01009369	Lever Knob, 3/8-16
14	02000362	Debris/Storage Bag
15	02000925	Hex Screw, ¼-20 x 2.75
16	02002785	LH Lower Panel

Ref.	Part Number	Description
17	02002786	RH Lower Panel
18	02002874	Cup Holder
19	02002970	RH Control Panel
20	02003603	Shoulder Bolt, ¾-16 x .50 x 1.0
21	02003725	Washer, .300 x .550 x .047
22	02004136	LH Control Assembly
23	02004138	Lift Valve Lever Bracket
24	02004142	LH Cover Control Panel
25	02004622	Spirol Pin, ¾ x 1.0
26	703-07603	RH Cover Control Panel
27	711-04214	Pin, .25 x .9375
28	711-1614	Valve Link
29	712-04199	Rivet Nut, ¼-20
30	714-0127	Cotter Pin, ¼ x .75
31	936-0253	Bell Washer, .525 x 1.00 x .050




Ref.	Part Number	Description
1	00012152	Nylock Nut, ¼-20
2	00014608	Nylock Nut, #10-32
3	00022560	Flange Counter Lock Nut, ⅜-16
4	00030906	Machine Screw, #10-32 x .625
5	710-3178	Carriage Bolt, ⅜-16 x .75
6	710-3256	Screw, ¼-20 x .500
7	710-0599	Hex Flange Screw, ¼-20 x .500
8	936-0160	Washer, .536 x .930 x .050
9	01002511	Jam Nut, ⅜-16
10	01004546	Spacer, .500 x .750 x .700
11	01008225	Push Nut, .335 x .780 x .015
12	01008531P	Flange Screw, #10-32 x .500
13	01009369	Lever Knob, ⅜-16
14	02000362	Debris/Storage Bag
15	02000925	Hex Screw, ¼-20 x 2.75
16	02002785	LH Lower Panel
17	02002786	RH Lower Panel
18	02002874	Cup Holder

Ref.	Part Number	Description
19	02003603	Shoulder Bolt, ⅜-16 x .50 x 1.0
20	02003725	Washer, .300 x .550 x .047
21	02004138	Lift Valve Lever Bracket
22	02004142	LH Cover Control Panel
23	02004622	Spirol Pin, ⅜ x 1.0
24	680-00119	LH Control Panel Assembly
25	680-00121	RH Bracket Control Panel Assembly
26	703-07328	Panel Plate
27	703-07330	Lower Side Panel
28	703-07603	RH Cover Control Panel
29	710-3168	Carriage Bolt, ⅜-16 x 1.00
30	711-04214	Pin, .25 x .9375
31	711-1614	Valve Link
32	712-04065	Flange Lock Nut, ⅜-16
33	712-04199	Rivet Nut, ¼-20
34	714-0127	Cotter Pin, ⅛ x .75
35	936-0253	Bell Washer, .525 x 1.00 x .050




Ref.	Part Number	Description
1	925-1707D	Battery
2	725-0157	Cable Tie
3	00013258	Boot Terminal, 1.00 x 2.50
4	00022560	Flange Counter Lock, 3/8-16
5	00032097	Ignition Nut w/ Cap, 5/8-32
6	710-3178	Carriage Bolt, 3/8-16 x .75
7	01002111	PTO Switch
8	01002251	Relay
9	912-3027	Flange Top Lock Nut, 1/4-20
10	01003581P	Ignition Switch
11	01004040	Grommet, .75
12	01009623	Batter Cable
13	01009905	PTO Switch Bracket
14	02000024P	Switch

Ref.	Part Number	Description
15	02002059	Battery Cable
16	02003038	Electric CDT Clip, 3/8
17	02003775	Electric CDT Clip, 5/8
18	02003984	Flange Nut, M8-1.25
19	02004355	Battery Bracket
20	710-3015	Hex Screw, 1/4-20 x .75
21	723-3064	Battery Strap
22	925-04893	Hour Meter
NS	01001811	Hour Meter Harness
NS	02002822	Wiring Harness
NS	02002824	Wiring Harness
NS	02004924	Fan Wiring Adapter
NS	02004925	Grammer Seat Adapter Harness
NS	629-04164	Lock Switch Wire Harness Assembly



Ref.	Part Number	Description
1	00012187	Lug Nut, ½-20
2	736-3014	Washer, .781 x 2.00 x .105
3	01009288	Hex Screw, ½-20 x 9.50
4	02002299	Nut, ½-20, Lock
5	02002668	Wheel Assembly, 24 x 12.00-12
6	02003355	Spacer, .51 x .75 x 7.49
7	02003396	Front Wheel Assembly, 16 x 6.50-8


Control Assembly



Ref.	Part Number	Description
1	00012158	Washer, .406 x .813 x .063
2	00013116	Hex Screw, 5/16-18 x 1.25
3	00013416	Hex Screw, 1/4-20 x 1.00
4	00022560	Flange Counter Lock Nut, 3/8-16
5	00023041	Counter Lock Nut, 1/4-20
6	00031602	Carriage Bolt, 1/4-20 x 1.00
7	00081551	Spacer, .407 x .625 x .375
8	01000101	Washer, .550 x 1.25 x .068
9	01000627	Hex Screw, 5/16-24 x .750
10	710-0599	Hex Flange Screw, 1/4-20 x .500
11	712-3004A	Flange Counter Lock Nut, 5/16-18
12	936-0133	Washer, .411 x 1.25 x 1.00
13	936-0425	Bell Washer, .325 x .930 x .045
14	01001161	Flange Screw, 5/16-18 x .625
15	01001366	Hex Screw, 3/8-16 x 2.25
16	01008410P	Rod End, 5/16
17	01008801	Nylon Rivet, 1/4 x .625
18	02003163	Flange Bearing, .752 x 1.25 x .305
19	02003170	Spacer, .344 x .500 x .375
20	02003327	RH Pump Control Bracket Assy.
21	02003330	LH Pump Control Bracket Assy.
22	02003377	Ball Bearing, .25 x .625 x .196

Ref.	Part Number	Description
23	02003379	Shoulder Spacer, .251 x 1.00 x .06
24	02003384	Rod Support End Bracket
25	02005054	Spacer, .381 x .750 x .040
26	02005055	Spacer, .381 x .75 x .150
27	02005056	Spacer, .381 x .750 x .312
28	02005057	Spacer, .256 x .500 x .330
29	02005290	LH Speed Control Cam Assembly
30	02005291	RH Speed Control Cam Assembly
31	02005292	LH Steering Pivot Assembly
32	02005293	RH Steering Pivot Assembly
33	02005463	Control Link Plate
34	02005468	Front Steering Pivot Assembly
35	02005482	Steering Pivot Mount Plate
36	02005483	Spacer, .385 x .750 x 1.28
37	02005566	Counter Lock Nut, 3/8-16
38	603-04618	LH Control Rod Assembly
39	603-04619	RH Control Rod Assembly
40	710-0514	Hex Screw, 3/8-16 x 1.00
41	710-05142	Screw, 3/8-16 x .875
42	710-05143	Screw, 3/8-16 x 1.25
43	710-0520	Hex Screw, 3/8-16 x 1.50
44	936-0463	Flat Washer, .25 x .630 x .0515

Front Axle Assembly




Front Axle Assembly

Ref.	Part Number	Description
1	00002766	Washer, .655 x 1.5 x .055
2	00022560	Flange Counter Lock Nut, 3/8-16
3	00060078	Grease Fitting, 1/4-28
4	710-0599	Hex Flange Screw, 1/4-20 x .500
5	01001161	Flange Screw, 5/16-18 x .625
6	01002620	Bearing Cup, L44610
7	01002621	Cone Bearing, L44643
8	01002622	Seal, 14858
9	01002624	Seal Ring
10	712-0359	Slot Nut, 3/4-16
11	01006294	Bell Washer, 1.25 x 2.50 x .180
12	01008404P	Spacer, .635 x .880 x .312
13	01009997	Self-Lock External Retainer
14	02000588	Washer, 1.00 x 2.00 x .075
15	02000589	Spacer, 1.00 x 1.25 x 3.47
16	02003187	Tie Rod Assembly, 1/2-20 x 28
17	02003217	Tie Rod Assembly, 5/8-18 x 14
18	02003220	Hex Screw, 5/8-11 x 4.00
19	02003222	Hex Screw, 5/8-11 x 1.75
20	02003357	Shoulder Bolt, .872 x 1.030 x 2.88


Ref.	Part Number	Description
21	712-3016	Hex Lock Nut, 5/8-11
22	02003804	Hex Screw, 1-14 x 5.5
23	02005073	Hex Screw, 3/8-16 x 1.50
24	714-0162	Cotter Pin, 5/32 x 1.25
25	717-04729	Yoke Steering Gear
26	719-04517	Axle
27	603-04645	Yoke Assembly
28	731-07348	Axle Grease Cap
29	680-00072	Axle Bumper Assembly
30	935-0199A	Rubber Bumper, .62 x .22
31	680-00074	LH Steering Gear Assembly
32	680-00075	RH Steering Gear Assembly
33	703-07259	RH Gear Cover Plate
34	936-0119	Lock Washer, 5/16
35	750-05335	Spacer, .635 x .875 x 1.031
36	703-07471	LH Gear Cover Plate
37	710-05000	Hex Screw, 5/8-11 x 2.25
38	710-05066	Screw, 3/8-16 x 2.25
39	710-05068	Adjustable Skid Shoe
40	712-04191	Flange Top Lock Nut, 1.0-14

Steering Column



Ref.	Part Number	Description
1	00011450	Shoulder Bolt, $\frac{3}{8}$ -16 x .495 x .500
2	936-0329	Lock Washer, .250 x .489 x .110
3	912-3057	Nut, $\frac{5}{16}$ -24
4	00022560	Flange Counter Lock Nut, $\frac{3}{8}$ -16
5	00070022	Washer, .533 x 1.25 x .058
6	710-3256	Screw, $\frac{1}{4}$ -20 x .500
7	01000517	Carriage Bolt, $\frac{1}{2}$ -13 x 1.25
8	936-0425	Bell Washer, .325 x .930 x .045
9	01003994	Retainer Clip
10	01008539P	U-Nut, $\frac{1}{4}$ -20
11	02003163	Flange Bearing, .752 x 1.25 x .305
12	02004002	Flange Slv. Bearing, .630 x .875 x .75
13	02004107	Box Steering Cover
14	02004109	Steering Shaft
15	02004110	Valve Steering Shaft
16	02004308	Steering Valve Spline Hub
17	02004622	Spirol Pin, $\frac{3}{16}$ x 1.0


Ref.	Part Number	Description
18	02005058	Steering Adjust/Lock Lever
19	02005378	Steering Box Housing Assembly
20	02005396	Wear Swing Plate
21	02005495	Steering Column Cover
22	02005512	Washer, .531 x 1.250 x .100
23	680-00082	Base Column Assembly
24	680-00093	Upper Steering Column Assembly
25	703-07470	Upper Steering Column Cover
26	710-3015	Hex Screw, $\frac{1}{4}$ -20 x .75
27	710-3140	Hex Screw, M6-1.00 x 14
28	710-3168	Carriage Bolt, $\frac{3}{8}$ -16 x 1.00
29	914-0470	Cotter Pin, $\frac{1}{8}$ x 1.25
30	917-1019	Splined Bore Miter Gear
31	731-06459	Steering Wheel Cover
32	731-3209	Steering Wheel
33	736-0173	Flat Washer, .28 x .74 x .063
34	736-0188	Flat Washer, .76 x 1.49 x .06



Ref.	Part Number	Description
1	00009812	Washer, .344 x .688 x .063
2	00011861	Hex Screw, 3/8-16 x 2.50
3	00012152	Nut, 1/4-20
4	00012165	Nut, 5/16-18
5	00022560	Flange Counter Lock Nut, 3/8-16
6	00023041	Counter Lock Nut, 1/4-20
7	00034167	Hex Screw, 3/8-16 x 5.00
8	01000489	Bell Washer, .265 x .75 x .062
9	712-3004A	Flange Counter Lock Nut, 5/16-18
10	01000799	Spacer, .315 x .500 x .520
11	01000913	Hex Screw, 1/4-20 x 1.25
12	936-0425	Bell Washer, .325 x .930 x .045
13	01001160	Carriage Bolt, 1/4-20 x .620
14	01006350	Shaft Collar, .625 x 1.00 x .438
15	01007122P	Hex Screw, 5/16-18 x 2.50
16	01007984	Spacer, .315 x .500 x .699
17	02000487	Flange Bearing
18	02002994	Screw, 5/16-18 x 1.25
19	02003377	Ball Bearing, .25 x .625 x .196


Ref.	Part Number	Description
20	02005057	Spacer, .256 x .500 x .330
21	02005464	Speed Control Link Assembly
22	02005547	Bracket
23	02005549	Pedal Control Link
24	02005560	Washer, .51 x .88 x .06
25	02005568	Flange Bearing, .502 x .875 x .180
26	02005570	Shoulder Bolt, 3/8-16 x .50 x .25
27	02005628	Lockout Hub Assembly
28	680-00103	Pedal Bellcrank Assembly
29	680-00132	Forward Pedal Assembly
30	680-00133	Reverse Pedal Assembly
31	680-00135	Control Arm Assembly
32	703-07763	Forward Pedal Grip
33	703-07764	Reverse Pedal Grip
34	710-0262	Carriage Bolt, 5/16-18 x 1.50
35	710-05070	Screw, 1/4-20 x .5
36	710-3105	Carriage Bolt, 5/16-18 x .875
37	732-04721	Torsion Spring, .66 x .56

Brake Pedal Assembly



Ref.	Part Number	Description
1	00006129	Hex Screw, $\frac{5}{16}$ -18 x 1.75
2	00022547	Counter Lock Nut, $\frac{5}{16}$ -18
3	00022560	Flange Counter Lock Nut, $\frac{3}{8}$ -16
4	00061053	Washer, .416 x .875 x .046
5	01004127	Hex Screw, $\frac{3}{8}$ -16 x 3.00
6	02003436	Spacer, .380 x .500 x .667
7	02003666	Hex Screw, $\frac{3}{8}$ -16 x 3.50
8	02005568	Flange Bearing, .502 x .875 x .180
9	02005591	Torsion Spring
10	02005592	Torsion Spring
11	02005606P	LH Brake Cable
12	02005607P	RH Brake Cable
13	02005612	Brake Carrier Assembly
14	02005703	Brake Roller Guide Bracket
15	02005714	Brake Control Link
16	02005718	Lockout Plate


Ref.	Part Number	Description
17	603-04639	Brake Pedal Assembly
18	703-06762	Park Engagement Bracket
19	703-06766	Brake Hook Bracket
20	703-06975	Brake Switch Mount Bracket
21	703-07762	Brake Pedal Grip
22	710-05070	Screw, $\frac{1}{4}$ -20 x .5
23	711-05058	Pin, .500 x .804
24	916-0104	E-Ring
25	736-04407	Flat Washer, .531 x 1.5 x .08
26	736-04418	Washer, .39 x .62 x .03
27	738-04360	Shoulder Screw, $\frac{5}{16}$ -18 x .375 x 2.00
28	741-04371	Bearing, .375 x .875
29	750-05071	Spacer, .319 x .375 x 1.056
30	750-05072	Spacer, .384 x .500 x 1.000
31	750-05178	Spacer, .38 x .5 x .955
32	750-05180	Spacer, .385 x .625 x .458



Ref.	Part Number	Description
1	00010958	Washer, ½
2	00011447	Capscrew, ¼-20 x 1.00
3	00012154	Washer, ¼
4	00022560	Flange Lock Nut, ⅜-16
5	00030046	HHCS, ½-13, 3.00
6	00031081	Clamp, ½
7	00031602	Carriage Bolt, ¼-20 x 1.00
8	710-0751	Hex Screw, ¼-20 x .620
9	01001160	Carriage Screw, ¼-20 x .62
10	912-3027	Nut, ¼-20, Hex Flange Lock
11	01004040	Grommet, .75 ID


Ref.	Part Number	Description
12	01008539P	U-Nut, ¼-20
13	01009362	Capscrew, ¼-20 x .750
14	680-00079	Bumper Assembly
15	02004120	Hitch Bracket
16	02004473	Heat Exchanger Assembly
17	02004480	Heat Exchanger Screen
18	02004481	Fan
19	703-07361	Cooler Mounting Bracket, LH
20	703-07360	Cooler Mounting Bracket, RH
21	710-3168	Carriage Bolt, ⅜-16 x 1.00
22	712-3083	Hex Nut, ½-13, Insert Lock

Deck Lift Assembly




Ref.	Part Number	Description
1	00002766	Washer, .655 x 1.5 x .055
2	00011459	Washer, .563 x 1.38 x .109
3	00012152	Nut, ¼-20
4	00022560	Flg. Cnter. Lock Nut, ⅜-16 (60" Deck)
—	912-0431	Flange Lock Nut, ⅜-16 (72" Deck)
5	00060078	Grease Fitting, ¼-28
6	936-0133	Washer, .411 x 1.25 x 1.00
7	01001744	Eye Bolt, ⅝-16 x 2.63
8	01001746	Eye Bolt Link, ⅝
9	01001855	Lift Ferrule
10	01001857	Lift Connecting Rod
11	01001930	Hex Flange Bearing
12	01003123	Spacer, .812 x 1.47 x .218
13	01003535	Shoulder Bolt, ⅜-16 x .625 x .437
14	01003993	Lynch Pin, ⅜ x 1.25
15	01003994	Retainer Clip
16	01004003	Washer
17	01004127	Hex Screw, ⅜-16 x 3.00
18	01006408	Washer, 1.25 x 2.25 x .075
19	01007527	Spacer, .630 x 1.06 x .440
20	01007680	Assembly Bellcrank
21	01007962	Screw, ⅝-18 x 2.0
22	01008453	Deck Lift Link Rod (60" Deck)
—	01007544	Deck Lift Link Rod (72" Deck)
23	01008801	Rivet, ¼ x .625
24	01010119	Flange Top Lock Nut, ½-13
25	02000293	RH Rod End, ⅝

Ref.	Part Number	Description
26	02000561	Deck Lift Link
27	02002384	Flange Bearing
28	02002708P	LH Lift Brace Bearing
29	02002709P	RH Lift Brace Bearing
30	02003043	Spacer, .375 x .625 x 2.20
31	02003257	Front Frame Support Assembly
32	02003505	Flat Head Screw, ¼-20 x .750
33	02003749	Wear Plate, 1.125 x 5.0
34	02003942	Lock Bracket
35	02003944	Spacer, .510 x .750 x 2.38
36	02003945	Spacer, .765 x 1.00 x 1.70
37	02004280	Lift Ferrule, 1.938
38	02004518	Hex Screw, ½-13 x 3.5
39	02004692	Rod, ⅝-18 x 5.5 (60" Deck)
—	02004691	Rod, ⅝-18 x 3.5 (72" Deck)
40	02005103	Tube, 3.0 x 1.5
41	02005350	Hydro Assist Bellcrank
42	02005352	Lift Bellcrank Assembly
43	02005354	Loft Offset Yoke Bracket
44	710-04813	Hex Screw, ⅝-11 x 3.00
45	711-05072	Front Lift Link Mount Shaft
46	711-05216	Deck Lift Shaft
47	712-0429	Hex Lock Nut, ⅝-18
48	912-3015	Jam Nut, ⅝-11
49	712-3056	Jam Nut, ⅝-18
50	736-0188	Flat Washer, .76 x 1.49 x .06




Ref.	Part Number	Description
1	737-04202	Pipe Plug, $\frac{3}{8}$
2	912-3019	Nut, $\frac{7}{16}$ -14
3	00014608	Nut, #10-32
4	00021975	Idler
5	00022560	Flange Counter Lock Nut, $\frac{3}{8}$ -16
6	00030906	Machine Screw, #10-32 x .625
7	00031081	Clamp, $\frac{1}{2}$
8	00060056	Nut, 8-32
9	00060078	Grease Fitting, $\frac{1}{4}$ -28
10	01000199	Extension Spring, 1.00 x 5.00 x .125
11	01000302	Shoulder Bolt, .625 x 1.95
12	01000308	Sleeve Bearing, .628 x .753 x .625
13	710-0560	Carriage Bolt, $\frac{3}{8}$ -18 x 1.75
14	710-3217	Machine Screw, #8-32 x .356
15	736-3052	Washer, .406 x 1.00 x .105
16	726-3008	Clip, .470 x 1.80
17	01001395	Hex Screw, $\frac{7}{16}$ -20 x 2.50
18	710-0216	Hex Screw, $\frac{3}{8}$ -16 x .750
19	01003269	Washer, .438 x 1.75 x .250
20	01003283	Oil Drain Hose
21	736-04131	Washer, .438 x 1.745 x .250
22	01005856	Key, .250 x .250 x 3.00
23	02002825	Brake Clutch
24	02003200P	Kawasaki FX850V-AS00-S Engine
25	02003201	Muffler
26	02003422	Choke Cable
27	02003543	Clutch Return Assembly
28	02004075	Idler Arm Assembly
29	910-0224	Hex Washer Screw, #10-16 x 0.500
30	710-0520	Hex Screw, $\frac{3}{8}$ -16 x 1.50
31	731-04914	Throttle Control Knob
32	936-0169	Lock Washer, $\frac{3}{8}$
33	936-0171	Lock Washer, $\frac{7}{16}$
34	737-04138	Fitting, 1.0
35	746-04534	Throttle Cable
36	751-11235	Exhaust Pipe
37	954-04233	Belt
38	756-04382	Drive Pulley

Engine Accessories, 72" Deck




Ref.	Part Number	Description
1	737-04202	Pipe Plug, 3/8
2	912-3019	Nut, 7/16-14
3	00010980	Hex Screw, 3/8-16 x 1.50
4	936-0169	Lock Washer, .375 x .680 x .100
5	00014608	Nut, #10-32
6	00021975	Idler
7	00022560	Flange Counter Lock Nut, 3/8-16
8	00030906	Machine Screw, #10-32 x .625
9	00031081	Clamp, 1/2
10	00060056	Nut, #8-32
11	00060078	Grease Fitting, 1/4-28
12	01000302	Shoulder Bolt, .625 x 1.95
13	01000308	Sleeve Bearing, .628 x .753 x .625
14	710-0560	Carriage Bolt, 3/8-18 x 1.75
15	936-0171	Lock Washer, .490 x .776 x .114
16	710-3217	Machine Screw, #8-32 x .356
17	736-3052	Washer, .406 x 1.00 x .105
18	726-3008	Clip, .470 x 1.80
19	01001395	Hex Screw, 7/16-20 x 2.50
20	710-0216	Hex Screw, 3/8-16 x .750
21	01003269	Washer, .438 x 1.75 x .250
22	01003283	Oil Drain Hose
23	736-04131	Washer, .438 x 1.745 x .250
24	01005856	Key, .250 x .250 x 3.00
25	01009635	Extension Spring, .98 x 5.0 x .140
26	02002825	Brake Clutch
27	02003521P	Kawasaki FXT00V-BS04-R Engine
28	02003522	Muffler
29	02003543	Clutch Return Assembly
30	02003743	Choke Cable
31	02004075	Idler Arm Assembly
32	910-0224	Hex Washer Screw, #10-16 x 0.500
33	731-04914	Throttle Control Knob
34	737-04138	Fitting, 1.0
35	946-04571	Throttle Cable
36	751-11236	Exhaust Pipe
37	954-04233	Belt
38	756-04382	Drive Pulley

60" Deck




Ref.	Part Number	Description
1	936-0169	Lock Washer, $\frac{3}{8}$
2	00012158	Washer, $\frac{3}{8}$
3	00022560	Flange Lock Hex Nut, $\frac{3}{8}$ -16
4	710-3178	Carriage Bolt, $\frac{3}{8}$ -16 x .75
5	750-3193	Wheel Spacer
6	01001169	Grass Catcher Roller
7	01001745	Pin, $\frac{5}{8}$ Dia. x 1.2
8	710-3034	Carriage Bolt, $\frac{3}{8}$ -16 x 1
9	710-0944	Hex Cap Screw, $\frac{3}{8}$ -16 x 4.50
10	01003253	Torsion Spring, 0.4 x 2.16
11	747-3384	Chute Deflector Rod
12	01004304	Hex Washer Screw, $\frac{3}{8}$ -16, .5
13	01005869P	T-Handle Latch Draw
14	01006693	Chute Deflector
15	01006748	Chute Deflector Bracket
16	01008049	Carriage Bolt, $\frac{3}{8}$ -16 x 4.00
17	01008225	Push Retainer
18	01008644	Finger Guard
19	01008790	Grass Catcher Roller Bracket
20	02000109	Pillow Block
21	02002800	J-Hook w/ Threaded Roller
22	02005195	Chute Baffle
23	02005200	Right Hand Front Adjustment Skirt
24	02005201	Left Hand Front Adjustment Skirt
25	02005694	Baffle, 60" Adjustment
26	634-3159	Complete Wheel, 5.00 Dia.
27	680-00117	60" Deck Assembly
28	703-06871	Deck Belt Cover
29	710-3168	Carriage Bolt, $\frac{3}{8}$ -16 x 1.00
30	711-05159	Ball Wheel Mounting Shaft
31	712-04065	Lock Nut, Nylon Insert, $\frac{3}{8}$ -16
32	912-0641	Hex Nut, M16-1.5
33	712-3083	Lock Nut, Nylon Insert, $\frac{1}{2}$ -13
34	921-04041	Water Nozzle Adaptor
35	728-04033	Pop Rivet, $\frac{3}{16}$
36	731-3005	Front Roller
37	936-0760	Lock Washer, 17 x 23.8 x 1.95
38	737-04003D	Deck Water Nozzle

72" Deck




Ref.	Part Number	Description
1	00011444	Hex Cap Screw, 3/8-16, 1.25
2	00011925	Hex Cap Screw, 3/8-16, 4.00
3	936-0169	Lock Washer, 3/8
4	00012158	Flat Washer, 3/8
5	00022560	Flange Lock Hex Nut, 3/8-16
6	710-3178	Carriage Bolt, 3/8-16 x .75
7	750-3193	Wheel Spacer
8	01001169	Grass Catcher Roller
9	01001745	Pin, 5/8 Dia. x 1.2
10	710-3034	Carriage Screw, 3/8-16 x 1.25
11	710-0944	Hex Cap Screw, 3/8-16 x 4.50
12	01003253	Torsion Spring, 0.4 x 2.16
13	01004304	Hex Washer Screw, 3/8-16, .5
14	01004707	Deck Roller Mount Bracket
15	01005869P	T-Handle Latch Draw
16	01008049	Carriage Bolt, 3/8-16 x 4.00
17	01008225	Push Retainer
18	01008526	Finger Guard
19	01009102	Pin, .375 x 14.06
20	01009705P	Chute Deflector
21	02000109	Pillow Block, Steel
22	02002800	J-Hook w/ Threaded Roller
23	02004868	Right Hand Front Adjustment Skirt
24	02004869	Left Hand Front Adjustment Skirt
25	02004874	Chute Deflector Bracket
26	02005195	Chute Baffle
27	02005696	Baffle, 72" Adjustment
28	634-3159	Complete Wheel, 5.00 Dia.
29	680-00112	72" Deck Assembly
30	703-07635	Deck Belt Cover
31	710-3168	Carriage Bolt, 3/8-16 x 1
32	711-05159	Ball Wheel Mounting Shaft
33	712-04065	Flange Lock Hex Nut, 3/8-16
34	912-0641	Hex Nut, M16-1.5
35	712-3083	Lock Nut, Nylon Insert, 1/2-13
36	921-04041	Water Nozzle Adaptor
37	728-04033	Pop Rivet, 3/16
38	731-3005	Front Roller
39	936-0760	Lock Washer, 17 x 23.8 x 1.95
40	737-04003D	Deck Water Nozzle

60" Spindle Assembly



Ref.	Part Number	Description
1	00002528	Hex Screw, $\frac{3}{8}$ -16 x 2.00
2	00008495	Hex Screw, $\frac{3}{8}$ -16 x 1.75
3	00011925	Hex Screw, $\frac{3}{8}$ -16 x 4.00
4	00012158	Washer, .406 x .813 x .063
5	00014270	Carriage Bolt, $\frac{3}{8}$ -16 x 2.00
6	00030276	Carriage Bolt, $\frac{3}{8}$ -16 x 1.50
7	00060078	Grease Fitting, $\frac{1}{4}$ -28
8	00068079	V-Belt
9	01000308	Sleeve Bearing, .628 x .753 x .625
10	736-3014	Washer, .781 x 2.00 x .105
11	736-3052	Washer, .406 x 1.00 x .105
12	710-3034	Carriage Bolt, $\frac{3}{8}$ -16 x 1.25
13	01003123	Spacer, .812 x 1.47 x .218
14	01003245	Spacer, .390 x .635 x 2.75
15	01003532AP	Spindle Assembly
16	01004415	Spacer, .760 x 2.00 x .925
17	01004478	Spindle Support Plate
18	01005213	Hex Screw, $\frac{3}{4}$ -16 x 7.00
19	01005376	V-Belt
20	01005388	Hex Screw, $\frac{3}{4}$ -16 x 9.00
21	01005616	Pulley
22	02003712	Extension Spring, .94x 7.57 x .14
23	02003740	Flat Grip, 1.0 x 3.2 x .25
24	02004447	Idler Pulley
25	02005019	Hi-Lift Blade, 21.0
26	02005077	Idler Pulley
27	02005079	Idler Pulley
28	02005097	Pulley
29	02005509	Double Idler Weldment w/ Handle
30	703-07010	Deck Idler Arm
31	710-0262	Carriage Bolt, $\frac{5}{16}$ -18 x 1.50
32	738-04376	Shoulder Spacer, .854 x .280
33	712-04063	Flange Lock Nut, $\frac{5}{16}$ -18
34	712-04065	Flange Lock Nut, $\frac{3}{8}$ -16
35	712-3078	Flange Lock Nut, $\frac{3}{4}$ -16
36	936-0227	Flat Washer, .390 x 1.500 x .134
37	736-3040	Flat Washer, .406 x 1.92 x .060

72" Spindle Assembly




72" Spindle Assembly

Ref.	Part Number	Description
1	00002528	Hex Screw, 3/8-16 x 2.00
2	00008495	Hex Screw, 3/8-16 x 1.75
3	00011861	Hex Screw, 3/8-16 x 2.50
4	00011925	Hex Screw, 3/8-16 x 4.00
5	00012158	Washer, .406 x .813 x .063
6	00014270	Carriage Bolt, 3/8-16 x 2.00
7	00022560	Flange Counter Lock Nut, 3/8-16
8	00030276	Carriage Bolt, 3/8-16 x 1.50
9	00060078	Grease Fitting, 1/4-28
10	01000308	Sleeve Bearing, .628 x .753 x .625
11	736-3014	Washer, .781 x 2.00 x .105
12	736-3052	Washer, .406 x 1.00 x .105
13	01002751	Spacer, .390 x .630 x 1.75
14	914-0104	Hair Pin, 1/8 x 1.125 x .072
15	01003123	Spacer, .812 x 1.47 x .218
16	01003245	Spacer, .390 x .635 x 2.75
17	01004478	Spindle Support Plate
18	01007499	Pulley
19	01007937	V-Belt
20	01008222	Idler Tension Bracket
21	01008247	Tension Handle Weldment
22	01008270	Idler Tension Handle Grip
23	01008542	Hex Screw, 3/4-16 x 7.50

Ref.	Part Number	Description
24	01008543	Hex Screw, 3/4-16 x 9.50
25	02000454	Spacer, .760 x 2.00 x 1.28
26	02000568	Blade, 25"
27	02000920P	Spindle Assembly
28	02001574	Tensioner Spring Rod
29	02002712	Idler Double Weldment
30	02003712	Extension Spring, .94 x 7.57 x .14
31	02004063	Idler Spring Bracket Adapter Plate
32	02004069	Extension Spring, .94 x 7.74 x .14
33	02004377	V-Belt
34	02004379	Pulley
35	02004447	Idler Pulley
36	02005077	Idler Pulley
37	02005079	Idler Pulley
38	703-07010	Deck Idler Arm
39	710-04829	Flange Bolt, 3/8-16 x 1.5
40	710-3168	Carriage Bolt, 3/8-16 x 1.00
41	712-04065	Flange Lock Nut, 3/8-16
42	712-3078	Flange Lock Nut, 3/4-16
43	936-0227	Flat Washer, .390 x 1.500 x .134
44	736-3040	Flat Washer, .406 x 1.92 x .060
45	738-04376	Shoulder Spacer, .854 x .280
46	750-05184	Spacer, .760 x 2.000 x .790


Kawasaki FX850V-AS00-S Cylinder/Crankcase



Kawasaki FX850V-AS00-S Cylinder/Crankcase


Ref.	Part Number	Description
11004	KM-11004-7025	Head Gasket
11008	KM-11008-7036	Complete Cylinder Head, #1
11008A	KM-11008-7037	Complete Cylinder Head, #2
11022	KM-11022-6007	Rocker Case, #1
11022A	KM-11022-7016	Rocker Case, #2
11061	KM-11061-7080	Rocker Case Gasket
11061A	KM-11061-7081	Breather Gasket
13272	KM-13272-7004	Breather Plate
14091	KM-14091-7060	Breather Cover
16126	KM-16126-7020	Breather Valve
32154	KM-32154-7019	Pipe
49015	KM-49015-6284	Crankcase Cover
49015A	KM-49015-6285	Crankcase Cover
49120	KM-49120-6173	Complete Crankcase
59071	KM-59071-2079	Joint
92043	KM-92043-7024	Pin
92049	KM-92049-7005	Oil Seal, 8 x 14 x 5
92049A	KM-92049-7020	Oil Seal, 7 x 15 x 13
92049B	KM-92049-7024	Oil Seal, 40 x 54 x 9
92049C	KM-92049-7026	Oil Seal, 40 x 62 x 8
92066	KM-92066-7002	Plug
92153	KM-92153-7043	Bolt, 6 x 12
130	KM-130AA0650	Flanged Bolt, 6 x 50
130A	KM-130CA1050	Flanged Bolt, 10 x 50
130B	KM-130CA1060	Flanged Bolt, 10 x 60
172	KM-172BA0818	Stud Bolt, 8 x 18
214	KM-214AA0408	Pan Screw, 4 x 8
601	KM-601A6308	Ball Bearing
670	KM-670B2011	O-Ring, 11mm

Kawasaki FX850V-AS00-S Piston/Crankshaft




Ref.	Part Number	Description
13001	KM-13001-7025	Engine Piston
13002	KM-13002-7005	Piston Pin
13008	KM-13008-6069	Piston Ring Set
13031	KM-13031-7079	Complete Crankshaft
13251	KM-13251-7019	Connecting Rod Assembly
92033	KM-92033-7013	Snap Ring
92153	KM-92153-2054	Bolt, 7 x 35.2

Kawasaki FX850V-AS00-S Lubrication Equipment



Ref.	Part Number	Description
13107	KM-13107-7009	Shaft
13272	KM-13272-7005	Plate
14075	KM-14075-7012	Cap Assembly
16154	KM-16154-7007	Pump Rotor, In
16154A	KM-16154-7008	Pump Rotor, Out
49065	KM-49065-2078	Oil Filter
49065A	KM-49065-7004	Oil Filter
59051	KM-59051-7011	Spur Gear
59231	KM-59231-7014	Filler
92043	KM-92043-7003	Pin
92066	KM-92066-7003	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7043	Bolt, 6 x 12
670	KM-670D2016	O-ring, 16mm


Kawasaki FX850V-AS00-S Valve & Camshaft



Kawasaki FX850V-AS00-S Valve & Camshaft


Ref.	Part Number	Description
11054	KM-11054-7018	Bracket
12004	KM-12004-7007	Intake Valve
12005	KM-12005-7008	Exhaust Valve
12009	KM-12009-7002	Valve Spring Retainer
12011	KM-12011-2052	Collet
12016	KM-12016-7016	Rocker Arm
12032	KM-12032-7001	Tappet
13070	KM-13070-7016	Guide
13116	KM-13116-7006	Push Rod
13272	KM-13272-7002	Plate
13272A	KM-13272-7003	Governor Plate
42036	KM-42036-7019	Sleeve
49078	KM-49078-7005	Engine Valve Spring
49118	KM-49118-7021	Complete Camshaft
92033	KM-92033-7012	Snap Ring, 18.5
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring
92152	KM-92152-7012	Collar
92153	KM-92153-7100	Bolt, 6 x 29.5
92200	KM-92200-2151	Washer, 8.1 x 18 x 0.5
92200A	KM-92200-7044	Washer, 20.3 x 29 x 2.28
92200B	KM-92200-7045	Washer, 20 x 46 x 0.91
130	KM-130AA0814	Flanged Bolt, 8 x 14
312	KM-312B0600	Hex Nut, 6mm

Kawasaki FX850V-AS00-S Cooling Equipment




Ref.	Part Number	Description
11055	KM-11055-7005	Bracket
13272	KM-13272-7006	Fan Plate
14037	KM-14037-7029-9H	Screen
27012	KM-27012-7006	Lift Hook
39067	KM-39067-7007	Oil Cooler
49089	KM-49089-7064-753	Engine Shroud, #1
49089A	KM-49089-7065-753	Engine Shroud, #2
49089B	KM-49089-7066	Rear Engine Shroud
49089C	KM-49089-7067-753	V-Bank Engine Shroud
55020	KM-55020-7010	Guard
59041	KM-59041-7013	Fan

Ref.	Part Number	Description
59066	KM-59066-7042-753	Fan Housing
92153	KM-92153-0010	Bolt
92153A	KM-92153-7007	Bolt
92153B	KM-92153-7043	Bolt, 6 x 12
92153C	KM-92153-7101	Bolt
92171	KM-92171-7015	Clamp
92172	KM-92172-7029	Socket Screw, 6 x 12
92192	KM-92192-7089	Tube
92192A	KM-92192-7090	Tube
130	KM-130B0620	Flanged Bolt, 6 x 20



Ref.	Part Number	Description
21066	KM-21066-7011	Voltage Regulator
21171	KM-21171-7036	Ignition Coil Assembly
21193	KM-21193-7035	Flywheel Assembly
26031	KM-26031-7033	Harness
26031A	KM-26031-7034	Harness
59031	KM-59031-7009	Charging Coil
92066	KM-92066-7002	Plug
92070	KM-92070-7004	Spark Plug
92072	KM-92072-7003	Band
92151	KM-92151-2097	Bolt, 12 x 30
92153	KM-92153-7029	Bolt
92172	KM-92172-7018	Screw, 5 x 20
92200	KM-92200-7040	Washer, 12.2 x 46 x 3
130	KM-130AA0620	Flanged Bolt, 6 x 20
510	KM-510A5100	Woodruff Key


Kawasaki FX850V-AS00-S Control Equipment



Ref.	Part Number	Description
11055	KM-11055-7001	Bracket
13107	KM-13107-7044	Governor Shaft
13271	KM-13271-7038	Plate
16169	KM-16169-7019	Choke Link
16171	KM-16171-7020	Link
39129	KM-39129-7020	Governor Spring
49103	KM-49103-7012	Governor Arm
49103A	KM-49103-7013	Governor Arm
49113	KM-49113-7046	Complete Control Panel
92009	KM-92009-2381	Screw, 5 x 30
92145	KM-92145-7044	Spring


Ref.	Part Number	Description
92145A	KM-92145-7055	Spring
92150	KM-92150-2182	Bolt, 5 x 18
92153	KM-92153-0009	Bolt, 6 x 12
92153A	KM-92153-7033	Bolt, 6 x 35
92153B	KM-92153-7043	Bolt, 6 x 12
92171	KM-92171-7018	Clamp
214	KM-214AA0408	Pan Screw, 4 x 8
311	KM-311B0600	Hex Nut, 6mm
312	KM-312B0500	Hex Nut, 5mm
411	KM-411B0600	Plain Washer, 6mm

Kawasaki FX850V-AS00-S Fuel Tank/Fuel Valve



Ref.	Part Number	Description
23062	KM-23062-7018	Complete Bracket
49019	KM-49019-7001	Fuel Filter
49040	KM-49040-7001	Fuel Pump
92153	KM-92153-7043	Bolt, 6 x 12
92170	KM-92170-2009	Clamp
92192	KM-92192-7088	Tube, 6.4 x 12.7 x 28.5
92192A	KM-92192-7102	Tube, 6 x 12.7 x 195
92192B	KM-92192-7116	Tube, 6 x 12.7 x 140
130	KM-130AA0620	Flanged Bolt, 6 x 20

Kawasaki FX850V-AS00-S Carburetor




Kawasaki FX850V-AS00-S Carburetor

Ref.	Part Number	Description
11009	KM-11009-2056	Gasket
11061	KM-11061-7037	Gasket
11061A	KM-11061-7038	Gasket
11061B	KM-11061-7039	Gasket
11061C	KM-11061-7070	Head/Manifold Gasket
11061D	KM-11061-7072	Carburetor/Manifold Gasket
11061E	KM-11061-7078	Carburetor/Pipe Gasket
14091	KM-14091-7031	Cover
15004	KM-15004-7043	Carburetor Assembly
16025	KM-16025-7010	Throttle Valve
16030	KM-16030-7004	Float Valve
16031	KM-16031-7003	Float
16041	KM-16041-7025	Carburetor Shaft
16041A	KM-16041-7039	Carburetor Shaft
16073	KM-16073-7011	Insulator
16126	KM-16126-7021	Valve
16184	KM-16184-7021	Float Chamber Assembly
16187	KM-16187-7005	Jet Needle
21188	KM-21188-7003	Solenoid
59076	KM-59076-7013	Intake Manifold
92009	KM-92009-7003	Screw
92009A	KM-92009-7004	Screw
92009B	KM-92009-7006	Drain Screw


Ref.	Part Number	Description
92026	KM-92026-7024	Spacer
92043	KM-92043-7014	Pin
92055	KM-92055-7012	O-Ring
92055A	KM-92055-7013	O-Ring
92055B	KM-92055-7013	O-Ring
92055C	KM-92055-7016	O-Ring
92063	KM-92063-7110	Main Jet, #118
92063A	KM-92063-7111	Main Jet, #120
92063B	KM-92063-7135	Main Jet, #115, 3280ft
92063C	KM-92063-7136	Main Jet, #112, 6560ft
92063D	KM-92063-7137	Main Jet, #117, 3280ft
92063E	KM-92063-7138	Main Jet, #114, 6560ft
92066	KM-92066-7009	Expansion Plug
92093	KM-92093-7001	Seal, 5.9
92093A	KM-92093-7002	Seal, 6.9
92145	KM-92145-7010	Spring
92145A	KM-92145-7011	Spring
92152	KM-92152-7005	Collar
92172	KM-92172-7005	Screw
92172A	KM-92172-7006	Screw
130	KM-130AA0635	Flanged Bolt, 6 x 35
172	KM-172BA06120	Stud Bolt, 6 x 120

Kawasaki FX850V-AS00-S Starter



Ref.	Part Number	Description
13081	KM-13081-7001	Clutch Assembly
13280	KM-13280-7002	Holder
21163	KM-21163-7021	Electric Starter
21188	KM-21188-7005	Solenoid
27012	KM-27012-7005	Lift Hook
32085	KM-32085-7001	Stopper
92033	KM-92033-7014	Snap Ring
92152	KM-92152-7013	Collar
92172	KM-92172-7032	Screw
130	KM-130AA0830	Flanged Bolt, 8 x 30


Kawasaki FX850V-AS00-S Muffler/Air Filter



Ref.	Part Number	Description
11010	KM-11010-7020	Air Filter Assembly
11011	KM-11011-7047	Air Filter Case
11011A	KM-11011-7048	Air Filter Case
11013	KM-11013-7038	Air Filter Element
11013A	KM-11013-7039	Air Filter Element
11054	KM-11054-7013-9X	Bracket
11054A	KM-11054-7016-9X	Bracket
11054B	KM-11054-7017-9X	Bracket
11055	KM-11055-7007-9X	Bracket
11060	KM-11060-7016	Muffler Gasket
11065	KM-11065-7008	Cap
11065A	KM-11065-7009	Cap

Ref.	Part Number	Description
11065B	KM-11065-7017	Cap
16060	KM-16060-6007	Intake Pipe
92015	KM-92015-1193	Nut
92153	KM-92153-7043	Bolt, 6 x 12
92171	KM-92171-7013	Clamp
92171A	KM-92171-7023	Air Filter Clamp
92192	KM-92192-7086	Tube
92192A	KM-92192-7087	Tube
92210	KM-92210-7027	Nut, M8
130	KM-130AA06120	Flanged Bolt, 6 x 120
130A	KM-130AA0816	Flanged Bolt, 8 x 16
461	KM-461F0800	Spring Washer, 8mm


Kawasaki FX850V-AS00-S Labels



Ref.	Part Number	Description
56014	KM-56014-7003	Emblem
56033	KM-56033-7002	Manual Label
56070	KM-56070-7001	Warning Label

[illegible]


Kawasaki FXT00V-BS04-R Cylinder/Crankcase



Kawasaki FXT00V-BS04-R Cylinder/Crankcase


Ref.	Part Number	Description
11004	KM-11004-7023	Head Gasket
11008	KM-11008-7034	Complete Cylinder Head, #1
11008A	KM-11008-7035	Complete Cylinder Head, #2
11022	KM-11022-7012	Rocker Case, #1
11022A	KM-11022-7013	Rocker Case, #2
11061	KM-11061-7055	Rocker Case Gasket
11061A	KM-11061-7065	Breather Cover Gasket
12021	KM-12021-7003	Reed Valve Assembly Breather
13271	KM-13271-7037	Breather Cover Plate
14091	KM-14091-7052	Breather Cover
27012	KM-27012-7004	Hook
32154	KM-32154-7014	Breather Pipe
32154A	KM-32154-7015	Breather Pipe
32154B	KM-32154-7019	Pipe
49015	KM-49015-7060	Crankcase Cover
49120	KM-49120-6169	Complete Crankcase
49120A	KM-49120-6174	Complete Crankcase
59071	KM-59071-2079	Joint
92043	KM-92043-1266	Pin
92045	KM-92045-7002	Ball Bearing, A15 x 32 x 96002
92049	KM-92049-7001	Oil Seal, 26 x 11 x 10.2
92049A	KM-92049-7005	Oil Seal, 8 x 14 x 5
92049B	KM-92049-7020	Oil Seal, 7 x 15 x 13
92049C	KM-92049-7024	Oil Seal, 40 x 54 x 9
92049D	KM-92049-7025	Oil Seal, 40 x 72 x 8
92066	KM-92066-7002	Plug
92153	KM-92153-7043	Bolt, 6 x 12
130	KM-130AA0630	Flanged Bolt, 6 x 30
130A	KM-130CA1040	Flanged Bolt, 10 x 40
130B	KM-130CA1065	Flanged Bolt, 10 x 65
172	KM-172BA0818	Stud Bolt, 8 x 18
214	KM-214AA0408	Pan Screw, 4 x 8
601	KM-601A6308	Ball Bearing

Kawasaki FXT00V-BS04-R Piston/Crankshaft



Ref.	Part Number	Description
13001	KM-13001-7021	Engine Piston
13002	KM-13002-7004	Piston Pin
13008	KM-13008-7004	Piston Ring Set
13025	KM-13025-7008	Piston Ring Set, 0.5
13029	KM-13029-7009	Engine Piston, 0.5
13031	KM-13031-7074	Complete Crankshaft
13251	KM-13251-7018	Connecting Rod Assembly
92033	KM-92033-2176	Snap Ring
92153	KM-92153-2054	Bolt, 7 x 35.2


Kawasaki FXT00V-BS04-R Lubrication Equipment



Ref.	Part Number	Description
13107	KM-13107-7009	Shaft
13271	KM-13271-7034	Pump Rotor Plate
16154	KM-16154-7007	Pump Rotor, In
16154A	KM-16154-7008	Pump Rotor, Out
49065	KM-49065-2078	Oil Filter
49065A	KM-49065-7004	Oil Filter
52005	KM-52005-7023	Gauge
59051	KM-59051-7026	Oil Pump Spur Gear
59071	KM-59071-7004	Joint


Ref.	Part Number	Description
59231	KM-59231-7012	Filler
92043	KM-92043-7003	Pin
92066	KM-92066-7003	Plug
92066A	KM-92066-7006	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7046	Spring
92153	KM-92153-7043	Bolt, 6 x 12
670	KM-670D2016	O-Ring, 16mm

Kawasaki FXT00V-BS04-R Valve & Camshaft




Ref.	Part Number	Description
12004	KM-12004-7006	Intake Valve
12005	KM-12005-7007	Exhaust Valve
12009	KM-12009-7001	Valve Spring Retainer
12009A	KM-12009-7002	Valve Spring Retainer
12011	KM-12011-2052	Collet
12011A	KM-12011-2056	Collet
12016	KM-12016-7011	Rocker Arm, #1, External
12016A	KM-12016-7013	Rocker Arm, #2, External
12016B	KM-12016-7014	Rocker Arm, #1, Internal
12016C	KM-12016-7015	Rocker Arm, #2, Internal
12020	KM-12020-7001	Rocker Shaft, Internal
12020A	KM-12020-7002	Rocker Shaft, External
12032	KM-12032-7002	Tappet
13070	KM-13070-7004	Guide
13116	KM-13116-2054	Push Rod
13116A	KM-13116-7005	Push Rod
13271	KM-13271-7007	Plate
13271A	KM-13271-7021	Governor Plate
42036	KM-42036-7010	Sleeve
49078	KM-49078-7002	Engine Valve Spring, Internal
49078A	KM-49078-7004	Engine Valve Spring, External
49118	KM-49118-7018	Complete Camshaft
92009	KM-92009-1109	Screw
92015	KM-92015-1137	Nut
92026	KM-92026-7019	Spacer
92033	KM-92033-7001	Snap Ring
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring

Kawasaki FXT00V-BS04-R Cooling Equipment




Ref.	Part Number	Description
13070	KM-13070-7013	Guide
13271	KM-13271-7035	Fan Plate
14037	KM-14037-7029-9H	Screen
39067	KM-39067-7007	Oil Cooler
49089	KM-49089-7062-753	Engine Shroud
49089A	KM-49089-7063-753	Engine Shroud
55020	KM-55020-7010	Guard
59041	KM-59041-7013	Fan
59066	KM-59066-7040-753	Fan Housing
92004	KM-92004-7021	Screen Stud
92153	KM-92153-7043	Bolt, 6 x 12
92171	KM-92171-7015	Clamp
92192	KM-92192-7078	Tube
92192A	KM-92192-7079	Tube
130	KM-130AA0610	Flanged Bolt, 6 x 10



Ref.	Part Number	Description
21066	KM-21066-7011	Voltage Regulator
21171	KM- 21171-7028	Ignition Coil Assembly, #1
21171A	KM- 21171-7029	Ignition Coil Assembly, #2
21193	KM- 21193-7034	Flywheel Assembly
26031	KM- 26031-7033	Harness
26031A	KM- 26031-7034	Harness
59031	KM- 59031-7009	Charging Coil
92009	KM- 92009-2308	Screw
92066	KM- 92066-7002	Plug
92070	KM- 92070-2088	Spark Plug
92072	KM- 92072-7003	Band
92151	KM- 92151-2097	Bolt, 12 x 30
92172	KM- 92172-7018	Screw, 5 x 20
92200	KM- 92200-7040	Washer, 12.2 x 46 x 3
130	KM- 130AA0620	Flanged Bolt, 6 x 20
510	KM- 510A5100	Woodruff Key


Kawasaki FXT00V-BS04-R Control Equipment



Ref.	Part Number	Description
11061	KM-11061-7056	Intake Pipe Gasket
13107	KM-13107-7040	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-7018	Link
39129	KM-39129-7017	Governor Spring
49103	KM-49103-7009	Governor Arm
49103A	KM-49103-7010	Governor Arm
49113	KM-49113-7042	Compete Control Panel
49113A	KM-49113-7048	Compete Control Panel
92009	KM-92009-2381	Screw, 5 x 30


Ref.	Part Number	Description
92145	KM-92145-7050	Spring
92150	KM-92150-2182	Bolt, 5 x 18
92153	KM-92153-7033	Bolt, 6 x 35
92171	KM-92171-7018	Clamp
130	KM-130BA0610	Flanged Bolt, 6 x 10
214	KM-214AA0408	Pan Screw, 4 x 8
311	KM-311B0600	Hex Nut, 6mm
312	KM-312B0500	Hex Nut, 5mm
411	KM-411B0600	Plain Washer, 6mm

Kawasaki FXT00V-BS04-R Carburetor




Ref.	Part Number	Description
11009	KM-11009-2056	Gasket
11061	KM-11061-7037	Gasket
11061A	KM-11061-7038	Gasket
11061B	KM-11061-7057	Insulator Gasket
11061C	KM-11061-7062	Manifold Gasket
11061D	KM-11061-7067	Gasket
14091	KM-14091-7059	Cover
15004	KM-15004-7003	Carburetor Assembly
15004A	KM-15004-7037	Carburetor Assembly
16025	KM-16025-7012	Throttle Valve
16030	KM-16030-7004	Float Valve
16031	KM-16031-7003	Float
16041	KM-16041-7035	Carburetor Chock Shaft
16041A	KM-16041-7036	Carburetor Throttle Shaft
16073	KM-16073-7010	Insulator
16126	KM-16126-7019	Chock Valve
16184	KM-16184-7021	Float Chamber Assembly
16187	KM-16187-7005	Jet Needle
21188	KM-21188-7003	Solenoid
59076	KM-59076-7010	Intake Manifold
92009	KM-92009-7003	Screw
92009A	KM-92009-7006	Drain Screw
92026	KM-92026-7022	Spacer
92043	KM-92043-7014	Pin
92055	KM-92055-7012	O-Ring
92055A	KM-92055-7013	O-Ring
92055B	KM-92055-7016	O-Ring
92063	KM-92063-7099	Main Jet, #134
92063A	KM-92063-7100	Main Jet, #140
92066	KM-92066-7009	Expansion Plug
92093	KM-92093-7001	Seal, 5.9
92093A	KM-92093-7002	Seal, 6.9
92145	KM-92145-7011	Spring
92145A	KM-92145-7039	Spring
92172	KM-92172-7005	Screw
92172A	KM-92172-7006	Screw
92172B	KM-92172-7031	Throttle Adjust Screw
130	KM-130AA0635	Flanged Bolt, 6 x 35
172	KM-172BA06120	Stud Bolt, 6 x 120

Kawasaki FXT00V-BS04-R Starter



Ref.	Part Number	Description
13081	KM-13081-7001	Clutch Assembly
13280	KM-13280-7002	Holder
21163	KM-21163-7021	Electric Starter
21188	KM-21188-7005	Solenoid
32085	KM-32085-7001	Stopper
92033	KM-92033-7014	Snap Ring
92152	KM-92152-7013	Collar
92172	KM-92172-7032	Screw
130	KM-130AA0830	Flanged Bolt, 8 x 30

Kawasaki FXT00V-BS04-R Muffler/Air Filter




Ref.	Part Number	Description
11010	KM-11010-7020	Air Filter Assembly
11011	KM-11011-7047	Air Filter Case
11011A	KM-11011-7048	Air Filter Case
11013	KM-11013-7038	Air Filter Element
11013A	KM-11013-7039	Air Filter Element
11054	KM-11054-7012-9X	Bracket
11054A	KM-11054-7013-9X	Bracket
11061	KM-11061-7056	Intake Pipe Gasket
11061A	KM-11061-7061	Muffler Gasket
11065	KM-11065-7008	Cap
11065A	KM-11065-7009	Cap
11065B	KM-11065-7017	Cap

Ref.	Part Number	Description
16060	KM-16060-6006	Intake Pipe
92015	KM-92015-1143	Nut
92015A	KM-92015-1193	Nut
92171	KM-92171-7013	Clamp
92171A	KM-92171-7023	Air Filter Clamp
92192	KM-92192-7075	Tube, 12.6 x 18.6 x 183
92192A	KM-92192-7076	Air Filter Tube
92192B	KM-92192-7096	Air Filter Tube
92210	KM-92210-7027	Nut, M8
130	KM-130AA06120	Flanged Bolt, 6 x 120
130A	KM-130AA0816	Flanged Bolt, 8 x 16
461	KM-461F0800	Spring Washer, 8mm

Kawasaki FXT00V-BS04-R Labels

56033




56070




56014



56080





56080A




Ref.	Part Number	Description
56014	KM-56014-7001	Emblem
56033	KM- 56033-7002	Manual Label
56070	KM- 56070-7001	Warning Label
56080	KM- 56080-7002	Brand Label
56080A	KM- 56080-7037	Brand Label

Electrical Schematic







[illegible]

[illegible]



To order replacement parts, call a Customer Support Representative at (800) 965-4CUB.
Locate your nearest Cub Cadet dealer at (877) 282-8684
or visit www.cubcadet.com to find the nearest Cub Cadet dealer in your area.

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
