

Cub Cadet®

ILLUSTRATED PARTS MANUAL



TANK L

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

To The Owner

Thank You

Thank you for purchasing a Cub Cadet Zero-Turn Tractor. It was carefully engineered to provide excellent performance when properly operated and maintained.

All information in this manual is relative to the most recent product information available at the time of printing. Please be aware that this Illustrated Part's Manual may cover a range of product specifications for various models.

Components listed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and equipment without notice and without incurring obligation.

Throughout this manual, all references to *right* (RH) and *left* (LH) are observed from the operating position.

Table of Contents

Frame	3	Engine Accessories (Kawasaki)	16
Seat Assembly.....	4	60" Deck.....	18
Hydro Controls.....	6	Electrical.....	20
Control Group.....	8	Electrical Schematic.....	21
Fuel Tank Assembly.....	10	Tank L Labels	22
Front Axle Assembly	11	RH Transmission 618-06079.....	24
Control Assembly	12	LH Transmission 618-06080	26
Deck Lift Assembly	14	Kawasaki FX850V	28

Record Product Information

To ease in ordering replacement parts, please locate the model plate on the equipment and record the information in the provided area to the right. You can locate the model plate by looking beneath the seat.

MODEL NUMBER

--	--	--	--	--	--	--	--	--	--	--

SERIAL NUMBER


--	--	--	--	--	--	--	--	--	--	--

Painted Parts

When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXX-0637). Please refer to the table below for current color codes:


0637	Black
4021	Yellow (Cub Cadet)
0499	Beige (Cub Cadet)

0685	Blue (Cub Cadet)
0691	Black Jack (Cub Cadet Commercial)




Ref	Part Number	Description
1	680-00348	Frame Assembly
2	680-00341	Front Axle Bracket Assembly
3	703-09463	Rear Bumper
4	703-09543	Hitch Bracket
5	712-0229	Push Nut, 3/8
6	710-05408	Carriage Bolt, 3/8-16 x 1.25
7	710-3168	Carriage Bolt, 3/8-16 x 1.00
8	712-04065	Nylock Nut, 3/8-16
9	735-0271A	Bumper, .62 Dia. x .3

Seat Assembly




Ref.	Part Number	Description
1	01008140P	Torsion Spring, .725 x 1.0 x .09
2	02004062P	Cable Support
3	680-00175	Folding ROPS Assembly
4	703-07814	Seat Mounting Bracket
5	703-07880	Deck Reinforcement Plate
6	703-08241	Seat Mounting Bracket
7	703-08324	Floor Panel Tray
8	703-08416	Floor Panel
9	703-08480	Seat Lever Latch
10	703-08496	Control Panel Cover
11	703-08633A	Front Panel Cover
12	703-09560	Seat Panel Cover, RH
13	710-0389	Carriage Bolt, 3/8-16 x .75
14	710-05070A	Screw, 1/4-20 x .5
15	710-0599	Hex Flange Screw, 1/4-20 x .500
16	710-0859	Hex Cap Screw, 3/8-16 x 2.50
17	712-04063	Nut, 5/16-18, Flangelock
18	712-04064	Nut, 1/4-20, Flangelock
19	712-04065	Nut, 3/8-16, Flangelock
20	912-3017	Nut, 3/8-16, Hex
21	726-3046	Clip, .250 Dia.
22	735-0271A	Bumper, .62 Dia. x .3
23	735-04286	Rubber Bumper, 2.5 x 1.0
24	738-04395	Shoulder Screw, .31 x .50, 1/4-20
25	738-0966A	Shoulder Bolt, .50 x .925, 3/8-16
26	738-1011A	Shoulder Bolt, .500 x 2.23, 3/8-16
27	757-04160	Seat, w/ Suspension
NS	SI-111880	6" Seat Track Kit
NS	SI-176201	Black Selfskin-Arm Pad Only
NS	SI-181773	Armrest Set-Cam Adjust
NS	SI-181774	Armrest-LH Selfskin Cam Adjust
NS	SI-181775	Armrest-RH Selfskin Cam adjust
NS	SI-310736	Seat Cover-Back
NS	SI-310737	Seat Cushion Cover
NS	SI-310843	Seatbelt Kit
NS	SI-781580	Delta Seat Switch

Hydro Controls




Ref.	Part Number	Description
1	918-06079	Transmission, RH
2	918-06080	Transmission, LH
3	680-00336	Transmission Bracket Assembly
4	703-09657	Spring Brake Mounting Bracket
5	703-09658	Brake Cable Mounting Bracket
6	710-04191	Carriage Bolt, 1/2-13 x 2.00
7	1767754	Screw, 10-24 x .500
8	710-05408	Carriage Bolt, 3/8-16 x 1.25
9	710-0805A	Hex Cap Screw, 5/16-18 x 1.50
10	712-04063	Nut, 5/16-18, Flangelock
11	712-04065	Nut, 3/8-16, Flangelock
12	712-04150	Nut, 1/2-13, Flangelock
13	912-3010	Nut, 5/16-18, Hex
14	732-04833	Fan Cover
15	732-05147	Extension Spring, .50 OD x 1.71
16	634-05087-0931	Wheel Assembly, 24 x 9.5-12
17	712-04311	Lug Nut, 1/2-13
18	710-0376	Hex Cap Screw, 5/16-18 x 1.00
19	712-3007	Jam Nut, 5/16-18
20	912-3009	Hex Lock Nut, 5/16-18



Ref.	Part Number	Description
1	680-00339	Brake Handle Assembly
2	703-08123	LH Control Panel
3	703-08482	RH Control Panel
4	703-09674	Dump Valve Actuator Bracket
5	703-09592	Boot Brake Bracket
6	703-09604	Brake Switch Mount
7	703-09665	Transmission Bypass Lever
8	703-09666	Neutral Switch Bracket
9	703-09745	Transmission Link Arm
10	703-09731	Neutral Pivot Control Lever
11	703-09739A	Neutral Arm
12	703-09912	Dump Valve Release Lever
13	710-0389	Carriage Bolt, 3/8-16 x .75
14	710-04666	Hex Flange Screw, 1/4-20 x .75
15	710-04683C	Screw, 3/8-16 x 1.00
16	710-05132	Screw, M6 x 8mm
17	710-05421	Machine Screw, #10-32 x .25
18	710-0599	Hex Flange Screw, 1/4-20 x .500
19	710-06021	Hex Cap Screw, 3/8-16 x 1.50
20	710-0607	Screw, 5/16-18 x .50
21	712-04065	Nut, 3/8-16, Flangelock
22	912-0431	Nut, 3/8-16, Flangelock


Ref.	Part Number	Description
23	912-3008	Jam Nut, 3/8-16
24	912-3027	Nut, 1/4-20, Hexflange
25	916-0114	Retainer Ring
26	720-04139B	Grip, .50 ID
27	720-0433	Grip, Seat, Adjustment (Yellow)
28	725-0157	Cable Tie
29	728-0199	Rivet, .3125
30	731-08438	Cup Holder
31	732-04481	Compression Spring, .844 x .97 x 1.5
32	936-0232	Washer, Wave, .531 x .781 x .013
33	736-0258	Flat Washer, .385 x 1.00 x .135
34	736-0342	Flat Washer, .283 x .750 x .030
35	736-04237	Flat Washer, .508 x 1.325 x .040
36	936-3004	Flat Washer, .406 x .875 x .105
37	738-0213	Shoulder Screw, .498 x 1.445
38	738-04425	Shoulder Screw, .342 x .335, 1/4-28
39	738-04446	Shoulder Spacer, M6
40	738-04483	Shoulder Spacer, .375 x .625 x .20
41	738-0706C	Shoulder Screw, .375 x .280, 1/4-14
42	946-05103	Brake Cable
43	750-05297	Spacer, .256 x .500 x .240
44	750-06360	Spacer, .51 x .75 x .390

Fuel Tank Assembly



Ref.	Part Number	Description
1	651-05090	Fuel Tank Assembly, LH
2	703-08484	Rear Fuel Bracket, RH
3	703-08495	Rear Fuel Bracket, LH
4	710-05412	Hex Cap Screw, 3/8-16 x .500
5	710-3168	Carriage Bolt, 3/8-16 x .500
6	712-04065	Nut, 3/8-16, Flangelock
7	725-0157	Cable Tie
8	726-3046	Clip, .250 Dia.
9	751-14490	Console, RH
10	02002253	Fuel Tank Grommet
11	735-05014	Grommet, .755 x .955 x .55
12	951-10375	Fuel Rollover Valve
13	951-12754	Fuel Cap
14	751-14492	Fuel Pickup Valve


Front Axle Assembly



Ref.	Part Number	Description
1	634-04750	Wheel Assembly, 13 x 6.50-6
2	680-00323	Front Axle (54" & 60")
3	680-00324	Yoke, Caster Wheel
4	710-05189	Hex Cap Screw, 1-14 x 7.0
5	710-05394A	Hex Cap Screw, 1/2-13 x 7.75
6	712-0359	Nut, 3/4-16, Slotted
7	712-04150	Nut, 1/2-13, Flangelock
8	712-04310	Nut, 1.0-14, Flangelock
9	716-04191	Retainer Ring
10	731-07348	Axle Grease Cap
11	714-0162	Cotter Pin, 5/32 x 1.25


Ref.	Part Number	Description
12	736-04604	Bell Washer, 1.25 x 2.50 x .180
13	736-04605	Washer, 1.00 x 2.00 x .075
14	737-04345	Grease Fitting, 1/4-28
15	737-04352	Grease Fitting, 1 39/64
16	721-04462	Seal
17	750-05438	Spacer, 1.005 x 1.247 x 4.1
18	741-04548	Cup Bearing
19	750-05553	Spacer, .812 ID x .218 LG
20	750-05625	Spacer, .515 x .749 x 6.313
21	741-04549	Cone Bearing
22	750-05600	Spacer, 1.00 x 1.50 x .437

Control Assembly



Ref.	Part Number	Description
1	603-05016A	Lapbar Lever Assembly, RH
2	603-05019A	Lapbar Lever Assembly, LH
3	680-00333	Pivot Hub Assembly
4	680-00342A	Pivot Housing Weldment, RH
5	680-00343A	Pivot Housing Weldment, LH
6	680-00344	Lapbar Adjustment Tube Assembly
7	703-09445	Damper Mounting Bracket
8	710-0458	Carriage Bolt, 5/16-18 x 1.75
9	710-0528	Hex Cap Screw, 5/16-18 x 1.25
10	710-3005	Hex Cap Screw, 3/8-16 x 1.25
11	710-3168	Carriage Bolt, 3/8-16 x 1.00
12	712-04063	Nut, 5/16-18, Flangelock
13	712-04064	Nut, 1/4-20, Flangelock
14	712-04065	Nut, 3/8-16, Flangelock
15	712-04150	Nut, 1/2-13, Flangelock
16	712-0711	Jam Nut, 3/8-24
17	912-3008	Jam Nut, 3/8-16
18	712-3046	Nut, Hex Jam, 5/16-18
19	720-05008	Grip, 1.0 ID
20	723-04080	Ball Joint, 3/8-24
21	723-05004	Rod End, 5/16 ID, Female LH
22	727-05021	Damper Cylinder, .87 OD x 7.06 LG
23	728-04062A	Rivet Nut, 3/8-16
24	735-0246A	Plug End
25	738-05025	Shoulder Screw, .498 Dia. x 1.296
26	738-05033	Shoulder Bolt, .75 x 3.25, 1/2-13
27	738-05034	Shoulder Screw, .395 Dia. x .56 LG
28	741-04050	Bearing, .75 x 1.00 x .73
29	741-0748	Flange Bushing, .500 ID x .627 OD
30	747-06212	Pump Rod

Deck Lift Assembly




Deck Lift Assembly

Ref.	Part Number	Description
1	02002596	Deck Lift Foot Pedal
2	941-0475	Bearing, .385 ID
3	680-00158	Lift Lock Mount
4	680-00350	Deck Lift Shaft, Rear
5	680-00349	Deck Lift Shaft, Front
6	703-08032	Latch Lock Bracket
7	703-08060	Lift Link Arm
8	703-08062	Deck Adjustment Lift Link Arm
9	680-00347	Deck Lift Arm Assembly
10	703-08070	Deck Lift Bellcrank
11	703-08252	Deck Lift Foot Pedal
12	703-08384	Deck Index Link Arm
13	703-08388A	Lift Index Slider Arm
14	710-04186	Hex Cap Screw, 1/2-13 x 1.25
15	728-04016	Rivet, 3/16 x .325
16	710-06047	Hex Cap Screw, 5/8-11 x 2.25
17	710-05355	Eye Bolt, 5/8-18 x 2.63
18	710-05418	Hex Cap Screw, 1/4-20 x 5.00
19	710-0607	Screw, 5/16-18 x .500
20	711-04061	Clevis Pin, .500 x 1.25
21	711-05629	Clevis Pin, .438 x 1.5
22	712-04064	Nut, 1/4-20, Flangelock
23	712-04151	Nut, 5/8-11, Flangelock
24	712-05007	Nut, 3/8-16, Flange Centerlock

Ref.	Part Number	Description
25	912-3015	Jam Nut, 5/8-11
26	950-0960A	Spacer, .635 x 1.25 x .445
27	914-0145	Click Pin, .092 x 1.64
28	914-0149B	Internal Cotter Pin
29	753-04070	Lynch Pin, .1875
30	914-0507	Cotter Pin, 3/32 x .750
31	720-04183	Lift Handle Grip
32	747-05465A	Lift Lock Rod
33	732-04929	Extension Spring, .969 OD x 6.180
34	732-0992	Compression Spring, .656 OD x 2.445
35	736-0242	Bevel Washer, .340 x .872 x .060
36	936-0272	Washer, .510 x 1.00 x .125
37	680-00322	Deck Rod Assembly
38	936-0326	Washer, .510 x 1.00 x .125
39	948-3051	Hex Flange Bearing
40	703-09695	Flat Washer, .531 x 2.125 x .250
41	736-04602	Washer, .640 x 1.25 x .050
42	750-05468	Spacer, 1.27 x 1.75 x .375
43	738-04222	Shoulder Screw, .437 x .50, 1/4-20
44	738-1127B	Shoulder Screw, .625 x .442, 3/8-16
45	710-3067	Hex Cap Screw, 1/2-13 x 1.75
46	711-05072	Front Lift Link Shaft, Threaded
47	712-04150	Nut, 1/2-13, Flangelock

Engine Accessories (Kawasaki)




Engine Accessories (Kawasaki)

Ref.	Part Number	Description
1	680-00227A	Idler Bracket
2	703-08607	Clutch Retainer Bracket
3	710-0216	Hex Cap Screw, 3/8-16 x .75
4	710-0425	Screw, #10-24 x .625
5	710-04377	Hex Cap Screw, 7/16-20 x 2.75
6	710-05376	Carriage Bolt, 3/8-16 x 1.00
7	710-0805A	Hex Cap Screw, 5/16-18 x 1.50
8	710-3168	Carriage Bolt, 3/8-16 x 1.00
9	710-3217	Screw, #8-32 x .375
10	711-1637	Stud, Pivot Ball Joint
11	712-0142	Nut, #8-32, Hex
12	712-0161	Nut, #10-24, Hexlock
13	712-0290	Nut, 7/16-14, Hexlock
14	712-04063	Nut, 5/16-18, Flangelock
15	712-04065	Nut, 3/8-16, Flangelock
16	912-0431	Nut, 3/8-16, Flangelock
17	712-04312	Nut, M8-1.25, Hexlock
18	712-0711	Jam Nut, 3/8-24
19	714-0118	Key, 1/4 x 1.50
20	917-05184	Electric PTO Clutch
21	725-0157	Cable Tie
22	726-04124	Clip, .407 x 1.80


Ref.	Part Number	Description
23	731-04914	Throttle Control Knob
24	732-04915A	Extension Spring, 1.5 x 7.5
25	936-0275	Washer, .344 x .688 x .065
26	736-3017	Washer, .471 x 1.50 x .225
27	721-04516	Pulley Cap
28	736-3082A	Washer, .471 x 1.50 x .225
29	937-0146	Grease Fitting
30	738-1126	Shoulder Screw, .625 x .302, 3/8-16
31	738-3102	Shoulder Bolt, .625 x 1.95, 7/16-14
32	741-04555	bearing, .638 x .753 x .615
33	946-04812	Choke Control Cable
34	946-04840	Throttle Cable
35	747-05707	Transmission Spring Hook
36	751-10291A	Oil Drain Hose
37	751-12520A	Muffler (FX850)
38	954-05037	Belt
39	756-04382	Drive Pulley
40	756-04487	Idler Pulley
41	726-04123A	Hose Clamp, .500 Dia.
42	751-10349-72	Fuel Hose., 1/4
43	751-12089-51	Vent Hose

60" Deck



Ref.	Part Number	Description
1	02005195	Chute Baffle
2	02005694	Baffle, 60" Adjustment
3	634-3159	Complete Wheel, 5.00 Dia.
4	680-00329	60" Deck Assembly
5	703-09922	Deck Belt Cover, RH
6	703-09921	Deck Belt Cover Bracket
7	703-09924	Deck Belt Cover, LH
8	710-04692	Hex Cap Screw, 3/8-16 x 7.25
9	710-0607	Screw, 5/16-18 x .500
10	710-1649	Carriage Screw, 3/8-16 x 4.50
11	710-3178	Carriage Bolt, 3/8-16 x .750
12	711-05604	Pin, 1/2-13 x .625 x 1.2
13	712-0229	Push Nut, 3/8
14	712-04064	Nut, 1/4-20, Flangelock
15	712-04065	Nut, 3/8-16, Flangelock
16	712-04150	Nut, 1/2-13, Flangelock
17	912-0641	Hex Nut, M16-1.5
18	720-04122	Wing Knob
19	732-04929	Extension Spring, .969 x 6.180
20	936-0287	Washer, .793 x 1.24 x .06
21	736-04296	Flat Washer, .632 x 1.00 x .160
22	936-0760	Lock Washer, 17 x 23.8 x 1.95
23	738-04146	Plug, Screw, M16-1.5
24	738-04222	Shoulder Bolt, .437 x .50, 1/4-20
25	750-3193	Wheel Spacer
26	918-05132	Spindle Assembly
27	680-00167A	Deck Idler Arm
28	680-00319	Idler Assembly
29	703-08855	Spacer, .5375 x 2.75 x .375
30	703-09434	Spindle Support Plate
31	710-0382	Hex Cap Screw, 1/2-13 x 5.00
32	710-04157	Screw, 3/8-16 x 2.00
33	710-04831A	Bolt, 5/16-18 x 1.25
34	710-05387	Hex Cap Screw, 3/4-16 x 7.00
35	710-05388	Hex Cap Screw, 3/4-16 x 9.00
36	712-04063	Nut, 5/16-18, Flangelock
37	712-04327	Nut, 5/8-18, Flangelock
38	712-3022	Nut, 1/2-13, Hexlock
39	712-3078	Nut, 3/4-16, Flangelock
40	714-04040	Bow Tie Cotter Pin


Ref.	Part Number	Description
41	721-04516	Pulley Cap
42	732-04911	Extension Spring, 1.248 x 8.5
43	736-3040	Washer, .406 x 1.92 x .060
44	736-3052	Washer, .406 x 1.00 x .105
45	937-0146	Grease Fitting
46	738-05030	Shoulder Bolt, 1.0 x 3.15, 5/8-18
47	938-3110	Shoulder Bolt, .750 x 2.23, 1/2-13
48	741-0338	Flange Bearing, .75 x .52
49	741-04552	Flange Bearing, 1.00 x .75
50	942-04415	Hi-Lift Blade, 21.0
51	747-05658	Spring Rod Hook
52	750-05553	Spacer, .812 x .218
53	750-05617	Spacer, .760 x 2.00 x .925
54	750-3213	Spacer, .405 x .75 x 3.875
55	954-04296	V-Belt
56	954-04319	Deck Belt
57	756-04487	Idler Pulley
58	756-04489	Spindle Pulley
59	756-04496A	Drive Pulley
60	756-04522	Idler Pulley
61	631-05176	Discharge Chute Assembly
62	710-0276	Carriage Bolt, 5/16-18 x 1.00
63	703-09625A	Chute Bracket
64	703-09626	Chute Bracket
65	726-04009	Push Cap
66	732-05128A	Torsion Spring
67	738-04549A	Shoulder Screw, 1/4-20
68	747-06318	Chute Rod
69	737-3001	Grease Fitting, 45 degree, 1/4-28
70	911-05758	Spindle Shaft
71	921-0385	Seal, Oil
72	941-3050	Cup Bearing
73	941-3051	Cone Bearing
74	736-04642	Washer, 1.50 x 2.52 x .075
75	750-05695	Ring, Seal
76	737-04373	Straight Adapter Fitting
77	710-0599	Hex Flange Screw, 1/4-20 x .500
78	726-0201	Speed Nut, .3125
79	735-0271A	Bumper, .62 Dia. x .3




Ref.	Part Number	Description
1	01009905	PTO Switch Bracket
2	703-07855	Battery Bracket
3	710-0389	Carriage Bolt, 3/8-16 x .750
4	710-3015	Hex Cap Screw, 1/4-20 x .75
5	712-04064	Nut, 1/4-20, Flangelock
6	712-04065	Nut, 3/8-16, Flangelock
7	723-3064	Battery Strap
8	725-0157	Cable Tie
9	925-04174	Electric PTO Switch

Ref.	Part Number	Description
10	925-04228	Key Switch
11	735-04285	Rubber Grommet, .75 x 1.062 x .50
12	925-3164A	Plunger Switch, NO/NC
13	925-06122	Hour Meter
14	925-1707D	Battery
15	625-05000	Key, Assembly
NS	725-06220	Wire Harness
NS	02002822	Wire Harness Adaptor, (Kaw. only)


Electrical Schematic



Tank L Labels




[illegible]




Ref.	Part Number	Description
1	PH-020207	Flange Head Screw
2	PH-025136	Nut
3	PH-025167	Nut, Flange 1/2-20 UNF
4	PH-036023-006	Plug, Magnetic Hex
5	PH-036325	Plug & O-Ring Assembly
6	PH-403007	Pulley (5")
7	PH-411134	Breather
8	PH-411154	Filter
9	PH-420004	Fan (7")
10	PH-SK000328	SA, RTN
11	PH-477036	Fan Spacer
12	PH-490169	Brake Assembly
13	PH-490214	Drum Assembly, 4 Bolt, 1" Shaft

LH Transmission 618-06080



Ref.	Part Number	Description
1	PH-020207	Flange Head Screw
2	PH-025136	Nut
3	PH-025167	Nut, Flange 1/2-20 UNF
4	PH-036023-006	Plug, Magnetic Hex
5	PH-036325	Plug & O-Ring Assembly
6	PH-403007	Pulley (5")
7	PH-411134	Breather
8	PH-411154	Filter
9	PH-420004	Fan (7")
10	PH-SK000328	SA, RTN
11	PH-477036	Fan Spacer
12	PH-490169	Brake Assembly
13	PH-490214	Drum Assembly, 4 Bolt, 1" Shaft


Kawasaki FX850V Cylinder/Crankcase



Ref.	Part Number	Description
11004	KM-11004-7025	Gasket-Head
11008	KM-11008-7036	Head-Comp-Cylinder
11008A	KM-11008-7037	Head-Comp-Cylinder
11022	KM-11022-6008	Case-Rocker
11022A	KM-11022-7025	Case Rocker
11061	KM-11061-0899	Gasket, Case Rocker
11061A	KM-11061-7081	Gasket, Breather
13272	KM-13272-7004	Plate, Breather
14091	KM-14091-7060	Cover, Breather
16126	KM-16126-7020	Valve, Breather
32154	KM-32154-7019	Pipe
49015	KM-49015-7088	Cover-Crankcase
49120	KM-49120-0724	Crankcase-Comp
59071	KM-59071-2079	Joint
92043	KM-92043-7024	Pin


Ref.	Part Number	Description
92049	KM-92049-7019	Seal-Oil,So 8x14x5 HS
92049A	KM-92049-7020	Seal, Oil, 7x15x13
92049B	KM-92049-7024	Seal-Oil,SD 40x54x9 R HS
92049C	KM-92049-7026	Seal-Oil,SD 40x62x8 L VS
92066	KM-92066-0762	Plug
92153	KM-92153-7043	Bolt, 6x12
130	KM-130BA0650	Bolt-Flanged, 6x50
130A	KM-130CA1050	Bolt-Flanged, 10x50
130B	KM-130CA1060	Bolt-Flanged, 10x60
172	KM-172BA0818	Bolt-Stud, 8x18
214	KM-214AA0408	Screw-Pan+-,4x8
411	KM-411AA1000	Washer, 10MM
601	KM-601A6308	Bearing-Ball
670	KM-670B2011	O Ring, 11MM

Kawasaki FX850V Piston/Crankshaft



Ref.	Part Number	Description
13001	KM-13001-7025	Piston-Engine
13002	KM-13002-7005	Pin-Piston
13008	KM-13008-6069	Ring-Set-Piston
13031	KM-13031-7079	Crankshaft-Comp
13251	KM-13251-7031	Rod-Assy-Connecting
92033	KM-92033-7017	Ring-Snap
92153	KM-92153-2054	Bolt,7x35.2


Kawasaki FX850V Valve/Camshaft



Ref.	Part Number	Description
11055	KM-11055-7009	Bracket
12004	KM-12004-7010	Valve-Intake
12005	KM-12005-0711	Valve-Exhaust
12009	KM-12009-7004	Retainer-Valve Spring
12011	KM-12011-2052	Collet
12016	KM-12016-7016	Arm-Rocker
12032	KM-12032-7001	Tappet
13070	KM-13070-0758	Guide
13116	KM-13116-7006	Rod-Push
13272	KM-13272-7002	Plate
13272A	KM-13272-7003	Plate,Governor
42036	KM-42036-7019	Sleeve

Ref.	Part Number	Description
49078	KM-49078-7008	Spring-Engine Valve
49118	KM-49118-7026	Camshaft-Comp
92033	KM-92033-7012	Ring-Snap
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring
92152	KM-92152-1689	Collar
92153	KM-92153-7100	Bolt, 6x29.5
92200	KM-92200-2151	Washer, 8.1x18x0.5
92200A	KM-92200-7044	Washer, 20.3x29x2.28
92200B	KM-92200-7045	Washer, 20x46x0.91
130	KM-130AA0814	Bolt-Flanged, 8x14
312	KM-312AA0600	Nut-Hex, 6MM


Kawasaki FX850V Lubrication Equipment



Ref.	Part Number	Description
13107	KM-13107-0749	Shaft
13272	KM-13272-7005	Plate
14075	KM-14075-0033	Cap-Assy
16154	KM-16154-1075	Rotor-Pump,Outer
16154A	KM-16154-1076	Rotor-Pump,Inner
16154B	KM-16154-1079	Rotor-Pump
49065	KM-49065-7004	Filter Oil
49065A	KM-49065-7010	Filter Oil
59051	KM-59051-7011	Gear-Spur


Ref.	Part Number	Description
59071	KM-59071-7023	Joint
59231	KM-59231-7014	Filler
92043	KM-92043-7003	Pin
92066	KM-92066-7003	Plug
92066A	KM-92066-7006	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7043	Bolt, 6x12
670	KM-670D2016	O-Ring, 16MM

Kawasaki FX850V Cooling Equipment



Ref.	Part Number	Description
11055	KM-11055-7005	Bracket
13272	KM-13272-7006	Plate, Fan
14037	KM-14037-70299H	Screen
27012	KM-27012-7009	Hook, Lift
39067	KM-39067-7007	Cooler-Oil
49089	KM-490897064753	Shroud-Engine
49089A	KM-490897065753	Shroud-Engine
49089B	KM-49089-7066	Shroud-Engine, Rear
49089C	KM-490897067753	Shroud-Engine, V-Bank
55020	KM-55020-70169H	Guard
59041	KM-59041-7019	Fan



Ref.	Part Number	Description
59066	KM-590667042753	Housing-Fan
92151	KM-92151-7012	Bolt, 6x12
92153	KM-92153-0010	Bolt
92153A	KM-92153-7007	Bolt
92153B	KM-92153-7043	Bolt, 6x12
92153C	KM-92153-7101	Bolt
92171	KM-92171-7015	Clamp
92192	KM-92192-7089	Tube
92192A	KM-92192-7090	Tube
130	KM-130AA0620	Bolt-Flanged, 6x20



Ref.	Part Number	Description
21066	KM-21066-7011	Regulator-Voltage
21171	KM-21171-0711	Coil-Assy-Ignition
21193	KM-21193-7049	Flywheel-Assy
26031	KM-26031-7033	Harness
26031A	KM-26031-7034	Harness
59031	KM-59031-7010	Coil-Charging
92066	KM-92066-0762	Plug
92070	KM-BPR4ES	Plug-Spark,RCJ8Y,Solid

Ref.	Part Number	Description
92072	KM-92072-7003	Band
92153	KM-92153-7029	Bolt
92154	KM-92154-7003	Bolt, 12x30
92172	KM-92172-7018	Screw, 5x20
92200	KM-92200-7040	Washer, 12.2x46x3
130	KM-130AA0620	Bolt-Flanged, 6x20
510	KM-510A5100	Key-Woodruff

Kawasaki FX850V Carburetor




Kawasaki FX850V Carburetor

Ref.	Part Number	Description
11009	KM-11009-2056	Gasket
11061	KM-11061-7037	Gasket
11061A	KM-11061-7038	Gasket
11061B	KM-11061-7039	Gasket
11061C	KM-11061-7070	Gasket, Head/Manifold
11061D	KM-11061-7091	Gasket, Carburetor/Pipe
11061E	KM-11061-7092	Gasket, Carburetor/Manifold
14091	KM-14091-7031	Cover
15004	KM-15004-0865	Carburetor - Assy
16025	KM-16025-7010	Valve-Throttle
16030	KM-16030-7004	Valve-Float
16031	KM-16031-7003	Float
16041	KM-16041-7025	Shaft-Carburetor
16041A	KM-16041-7039	Shaft-Carburetor
16073	KM-16073-7011	Insulator
16126	KM-16126-7021	Valve
16184	KM-16184-7023	Chamber - Assy - Float
16187	KM-16187-7005	Needle-Jet
21188	KM-21188-7003	Solenoid
59076	KM-59076-7013	Manifold-Intake
92004	KM-92004-7028	Stud, 6x120
92009	KM-92009-7003	Screw
92009A	KM-92009-7004	Screw

Ref.	Part Number	Description
92009B	KM-92009-7006	Screw, Drain
92026	KM-92026-7024	Spacer
92043	KM-92043-7014	Pin
92055	KM-92055-7013	Ring-O
92055A	KM-92055-7013	Ring-O
92055B	KM-92055-7016	Ring-O
92055C	KM-92055-7024	Ring-O
92063	KM-92063-7110	Jet-Main, #118
92063A	KM-92063-7111	Jet-Main, #120
92063B	KM-92063-7135	Jet-Main, #115
92063C	KM-92063-7136	Jet-Main, #112
92063D	KM-92063-7137	Jet-Main, #117
92063E	KM-92063-7138	Jet-Main, #114
92066	KM-92066-7009	Plug, Expansion
92093	KM-92093-7001	Seal
92093A	KM-92093-7002	Seal
92145	KM-92145-7010	Spring
92145A	KM-92145-7011	Spring
92152	KM-92152-7005	Collar
92172	KM-92172-7005	Screw
92172A	KM-92172-7006	Screw
130	KM-130AA0635	Bolt-Flanged, 6x35


Kawasaki FX850V Control Equipment



Ref.	Part Number	Description
11055	KM-11055-7001	Bracket
13107	KM-13107-7047	Shaft, Governor
13271	KM-13271-7038	Plate
16169	KM-16169-7020	Link-Choke
16171	KM-16171-7020	Link
39129	KM-39129-7020	Spring-Governor
49103	KM-49103-7012	Arm-Governor
49103A	KM-49103-7018	Arm-Governor
49113	KM-49113-7060	Panel-Comp-Control
92009	KM-92009-2381	Screw,5x30
92145	KM-92145-7044	Spring

Ref.	Part Number	Description
92145A	KM-92145-7055	Spring
92150	KM-92150-2182	Bolt,5x18
92153	KM-92153-0009	Bolt,6x12
92153A	KM-92153-7033	Bolt,6x35
92153B	KM-92153-7043	Bolt,6x12
92171	KM-92171-7018	Clamp
92172	KM-92172-7033	Screw, 4x8
311	KM-311AA0600	Nut-Hex, 6MM
312	KM-312AA0500	Nut-Hex, 5MM
411	KM-411AA0600	Washer-Plain


Kawasaki FX850V Air Filter/Muffler




Ref.	Part Number	Description
11010	KM-11010-7028	Filter-Assy-Air
11011	KM-11011-7056	Case-Air Filter
11013	KM-11013-7044	Element-Air Filter
11013A	KM-11013-7045	Element-Air Filter
11054	KM-11054-70139X	Bracket
11054A	KM-11054-70169X	Bracket
11055	KM-11055-70079X	Bracket
11060	KM-11060-7016	Gasket-Muffler
11065	KM-11065-7025	Cap
11065A	KM-11065-7031	Cap
11065B	KM-11065-7032	Cap
16060	KM-16060-0723	Pipe-Intake
92015	KM-92015-1367	Nut

Ref.	Part Number	Description
92066	KM-92066-0095	Plug
92153	KM-92153-7043	Bolt, 6x12
92170	KM-92170-2042	Clamp
92173	KM-92173-7003	Clamp
92173A	KM-92173-1001	Clamp
92173B	KM-92173-7011	Clamp
92192	KM-92192-7086	Tube
92192A	KM-92192-7166	Tube
92210	KM-92210-7027	Nut, M8
130	KM-130AA06120	Bolt, Flanged, 6x120
130A	KM-130AA0816	Bolt, Flanged, 8x16
461	KM-461DA0800	Washer-Spring, 8MM

Kawasaki FX850V Fuel Tank/Valve



Ref.	Part Number	Description
23062	KM-23062-7018	Bracket-Comp
49019	KM-49019-0014	Filter-Fuel
49040	KM-49040-7001	Pump-Fuel
92153	KM-92153-7043	Bolt, 6x12
92170	KM-92170-2009	Clamp
92192	KM-92192-7088	Tube, 6.4 x 12.7x28.5
92192A	KM-92192-7169	Tube, 6.35x12.7x140
92192B	KM-92192-7173	Tube, 6.35x12.7x195
130	KM-130AA0620	Bolt-Flanged, 6x20



Ref.	Part Number	Description
13081	KM-13081-7001	Clutch-Assy
13091	KM-13091-2068	Holder, Brush
13168	KM-13168-2148	Lever, Shift
16073	KM-16073-2098	Insulator
16146	KM-16146-2077	Coaver-Assy
16146A	KM-16146-7029	Cover-Assy
21039	KM-21039-2059	Brush
21040	KM-21040-2052	Spring-Brush
21080	KM-21080-2058	Armature
21163	KM-21163-7025	Starter-Electric

Ref.	Part Number	Description
27010	KM-27010-7005	Switch
27012	KM-27012-7005	Hook, Lift
32085	KM-32085-2097	Stopper
92002	KM-92002-2277	Bolt
92015	KM-92015-2146	Nut
92015A	KM-92015-2147	Nut
92033	KM-92033-2081	Ring-Snap
92210	KM-92210-2085	Nut
130	KM-130AA0830	Bolt-Flanged, 8x30

Kawasaki FX850V Labels

56014



56033



56070



Ref.	Part Number	Description
56014	KM-56014-0706	Emblem
56033	KM-56033-7001	Label-Manual
56070	KM-56070-7001	Label-Warning

[illegible]

[illegible]

[illegible]



To order replacement parts, call a Customer Support Representative at (800) 965-4CUB.
Locate your nearest Cub Cadet dealer at (877) 282-8684
or visit www.cubcadet.com to find the nearest Cub Cadet dealer in your area.

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
