




Parts Manual



SERIES 7000 COMPACT TRACTOR MODEL 7254

CUB CADET LLC P.O. BOX 361131 CLEVELAND, OHIO 44136-0019 [www.cubcadet.com]


PRINTED IN U.S.A.
ECO12842

FORM NO. 769-00091B
(2/03)

TABLE OF CONTENTS


DESCRIPTION	PAGE
Frame	3
Pedestal	4
Front Axle 4WD	5
4WD Axle Assembly	6
Hydraulics	10
Lift Valve and Position Control	11
Dash Panel and Steering Wheel	12
Controls	14
Battery and Electrical	16
Transmission Connections	17
Transmission	
4WD Transmission	18
Differential and Final Drive	20
4WD Traction Drive	22
PTO Drive	24
Engine and Drive Shaft	26
Engine	
Cylinder Heads and Crankcase	28
Pistons and Crankshaft	30
Valves and Camshaft	31
Lubrication	32
Electrical	33
Cooling	34
Control Linkage and Governor	36
Carburetor	37
Air Filter	38
Starter	39
Hood, Grill and Side Panels	40
Fender and Running Board	42
Seat Assembly	44
Fuel Tank	45
Foldable ROPS	46
Three Point Hitch	47
Auxiliary Hydraulic Loader Valve (If Equipped)	48
Wheels	50

FRAME




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0666		Frame	1
2	703-3503A		Lever, Hood Latch	1
3	703-3497A		Bracket, Running Board Mtg. LH	1
4	703-3379A		Bracket, Running Board Mtg. RH ...	1
5	703-05137		Bracket, Hood Latch Mtg.	1
6	710-3083		Screw, Hex Cap, 5/16-18 x 1.375 GR5	3
7	710-0451		Screw, Carriage, 5/16-18 x .75	2
8	710-1260A		Screw, Hex Wash. Hd. 5/16-18 x .75	6
9	712-3004A		Nut, Hex Flange Lock, 5/16-18	5
10	726-0455		Latch, Hood	1

PEDESTAL




REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.
1	703-3383A	Pedestal	1	11	710-3008	Screw, Hex Cap	2
2	703-3717	Bracket, Dash Mtg. RH	1			5/16-18 x .75 GR5	
3	703-3721	Bracket, Dash Mtg. LH	1	12	711-1361	Shaft, Steering	1
4	703-3725	Bracket, Steering Column	1	13	712-0292	Nut, Speed, 1/4-20	2
5	703-3895	Bracket, Brake Lever	1	14	712-0411	Nut, Hex Nylon Insert Lock,	4
6	703-4064	Bracket, Pump Mtg.	1			5/16-24 GR8	
7	710-0623	Screw, Hex Wash, Hd Tapp	4	15	712-3004A	Nut, Hex Flange Lock, 5/16-18	2
		3/8-16 x .75		16	714-0104	Pin, Internal Cotter	4
8	710-0642	Screw, Hex Wash, Hd Tapp	4	17	716-0101	Ring, Snap, .75 ID	1
		1/4-20 x .75		18	718-3129	Pump, Hydraulic Steering	1
9	710-0653	Screw, Hex Wash, Hd Tapp	4	19	731-3359	Lever, Parking Brake	1
		1/4-20 x .375		20	736-0343	Washer, Flat, .33 x 1.25 x .12 ...	2
10	710-1260A	Screw, Hex Wash, Hd Tapp	3	21	741-0245	Bearing, Hex Flange, .75 ID	1
		5/16-18 x .75		22	747-3454	Pin, Parking Brake Pivot	1
				23	747-3543A	Rod, Parking Brake	1

FRONT AXLE 4WD



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0735	0637	Plate, Steering Cylinder Mtg.	1
2	618-3207		Axle Assembly, Front 4WD	1
3	710-1843		Screw, Hex Cap, M12-1.75 x 25.GR8	4
4	710-3006		Screw, Set, 5/16-18 x 3/8	1
5	710-3067		Screw, Hex Cap, 1/2-13 x 1.75 GR5	12
6	711-1410		Stud, Cylinder Mtg.	1
7	712-3016		Nut, Hex Nylon Insert Lock 5/8-11 GR5	2
8	712-3083		Nut, Hex Nylon Insert Lock 1/2-13 GR8	12
9	712-3107		Nut, Hex Lock, 3/4-10	1
10	717-3502		Cylinder, Steering	1
11	717-3513A		Shaft, Drive 4WD	1
12	719-3158		Bracket, Axle Mtg.	2


4WD AXLE ASSEMBLY



4WD AXLE ASSEMBLY

REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	IM-326021860	Housing Assembly, Axle Includes Ref. No. 2	1	27	IM-040106206	Bearing, Ball	2
2	IM-030500820	Pin, Dowel	4	28	IM-036100030	Ring, Snap	2
3	IM-326345040	Housing, Axle LH	1	29	IM-330310712	Kingpin	2
4	IM-398400440	Gauge, Oil Level	1	30	IM-334525190	Arm, Steering LH	1
5	IM-322013110	Housing Assembly, Pinion Gear .. Includes Ref. No. 2	2	31	IM-334525200	Arm, Steering RH	1
6	IM-052300400	O-Ring	2	32	IM-011511025	Bolt, M10 x 25	12
7	IM-040136204	Bearing, Ball	2	33	IM-011511030	Bolt, M10 x 30	4
8	IM-040106303	Bearing, Ball	2	34	IM-011510820	Bolt, M8 x 20	12
9	IM-036500047	Ring, Snap	2	35	IM-011510825	Bolt, M8 x 25	8
10	IM-326240290	Gear, Final Pinion Idler	4	36	IM-010311035	Bolt, M10 x 35	2
11	IM-322511091	Shaft, Idler Drive	2	37	IM-010301212	Bolt, M12 x 12	3
12	IM-052300650	O-Ring	2	38	IM-020900008	Nut, M8	2
13	IM-322117840	Housing, Final Drive LH	1	39	IM-399234470	Collar	2
14	IM-322117850	Housing, Final Drive RH	1	40	IM-010310825	Bolt, M8 x 25	2
15	IM-326240280	Gear, Final Drive Pinion	2	41	IM-334712010	Rod, Tie	1
16	IM-042532006	Bearing, Tapered	2	42	IM-334801170	Tie Rod End, LH	1
17	IM-040106006	Bearing, Ball	2			Includes Ref. Nos. 44 thru 46	
18	IM-050600038	Seal, Oil	2	44	IM-334810207	Cover, Dust	2
19	IM-064600016	Plug	2	45	IM-334810209	Nut, Castle, M12 x 1.25	2
20	IM-025100016	Washer, Seal	2	46	IM-030103025	Pin, Cotter	2
21	IM-025100012	Washer, Seal	3	47	IM-334801150	Tie Rod End, RH	1
22	IM-322212311	Housing, Final Drive	2			Includes Ref. Nos. 44 thru 46	
23	IM-326312330	Wheel Hub/Shaft	2	48	IM-020109029	Nut, Jam, LH Thrd	1
24	IM-326370450	Gear, Final Drive	2	49	IM-020800014	Nut, Jam, M14 RH Thrd	1
25	IM-050609043	Seal, Oil, 35mm x 55mm x 15mm	2	50	IM-025100020	Washer, Seal	1
26	IM-040106205	Bearing, Ball	2	51	IM-040106304	Bearing, Ball	2
				52	IM-199280540	Shim, 0.2T	AR
				53	IM-199280550	Shim, 0.5T	AR


4WD AXLE ASSEMBLY



4WD AXLE ASSEMBLY


REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	IM-322017890	Mtg. Bracket, Axle Front Includes Ref. No. 2	1
2	IM-398510090	Bushing	1
3	IM-322017900	Mtg. Bracket, Axle Rear Includes Ref. No. 4	1
4	IM-398510450	Bushing	1
5	IM-050301140	Seal, Oil	1
6	IM-399261550	Washer, Thrust	1
7	IM-050309056	Seal, Oil	1
8	IM-399261580	Washer, Thrust	1
9	IM-060620000	Fitting, Grease	2
10	IM-395910030	Shim Kit, Service Only	1
11	IM-399234160	Collar	1
12	IM-052100210	O-Ring	1
13	IM-020109079	Nut	1
14	IM-326211011	Shaft, Differential LH	1
15	IM-326211021	Shaft, Differential RH	1
16	IM-199280630	Shim, 0.1T	AR
17	IM-199280640	Shim, 0.2T	AR
18	IM-199280650	Shim, 0.5T	AR
19	IM-040106305	Bearing, Ball	1
20	IM-399211140	Spacer	1
21	IM-040156305	Bearing, Ball	1
22	IM-326110490	Housing, Differential	1
23	IM-399310150	Plate, Locking	3
24	IM-010110816	Bolt, M8 x 16	6
25	IM-326130160	Shaft, Pinion	1
26	IM-030300540	Pin, Spring	1
27	IM-322050621	Gear Set, Ring and Pinion	1
28	IM-326160060	Gear, Pinion	2
29	IM-399261070	Washer, Thrust	2
30	IM-326140200	Gear, Differential	2
31	IM-040106304	Bearing, Ball	2
32	IM-399211130	Spacer	1
33	IM-199281030	Shim, 0.1T	AR
34	IM-199281040	Shim, 0.2T	AR
35	IM-199281050	Shim, 0.5T	AR
36	IM-399260530	Washer, Thrust	1
37	IM-199281240	Shim, 0.1T	AR
38	IM-199281250	Shim, 0.2T	AR
39	IM-199280430	Shim, 0.5T	AR
40	IM-042530205	Bearing, Tapered Roller	2
41	IM-050209004	Seal, Oil	1

HYDRAULICS




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	710-0607		Screw, Hex Wash Hd. Tapp 5/16-18 x .5	9	9	727-3178		Hose, Oil Return	1
2	712-3004A		Nut, Hex Flange Lock, 5/161-18 GR5	2	10	727-3182		Tube, Lift Return Line	1
3	726-0132		Clamp, Adjustable Hose	2	11	727-3184		Hose, Lift Cylinder	1
4	726-04004		Clamp, Hose	5	12	727-3185A		Hose, Lift Inlet	1
5	726-0475		Clamp, Hose	5	13	727-3187A		Hose, Steering Pressure	1
6	727-3012		Fitting, 90 Degree	3	14	727-3188A		Hose, Steering Tank	1
7	727-3168		Hose, Steering	2	15	727-3199		Manifold, Return	1
8	727-3177		Tube, Oil Cooler Return	1	16	727-3209		Tube, Cylinder Return	1
					17	737-3127		Fitting, 90 Degree	1

LIFT VALVE AND POSITION CONTROL



REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.
1	603-0663	Link Assembly, Feedback	1	17	712-3004A	Nut, Hex Flange Lock, 5/16-18 GR5	2
2	603-04091	Link Assembly, Input	1	18	712-3029	Nut, Hex Jam, 1/2-20 GR5	2
3	603-04085	Link, HI-LO Shifter	1	19	715-0120	Pin, Spirol, 3/16 x 1.0	1
4	703-3360	Link, Feedback	1	20	718-3130	Valve, Hydraulic Lift	1
5	703-3610	Bracket, Lift Brace	1	21	723-3013	Washer, Friction, .515 x 1.5 x .12	1
6	703-04084	Bracket, Valve Mtg.	1	22	731-3321	Grip, Handle	2
7	703-3698A	Handle, HI-LO Shifter	1	23	732-0330	Spring, Compression	1
8	703-3762	Bracket, Lift Mtg.	1	24	732-0499	Spring, Compression	1
9	703-3763A	Handle, Lift	1	25	736-3019	Washer, Flat, .531 x 1.062 x .134	1
10	710-0564	Screw, Hex Cap, 1/4-20 x 2.75 GR5	3	26	736-3022	Washer, Belleville,53 x 1.375 x .06	2
11	710-0607	Screw, Hex Wash Hd. Tapp 5/16-18 x .5	7	27	719-3013	Clevis, Adjustment	1
12	710-3008	Screw, Hex Cap, 5/16-18 x .75 GR5	2	28	741-3084	Bearing, Nylon Flange .75 ID	2
13	711-1316	Ferrule, Feedback Adjustment ..	2	29	747-3394	Rod, Feedback	1
14	711-1612	Pin, .25 x 1.0	1	30	747-04131	Rod, HI-LO Connecting	1
15	711-1614	Link, Valve	1	31	603-04086	Shaft, HI-Lo Shifter	1
16	712-0324	Nut, Hex Nylon Insert Lock 14-20 GR8	7	32	712-3058	Nut, Hex Nylon Lock, 1/2-20	1
				33	714-0104	Pin, Internal Cotter	2


DASH PANEL AND STEERING WHEEL



DASH PANEL AND STEERING WHEEL

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0711		Tab Assembly, Throttle	1
2	629-3061		Wire Harness, Dash	1
3	631-0076		Boot, Steering Shaft	1
4	631-04007A		Dash	1
5	703-05132		Plate, Throttle Mtg.	1
6	710-0604A		Screw, Hex Wash. Hd. Tapp 5/16-18 x .625	2
7	710-0924		Screw, Pan Hd., 1/4-20 x .75	4
8	710-3013		Screw, Hex Cap, 1/4-20 x .5 GR5 ..	6
9	712-0237		Nut, Hex Lock, 5/16-24	1
10	712-0292		Nut, Speed, 1/4-20	2
11	712-0116		Nut, Hex Insert Jam Lock, 3/8-24	1
12	723-3013		Washer, Friction, .515 x 1.5 x .12 ..	1
13	725-2017		Plug	1
14	725-3265		Panel, Instrument	1
	725-3285		Bulb	12
	735-0688		Plug	12
15	725-3274		Switch, Headlight	1
16	725-3276		Switch, PTO	1
17	725-3277		Switch, Ignition	1
18	725-3279		Switch, Hazard	1
19	731-3209		Steering Wheel, Soft Grip	1
20	731-3210		Cover, Steering Wheel	1
21	731-3298		Handle, Throttle	1
22	731-3344		Panel, Dash Insert	1
23	736-0242		Washer, Belleville, .34 x .872 x .06	1
24	736-0329		Washer, Lock, 1/4	3
25	736-0112		Washer, Belleville, .531 x 1.62 x .045	2
26	736-3052		Washer, Flat, .406 x 1.0 x .105	1
27	746-3086A		Cable, Throttle	1
28	759-3950		Key Set, Ingition	1


CONTROLS



CONTROLS

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0671		Shaft Assembly, Brake	1	33	714-3020		Pin, Internal Cotter	1
2	603-0672		Shaft Assembly, Forward	1	34	725-3164A		Switch, Plunger	1
3	603-0673A		Link Assembly, Pedal	1	35	725-3191A		Switch, Plunger	1
4	603-0674A		Plate, Bearing	1	36	727-04033		Cylinder, Damper	1
5	603-0678		Link Assembly, Brake LH	1	37	731-3296		Pedal, Brake	1
6	603-0679A		Link Assembly, Parking Brake ..	1	38	731-3299A		Pedal, Forward/Reverse	1
7	603-0680		Link Assembly, Brake RH	1	39	731-3320		Pedal, Differential	1
8	603-0749		Shaft Assembly, Differential	1	40	731-3321		Grip, Handle	1
9	603-0770		Link, PTO Select	1	41	732-0324		Spring, Compression	2
10	703-3152		Bracket, Reverse Switch	1	42	732-0756A		Spring, Torsion	1
11	703-3541		Bracket, Differential Pivot	1	43	732-0859		Spring, Rev/No Cut	1
12	703-3571		Handle, PTO	1	44	732-3065		Spring, Compression	1
13	703-3575		Link, Differential Pivot	1	45	732-3117		Spring, Switch Actuator	1
14	703-3582		Bracket, Diff. Actuator Mtg.	1	46	732-3118		Spring, Extension	1
15	703-4099		Bracket, Reverse Switch	1	47	736-0173		Washer, Flat, .28 x .74 x .063 ...	3
16	710-0599		Screw, Hex Wash Hd Tapp	2	48	736-0185		Washer, Flat, .375 x .738 x .063	2
			1/4-20 x .5		49	736-0232		Washer, Wave, .53 x .78 x .013	1
17	710-0642		Screw, Hex Wash Hd Tapp	4	50	736-3019		Washer, Flat, .53 x .1.06 x .134	3
			1/4-20 x .75		51	736-3069		Washer, Flat, .53 x .875 x .15 ...	1
18	710-1260A		Screw, Hex Wash Hd Tapp	12	52	738-0509		Screw, Shoulder, .50 x 1.825	1
			5/16-18 x .75		53	738-0533		Screw, Shoulder, .498 x 1.635	1
19	710-0654A		Screw, Hex Wash Hd Tapp	2	54	738-0689		Screw, Shoulder	1
			3/8-16 x 1.0					1/2 x .180: 3/8-24	
20	711-0415		Pin, Clevis, 3/8 x 1.75	1	55	741-0491		Bearing, Nylon, .50 ID x .341	2
21	711-0723A		Ferrule, 3/8-24 x .375 Dia. Hdn	3	56	741-0598		Bearing, Hex Flange, .752 ID	2
22	711-1362		Ferrule, Brake	3	57	741-3073		Bearing, Flange, .375 x .58 x .25	2
23	711-3397		Ferrule, 3/8-24 x .37	1	58	741-3074		Bearing, Flange.....	2
24	712-0239		Nut, Hex Lock, 1/2-20	3				.626 x .938 x .344	
25	712-0379		Nut, Hex Flange Lock, 3/8-24 ...	1	59	741-3084		Bearing, Flange.....	2
26	712-0431		Nut, Hex Flange Lock, 3/8-16 ...	1				.751 x 1.125 x .375	
27	712-0711		Nut, Hex Jam, 3/8-24	1	60	747-3396		Rod, Hydro Control	1
28	712-3027		Nut, Hex Flange Lock, 1/4-20 ...	3	61	747-3399		Rod, Brake, LH	1
29	712-3077		Nut, Hex, M8 x 1.25 GR8.8	2	62	747-3400		Rod, Brake, RH	1
30	713-3000		Link, Chain	1	63	747-3414		Rod, PTO Control	1
31	714-0104		Pin, Internal Cotter	11	64	747-3428		Rod, Diff. Lock Control	1
32	714-0147		Pin, Internal Cotter	2					


BATTERY AND ELECTRICAL



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
†	629-3060		Harness, Main Wire	1
2	703-4104	0637	Strap, Battery Holddown	1
3	703-4131		Bracket, Fuse Center	1
4	710-0206		Screw, Hex Cap, 1/4-10 x .875 GR5	2
5	710-0599		Screw, Hex Wash Hd. Tapp	2
			1/4-20 x .5	
6	712-0324		Nut, Hex Nylon Insert Lock, 1/4-20	2
7	712-0421		Nut, Wing w/Bell Washer, 5/16-18	2
8	725-3174		Battery, 500 cca Dry	1
9	725-3273		Switch, PTO Reverse Override	1
10	747-3433		Rod, Battery Holddown	2


† Not Shown

TRANSMISSION CONNECTIONS



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0748	0637	Bracket, Lower Hitch RH	1	12	710-3039		Screw, Hex Cap	4
2	603-0751	0637	Bracket, Lower Hitch LH	1	13	710-3067		Screw, Hex Cap	2
3	603-0753	0637	Bracket, Top Link	1	14	710-3119		Screw, Hex Cap	6
4	603-0754A	0637	Bracket, Cylinder	1	15	710-3131		Screw, Hex Cap	10
5	603-0758	0637	Bracket, Drawbar	1	16	711-1503		Pin, Lift, .75 x 2.125	1
6	703-3542A		Shield, PTO	1	17	712-3063		Nut, Hex Lock, 5/8-18	8
7	777S30634		Graphic, Warning	1	18	716-0101		Ring, Snap, 75 Dia	1
8	703-3548A		Bracket, Chain LH	1	19	717-3504		Cylinder, Lift	1
9	703-3549A		Bracket, Chain RH	1	20	736-0192		Washer, Flat, .531 x .93 x .09	2
10	710-0505		Screw, Hex Cap	4	21	703-05133		Bracket, Hitch Clip	1
11	710-0964A		Screw, Hex Cap	8	22	747-04109		Rod, Top Link Retainer	1
	710-1515		Screw, Hex Cap	1					

4WD TRANSMISSION




4WD TRANSMISSION

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
†	618-04059		Service Transmission Ass'y. — See Note below.	1	21	716-0111		Ring, Retaining	1
	737-3025		Transmission Oil, 1 Qt.	6.5 gal.	22	716-0195		Ring, Retaining	1
	737-3062		Transmission Oil, 1 Gal.		23	717-3507		Pump, Hydrostatic Transmission	1
	737-3035		Transmission Oil, 5 Gal.		24	718-3131		Pump, Auxiliary Hydraulic	1
	759-3958		Sealant, Loctite® Black, 5.3 oz.	AR	25	719-3166		Arm, Upper Hitch RH	1
1	603-0688A		Arm, Hydro Control	1	26	719-3167		Arm, Upper Hitch LH	1
2	603-0712A		Bracket, Transmission Mtg. RH	1	27	721-0501		O-Ring, 2.987 ID x .103 Dia	1
3	603-0713A		Bracket, Transmission Mtg. RH	1	28	721-0510		Seal, Oil, 1.5 x 2.0 x .25	2
4	619-3059		Cover, Transmission Housing ..	1	29	723-0405		Filter, Oil	1
5	703-3577		Plate, Feedback	1	30	723-3014		Filter, Oil	1
6	703-3715		Baffle, Oil	1	31	723-3021		Breather, Transmission	1
7	703-05041		Arm, Neutral RH	1	32	725-3272		Sensor, RPM	1
8	703-05042		Arm, Neutral LH	1	33	727-3012		Fitting, 90°	2
9	710-0294		Screw, Hex Cap,	4	34	727-3176		Tube, Auxiliary Pump Suction ..	1
			1/4-20 x .375 GR5		35	727-3181		Tube, Hydro Suction	1
10	710-0591		Screw, Hex Cap Lock,	1	36	731-04018		Grommet	1
			3/8-24 x 1.0 GR5		37	732-1162		Spring, Extension	1
11	710-0833		Screw, Hex Cap,	4	38	736-3052		Washer, Flat, .406 x 1.0 x .105 .	2
			5/16-18 x 5.25 GR5		39	737-0146		Fitting, Grease	1
12	710-1633		Screw, Plug, M14 x 1.5 x .827 ..	1	40	737-0349		Plug, Fitting	2
13	710-1853		Screw, Hex Special Set,	1	41	737-3105		Fitting, Filter Nipple	1
			5/16-18 x .625		42	737-3108		Fitting, 90°	1
14	710-3005		Screw, Hex Cap,	4	43	737-3111		Fitting, 90°	1
			3/8-16 x 1.25 GR5		44	737-3112		Fitting, Straight	1
15	710-3013		Screw, Hex Cap,	2	45	737-3113		Fitting, Straight	2
			1/4-20 x .5 GR5		46	738-0108		Screw, Shoulder, .498 Dia x 1.45	1
16	710-3032		Screw, Hex Cap,	6	47	738-0430		Screw, Shoulder, .50 Dia x .685	1
			1/2-13 x 1.25 GR5		48	738-04001		Screw, Shoulder,	4
17	710-3120		Screw, Hex Cap Lock ,	9				.625 x .18: 1/2-13	
			3/8-16 x 1.5 GR5		49	741-1110		Bearing, Sleeve,	2
18	710-3262		Screw, Low Hd. Cap,	2				1.52 x 1.75 x 1.0	
			3/8-16 x .75		50	750-1208		Spacer, .40 x 1.0 x 3.9	4
19	711-1355		Shaft, Rock	1	51	750-1239		Spacer, 1.52 x 2.25 x .188	2
20	712-0431		Nut, Hex Flange Lock, 3/8-16 ...	2	52	737-04018		Dipstick	1

† DOES NOT include the following components and their associated mounting hardware: Brake Assemblies; Hydro Pump w/Filter and Linkage; Transmission Mounting Brackets; 3 Point Hitch Rock Shaft and Arms; and RPM Sensor. Also DOES NOT include the hydraulic tubes and fittings.


DIFFERENTIAL AND FINAL DRIVE



DIFFERENTIAL AND FINAL DRIVE

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	619-3060		Housing, Axle	2
2	661-3014		Brake Assembly, Drum	2
3	710-0538		Screw, Hex Cap Lock, 5/16-18 x .625 GR5	10
4	710-1695		Screw, Socket Hd. Cap, 3/8-16 x 1.0 ...	4
5	710-3119		Screw, Hex Cap Lock, 3/8-16 x .75 GR5	4
6	710-3238		Screw, Hex Cap Lock, 7/16-14 x 1.75 GR5	24
7	711-1326		Shaft, Axle Stub RH	1
8	711-1327		Shaft, Axle	2
9	711-1358		Shaft, Axle Stub LH	1
10	711-1389A		Shaft, Differential Lock Actuator	1
11	715-0226		Pin, Dowel, .3752 x .75	8
12	715-3010		Pin, Dowel, .25 x .75	4
13	716-0180		Ring, Retaining	2
14	716-0195		Rjng, Retaining	2
15	716-0196		Ring, Retaining	2
16	716-0390		Ring, Retaining	2
17	716-0391		Ring, Retaining	4
18	716-0396		Clip, Rotor	1
19	716-0397		Ring, Retaining	1
20	717-1120		Gear, Differential, 10T	4
21	717-1173		Shaft, Cross	1
22	717-1178		Shaft, Cross	2
23	717-1180		Block, Differential Pinion	1
24	717-3316		Gear, Bevel, 65T	1
25	717-3317		Gear, Miter, 14T	2
26	717-3471		Gear, Drop Axle, 42T RH	1
27	717-3478		Gear, Drop Axle, 42T LH	1
28	718-0666		Carrier, Differential	1
29	718-3104		Collar, Differential Lock	1
30	718-3105		Yoke, Differential Lock	1
31	718-3112		Cover, Bearing	1
32	721-0495		Seal, Oil, 50mm x 75 mm x 10mm	2
33	721-0496		Seal, Oil	1
34	721-3020A		Seal, Oil, 1.181 x 2.453 x .276	2
35	732-0187		Spring, Compression	1
36	736-0355		Washer, Flat, .56 x 1.0 x .04	1
37	736-0715		Washer, Thrust, 1.12 x 1.75 x .03	4
38	741-0721		Bearing, Ball	2
39	741-1104		Bearing, Ball	2
40	741-1107		Bearing, Ball	2
41	741-1112		Bearing, Thrust	2
42	741-3033A		Bearing, Ball	2
43	741-3080		Bearing, Needle	1
44	761-3071		Drum, Brake	2


4WD TRACTION DRIVE



4WD TRACTION DRIVE

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0906		Pin Assembly, 2 Speed	1
2	710-0573		Screw, Hex Cap Lock, 5/16-18 x 1.25 GR5	4
3	710-3006		Screw, Cup Set, 5/16-18 x 3/8	1
4	711-1339		Shaft, Motor	1
5	711-1344		Shaft, Pinion, 16T	1
6	711-1372		Shaft, 4WD	1
7	711-1397		Shaft, 2 Speed Actuator	1
8	715-0159		Pin, Spirol, 3/16 x .875	1
9	716-0185		Ring, Retaining	1
10	716-0384		Ring, Retaining	1
11	716-0387		Ring, Retaining	1
12	716-0393		Ring, Retaining	1
13	716-0396		Clip, Rotor	1
14	717-3472		Gear, Drive Pinion, LO 24T:17T	1
15	717-3473		Gear, Drive Pinion, HI 33T: 17T	1
16	717-3480		Gear, Drive, LO:59T; HI 50T	1
17	717-3484		Clutch, Overrunning	1
18	718-0674		Cover, Front	1
19	718-0678		Spacer, Drive	1
20	718-3116		Collar, 2 Speed	1
21	721-0496		Seal, Oil	1
22	721-0501		O-Ring	1
23	721-0507		Seal, Oil	1
24	732-0863		Spring, Detent	1
25	736-0715		Washer, Thrust	1
26	741-0862		Ball, Detent	1
27	741-1106		Bearing, Ball	1
28	741-1107		Bearing, Ball	1
29	741-1109		Bearing, Angular Contact Ball	1
30	741-1112		Bearing, Thrust	1
31	741-3037		Bearing, Ball	1
32	741-3057		Bearing, Ball	1
33	741-3118		Bearing, Sleeve	2
34	748-3096		Yoke, 2 Speed	1


PTO DRIVE



PTO DRIVE

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	618-3189		Clutch Assembly, PTO	1	31	718-3116		Collar, 2 Speed	1
2	619-3076A		Housing, Rear	1	32	718-3134		Coupling, PTO	1
3	710-0538		Screw, Hex Cap Lock,	6	33	719-0551A		Actuator, PTO	1
			5/16-18 x .625 GR5		34	721-0496		Seal, Oil	1
4	710-1238		Screw, Hex Wash Hd,	2	35	721- 0497		Seal, Oil	1
			5/16-18 x .875 GR5		36	721-0500		O-Ring	1
5	710-3006		Screw, Cup Set, 5/16-18 x 3/8 ..	1	37	721-0504		Plug, Oil	1
6	710-3013		Screw, Hex Cap, 1/4-20 x .5 GR5	1	38	721-0509		Seal, Oil	1
7	710-3118		Screw, Hex Cap Lock,	9	39	721-3020A		Seal, Oil	1
			3/8-16 x 1.0 GR5		40	732-0187		Spring, Compression	1
8	710-04003		Screw, Round Hd, 6mm x 40mm	6	41	732-0863		Spring, Detent	1
9	711-1325		Shaft, 540 PTO	1	42	732-0980		Spring, Compression	1
10	711-1337		Shaft, Input	1	43	736-0355		Washer, Flat, .56 x 1.0 x .040 ...	1
11	711-1345		Shaft, 2000 PTO	1	44	736-0463		Washer, Flat,	1
12	711-1371		Shaft, PTO Back	1				.25 x .630 x .0515	
13	711-1373		Shaft, PTO Actuator	1	45	736-0615		Washer, Thrust,	2
14	716-0180		Ring, Retaining	4				1.007 x 1.542 x .03	
15	716-0200		Ring, Retaining	1	46	741-0724		Bearing, Sleeve,	1
16	716-0201		Ring, Retaining	1				20mm x 23mm x 20mm	
17	716-0384		Ring, Retaining	1	47	741-0862		Ball, Detent	1
18	716-0393		Ring, Retaining	1	48	741-0991		Bearing, Sleeve,	2
19	716-0397		Ring, Retaining	1				13mm x 15mm x 10mm	
20	716-3001		Ring, Retaining	1	49	741-1100		Bearing, Ball	1
21	717-3469		Gear, 540 PTO: 81T	1	50	741-1118		Bearing, Needle	1
22	717-3479		Gear, Auxiliary Drive Idler: 28T .	1	51	741-3033A		Bearing, Ball	5
23	717-3487		Gear, 2000 PTO: 61T	1	52	741-3037		Bearing, Ball	2
24	717-3490		Gear, Auxiliary Drive Pinion: 28T	1	53	741-3057		Bearing, Ball	3
25	717-3491		Gear, Auxiliary Drive: 32T	1	54	741-3083		Bearing, Needle Thrust	1
26	717-3492		Gear, 540 PTO Pinion: 14T	1	55	748-3094		Arm, PTO Select	1
27	717-3494B		Gear, 2000 PTO Pinion: 54T	1	56	750-1223		Spacer, 13mm x 20mm x 14mm	1
28	717-3500		Gear, 2000 PTO Pinion: 34T	1	57	750-1228		Spacer, .80 x 1.85 x .855	1
29	718-0668		Gear, Spline Coupling	1	58	736-0570		Washer, Flat, .865 x 1.145 x .03	1
30	718-0681		Cover, 2000 PTO	1	59	750-0532		Spacer, .980 x 1.25 x .420	1

ENGINE AND DRIVE SHAFT




ENGINE AND DRIVE SHAFT

REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.
†	629-3063	Harness, Engine	1	23	717-3498	Shaft, Drive	1
1	703-3521A	Plate, Engine Mtg.	1	24	718-3132	Cooler, Oil	1
2	703-3684	Bracket, Filler Neck	1	25	722-3022	Tape, Foam, .625 wide	42in.
3	703-3688	Bracket, Radiator Mtg. RH .	1	26	723-3061	Seal, Heat Baffle	96in.
	777S30632	Graphic, Warning	1	27	725-3282	Wire, Battery Neg.	1
4	703-3689	Bracket, Radiator Mtg. LH .	1	28	725-3289	Wire, Battery Pos.	1
	777S30632	Graphic, Warning	1	29	726-0154	Tie, Cable - Push Mount	4
5	703-3691	Plate, Radiator Baffle	1	30	726-0205	Clamp, Hose	7
	777S30631	Graphic, Fan Warning	1	31	726-0476	Clamp, Hose - Adjustable ..	1
	777S30633	Graphic, Warning	1	32	726-0480	Clamp, Hose	6
6	703-3692	Bracket, Radiator Mtg.	1	33	731-04018	Grommet	2
7	703-3722	Bracket, Ovrflw Bottle Mtg.	1	34	731-3364	Shroud, Fan	1
8	703-05140	Plate, Baffle RH	1	35	735-0226	Grommet	2
9	703-05141	Plate, Baffle LH	1	36	736-0173	Washer, Flat,	7
10	703-4063	Shield, Heat	1			.28 x .74 x .063	
11	710-0357	Screw, Square Hd. Set,	2	37	746-04015	Cable, Choke Control	1
		3/8-16		38	751-3130	Fuel Line 5/16 ID	94in.
12	710-0514	Screw, Hex Cap,	4	39	751-3166	Muffler	1
		3/8-16 x 1.0 GR5		40	751-3177	Hose, Filler to Radiator	1
13	710-0597	Screw, Hex Cap,	2	41	751-3185	Radiator	1
		1/4-20 x 1.0 GR5		42	751-3187	Hose, Lower Radiator	1
14	710-0599	Screw, Hex Wash Hd Tapp	4	43	751-3189	Hose, Engine to Filler Neck	1
		1/4-20 x .5		44	751-3190	Filler Neck, Remote Radiator	1
15	710-0607	Screw, Hex Wash Hd Tapp	12	45	751-3192	Cap, Remote Filler	1
		5/16-18 x .5		46	751-3193	Screen, Radiator	1
16	710-0623	Screw, Hex Wash Hd Tapp	4	47	751-3203	Hose, Intake Air	1
		3/8-16 x .75		48	KM-49040-2065	Pump, Fuel	1
17	710-1260A	Screw, Hex Wash Hd Tapp	8	49	KM-49019-1055	Filter, Fuel	1
		5/16-18 x .75		50	KM-11060-2467	Gasket, Exhaust	2
18	710-1376	Screw, Hex Cap, M8-20 x 16	1	51	KM-461F0800	Washer, Spring	4
19	710-3015	Screw, Hex Cap,	9	52	KM-317R0800	Nut, Hex	4
		1/4-20 x .75 GR5		53	KM-92038-2101	Key, Crankshaft	1
20	710-3208	Screw, Hex Cap,	6	54	KM-43078-2055	Bottle, Over Flow	1
		M10 x 1.5 x 25		55	KM-39062-2086	Tube	1
21	712-0324	Nut, Hex Nylon Insert Lock	11				
		1/4-20 GR8					
22	712-0431	Nut, Hx Flng Lock, 3/8-16	4				

† Not Shown


CYLINDER HEADS AND CRANKCASE



CYLINDER HEADS AND CRANKCASE


REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11004-2142	Gasket, Head	2
2	KM-11008-2145	Head, Cylinder	1
3	KM-11008-2146	Head, Cylinder	1
4	KM-11022-2072	Cover, Rocker	1
5	KM-11022-2073	Cover, Rocker	1
6	KM-11060-2466	Gasket, Breather	1
7	KM-11060-2470	Gasket, Rocker Cover	2
8	KM-13271-2105	Plate, Breather	2
9	KM-14091-2064	Cover, Breather	1
10	KM-16126-2225	Valve, Breather	2
11	KM-49015-6239	Cover, Crankcase	1
12	KM-49120-6127	Crankcase, (Includes Ref. Nos. 13 and 19)	1
13	KM-59071-2079	Joint	1
14	KM-92009-2308	Screw	2
15	KM-92043-1037	Pin	6
16	KM-92049-2242	Seal, Oil	1
17	KM-92049-2243	Seal, Oil	1
18	KM-92093-2086	Seal	1
19	KM-92141-2118	Bearing, Plane	1
20	KM-92141-2119	Bearing, Plane	1
21	KM-92151-2158	Bolt, M8 x 55	4
22	KM-92151-2159	Bolt, M8 x 80	8
23	KM-92170-2002	Clamp	2
24	KM-92191-2105	Tube	1
25	KM-130G0630	Bolt, Flange	8
26	KM-130G0830	Bolt, Flange	4
27	KM-130G0845	Bolt, Flange	6
28	KM-130G0860	Bolt, Flange	4
29	KM-172G0822	Bolt, Stud	4
30	KM-670B2011	O-Ring	3

PISTONS AND CRANKSHAFT




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-13001-2125	Piston	2
2	KM-13002-2069	Pin, Piston	2
3	KM-13008-6007	Ring Set, Piston	2
4	KM-13251-2058	Rod, Connecting	2
		(Includes Ref No. 8 [Qty. 2])	
5	KM-49119-2198	Crankshaft Assembly	1
		(Includes Ref Nos. 6 and 9)	
6	KM-59051-2358	Gear, Spur, 33T	1
7	KM-92036-008	Ring, Snap	4
8	KM-92151-2150	Bolt, 7 x 36	4
9	KM-510A5100	Key, Woodruff	1

VALVES AND CAMSHAFT




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11051-2092	Bracket	2	10	KM-49078-2060	Spring, Valve	4
2	KM-12004-2113	Valve, Intake	2	11	KM-49118-2138	Camshaft	1
3	KM-12005-2100	Valve, Exhaust	2	12	KM-92049-2100	Seal, Oil	4
4	KM-12009-2060	Retainer, Valve Spring	4	13	KM-92145-2085	Spring	1
5	KM-12011-2052	Collet	8	14	KM-92151-2165	Bolt, M6	4
6	KM-12016-2063	Arm, Rocker	4	15	KM-92152-2077	Collar	4
7	KM-12032-2060	Tappet	4	16	KM-92200-2128	Washer, 8.1 x 18 x .5	4
8	KM-13116-2074	Rod, Push	4	17	KM-130G0814	Bolt, Flanged	4
9	KM-16007-2052	Seat, Spring	4	18	KM-311B0600	Nut, Hex	4

LUBRICATION




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11009-2566	Gasket, Drain Plug	2	12	KM-59051-2354	Gear, Spur, 33T	1
2	KM-13107-2281	Shaft, Oil Pump	1	13	KM-99969-1395	Drain, Oil	1
3	KM-13280-2061	Holder, Oil Pump	1	14	KM-92042-014	Pin	2
4	KM-14091-2065	Cover, Oil Pump	1	15	KM-92066-2099	Plug, Drain	2
5	KM-16115-2126	Cap, Oil Filler	1	16	KM-92144-2053	Spring	1
6	KM-16154-1075	Rotor, Pump Outer	1	17	KM-130G0616	Bolt, Flanged	3
7	KM-16154-1076	Rotor, Pump Inner	1	18	KM-130G0625	Bolt, Flanged	2
8	KM-32153-20769H	Pipe, Oil Gauge	1	19	KM-600A1300	Ball, Steel	1
9	KM-49065-2078	Filter, Oil	1	20	KM-670B2010	O-Ring	1
10	KM-49065-2082	Filter, Oil Suction	1	21	KM-670B3025	O-Ring	1
11	KM-52005-2132	Gauge, Oil	1				

ELECTRICAL



REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11009-2766	Gasket	1	16	KM-92037-2101	Clamp	1
2	KM-11052-2068	Bracket	1	17	KM-BPR2ES	Plug, Spark	2
3	KM-14083-2055	Cover, Flywheel	1	18	KM-92072-1195	Band	1
4	KM-21066-2079	Regulator, Voltage	1	19	KM-92151-2097	Bolt, 12 x 30	1
5	KM-21121-2090	Coil, Ignition, No. 1	1	20	KM-92170-2060	Clamp	4
6	KM-21121-2091	Coil, Ignition, No. 2	1	21	KM-92171-2060	Clamp	1
7	KM-21193-2177	Flywheel Assembly	1	22	KM-92200-2119	Washer, 12.2 x 40 x 3.0	1
8	KM-26004-1093	Fuse	1	23	KM-130G0520	Bolt, Flanged	4
9	KM-26030-2326	Harness (Includes Ref. No. 8) .	1	24	KM-130G0630	Bolt, Flanged	2
10	KM-27010-2170	Switch	1	25	KM-130G0812	Bolt, Flanged	2
11	KM-27010-2182	Switch	1	26	KM-130G0816	Bolt, Flanged	2
12	KM-590331-2127	Coil, Charging	1	27	KM-130G0820	Bolt, Flanged	4
13	KM-92009-2273	Screw	4	28	KM-214B0510	Screw, Pan	1
14	KM-92022-2104	Washer	2	29	KM-241B0406	Screw, Pan	1
15	KM-92027-1568	Collar, 8.3 x 11.5 x 9	4	30	KM-510A5100	Key, Woodruff	1


COOLING



COOLING


REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11009-3028	Gasket	2
2	KM-11060-2475	Gasket, Thermostat	1
3	KM-13107-2097	Shaft, Impeller	1
4	KM-13107-2246	Shaft, Pulley	1
5	KM-13304-6010	Housing Assembly Includes Ref. Nos. 23, 25 & 45	1
6	KM-16142-2077	Cover, Pump	1
7	KM-16160-2127	Body, Upper	1
8	KM-16160-6001	Body, Valve	1
9	KM-39062-2084	Hose, Cooling	1
10	KM-39062-2088	Hose, Cooling	1
11	KM-39062-2089	Hose, Cooling	1
12	KM-41077-2064	Adapter	1
13	KM-49044-2063	Pump Assembly, Water	1
14	KM-49054-2058	Thermostat	1
15	KM-49063-1054	Seal, Mechanical	1
16	KM-59011-2058	Belt	1
17	KM-59041-2092	Fan	1
18	KM-59051-2355	Gear, Spur, 25T	1
19	KM-59091-2054	Pulley	1
20	KM-59091-20559H	Pulley	1
21	KM-59256-2069	Impeller	1
22	KM-59336-2078	Case, Pump	1
23	KM-92026-2311	Spacer, 12 x 18 x 1.4	1
24	KM-92043-2237	Pin	1
25	KM-92045-2191	Bearing, Ball	2
26	KM-92049-2111	Seal, Oil	1
27	KM-92170-1284	Clamp	2
28	KM-92171-2056	Clamp	4
29	KM-92180-2013	Shim, T=0.6	AR
30	KM-92180-2014	Shim, T=1.2	AR
31	KM-92200-2134	Washer	1
32	KM-92200-2135	Washer 10.2 x 19 x 0.8	1
33	KM-130C0812	Bolt, Flanged	2
34	KM-130G0625	Bolt, Flanged	3
35	KM-130G0635	Bolt, Flanged	6
36	KM-130G0820	Bolt, Flanged	3
37	KM-130G0830	Bolt, Flanged	2
38	KM-130G0835	Bolt, Flanged	4
39	KM-130G0845	Bolt, Flanged	1
40	KM-130G0860	Bolt, Flanged	2
41	KM-130G0880	Bolt, Flanged	4
42	KM-315B1000	Nut, Hex Fine	1
43	KM-410B1000	Washer, Plain	1
44	KM-461F0800	Washer, Spring	3
45	KM-481J2800	Circlip	1
46	KM-551A0314	Pin, Dowel	1
47	KM-670B1507	O-Ring	1

CONTROL LINKAGE AND GOVERNOR




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11051-2113	Bracket	1	18	KM-92037-2209	Clamp	2
2	KM-13168-2466	Lever, Throttle	1	19	KM-92143-2135	Collar, 6 x 13 x 2.3	2
3	KM-13168-2467	Lever, Choke	1	20	KM-92143-2148	Collar	1
4	KM-16169-2142	Link, Choke	1	21	KM-92144-2052	Spring	1
5	KM-16171-2091	Link	1	22	KM-92145-2058	Spring	1
6	KM-21187-2073	Arm Assembly	1	23	KM-92145-2095	Spring	1
7	KM-39003-2091	Arm, Governor Pivot	1	24	KM-92150-2182	Bolt, 5 x 18	2
8	KM-39129-2099	Spring, Governor	1	25	KM-92200-2035	Washer	1
9	KM-42036-2060	Sleeve	1	26	KM-92200-2108	Washer, 6.5 x 22 x 1.2	2
10	KM-49110-2094	Gear Assembly, Governor	1	27	KM-92200-2120	Washer, 8.3 x 16 x 2.3	1
11	KM-49113-2170	Panel, Control Complete	1	28	KM-92200-2122	Washer, 6.2 x 30 x 0.5	1
12	KM-92002-1902	Bolt	1	29	KM-130B0630	Bolt, Flanged	2
13	KM-92002-2269	Bolt	1	30	KM-130G0614	Bolt, Flanged	2
14	KM-92009-2381	Screw, 5 x 30	2	31	KM-311B0600	Nut, Hex	1
15	KM-92015-1339	Nut	2	32	KM-312B0500	Nut, Hex	2
16	KM-92022-2372	Washer, 6 x 19 x 1.2	1	33	KM-411B0600	Washer, Plain	1
17	KM-92027-1461	Collar	1	34	KM-482J7000	Circlip, E-Ring	1

CARBURETOR




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11060-2468	Gasket, Intake Manifold	1	14	KM-23013-2063	Screw Assembly	1
2	KM-11060-2469	Gasket, Intake Manifold	1	15	KM-59076-2065	Manifold, Intake	1
3	KM-11060-2471	Gasket, Intake Pipe	2	16	KM-92037-1610	Clamp	1
4	KM-11061-2075	Gasket	1	17	KM-92063-2353	Jet, Main, #110	1
5	KM-15003-2786	Carburetor Assembly	1		KM-92063-2410	Jet, Main, #105	AR
6	KM-16060-2194	Pipe, Intake	1		KM-92063-2420	Jet, Main, #107.5	AR
7	KM-16073-2206	Insulator	1	18	KM-92063-2370	Jet, Main, #111.3	1
8	KM-16146-2227	Cover Assembly	1		KM-92063-2380	Jet, Main, #106.3	AR
9	KM-16183-2006	Float Assembly	1		KM-92063-2421	Jet, Main, #108.8	AR
10	KM-16184-2007	Chamber, Float	1	19	KM-92064-2106	Jet, Pilot, #45	2
11	KM-16185-2041	Valve Assembly, Throttle	1	20	KM-130G0825	Bolt, Flanged	8
12	KM-16186-2036	Valve Assembly, Choke	1	21	KM-130T06110	Bolt, Flanged	4
13	KM-23013-2059	Screw Assembly	1	22	KM-701Q061000	Tube, PVC	1

AIR FILTER




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11011-2314	Case, Air Filter Body	1
2	KM-11011-2315	Case, Air Filter Upper	1
3	KM-11011-2316	Case, Air Filter Lower	1
4	KM-11013-2195	Element, Air Filter	1
5	KM-11013-2194	Precleaner, Foam	1
6	KM-11051-2088	Bracket	1
7	KM-11051-2089	Bracket, Air Filter	1
8	KM-11061-2085	Gasket, Air Filter	1
9	KM-92004-2152	Stud, 6 x 30	1
10	KM-92015-2138	Nut	1
11	KM-92093-2113	Seal	1
12	KM-92200-2136	Washer	1
13	KM-92210-2079	Nut	1
14	KM-130G0614	Bolt, Flanged	3
15	KM-130G0630	Bolt, Flanged	3
16	KM-317R0800	Nut, Hex	1
17	KM-461F0800	Washer, Spring	1

STARTER



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11012-2226	Cap	1
2	KM-13081-2108	Clutch Assembly	1
3	KM-13091-2068	Holder, Brush	1
4	KM-13168-2131	Lever, Shift	1
5	KM-14024-2205	Cover	1
6	KM-16073-2098	Insulator	1
7	KM-16146-2187	Cap, Starter End	1
8	KM-16146-2225	Cone, Starter Nose	1
9	KM-21039-2059	Brush	4
10	KM-21040-2052	Spring, Brush	4
11	KM-21080-2054	Armature	1
12	KM-21163-2120	Starter, Electric	1
13	KM-27010-2122	Solenoid, Starter	1
14	KM-32085-2097	Stopper	1
15	KM-92002-2277	Bolt	2
16	KM-92015-2146	Nut	2
17	KM-92015-2147	Nut	1
18	KM-92033-2081	Ring, Snap	1
19	KM-130G0835	Bolt, Flanged	2
20	KM-317B0800	Nut, Hex	2
21	KM-461F0800	Washer, Spring	2


HOOD, GRILL AND SIDE PANELS



HOOD, GRILL AND SIDE PANELS

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0719	0637	Hinge Assembly, Hood	1
2	603-0784	0637	Bracket, Side Panel Mtg. RH	1
3	603-0785	0637	Bracket, Side Panel Mtg. LH	1
4	603-0924	0637	Bracket, Side Panel Mtg. RH Rear	1
5	603-0925	0637	Bracket, Side Panel Mtg. LH Rear	1
6	625-0052		Headlight Assembly	1
	725-3161A		Bulb, Headlight	4
7	703-3394		Screen, Intake	1
8	703-3712		Shield, Upper Heat	1
9	703-3764		Bracket, Panel Mtg.	1
10	703-3765		Shield, Lower Heat	1
11	710-0473		Screw, Truss Hd, 10-24 x .5	6
12	710-0599		Screw, Hex Wash Hd Tapp	14
			1/4-20 x .5	
13	710-0751		Screw, Hex Cap, 1/4-20 x .62 GR5	4
14	710-3170		Stud, Cylinder, 5/16-18 Thrd	4
15	712-0272		Nut, Hex Sems, 10-24	6
16	712-0324		Nut, Hex Nylon Insert Lock, 1/4-20	4
17	712-0431		Nut, Hex Flange Lock, 3/8-16	2
18	712-3004A		Nut, Hex Flange Lock, 5/16-18	4
19	726-3056		Latch, 1/4 Turn Panel	4
20	727-3194		Cylinder, Gas Spring	2
21	731-3277		Hood	1
	777D05419		Graphic, Hood RH	1
	777D05420		Graphic, Hood LH	1
	777D06178		Graphic, Model 7254 PosiTrak RH	1
	777D06179		Graphic, Model 7254 PosiTrak LH	1
22	731-3278		Panel, Side RH	1
23	731-3279		Panel, Side LH	1
24	732-0936		Clip, Spring	4
25	732-0937		Spring, Compression	4
26	736-0272		Washer, Flat, .510 x .93 x .060	2
27	738-0380		Screw, Shoulder, .5 x .27 Lg 3/8-16	2
28	726-04010		Clip, Retaining	1


FENDER AND RUNNING BOARD



FENDER AND RUNNING BOARD


REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	625-0023B		Light Assembly, Rear RH	1
	725-3262		Bulb Only, Tail Light	1
	725-3263		Bulb Only, Reverse Indicator Light	1
	629-3059		Harness, Tail Light	1
2	625-0024B		Light Assembly, Rear RH	1
	725-3262		Bulb Only, Tail Light	1
	725-3263		Bulb Only, Reverse Indicator Light	1
	629-3059		Harness, Tail Light	1
3	703-3451		Bracket, Seat Mtg. LH	1
4	703-3572		Bracket, Seat Mtg. RH	1
5	703-3754		Bracket, Rear Seat Support	1
6	710-0604A		Screw, Hex Wash Hd. Tapp	8
			5/16-18 x .625	
7	710-3038		Screw, Hex Cap	4
			5/16-18 x .875 GR5	
8	710-0206		Screw, Hex Cap	4
			1/4-20 x .875 GR5	
9	710-3021		Screw, Hex Wash Hd. Tapp	3
			5/16-18 x .625	
10	710-3008		Screw, Hex Cap	2
			5/16-18 x .75 GR5	
11	710-1242		Screw, Truss Phillips Hd.	8
			5/16-14 x .75	
12	710-1260A		Screw, Hex Wash Hd. Tapp	3
			5/16-18 x .75	
13	710-0971		Screw, Pan Hd. 5/16-18 x 1.0	2
14	726-3057		Clip, Tail Light	4
15	726-3046		Clip, Ratchet Fastener	12
16	726-0211		Speed Nut, 'U' Type, 5/16-18	6
17	731-3324		Cover, Fender	1
	777S30630		Graphic, Warning	1
18	731-3289		Fender	1
	777S30635		Graphic, Warning	1
	777D06181		Graphic, Series 7000	1
19	631-04005		Cover, Fender, RH	1
20	631-04006		Cover, Fender, LH	1
21	735-0669		Pad, Floor, RH	1
22	735-0670		Pad, Floor, LH	1
23	735-0690		Grommet, .4375 ID x .75	4
24	736-3089		Washer, Flat, .345 x 1.0 x .100	4
25	750-3310		Spacer, Flange, .3125 x .4375 x .625	4
26	750-04143		Spacer, .258 x .5 x .5	4

SEAT ASSEMBLY




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0860	0637	Support, Seat - Upper	1
2	603-0866		Track Ass'y., Seat w/Latch	1
3	703-3208		Track Ass'y., Seat w/o Latch	1
4	703-3681A		Tray, Lower Seat	1
5	703-3711		Bracket, Seat Belt	2
6	710-0376		Screw, Hex Cap, 5/16-18 x 1.0 GR5	2
7	710-0451		Screw, Carriage, 5/16-18 x .75	4
8	710-0528		Screw, Hex Cap, 5/16-18 x 1.25 GR5	2
9	710-0759		Screw, Hex Flange,	4
			5/16-18 x .625 GR5	
10	710-3250		Screw, Socket Hd Cap, 5/16-18 x 1.5	4
11	712-3004A		Nut, Hex Flange Lock, 5/16-18	12
12	725-3167		Switch, Snap Mount (N.O.)	1
13	732-3080A		Spring, Compression, 1.28 x 3.5	2
14	738-0140		Screw, Shoulder, .435 x .178-5/16-18	4
15	750-0258		Spacer, .315 x .750 x .375	4
16	757-04006		Seat, High Back	1
	777D04541		Graphic, Cub Cadet	1
	777D01782		Graphic, USA	1
17	757-3013		Belt Assembly, Seat	1

FUEL TANK




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	703-3563		Bracket, Front Tank Mtg.	1
2	710-0817		Screw, Hex Wash Hd Tapp 5/16-18 x 1.25	4
3	710-1260A		Screw, Hex Wash Hd Tapp 5/16-18 x .75	3
4	736-0231		Washer, Flat, .344 x 1.125 x .12	4
5	751-3124B		Cap, Fuel	1
6	751-3175		Sensor, Fuel Level	1
7	751-3200A		Tank, Fuel	1

FOLDABLE ROPS




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0716		ROPS Assembly, Lower	1
2	603-0717		ROPS Assembly, Upper	1
3	603-0858		Mounting Assembly, ROPS RH	1
4	603-0861		Mounting Assembly, ROPS LH	1
5	710-0376		Screw, Hex Cap, 5/16-18 x 1.0 GR5	2
6	710-0515		Screw, Hex Cap, 1/2-20 x 3.5 GR5	2
7	710-3032		Screw, Hex Cap, 1/2-13 x 1.25 GR5	8
8	710-3131		Screw, Hex Cap, 1/2-13 x 1.0 GR5	8
9	711-1610		Pin, Clevis, .5 x 3.5	2
10	712-3046		Nut, Hex Jam, 5/16-18	2
11	712-3058		Nut, Hex Nylon Insert Lock, 1/2-20	2
12	712-3066		Nut, Hex, 1/2-20 GR5	2
13	714-3003		Pin, Internal Cotter	2
14	725-3280		Light Assembly, Hazard	2
	725-3286		Bulb, Light	2
15	736-0921		Washer, Lock, 1/2	2
16	731-0757-16		Conduit	16in.

THREE POINT HITCH



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0750		Link, Lower Hitch	2	11	712-0301		Nut, Hex, 3/4-10 GR5	2
2	603-0756		Link, Lift - Fixed	1	12	712-3058		Nut, Hex Insert Lock, 1/2-20	2
3	603-0757		Link, Lift - Adjustable	1	13	714-0117		Pin, Internal Cotter, .148 x 3.0 ..	2
4	603-0765		Link, Upper Center	1	14	714-0147		Pin, Internal Cotter, .125 x 1.75	2
5	603-0933		Chain Assembly, Check	2	15	714-0149B		Pin, Internal Cotter	4
6	711-0174		Pin, Clevis, .624 Dia.	2	16	736-0156		Washer, Flat, .635 x 1.12 x .09	2
7	711-1105		Pin, Klik, 1.75 Lg.	2	17	736-0262		Washer, Flat, .385 x .87 x .09	2
8	711-1432		Pin, Upper Lift Arm	2	18	736-0364		Washer, Lock, 3/4	2
9	711-1622		'U' Clevis, Check Chain	2	19	703-3553		Bar, Draw	1
10	711-1648		Pin, Clevis, .75 x 2.75	2	20	747-04014		Pin, Double Clevis	2


AUXILIARY HYDRAULIC LOADER VALVE (IF EQUIPPED)



AUXILIARY HYDRAULIC LOADER VALVE (IF EQUIPPED)

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	603-0813	Pivot Bracket Assembly	1
2	603-0862	Valve Handle Assembly	1
3	703-3598-0637	Loader Valve Mount Bracket	1
4	703-3972-0637	Fitting Mount Plate	1
5	703-3973-0637	Rear Fitting Mount Plate	1
6	710-0501	Hex Screw, 1/4-20, 2.00, Gr5	2
7	710-0599	Hex Wash. Hd. Tapp Screw	2
		1/4-20 x .50	
8	710-0604A	Hex Wash. Hd. Tapp Screw	2
		5/16-18 x .625	
9	710-1260A	Hex Wash. Hd. Tapp Screw	4
		5/16-18 x .75	
10	711-1611	Valve Pivot Shaft	1
11	711-1624	Valve Spool Link	1
12	711-1637	Ball Joint Pivot Stud	1
13	711-1642	Clevis Pin, .199 x .8125	1
14	712-0256	Jam Nut, 5/16-24, Gr2	2
15	712-0324	Hex Lock Nut, 1/4-20, Gr8, Nylon	2
16	713-3000	Chain Link	1
17	714-0104	Internal Cotter Pin	1
18	716-0865	Snap Ring, .5	2
19	718-3138	Auxiliary Hydraulic Pump	1
	759-3964	Pin, Dowel	2
	759-3965	Bolt, Mounting	4
	759-3966	Coupler, Splined	1
20	718-3140	Loader Control Valve	1
21	723-0488	Ball Joint, .3125 Id x 5/16-24	1
22	727-3012	Fitting, 90° 6-6 Orb	2
23	727-3206	Tube, Tandem Pump Suction	1
24	727-3210	Tube, Hydraulic - Bucket Rollback	1
25	727-3211	Tube, Hydraulic - Bucket Dump ..	1
26	727-3212	Tube, Hydraulic - Boom Lift	1
27	727-3213	Tube, Hydraulic - Boom Lower ...	1
28	727-3224	Coupling, Male Hydraulic, 3/8-18	2
29	727-3225	Coupling, Female Hydr. 3/8-18 ...	2
30	727-3226	Tube, Auxiliary Pump Pressure ..	1
31	727-3227	Tube, Valve Pressure	1
32	727-3228	Tube, Valve Return	1
33	727-3229	Tube, Valve Return	1
34	727-3261	Plug, Hydraulic Coupler - Male ...	2
35	727-3262	Plug, Hydraulic Coupler - Female	2
36	731-3353	Knob, 1.625 Dia x 3/8-16 Thd	1
37	731-3374	Washer, Indicator - Red	1
38	731-3375	Washer, Indicator - Yellow	1
39	731-3376	Washer, Indicator - Green	1
40	731-3377	Washer, Indicator - Blue	1
41	735-0696	Joystick Boot	1
42	737-3111	Fitting, 90° -8 Orb	1
43	737-3112	Fitting, Straight -8 Orb	2
44	737-3113	Fitting, Straight	2
45	737-3125	Fitting, Straight - 6 Orb	2
46	737-3129	Fitting, Bulkhead 3/4-16 x 3/8-18	4
47	737-3130	Fitting, Bulkhead 3/4-16 x 3/4-16	2
48	750-0845	Spacer, .34 ID x .5 OD x .31	1

WHEELS



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	634-3045		Rim, TURF Tire - Front	2
	634-04018		Rim, INDUSTRIAL Tire - Front	2
	734-0255		Valve Stem	2
2	734-3122		Tire, Turf	2
	734-04020		Tire, Industrial	2
3	634-3046		Rim, TURF Tire - Rear	2
	634-04017		Rim, INDUSTRIAL Tire - Rear	2
	734-0255		Valve Stem	2
4	734-3124		Tire, Turf	2
	734-04013		Tire, Industrial	2
5	710-1808		Screw, Lug, M12	10
6	710-3294		Bolt, Lug, M14 x 1.5 x 20	12

NOTES
