



Parts Manual



SERIES 5000 COMPACT TRACTOR MODEL 5254

CUB CADET LLC P.O. BOX 361131 CLEVELAND, OHIO 44136-0019 [www.cubcadet.com]

PRINTED IN U.S.A.


FORM NO. 769-00878B

(4/05)

TABLE OF CONTENTS


DESCRIPTION	PAGE
Frame	3
Pedestal	4
Axle, Front	5
4WD Axle Assembly	6
Hydraulics	10
Lift Valve	11
Dash Panel and Steering Wheel	12
Controls	14
Battery and Electrical	16
Transmission Mounting	17
Transmission	
4WD Transmission Connections	18
Transmission Drive	20
PTO Drive	22
Hydrostatic Transmission	24
Engine and Drive Shaft	26
Engine	
Cylinder Heads and Crankcase	28
Pistons and Crankshaft	30
Valves and Camshaft	31
Lubrication	32
Electrical	33
Cooling	34
Control Linkage and Governor	36
Carburetor	37
Air Filter	38
Starter	39
Hood, Grill and Side Panels	40
Fender and Running Board	41
Seat Assembly	42
Fuel Tank	43
Three Point Hitch	44
Foldable ROPS	46
Deck Lift	47
Wheels	48

FRAME




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0961A	0637	Frame	1	16	710-1260A		Screw, Hex Wash. Hd., 5/16-18 x .75	25
2	703-05031	0637	Bracket, Front Seat Mount	1	17	710-3005		Screw, Hex Cap, 3/8-16 x 1.25 GR5	2
3	703-05782		Bracket, Hood Latch Mtg. ...	1	18	710-3015		Screw, Hex Cap, 1/4-20 x .75 GR5	4
4	703-05714	0637	Bracket, Fitting Mtg.	1	19	712-04064		Nut, Hex Nylon Flange Lock, 1/4-20 GRF	2
5	703-05737	0637	Shield, Drive Shaft	1	20	712-3000		Nut, Hex Lock, 3/8-20 GrB.	2
6	703-05741		Keeper, Belt	1	21	712-04063		Nut, Hex Flange Insert Lock, 5/16-16 GrF	2
7	703-05743	0637	Bracket, Aux. Pump Mtg. ...	1	22	718-04129		Bushing, Tapered	1
8	703-05748	0637	Shield, Lower Drive Shaft ..	1	23	718-04130		Pump, Aux. Hydraulic	1
9	703-05771A	0637	Plate, Filter Mounting	1	24	726-0211		Nut, U Speed, 5/16-18	4
10	703-4124A	0637	Bracket, Running Brd. Mtg. ...	1	25	726-0475		Clamp	1
11	703-4125A	0637	Bracket, Running Brd. Mtg. ...	1	26	736-0329		Washer, Lock, 1/4	2
12	710-3025		Screw, Hex Cap, 5/16-18 x .625 GR5	2	27	754-04086		Belt, HTS, 5 x 25 x 500	1
13	710-0473		Screw, Truss Hd. Mach. #10-24 x .5	3	28	756-04176		Pulley, 52T Cog	1
14	710-0607		Screw, Hex Wash. Hd Tapp 5/16-18 x .5	1	29	736-0722		Washer, Lock, #10	3
15	710-1194		Screw, Hex Mach. #10-24 x 1.0 GR5	3					

PEDESTAL




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-04001A		Shaft, Steering	1	13	710-3008		Screw, Hex Cap	2
2	703-3383D	0637	Pedestal	1				5/16-18 x .75 GR5	
3	703-3717	0637	Bracket, Dash Mtg. RH	1	14	712-0292		Nut, Speed, 1/4-20	2
4	703-3721	0637	Bracket, Dash Mtg. LH	1	15	712-3004A		Nut, Hex Flange Lock, 5/16-18	2
5	703-05361	0637	Bracket, Steering Column	1	16	714-0104		Pin, Internal Cotter	4
6	703-3895		Bracket, Brake Lever	1	17	718-3155		Pump, Hydraulic Steering	1
7	703-4154	0637	Bracket, Pump Mtg.	1	18	731-3359		Lever, Parking Brake	1
8	710-0623		Screw, Hex Wash, Hd Tapp	4	19	732-3002		Spring, Extension	1
			3/8-16 x .75		20	736-0343		Washer, Flat, .33 x 1.25 x .12 ...	2
9	710-0642		Screw, Hex Wash, Hd Tapp	4	21	741-0245		Bearing, Hex Flange, .75 ID	1
			1/4-20 x .75		22	747-04001		Rod, Parking Brake	1
10	710-0653		Screw, Hex Wash, Hd Tapp	4	23	747-3454		Pin, Parking Brake Pivot	1
			1/4-20 x .375		24	703-05362		Plate, Bearing	1
11	710-1260A		Screw, Hex Wash, Hd Tapp	3	25	710-3015		Screw, Hex Cap,	2
			5/16-18 x .75					1/4-20 x .75 GR5	
12	710-1690		Screw, Hex,	4	26	712-0324		Nut, Hex Insert Lock, 1/4-20	2
			M6-1 x 16 Hardened		27	736-0173		Washer, Flat, .28 x .74 x .063 ...	2

FRONT AXLE



REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.
1	618-04028A	Axle, 4WD Front	1
2	703-05357	Bracket, Cylinder Mounting	1
3	710-04208	Screw, Hex Cap, w/Patch..... M12-1.75 x 25 GR8	4
4	710-04214	Screw, Sq. Hd Lock. 5/16-18	1
5	710-3181	Screw, Hex Cap	8
		1/2-13 x 1.5 GR5	
6	711-1410	Stud, Cylinder Mounting	1
7	712-3016	Nut, Hex Insert Lock 5/8-11 GR5	2
8	712-3050	Nut, Lug, 7/16-14	8
9	712-3083	Nut, Hex Insert Lock, 1/2-13 GR8	8
10	712-3107	Nut, Hex Lock, 3/4-10 GRC	1
11	717-04010	Shaft, 4WD Drive	1
12	717-04119	Cylinder, Steering	1
13	736-0272	Washer, Flat, .51 x 1.0 x .06	8
14	736-0921	Washer, Lock, 1/2	2
15	738-04049	Screw, Shoulder, .75 x 1.03	1


4WD AXLE ASSEMBLY



4WD AXLE ASSEMBLY

REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.
1	619-04017A	Housing, Kingpin	2
	759-3958	Sealant, Loctite® Black, 5.3 oz.	AR
2	619-04020A	Housing, Axle Drop, RH	1
3	619-04021A	Housing, Axle Drop, LH	1
4	619-04024A	Cover, Axle	2
5	619-04027A	Arm, Steering, LH	1
6	619-04028A	Arm, Steering, RH	1
7	710-1313	Screw, Hex Cap,	8
		M10-1.5 x 35 GR8.8	
8	710-1323	Plug, Hex, 3/8-16 x .5	2
9	710-1681	Screw, Hex Cap,	12
		M8-1.25 x 20 GR8.8	
10	710-1633	Plug, Screw, M14-1.5 x .827	2
11	710-1683	Screw, Hex Cap, M8-1.25 x 30	2
12	710-3208	Screw, Hex Cap, M10-1.5 x 25	8
13	711-04060	Axle, Flange	2
	710-0852	Stud, Rib Neck, 7/16-14 x 1.6	8
14	711-04104	Shaft, Stub	2
15	711-04106	Shaft, Kingpin	2
16	712-0690	Nut, Hex, M8-1.25	2
17	712-3103	Nut, Hex Flange Lock, M12-1.75	2
18	712-3104	Nut, Hex, M12-1.75 RH Thrd.	1
19	712-3105	Nut, Hex, M12-1.75 LH Thrd.	1
20	715-04014	Pin, Dowel, 8mm x 20mm	2
21	716-0201	Ring, Retaining	2
22	716-0393	Ring, Retaining	2
23	717-04040	Gear, Bevel, 13T	2
24	717-04041	Gear, Bevel, 34T	2
25	717-04045	Gear, Bevel, 14T	4
26	721-04087	Seal, Oil, 38 x 55 x 7 w/Dirt Lip	2
27	721-04066	O-Ring, 40mm x 3mm	2
28	721-0497	Seal, Oil, 35mm x 55mm x 8mm	2
29	723-0462	Ball Joint, 12-1.75 RH	1
30	723-0463	Ball Joint, 12-1.75 LH	1
31	736-0567	Washer, Flat, .39 x .75 x .062	2
32	741-0301	Bearing, Ball	2
33	741-04034	Bearing, Ball	2
34	741-04043	Bearing, Tapered Roller w/ Race ...	2
35	741-04044	Bearing, Ball	2
36	741-04068	Bearing, Ball	2
37	741-0919	Bearing, Ball	2
38	741-3033A	Bearing, Ball	2
39	747-04134	Rod, Tie, M12-1.75	1


4WD AXLE ASSEMBLY



4WD AXLE ASSEMBLY


REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.
1	603-04050	Bracket, Front Axle Mtg. - Rear	1
	737-0146	Fitting, Lube, 1/4-28	1
	741-04036	Bearing, Sleeve	1
2	603-04051	Bracket, Front Axle Mtg. - Front	1
	737-0146	Fitting, Lube, 1/4-28	1
	741-04037	Bearing, Sleeve	1
3	619-04009A	Housing, Main Axle RH	1
4	619-04120	Housing, Differential	1
5	619-04019A	Housing, Axle LH	1
6	710-1313	Screw, Hex Cap,	2
		M10-1.5 x 35 GR8.8	
7	710-1682	Screw, Hex Cap,	8
		M8-1.25 x 25 GR8.8	
8	710-3175	Screw, Hex Cap,	6
		M8-1.25 x 14 GR8.8	
9	710-1633	Plug, Screw, M14-1.5 x .827	1
10	710-3208	Screw, Hex Cap, M10-1.5 x 25	8
11	711-04051	Shaft, Input, 11T	1
12	711-04384	Shaft, Cross	1
13	711-04107	Shaft, Axle	2
14	712-04043	Nut, Special, 24mm	1
15	716-04045	Ring, Retaining	2
16	715-04014	Pin, Dowel, 8mm x 20mm	4
17	717-04023	Gear, Bevel, 35T	1
18	717-04046	Gear, Miter, 10T	2
19	717-04047	Gear, Miter, 16T	2
20	721-04056	Seal, Oil, 52mm x 35mm x 10mm ..	1
21	721-04067	O-Ring, 19mm x 3mm	1
22	731-04336	Dipstick, Front Axle	1
	721-04058	Washer, Seal	1
23	736-0264	Washer, Flat, .33 x .63 x .0635	6
24	736-0287	Washer, Flat, .793 x 1.24 x .06 Hdn.	1
25	736-04098	Washer, Special Spherical	2
26	736-0562	Washer, Flat, .793 x 1.37 x .005	AR
	736-0563	Washer, Flat, .793 x 1.37 x .010	AR
	736-0564	Washer, Flat, .793 x 1.37 x .015	AR
	736-0565	Washer, Flat, .793 x 1.37 x .020	AR
	737-0566	Washer, Flat, .793 x 1.37 x .025	AR
27	741-04038	Washer, Thrust, 1.66 x 2.59 x .059	1
28	741-04039	Washer, Thrust, 1.03 x 1.73 x .059	1
29	741-04042	Bearing, Tapered Roller w/ Race ...	2
30	741-04044	Bearing, Ball	2
31	741-04045	Bearing, Ball	1
32	741-04046	Bearing, Ball	1
33	750-04133	Spacer, 20 x 25 x 16mm	2
34	750-04164	Spacer, 25 x 35 x 12mm	1
35	750-0750	Spacer, .5 x .75 x .86	2
	737-3065	Oil, 85W-140	2.5 qt.

HYDRAULICS



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	712-3035		Nut, Hex Jam, 9/16-18 GR5	2	11	727-04083		Tube, Return	1
2	723-3014		Filter, Oil	1	12	727-04096		Hose, Steering Pressure	1
3	725-0157		Tie, Cable	7	13	727-04097		Hose, Aux. Pump-Filter	1
4	727-04000		Hose, Steering	2	14	727-3012		Fitting, 90 Degree	3
5	727-04002		Hose, Steering - Tank	1	15	737-04033		Fitting, 90 Degree Swivel	3
6	727-04003		Hose, Lift Inlet	1	16	737-04035		Fitting, Elbow	1
7	727-04014		Hose, Lift Cylinder	1	17	737-3111		Fitting, 90 Degree	1
8	727-04015		Tube, Cylinder Return	1	18	737-04087		Fitting, Bulkhead	2
9	727-04079		Tube, U Return	1	19	737-04101		Fitting, 90 Degree	1
10	727-04082		Tube, Return Tank	1	20	737-3127		Fitting, 90 Degree	1


DASH PANEL AND STEERING WHEEL



DASH PANEL AND STEERING WHEEL

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-04305		Bracket, Throttle Cable	1
2	629-04112		Wire Harness, Dash	1
3	631-0076		Boot, Steering Shaft	1
4	631-04007B		Dash	1
5	703-05132A		Bracket, Throttle Mtg.	1
6	710-0604A		Screw, Hex Wash. Hd. Tapp	2
			5/16-18 x .625	
7	710-0924		Screw, Pan Hd., 1/4-20 x .75	4
8	710-3013		Screw, Hex Cap, 1/4-20 x .5 GR5	6
9	712-0116		Nut, Hex Insert Jam Lock, 3/8-24 ..	1
10	712-0237		Nut, Hex Lock, 5/16-24	1
11	712-0292		Nut, Speed, 1/4-20	2
12	723-3013		Washer, Friction, .515 x 1.5 x .12 ..	1
13	725-04022		Meter, Hour/Indicator	1
14	725-04076		Switch, PTO	1
15	725-04241		Gauge, Fuel	1
16	725-04261		Gauge, RPM	1
17	725-2017		Plug	1
18	725-3274		Switch, Headlight	1
19	725-3277		Switch, Ignition	1
20	725-3279B		Switch, Hazard	1
21	731-05066		Panel, Meter	1
22	731-3209		Steering Wheel, Soft Grip	1
23	731-3210		Cover, Steering Wheel	1
24	731-3298		Handle, Throttle	1
25	731-3344		Panel, Dash Insert	1
26	731-3372		Extension, Dash	1
27	736-0255		Washer, Belleville, .51 x 1.14 x .04	2
28	736-0329		Washer, Lock, 1/4	2
29	736-04062		Washer, Flat, .344 x 1.5 x .1	1
30	736-0331		Washer, Belleville, .39 x 1.13 x .062	5
31	736-3072		Washer, Flat, .38 x .93 x .110 Hdn	1
32	732-04288		Spring, Torsion	1
33	738-04170		Screw, Shoulder, .374 x .56	1
34	759-3950		Key Set, Ingition	1
35	725-04243		Lamp, Yellow Panel	1


CONTROLS



CONTROLS


REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-04016		Handle, 4WD	1	37	712-3027		Nut, Hex Flange Lock, 1/4-20 ...	3
2	603-04018		Link, Hi-Lo	1	38	712-3058		Nut, Hex Insert Lock, 1/2-20	2
3	603-04019		Bracket, 4WD Pivot	1	39	713-3000		Link, Chain	1
4	603-04020		Link, 4WD	1	40	714-0104		Pin, Internal Cotter	12
5	603-0945		Shaft Assembly, Pedal	1	41	714-0145		Pin, Internal Cotter	2
6	603-0947		Shaft Assembly, Reverse	1	42	714-0507		Pin, Cotter, 3/32 x .750	1
7	603-0948A		Link Assembly, Parking Brake ..	1	43	714-0147		Pin, Internal Cotter	4
8	603-04273		Shaft Assembly, Brake	1	44	716-0104		E-Ring, .5 Dia	1
9	703-05039		Link, Hi-Lo Pivot	1	45	725-04232		Switch, Plunger (Brake)	1
10	703-05665		Bracket, Hi-Lo Shifter	1	46	725-3164A		Switch, Plunger (Reverse)	1
11	703-05666		Handle, Hi-Lo Shift	1	47	725-3167		Switch, Plunger (Brake)	1
12	703-05674		Bracket, Switch	1	48	727-04004		Cylinder, Damper	1
13	703-4105		Lever, Brake	1	49	731-3249A		Pedal, Brake	1
14	703-3012		Link, Pedal Mounting	1	50	731-3247		Pedal, Forward	1
15	703-3152		Bracket, Reverse Switch	1	51	731-3248		Pedal, Reverse	1
16	703-3156A		Link, Brake Pedal	1	52	731-3250		Pedal, Diff. Lock	1
17	703-3183		Bracket, Pedal Brace	1	53	731-3321		Grip, Handle	2
18	710-0521		Screw, Hex Cap	1	54	732-04009		Spring, Compression	2
			3/8-16 x 3.0 GR8		55	732-0859A		Spring, Rev/No Cut	1
19	710-0599		Screw, Hex Wash Hd Tapp	6	56	732-0384		Spring, Extension, .62 x 6.12	1
			1/4-20 x .5		57	732-3118		Spring, Extension, 3/8 x 1.44	1
20	710-0607		Screw, Hex Wash. Hd. Tapp,	2	58	736-0160		Washer, Flat, .53 ID x .93 x .05 .	1
			5/16-18 x .5		59	736-0173		Washer, Flat, .28 x .74 x .063 ...	3
21	710-0623		Screw, Hex Wash Hd Tapp	3	60	736-0185		Washer, Flat, .375 x .74 x .063	1
			3/8-16 x .75		61	736-3019		Washer, Flat, .53 x .1.06 x .134	4
22	710-0642		Screw, Hex Wash Hd Tapp	2	62	738-0140		Screw, Shoulder, .435 x 1.78	1
			1/4-20 x .75		63	738-0255		Screw, Shoulder, .375 x .181 ...	1
23	710-0703		Screw, Carriage, 1/4-20 x .75 GR5	1	64	738-0533		Screw, Shoulder, .498 x 1.635	1
24	710-3005		Screw, Hex Cap	2	65	738-0982		Screw, Shoulder	1
			3/8-16 x 1.25 GR5					.498 x 3.245: 3/8-16	
25	710-3170		Stud, Cylinder, 5/16-18	1	66	741-0598		Bearing, Hex Flange, .752 ID	4
26	711-04038		Ferrule, Brake	2	67	741-0491		Bearing, Nylon, .50 ID x .341	8
27	711-0701		Pin, Clevis, .25 x .5	1	68	741-3073		Bearing, Flange, .375 x .58 x .25	2
28	711-3397		Ferrule, 3/8-24 x .37	2	69	746-04017		Cable, Diff Lock	1
29	711-0679A		Pin, Clevis, 3/8 x 2.015	1	70	747-04021		Rod, Brake, LH	1
30	711-0723A		Ferrule, 3/8 - 24 x .375	2	71	747-04022		Rod, Brake, RH	1
31	711-1363		Pin, 3/8-16: 3/8 x 2.43	1	72	747-04034		Link, 4WD Handle	1
32	712-0375		Nut, Hex Lock, 3/8-16	3	73	747-3486		Rod, Hydro Control	1
33	712-04064		Nut, Hex Flange Nylon Lock	1	74	747-3324		Rod, Rear Connecting	1
			14-20 GRF		75	747-3353		Rod, Front Connecting	1
34	712-0431		Nut, Hex Flange Lock, 3/8-16 ...	4	76	747-3366		Shaft, Diff. Lock	1
35	712-0711		Nut, Hex Jam, 3/8-24	2	77	748-0227A		Bearing, Hex Flange, .629 ID	2
36	712-3004A		Nut, Hex Flange Lock, 5/16-18	2	78	750-0668		Spacer, .39 x .625 x 1.74	1

BATTERY AND ELECTRICAL




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	629-04128		Harness, Main Wire	1
2	703-05695	0637	Bracket, Relay Mtg.	2
3	703-4104	0637	Strap, Battery Holddown	1
4	710-0206		Screw, Hex Cap, 1/4-10 x .875 GR5	2
5	710-0224		Screw, Hex Wash Hd. Tapp	3
			#10-16 x .5	
6	710-0599		Screw, Hex Wash Hd. Tapp	4
			1/4-20 x .5	
7	712-0324		Nut, Hex Nylon Insert Lock, 1/4-20	2
8	712-0421		Nut, Wing w/Bell Washer, 5/16-18	2
9	725-0157		Tie, Cable	7
10	725-3174		Battery, 500 cca Dry	1
11	747-3433		Rod, Battery Holddown	2

TRANSMISSION MOUNTING



REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.
1	N/A	Transmission Assembly	1
2	603-04193	Link, Diff Lock Actuator	1
3	710-3071	Screw, Hex Cap	4
		1/2-13 x 2.0 GR8	
4	711-0701	Pin, Clevis, .25 x .50	1
5	712-3061	Nut, Hex Insert Lock, 3/8-24	1
6	712-3083	Nut, Hex Insert Lock, 1/2-13	4
7	714-0104	Pin, Internal Cotter	1
8	731-05247	Fan, Transmission Cooling	1
9	736-3019	Washer, Flat, .531 x .1062 x .134	8
10	738-0689	Screw, Shoulder, 1/2 Dia. x .180	1
11	725-0157	Tie, Cable	1
12	723-3014	Filter, Oil	1
13	727-04098	Hose, Filter	1
14	727-04104	Adapter, Oil Filter	1
15	737-04101	Fitting, 90° Elbow	1
16	737-04102	Fitting, 90° Elbow	1


4WD TRANSMISSION CONNECTIONS



4WD TRANSMISSION CONNECTIONS

REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.
	737-3120	Transmission Oil, 1 Qt.	5 gal.	19	712-3004A	Nut, Hex Flange Lock, 5/16-18 GR5	3
	737-3121	Transmission Oil, 1 Gal.					
	759-3958	Sealant, Loctite® Black, 5.3 oz.	AR	20	712-3005	Nut, Hex Flange Lock, 3/8-16	1
1	603-0980	Arm, Hydro	1	21	716-0111	Ring, Retaining	1
2	603-04192	Bracket, Clutch Torque	1	22	718-04141	Pump, Hydrostatic Transmission	1
3	603-04195	Bracket, Return	1	23	721-04002	O-Ring, 2.425 ID x .103	1
4	603-04298	Bracket, Filter Mounting	1	24	726-0205	Clamp, Hose	1
5	703-05041	Arm, Neutral - RH	1	25	727-3002	Fitting, Straight	1
6	703-05042	Arm, Neutral - LH	1	26	727-3012	Fitting, 90 Degree	1
7	703-05742	Keeper, Belt	1	27	727-04095	Tube, Hydro Inlet	1
8	710-0189	Screw, Hex Cap, 5/16-18 x 3.0 GR5	2	28	731-05247	Fan, Transmission Cooling	1
9	710-0299	Screw, Hex Cap, 1/4-28 x 1.0 GR5	1	29	732-3119	Spring, Extension,50 x 1.975 x .072	1
10	710-0751	Screw, Hex Cap, 1/4-20 x .62 GR5	2	30	736-0119	Washer, Lock, 5/16	4
11	710-0817	Screw, Hex Wash. Hd. Tapp, ... 5/16-18 x 1.25 GR5	2	31	736-0331	Washer, Belleville	1
12	710-1882	Screw, Hex Flange, 5/16-18 x 1.5 GR5	3	32	736-0864	Washer, Thrust, .375 x .812 x .06	1
13	710-3218	Screw, Socket Hd. Cap 1/4-20 x .62 GR8	4	33	737-0296	Vent, 3/8 Dia	1
14	710-3226	Screw, Hex Cap Lock, 5/16-18 x 5.5 GR5	2	34	737-0299	Fitting, Elbow	1
15	710-3242	Screw, Set - Lock 5/16 x .5 GR5	1	35	737-0349	Fitting, Plug	2
16	710-04040	Screw, Shoulder,497 x .750: 3/8-16	1	36	737-04011	Adapter, Oil Filter	1
17	712-0262	Nut, Hex Jam Lock, 3/8-24	1	37	737-04026	Fitting, Run Tee	1
18	712-0896	Nut, Hex Nylon Lock, 1/4-28	2	38	737-04032	Indicator, Oil Level Sight	1
				39	737-04047	Fitting, Elbow	1
				40	748-04086	Adapter, Cog Pump	1
				41	751-0535	Hose, Fuel Line	.38in
				42	751-3130	Hose, Vent	13 in.
				43	GW-90064	Screw, Hex Wash Hd Tapp 3/8-16 x .62	2
				44	BS-492932S	Filter, Hydro Pump	1


TRANSMISSION DRIVE



TRANSMISSION DRIVE

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	611-3033		Shaft, Axle RH	1	45	719-04001		Cover, Trans. Large	1
2	611-3034		Shaft, Axle LH	1	46	719-04002		Cover, Trans. Small	1
3	618-0226		Collar Assembly, Hi-Lo	1	47	719-04153		Housing, Trans.	1
4	618-3183		Collar Assembly, Diff Lock	1	48	719-04004		Housing, Axle Inner - RH	1
5	703-05045		Bracket, Diff. Lock	1	49	719-04005		Housing, Axle Inner - LH	1
6	710-0176		Screw, Hex Cap, 5/16-18 x 2.75 GR5	4	50	721-0381		Seal, Oil	2
7	710-0378		Screw, Hex Cap, 5/16-18 x 2.5 GR5	6	51	721-0496		Seal, Oil	3
8	710-0602		Screw, Hex Wash. Hd. Tapp, ... 5/16-18 x 1.0	21	52	721-0519		Seal, Gland	1
9	710-0817		Screw, Hex Wash. Hd. Tapp, ... 5/16-18 x 1.25	12	53	721-3020A		Seal, Oil	2
10	710-1880		Screw, Hex Cap, w/Patch 5/16-18 x .75GR5	8	54	721-04004		Seal, Oil	1
11	710-1633		Screw, Plug, M14 x 1.5 x .827	1	55	711-1680		Shaft, 4WD	1
12	710-3006		Screw, Set, 5/16-18 x .375	2	56	732-04003		Spring, Torsion	2
13	710-04035		Screw, Shoulder	4	57	732-04010		Spring, Compression, .845 x 1.0	1
			.309 x .375: 1/4-20		58	732-04101		Spring, Compression, .24 x .563	2
14	711-1675		Shaft, Output, 11T	1	59	736-0119		Washer, Lock, 5/16	6
15	711-1676		Shaft, Cross, .625 x 3.95	1	60	736-04126		Washer, Flat, .597 x 1.0 x .04 ..	2
16	711-04302		Shaft, Diff. Lock Actuator	1	61	736-0371		Washer, Flat, .343 x .88 x .062	2
17	711-04300		Shaft, Hi-Lo Actuator	1	62	736-0615		Washer, Thrust	2
18	711-04137		Shaft, Drive	1	63	736-0266		Washer, Flat, 1.52 x 2.0 x .030	AR
19	712-0273		Nut, Hex Insert Lock, 5/16-24	2		736-04095		Washer, Flat, 1.52 x 2.0 x .005	AR
20	714-0135		Key, Woodruff, 1/4 x 3/4	1		736-04096		Washer, Flat, 1.52 x 2.0 x .015	AR
21	715-3010		Pin, Dowel, .25 x .75	4	64	741-0343		Pin, Brake Actuating	4
22	716-0114		Ring, Retaining	1	65	741-0363		Bearing, Needle	1
23	716-0127		Ring, Snap	1	66	741-0862		Ball, Detent	2
24	716-0180		Ring, Retaining	5	67	741-1104		Bearing, Ball	2
25	716-0194		Clip, Rotor	6	68	741-3033A		Bearing, Ball	2
26	716-04005		Ring, Retaining	1	69	741-3057		Bearing, Ball	1
27	716-04030		Ring, Retaining	2	70	741-3083		Bearing, Needle Thrust	1
28	717-0678		Pad, Brake	6	71	741-04014		Bearing, Ball	3
29	717-0682		Plate, Brake Puck	2	72	741-04066		Bearing, Ball	1
30	717-3534		Gear, Spur, 12T	1	73	750-3364		Spacer, 1.51 x 1.75 x 2.41	1
31	717-3535		Gear, Spur, 34T	1	74	750-04024		Spacer, 1.515 x 2.039 x .335 ...	1
32	717-3536		Gear, Spur, 19T	1	75	717-04043		Gear, Spiral Bevel, 36T	1
33	717-3537		Gear, Spur, 27T	1	76	761-0215		Disc, Brake	4
34	717-3538		Gear, Spur, 56T	1	77	761-04000		Yoke, Brake	2
35	717-3541		Gear, Bevel, 16T	1	78	761-04001		Bracket, Brake Anti Rotation	2
36	717-3542		Gear, Bevel, 16T Lock	1	79	761-04002		Plate, Puck Retainer	2
37	717-3545		Gear, Bevel, 10T Diff.	2	80	761-04003		Arm, Brake Actuator - LH	1
38	717-04132		Gear, Spiral Bevel, 13T	1	81	761-04004A		Arm, Brake Actuator - RH	1
39	717-04133		Gear, Spiral Bevel, 54T	1	82	750-04413		Spacer, .573 x .938 x .832	1
40	718-3148A		Cover, Differential	1	83	750-04416		Plug, .437 x .16	1
41	718-3149A		Cover, Differential Lock	1	84	617-04004		Gear Assembly w/Bearings	1
42	718-3150		Block, Thrust	2		741-0991		Bearing, Sleeve, 13 x 15 x 10	2
43	718-04080		Yoke, Diff. Lock Actuator	1	85	711-04301		Shaft, 4WD Actuator	1
44	718-04081		Yoke, Shift, Hi-Lo	1	86	716-0185		Ring, Retaining	1
					87	716-0204		Ring, Retaining	1
					88	718-04079		Yoke, 4WD	1
					89	718-0668		Gear, Spline Coupling	1
					90	718-3116		Collar, Shift	1
					91	741-3037		Bearing, Ball	1


PTO DRIVE



PTO DRIVE

REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	710-0650		Screw, Hex Wash. Hd. Tapp. 5/16-18 x .875	2
2	710-1177		Screw, Socket Hd. 5/16-18 x .75	3
3	710-04116		Screw, 12 Pt. Wash. Hd. w/Patch ... 3/8-16 x 1.25	1
4	711-1325A		Shaft, 540 PTO	1
5	711-1683A		Shaft, Clutch Back	1
6	711-1684		Shaft, 2000 PTO	1
7	711-1685		Shaft, Input PTO	1
8	714-0128		Key, Square, 1/4 x 1. 0	1
9	716-0180		Ring, Retaining	2
10	716-0181		Ring, Retaining	1
11	716-0384		Ring, Retaining	1
12	716-0387		Ring, Retaining	1
13	716-0393		Ring, Retaining	2
14	716-04000		Ring, Retaining	2
15	717-3469		Gear, 540 PTO, 81T	1
16	717-3487		Gear, 2000 PTO , 61T	1
17	717-3492		Gear, Pinion, 540 PTO:14T	1
18	717-3494C		Gear, Pinion, 2000 PTO:54T	1
19	717-3551		Gear, Pinion, 2000 PTO:34T	1
21	718-0681		Cover, 2000 PTO	1
22	718-04000		Adapter, PTO Output	1
23	718-04009		Clutch Assy. PTO	1
24	721-0504		Plug, Oil, 1.875 x .375	1
25	721-04094		Seal, Oil	1
26	721-0509		Seal, Oil	1
27	721-04002		O-Ring, 2.425 ID x .103	1
28	721-04124		Seal, Oil	1
29	721-04005		Seal, Oil	1
30	736-0570		Washer, Flat, .865 x 1.145 x .030 ..	1
31	736-04001		Washer, Thrust	1
32	738-04003		Spacer, Shoulder	1
33	741-1100		Bearing, Ball	1
34	741-3033A		Bearing, Ball	3
35	741-3037		Bearing, Ball	2
36	741-3057		Bearing, Ball	2
37	741-04034		Bearing, Ball	2
38	750-3365		Spacer, 15mm x 20mm x 14mm	1
39	750-04013		Spacer, .6 x 1.0 x 1.345	1
40	750-04020		Spacer, 1.004 x 1.375 x .25	1
41	716-04049		Ring, Retaining	1
42	736-0454		Washer, Flat, .915 x 1.37 x .010	2


HYDROSTATIC TRANSMISSION



HYDROSTATIC TRANSMISSION

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	HG-52224	Shaft, Pump Input	1
2	HG-2000022	Ring, Wire Retaining	4
3	HG-2000038	Ring, Retaining	1
4	HG-2000023	Spacer	1
5	HG-2000032	Bearing, Ball	1
6	HG-51092	Seal, Lip	1
7	HG-2000037	Seal, Lip	1
8	HG-2000014	Arm, Trunnion	1
9	HG-2000015	Guide, Slot	1
10	HG-2510096	Housing Assembly	1
11	HG-50552	Bearing Assembly, Thrust Ball	2
12	HG-2000024	Washer, Block Thrust	2
13	HG-2000025	Spring, Block	2
14	HG-2510014	Kit, Pump Cylinder Block	1
15	HG-2000007	Shaft, Motor	1
16	HG-70973	Kit, Center Section	1
17	HG-50641	Pin	2
18	HG-2000061	Gasket, Center Section	1
19	HG-50203	Swashplate, Variable	1
20	HG-2510013	Kit, Motor Cylinder Block	1
21	HG-70743	Shock Valve	2
22	HG-9007314-0808	Screw, Socket Head Cap	8
	HG-2510010	Kit, Overhaul Seal	1

ENGINE AND DRIVE SHAFT




ENGINE AND DRIVE SHAFT

REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE DESCRIPTION	QTY.
†	629-04131	Harness, Engine	1	25	717-04112	Shaft, Drive	1
1	703-3521B	Plate, Engine Mtg.	1	26	718-04068	Bushing, D Type	1
2	703-3684	Bracket, Filler Neck	1	27	718-04069	Flywheel	1
3	703-3688	Bracket, Radiator Mtg. RH	1	28	722-0268	Grommet, Rubber	2
	777S30632	Graphic, Warning	1	29	722-3022	Tape, Foam, .625 wide	42in.
4	703-3689	Bracket, Radiator Mtg. LH .	1	30	723-3061	Seal, Heat Baffle	103in.
	777S30632	Graphic, Warning	1	31	725-3282	Wire, Battery Neg.	1
5	703-3691	Plate, Radiator Baffle	1	32	725-3289	Wire, Battery Pos.	1
	777S30631	Graphic, Fan Warning	1	33	726-0205	Clamp, Hose	7
	777S30633	Graphic, Warning	1	34	726-0476	Clamp, Hose - Adjustable .	1
6	703-3692	Bracket, Radiator Mtg.	1	35	726-0480	Clamp, Hose	4
7	703-3722	Bracket, Ovrflw Bottle Mtg.	1	36	726-04026	Clamp, Hose	2
8	703-05140B	Plate, Baffle RH	1	37	731-04018	Grommet	2
9	703-05141B	Plate, Baffle LH	1	38	731-3364	Shroud, Fan	1
10	703-4063B	Shield, Heat	1	39	735-0226	Grommet	1
11	710-0195	Screw, Hex Cap,	2	40	736-0173	Washer, Flat,	4
		1/4-28 x .625 GR5				.28 x .74 x .063	
12	710-0357	Screw, Square Hd. Set,	2	41	746-3086A	Cable, Throttle	1
		3/8-16		42	746-04015	Cable, Choke Control	1
13	710-0514	Screw, Hex Cap,	4	43	751-3130	Fuel Line 5/16 ID	92in.
		3/8-16 x 1.0 GR5		44	751-3166	Muffler	1
14	710-0597	Screw, Hex Cap,	2	45	751-3177	Hose, Filler to Radiator	1
		1/4-20 x 1.0 GR5		46	751-3185	Radiator	1
15	710-0599	Screw, Hex Wash Hd Tapp	4	47	751-3187	Hose, Lower Radiator	1
		1/4-20 x .5		48	751-3189B	Hose, Engine to Filler Neck	1
16	710-0607	Screw, Hex Wash Hd Tapp	12	49	751-3190	Filler Neck,	1
		5/16-18 x .5				Remote Radiator	
17	710-0623	Screw, Hex Wash Hd Tapp	4	50	751-3192	Cap, Remote Filler	1
		3/8-16 x .75		51	751-3193	Screen, Radiator	1
18	710-3218	Screw, Socket Hd Cap,	4	52	751-3203	Hose, Intake Air	1
		1/4-20 x .62 GR8		53	KM-49040-2065	Pump, Fuel	1
19	710-1260A	Screw, Hex Wash Hd Tapp	8	54	KM-49019-1055	Filter, Fuel	1
		5/16-18 x .75		55	KM-11060-2467	Gasket, Exhaust	2
20	710-1376	Screw, Hex Cap,	1	56	KM-461F0800	Washer, Spring	4
		M8-20 x 16 GR8.8		57	KM-317R0800	Nut, Hex	4
21	710-3015	Screw, Hex Cap,	9	58	KM-92038-2101	Key, Crankshaft	1
		1/4-20 x .75 GR5		59	KM-43078-2055	Bottle, Over Flow	1
22	710-3208	Screw, Hex Cap,	6	60	KM-39062-2086	Tube	1
		M10 x 1.5 x 25 GR5		61	725-0157	Tie, Cable	2
23	712-04064	Nut, Hex Insert Flange Lock	11	62	751-10054	Sleeve, Fuel Line Reflective	1
		1/4-20 GrF		63	751-0535	Fuel Line, 1/4 Return	65in.
24	712-04065	Nut, Hx Insert Flange Lock,	4				
		3/8-16 GrF					

† Not Shown


CYLINDER HEADS AND CRANKCASE



CYLINDER HEADS AND CRANKCASE


REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11004-2142	Gasket, Head	2
2	KM-11008-2145	Head, Cylinder	1
3	KM-11008-2146	Head, Cylinder	1
4	KM-11022-2072	Cover, Rocker	1
5	KM-11022-2073	Cover, Rocker	1
6	KM-11060-2466	Gasket, Breather	1
7	KM-11060-2470	Gasket, Rocker Cover	2
8	KM-13271-2105	Plate, Breather	2
9	KM-14091-2064	Cover, Breather	1
10	KM-16126-2225	Valve, Breather	2
11	KM-49015-6239	Cover, Crankcase	1
12	KM-49120-6127	Crankcase, (Includes Ref. Nos. 13 and 19)	1
13	KM-59071-2079	Joint	1
14	KM-92009-2308	Screw	2
15	KM-92043-1037	Pin	6
16	KM-92049-2242	Seal, Oil	1
17	KM-92049-2243	Seal, Oil	1
18	KM-92093-2086	Seal	1
19	KM-92141-2118	Bearing, Plane	1
20	KM-92141-2119	Bearing, Plane	1
21	KM-92151-2158	Bolt, M8 x 55	4
22	KM-92151-2159	Bolt, M8 x 80	8
23	KM-92170-2002	Clamp	2
24	KM-92191-2105	Tube	1
25	KM-130G0630	Bolt, Flange	8
26	KM-130G0830	Bolt, Flange	4
27	KM-130G0845	Bolt, Flange	6
28	KM-130G0860	Bolt, Flange	4
29	KM-172G0822	Bolt, Stud	4
30	KM-670B2011	O-Ring	3

PISTONS AND CRANKSHAFT




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-13001-2125	Piston	2
2	KM-13002-2069	Pin, Piston	2
3	KM-13008-6007	Ring Set, Piston	2
4	KM-13251-2058	Rod, Connecting	2
		(Includes Ref No. 8 [Qty. 2])	
5	KM-49119-2198	Crankshaft Assembly	1
		(Includes Ref Nos. 6 and 9)	
6	KM-59051-2358	Gear, Spur, 33T	1
7	KM-92036-008	Ring, Snap	4
8	KM-92151-2150	Bolt, 7 x 36	4
9	KM-510A5100	Key, Woodruff	1

VALVES AND CAMSHAFT




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11051-2092	Bracket	2	10	KM-49078-2060	Spring, Valve	4
2	KM-12004-2113	Valve, Intake	2	11	KM-49118-2138	Camshaft	1
3	KM-12005-2100	Valve, Exhaust	2	12	KM-92049-2100	Seal, Oil	4
4	KM-12009-2060	Retainer, Valve Spring	4	13	KM-92145-2085	Spring	1
5	KM-12011-2052	Collet	8	14	KM-92151-2165	Bolt, M6	4
6	KM-12016-2063	Arm, Rocker	4	15	KM-92152-2077	Collar	4
7	KM-12032-2060	Tappet	4	16	KM-92200-2128	Washer, 8.1 x 18 x .5	4
8	KM-13116-2074	Rod, Push	4	17	KM-130G0814	Bolt, Flanged	4
9	KM-16007-2052	Seat, Spring	4	18	KM-311B0600	Nut, Hex	4

LUBRICATION




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11009-2566	Gasket, Drain Plug	2	12	KM-59051-2354	Gear, Spur, 33T	1
2	KM-13107-2281	Shaft, Oil Pump	1	13	KM-99969-1395	Drain, Oil	1
3	KM-13280-2061	Holder, Oil Pump	1	14	KM-92042-014	Pin	2
4	KM-14091-2065	Cover, Oil Pump	1	15	KM-92066-2099	Plug, Drain	2
5	KM-16115-2126	Cap, Oil Filler	1	16	KM-92144-2053	Spring	1
6	KM-16154-1075	Rotor, Pump Outer	1	17	KM-130G0616	Bolt, Flanged	3
7	KM-16154-1076	Rotor, Pump Inner	1	18	KM-130G0625	Bolt, Flanged	2
8	KM-32153-20769H	Pipe, Oil Gauge	1	19	KM-600A1300	Ball, Steel	1
9	KM-49065-2078	Filter, Oil	1	20	KM-670B2010	O-Ring	1
10	KM-49065-2082	Filter, Oil Suction	1	21	KM-670B3025	O-Ring	1
11	KM-52005-2132	Gauge, Oil	1				

ELECTRICAL



REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11009-2766	Gasket	1	16	KM-92037-2101	Clamp	1
2	KM-11052-2068	Bracket	1	17	KM-BPR2ES	Plug, Spark	2
3	KM-14083-2055	Cover, Flywheel	1	18	KM-92072-1195	Band	1
4	KM-21066-2079	Regulator, Voltage	1	19	KM-92151-2097	Bolt, 12 x 30	1
5	KM-21121-2090	Coil, Ignition, No. 1	1	20	KM-92170-2060	Clamp	4
6	KM-21121-2091	Coil, Ignition, No. 2	1	21	KM-92171-2060	Clamp	1
7	KM-21193-2177	Flywheel Assembly	1	22	KM-92200-2119	Washer, 12.2 x 40 x 3.0	1
8	KM-26004-1093	Fuse	1	23	KM-130G0520	Bolt, Flanged	4
9	KM-26030-2326	Harness (Includes Ref. No. 8) ..	1	24	KM-130G0630	Bolt, Flanged	2
10	KM-27010-2170	Switch	1	25	KM-130G0812	Bolt, Flanged	2
11	KM-27010-2182	Switch	1	26	KM-130G0816	Bolt, Flanged	2
12	KM-59031-2127	Coil, Charging	1	27	KM-130G0820	Bolt, Flanged	4
13	KM-92009-2273	Screw	4	28	KM-214B0510	Screw, Pan	1
14	KM-92022-2104	Washer	2	29	KM-241B0406	Screw, Pan	1
15	KM-92027-1568	Collar, 8.3 x 11.5 x 9	4	30	KM-510A5100	Key, Woodruff	1


COOLING



COOLING


REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11009-3028	Gasket	2
2	KM-11060-2475	Gasket, Thermostat	1
3	KM-13107-2097	Shaft, Impeller	1
4	KM-13107-2246	Shaft, Pulley	1
5	KM-13304-6010	Housing Assembly Includes Ref. Nos. 23, 25 & 45	1
6	KM-16142-2077	Cover, Pump	1
7	KM-16160-2127	Body, Upper	1
8	KM-16160-6001	Body, Valve	1
9	KM-39062-2084	Hose, Cooling	1
10	KM-39062-2088	Hose, Cooling	1
11	KM-39062-2089	Hose, Cooling	1
12	KM-41077-2064	Adapter	1
13	KM-49044-2063	Pump Assembly, Water	1
14	KM-49054-2058	Thermostat	1
15	KM-49063-1054	Seal, Mechanical	1
16	KM-59011-2058	Belt	1
17	KM-59041-2092	Fan	1
18	KM-59051-2355	Gear, Spur, 25T	1
19	KM-59091-2054	Pulley	1
20	KM-59091-20559H	Pulley	1
21	KM-59256-2069	Impeller	1
22	KM-59336-2078	Case, Pump	1
23	KM-92026-2311	Spacer, 12 x 18 x 1.4	1
24	KM-92043-2237	Pin	1
25	KM-92045-2191	Bearing, Ball	2
26	KM-92049-2111	Seal, Oil	1
27	KM-92170-1284	Clamp	2
28	KM-92171-2056	Clamp	4
29	KM-92180-2013	Shim, T=0.6	AR
30	KM-92180-2014	Shim, T=1.2	AR
31	KM-92200-2134	Washer	1
32	KM-92200-2135	Washer 10.2 x 19 x 0.8	1
33	KM-130C0812	Bolt, Flanged	2
34	KM-130G0625	Bolt, Flanged	3
35	KM-130G0635	Bolt, Flanged	6
36	KM-130G0820	Bolt, Flanged	3
37	KM-130G0830	Bolt, Flanged	2
38	KM-130P0835	Bolt, Flanged	4
39	KM-130G0845	Bolt, Flanged	1
40	KM-130G0860	Bolt, Flanged	2
41	KM-130G0880	Bolt, Flanged	4
42	KM-315B1000	Nut, Hex Fine	1
43	KM-410B1000	Washer, Plain	1
44	KM-461F0800	Washer, Spring	3
45	KM-481J2800	Circlip	1
46	KM-551A0314	Pin, Dowel	1
47	KM-670B1507	O-Ring	1

CONTROL LINKAGE AND GOVERNOR




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11051-2113	Bracket	1	18	KM-92037-2209	Clamp	2
2	KM-13168-2466	Lever, Throttle	1	19	KM-92143-2135	Collar, 6 x 13 x 2.3	2
3	KM-13168-2467	Lever, Choke	1	20	KM-92143-2148	Collar	1
4	KM-16169-2142	Link, Choke	1	21	KM-92144-2052	Spring	1
5	KM-16171-2091	Link	1	22	KM-92145-2058	Spring	1
6	KM-21187-2073	Arm Assembly	1	23	KM-92145-2095	Spring	1
7	KM-39003-2091	Arm, Governor Pivot	1	24	KM-92150-2182	Bolt, 5 x 18	2
8	KM-39129-2099	Spring, Governor	1	25	KM-92200-2035	Washer	1
9	KM-42036-2060	Sleeve	1	26	KM-92200-2108	Washer, 6.5 x 22 x 1.2	2
10	KM-49110-2094	Gear Assembly, Governor	1	27	KM-92200-2120	Washer, 8.3 x 16 x 2.3	1
11	KM-49113-2170	Panel, Control Complete	1	28	KM-92200-2122	Washer, 6.2 x 30 x 0.5	1
12	KM-92002-1902	Bolt	1	29	KM-130G0630	Bolt, Flanged	2
13	KM-92002-2269	Bolt	1	30	KM-130G0614	Bolt, Flanged	2
14	KM-92009-2381	Screw, 5 x 30	2	31	KM-311B0600	Nut, Hex	1
15	KM-92015-1339	Nut	2	32	KM-312B0500	Nut, Hex	2
16	KM-92022-2372	Washer, 6 x 19 x 1.2	1	33	KM-411B0600	Washer, Plain	1
17	KM-92027-1461	Collar	1	34	KM-482J7000	Circlip, E-Ring	1

CARBURETOR




REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11060-2468	Gasket, Intake Manifold	1	14	KM-23013-2063	Screw Assembly	1
2	KM-11060-2469	Gasket, Intake Manifold	1	15	KM-59076-2065	Manifold, Intake	1
3	KM-11060-2471	Gasket, Intake Pipe	2	16	KM-92037-1610	Clamp	1
4	KM-11061-2075	Gasket	1	17	KM-92063-2353	Jet, Main, #110	1
5	KM-15003-2786	Carburetor Assembly	1		KM-92063-2410	Jet, Main, #105	AR
6	KM-16060-2194	Pipe, Intake	1		KM-92063-2420	Jet, Main, #107.5	AR
7	KM-16073-2206	Insulator	1	18	KM-92063-2370	Jet, Main, #111.3	1
8	KM-16146-2227	Cover Assembly	1		KM-92063-2380	Jet, Main, #106.3	AR
9	KM-16183-2006	Float Assembly	1		KM-92063-2421	Jet, Main, #108.8	AR
10	KM-16184-2007	Chamber, Float	1	19	KM-92064-2106	Jet, Pilot, #45	2
11	KM-16185-2041	Valve Assembly, Throttle	1	20	KM-130G0825	Bolt, Flanged	8
12	KM-16186-2036	Valve Assembly, Choke	1	21	KM-130T06110	Bolt, Flanged	4
13	KM-23013-2059	Screw Assembly	1	22	KM-701Q061000	Tube, PVC	1

AIR FILTER




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11011-2314	Case, Air Filter Body	1
2	KM-11011-2315	Case, Air Filter Upper	1
3	KM-11011-2316	Case, Air Filter Lower	1
4	KM-11013-2195	Element, Air Filter	1
5	KM-11013-2194	Precleaner, Foam	1
6	KM-11051-2088	Bracket	1
7	KM-11051-2089	Bracket, Air Filter	1
8	KM-11061-2085	Gasket, Air Filter	1
9	KM-92004-2152	Stud, 6 x 30	1
10	KM-92015-2138	Nut	1
11	KM-92093-2113	Seal	1
12	KM-92200-2136	Washer	1
13	KM-92210-2079	Nut	1
14	KM-130G0614	Bolt, Flanged	3
15	KM-130G0630	Bolt, Flanged	3
16	KM-317R0800	Nut, Hex	1
17	KM-461F0800	Washer, Spring	1

STARTER



REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	KM-11012-2226	Cap	1
2	KM-13081-2108	Clutch Assembly	1
3	KM-13091-2068	Holder, Brush	1
4	KM-13168-2131	Lever, Shift	1
5	KM-14024-2205	Cover	1
6	KM-16073-2098	Insulator	1
7	KM-16146-2187	Cap, Starter End	1
8	KM-16146-2225	Cone, Starter Nose	1
9	KM-21039-2059	Brush	4
10	KM-21040-2052	Spring, Brush	4
11	KM-21080-2054	Armature	1
12	KM-21163-2120	Starter, Electric	1
13	KM-27010-2122	Solenoid, Starter	1
14	KM-32085-2097	Stopper	1
15	KM-92002-2277	Bolt	2
16	KM-92015-2146	Nut	2
17	KM-92015-2147	Nut	1
18	KM-92033-2081	Ring, Snap	1
19	KM-130P0835	Bolt, Flanged	2
20	KM-317B0800	Nut, Hex	2
21	KM-461F0800	Washer, Spring	2


HOOD, GRILL AND SIDE PANELS



HOOD, GRILL AND SIDE PANELS


REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	625-04004		Headlight Assembly	1
	725-04084		Bulb Assembly, Headlight	2
2	703-05281	0637	Brkt, Side Pnl. Mtg. RH	1
3	703-05284	0637	Brkt, Side Pnl. Mtg. RH Rear	1
4	703-05293	0637	Brkt, Side Pnl. Mtg. LH Rear	1
5	703-05295	0637	Brkt, Side Panel Mtg. LH	1
6	703-05652	0637	Bracket, Hinge, RH	1
7	703-05653	0637	Bracket, Hinge, LH	1
8	703-05655	0637	Bracket, Hood Mounting	1
9	703-3394		Screen, Intake	1
10	703-3764	0637	Bracket, Panel Mtg.	2
11	703-3765	0637	Shield, Lower Heat	1
12	710-04164		Screw, Hex Wash Hd, #8-18 x .375	1
13	710-0473		Screw, Truss Hd, 10-24 x .5	6
14	710-0599		Screw, Hex Wash Hd Tapp	14
			1/4-20 x .5	
15	710-0607		Screw, Hex Wash Hd Tapp	4
			5/16-18 x .5	
16	710-0751		Screw, Hex Cap	4
			1/4-20 x .62 GR5	
17	710-0895		Screw, Hex Wash. Hd.	6
			1/4-20 x .75	
18	710-1220		Screw, Truss Phil. Hd.	8
			12-16 x .75	
19	710-3170		Stud, Cylinder, 5/16-18 Thrd	4
20	712-0272		Nut, Hex Sems, 10-24	6
21	712-04063		Nut, Hex Insert Flange Lock, 5/16-18	4
22	712-04065		Nut, Hex Insert Flange Lock, 3/8-16	2
23	714-0104		Pin, Internal Cotter	1
24	726-0233		Nut, Push, .25 ID	4
25	726-3056		Latch, 1/4 Turn Panel	4
26	727-3194		Cylinder, Gas Spring	2
27	731-04211		Bezel, Headlight	1
28	731-04540		Panel, Side LH	1
29	731-04541		Panel, Side RH	1
30	731-05161		Cover, Hood	1
31	731-05301		Hood	1
	777D07558		Graphic, Hood RH	1
	777D07559		Graphic, Hood LH	1
	777D07732		Graphic, Model 5254 LH	1
	777D07733		Graphic, Model 5254 RH	1
32	732-04281A		Spring, Torsion	1
33	732-0936		Clip, Spring	4
34	732-0937		Spring, Compression	4
35	736-0272		Washer, Flat, .51 x 1.0 x .060	2
36	738-0380		Screw, Shoulder, .5 x .27 Lg 3/8-16	2
37	747-1323A		Rod, .25 x 4.55	1
38	783-04714		Plate, Latch	1
39	783-4717A		Bracket, Latch Pivot	1

FENDER AND RUNNING BOARD




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	631-04031		Cover, Fender, LH	1	11	710-0971		Screw, Pan Hd. 5/16-18 x 1.0 ..	2
2	631-04032		Cover, Fender, RH	1	12	710-1260A		Screw, Hex Wash. Hd. Tapp ..	4
3	703-05105	0637	Bracket, Running Brd Mtg. RH	1				5/16-18 x .75	
4	703-05113	0637	Bracket, Running Brd Mtg. LH	1	13	710-3013		Screw, Hx. Cap, 1/4-20 x .5 GR5	6
5	703-05199	0716	Running Board	1	14	712-0324		Nut, Hx. Insert Lck, 1/4-20 GR8	6
	777S32332		Graphic, Instruction	1	15	725-3273		Switch, PTO Reverse	1
	777S32274		Graphic, Warning	1	16	726-0211		Nut, Speed, 5/16-18	2
6	703-05306A		Bracket, Lift Float Gate	1	17	731-05089		Fender	1
7	703-05307A		Bracket, Shift Gate, Hi-Lo	1		777D08643		Graphic, Reflector RH	1
8	710-0602		Screw, Hex Wash. Hd. Tapp ...	2		777D08642		Graphic, Reflector LH	1
			5/16-18 x 1.0			777D07729		Graphic, Power Shaft	1
9	710-0895		Screw, Hex Wash. Hd. Tapp	4		777S32286		Graphic, Warning	1
			1/4-15 x .75			777D08753		Graphic, 4WD	2
10	710-1242		Screw, Truss Phillips Hd.	8	18	735-0275		Pad, Floor - LH	1
			5/16-14 x .75		19	735-0276		Pad, Floor - RH	1
					20	736-3090		Washer, Flat, .26 x .72 x .06 ...	6

SEAT



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	703-1812A	0716	Bracket, Seat Pivot	1	10	725-3167		Switch, Seat, N/O	1
2	703-3208		Track, Seat - w/o Latch	1	11	732-0735		Spring, Compression	2
3	703-3431		Track, Seat - w/Latch	1	12	735-04039		Cap, Spring	2
4	703-4149	0716	Bracket, Seat Support	1	13	736-0343		Washer, Flat, .33 x 1.25 x .12 ..	2
5	703-4151	0637	Bracket, Seat Belt	2	14	738-0140		Screw, Shoulder,	4
6	710-1669		Screw, Pan Hd. Mach.	4				.435 x .178:5/16-18	
7	710-3005		Screw, Hex Cap,	4	15	750-0258		Spacer, .315 x .75 x .375	2
8	710-0376		Screw, Hex Cap,	6	16	750-04247		Spacer, .505 x .88 x .44	4
9	712-04063		Nut, Hex Insert Flange Lock ...	10	17	757-04005		Seat, High Back	1
			5/16-18 GR5			777D06883		Graphic, CubCadet	1
						777D01782		Graphic, USA	1
					18	757-3013		Belt Assembly, Seat	1
					19	725-0154		Tie, Push Mnt. Cable	1


THREE POINT HITCH



THREE POINT HITCH


REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-04062	0637	Plate, Cylinder Mounting	1
2	603-0964		Link Assembly, Upper	1
3	603-0965		Link, Lower	2
4	603-0970		Link, Fixed Lift	1
5	603-0971A	0637	Bracket Assembly, Rear Hitch	1
6	603-0972	0637	Plate, Cylinder Mounting	1
7	603-0973		Link, Adjustable Lift	1
			603-0968 Link Rod RH Thrd.	1
			603-0969 Link Rod LH Thrd.	1
			711-1744 Turnbuckle	1
			712-04051 Jam Nut, M20 x 2.5 RH	1
8	603-0977		Chain Assembly, Check	1
			603-0974 Chain Link RH Thrd. ...	1
			603-0975 Chain Link Lh Thrd.	1
			603- 0976 Chain Rod, Adjust.	1
9	619-3095		Arm, Hitch Lift - LH	1
10	619-3096		Arm, Hitch Lift - RH	1
11	703-4137	0637	Shield, PTO Shaft	1
	777S30634		Graphic, Warning	1
12	703-4143	0637	Bracket, Chain Mounting	1
13	710-04186		Screw, Hex Cap Lock,	4
			1/2-13 x 1.25 GR5	
14	710-0514		Screw, Hex Cap, 3/8-16 x 1.0 GR5	11
15	710-0599		Screw, Hex Wash. Hd. Tapp	5
			1/4-20 x .5	
16	710-3168		Screw, Carriage, 3/8-16 x 1.0	4
17	710-3296		Screw, Hex Cap, 1/4-20 x .75 GR5	1
18	731-04114		Cover, PTO Shaft	1
19	711-0599		Pin, Clevis, .372 x 1.79	4
20	711-1105		Pin, Klik	4
21	711-1733		Pin, Clevis, 19mm x 84mm	1
22	711-1743		Pin, Hitch, .75 OD	2
23	711-1750		Shaft, Hitch Rock	1
24	711-1753		Clevis, Chain	2
25	711-1761		Pin, Clevis, .75 x 1.938	2
26	712-0301		Nut, Hex Jam, 3/4-10 GR5	2
27	712-0431		Nut, Hex Flange Lock, 3/8-16 GRF	13
28	714-0117		Pin, Internal Cotter	1
29	714-0142		Pin, Cotter, 3/16 x 1.5	2
30	714-0149B		Pin, Internal Cotter	4
31	715-0121		Pin, Spirol, 1/4 x 2.0	2
32	716-04004		Ring, Retaining	2
33	717-3532		Cylinder, Lift	1
34	736-0255		Washer, Belleville, .51 x 1.14 x .04	1
35	736-0315		Washer, Flat, .76 x 1.5 x .12	2
36	736-0364		Washer, Lock, 3/4	2
37	737-3000		Fitting, Lube, 3/16 Drive	1
38	738-0143		Screw, Shoulder, 3/8-16	1
39	741-04084		Bearing, Sleeve, 1.25 x 1.50 x 1.25	2
40	747-04122		Rod, Top Link Hanger	1
41	736-0185		Washer, Flat, .375 x .738 x .063	8
42	736-0272		Washer, Flat, .51 x 1.0 x .06	4
43	736-04177		Washer, Flat, .938 x 1.75 x .235	4

FOLDABLE ROPS




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-04012		Rops, Lower	1	12	731-0757		Conduit	12in.
2	703-05032	0637	Bracket, Rear Seat Mtg.	1	13	736-0148		Washer, Ext. Tooth Lock, 3/8	1
3	703-05770	0637	Plate, Spacer	2	14	736-0185		Washer, Flat, .375 x .74x.063	8
4	710-0514		Screw, Hex Cap,	8	15	736-0272		Washer, Flat, .51 x 1.0 x .060	8
			3/8-16 x 1.0 GR5		16	736-0921		Washer, Lock, 1/2	2
5	710-1260A		Screw, Hex Wash. Hd. Tapp	3	17	736-3089		Washer, Flat, .345 x 1.0 x .10	4
			5/16-18 x .75		18	711-04393		Pin, Pull	2
6	710-3032		Screw, Hex Cap,	8	19	603-04275		Base, ROPS RH	1
			1/2-13 x 1.25 GR5		20	603-04277		Base, ROPS LH	1
7	710-3038		Screw, Hex Cap,	4	21	603-04278	0637	Upper Tube	1
			5/16-18 x .875 GR5		22	736-0600		Washer, Flat	2
8	712-04065		Nut, Hx. Insert Flange Lck, ..	8	23	714-3003		Pin, Internal Cotter	2
			3/8-16 GRF		24	731-05131		Knob Assembly	2
9	712-3066		Nut, Hex, 1/2-20 GR5	2	25	712-3083		Nut, Hex Insert Lock, 1/2-13	2
10	725-04266		Light, Hazard	2	26	710-3067		Screw, Hex Cap,	2
11	726-0211		Nut, Speed, 5/16-18	2				1/2-13 x 1.75 GR5	

DECK LIFT




REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	603-0959		Shaft. Lift	1
2	603-0960	0637	Arm, Lift	1
3	603-0979	0637	Plate, Lift Crank	1
4	711-04343		Pin, Clevis, .625 x 2.18	1
5	714-0145		Pin, Internal Cotter	2
6	715-0118		Pin, Spirol, 5/16 x 1.75	2
7	736-0531		Washer, Flat, .635 x 1.24 x .181	1
8	741-0170		Bearing, Flange w/Flats	2
9	747-3484A		Rod, Crank Lift	1

FUEL TANK



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	710-3119		Screw, Hex Cap, Lock	4
2	736-0262		Washer, Flat, .385 x .87 x .092	7
3	751-3124B		Cap, Fuel	1
4	751-10099		Sensor, Fuel Level	1
5	751-3211		Tank, Fuel	1
6	735-0149		Bushing, Rubber	1
7	751-3174		Fitting, Fuel Return	1

WHEELS



REF. NO.	PART NUMBER	CODE	DESCRIPTION	QTY.
1	634-04004		Rim Assembly	2
	734-0255		Valve Stem	2
2	634-04111		Rim Assembly, Turf Tire	2
	634-04118		Rim Assembly, Ag Tire	2
	734-0255		Valve Stem	
3	712-3050		Nut, Lug, 7/16-14	18
4	734-04002		Tire, Turf, 18 x 8.5 x 8	2
	734-04044		Tire, Ag, 18 x 9.5 x 8	2
5	734-04080		Tire, Turf, 26 x 12.0 x 12	2
	734-04043		Tire, Ag, 26 x 12 x 12	2