




ILLUSTRATED PARTS MANUAL



Stand-On Spreader

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

To The Owner

Thank You

Thank you for purchasing a Cub Cadet Commercial Stand-On Spreader. It was carefully engineered to provide excellent performance when properly operated and maintained.

All information in this manual is relative to the most recent product information available at the time of printing. Please be aware that this Illustrated Part's Manual may cover a range of product specifications for various models.

Components listed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and equipment without notice and without incurring obligation.

Throughout this manual, all references to *right* (RH) and *left* (LH) are observed from the operating position.

Table of Contents

Hopper Assembly	3	Shut-Off Plate Assembly	9
Sulky Assembly.....	4	Control Assembly	10
Impeller Assembly.....	6	Transmission Assembly.....	12
Front Frame Assembly	7	Decal Assembly	14
Remote Deflector Assembly	8		

Record Product Information

To ease in ordering replacement parts, please locate the model plate on the equipment and record the information in the provided area to the right. You can locate the model plate by standing at the operator's position and looking underneath the control panel.

MODEL NUMBER

--	--	--	--	--	--	--	--	--	--	--

SERIAL NUMBER

--	--	--	--	--	--	--	--	--	--	--


Painted Parts

When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXXX-0637). Please refer to the table below for current color codes:

0637	Black
4021	Yellow (Cub Cadet)
0499	Beige (Cub Cadet)

0685	Blue (Cub Cadet)
0691	Black Jack (Cub Cadet Commercial)


Hopper Assembly



Ref.	Part Number	Description
1	00005530	Washer, 3/8
2	00018628	Washer, 1/4
3	00030322	Cam Agitator Assembly
4	00031167	Hex Cap Screw, 1/4-20 x 1.50
5	00060027	Agitator Bearing
6	00060033	Washer, 1/4, SS
7	712-0324	Nut, 1/4-20, SS
8	00060043	Rate Control Knob
9	00060044	Rate Control Arm
10	00060046	Screen Clip, SS
11	00060049	Agitator Arm Assembly


Ref.	Part Number	Description
12	00060050	Spring Retainer Clip
13	00060057	Machine Screw, 1/4-20 x 7/8
14	02004176	80# Hopper
15	01005631	Screw, #8 x 3/8, SS
16	01010116	Screen, SS
17	01006772	Rate Plate
18	01009729	Hopper Extension
19	00035678	Machine Screw, 10-24 x 3/4, SS
20	00070027	Nut, 10-24, SS
21	01005630	Washer, #8, SS

Sulky Assembly




Ref.	Part Number	Description	Ref.	Part Number	Description
1	00006246	Key, 3/16" x 1"	22	01009243	Self Tapping Screw, 3/8-16 x .875
2	00011438	Hex Cap Screw, 3/8-16 x 1.50	23	01009260	Flange Bushing
3	00012152	Nut, 1/4-20	24	01009302	V-Belt, A-Section
4	00012165	Nut, 5/16-18	25	01009314	Cast Pulley
5	00013116	Hex Cap Screw, 5/16-18 x 1.25	26	01009366	Rubber Grommet
6	00013675	Washer	27	01009457	U-Bolt
7	00017584	Carriage Bolt, 1/4-20 x .75	28	01009464	Rubber Engine Mounting
8	00022560	Hex Nut, 3/8-16 Flange Lock	29	02004352	Nut, 5/16-18, Flange Whiz, SS
9	00060078	Grease Fitting, 1/4-28 x 3/16	30	02004558	Pulley, 3.25 OD
10	710-3005	Hex Cap Screw, 3/8-16 x 1.25	31	02004567-0637	Engine Idler Plate
11	710-0642	Self Tapping Screw, 1/4-20 x .75	32	680-00025-0637	Foot stand Weldment
12	712-3004A	Nut, 5/16-18, Hex Flange Lock	33	703-06867-0637	Fender, RH
13	712-3075	Jam Nut, 1.0-14	34	703-07020-0637	Bracket
14	936-0133	Flat Washer, 1.25 x .411 x .100	35	703-07084-0637	Fender, LH
15	01001864	Self Tapping Screw, 10-24 x .50	36	703-07086-0637	Cover Plate
16	912-3027	Lock Nut, 1/4-20	37	703-07136-0637	Cable Mounting Bracket
17	01007972P	Engine, Kawasaki	38	703-07189-0637	Engine Plate
18	01008016	Fan Guard	39	703-07191-0637	Isolator Mounting Bracket
19	01008763	Hex Cap Screw, 1/4-20 x .75	40	712-04063	Nut, 5/16-18, Nylon Flange Lock
20	01008764	Hex Cap Screw, 5/16-18 x .75	41	732-04629	Extension Spring, .75 x 4.280
21	01008877-0637	Clevis Pin Pivot Weldment	42	738-04162A	Shoulder Spacer, .884 x .190

Impeller Assembly




Ref.	Part Number	Description
1	00030317	Impeller
2	00030382	Impeller Shaft
3	00030384	Oil Gearset Seal
4	00030385	V Gearset Seal
5	00030415	Tap Screw
6	00030591	Gearset Housing
7	00030592	Gearset Cover
8	00030593	Gearset Cap
9	00030594	Bevel Gearset Gear
10	00030595	Pinion Gearbox Gear
11	00060022	Roll Pin, 1/8 x 5/8
12	00060069	Roll Pin, 1/8 x 7/8, SS
13	01000129	Screw, 8-18, #6 x 5/8

Front Frame Assembly




Ref.	Part Number	Description	Ref.	Part Number	Description
1	00031485	Carriage Bolt, 5/16-18 x 3/4, SS	11	01009255	Jam Nut, 3/4-16
2	00060019	Roll Pin, 5/32 x 1-1/4, SS	12	01009256	Shut-Off Cable bracket
3	00060078	Grease Fitting, 1/4-28 x 3/16	13	01009257	Deflector Cable bracket
4	712-0161	Nut, #10-24	14	01009304	Shield, SS
5	01004185	Hex Cap Screw, 3/4-16 x 6.50	15	01009499	Shaft Collar
6	01007833	Front Axle	16	01009831	Screw, 10-24 x 1.25
7	680-00038-0637	Handle Weldment	17	01009896	Bushing
8	01009341	Front Frame Weldment Includes:	18	01009897	Washer, .89ID x 1.5OD x .09, SS
	00060078	Grease Fitting, 1/4-28 x 3/16	19	680-00028	Pivot Bracket Weldment
	00060041	Axle Bearing	20	02004352	Nut, 5/16-18, Flange Whiz, SS
9	634-04556	Drive Wheel Assembly, 13 x 6.5-6	21	02004353	Carriage Bolt, 1/4-20 x 3/4, SS
10	634-04557	Idler Wheel Assembly, 13 x 6.5-6	22	02004354	Nut, 1/4-20 Flange Whiz, SS

Remote Deflector Assembly



Ref.	Part Number	Description
1	00018628	Washer, 1/4
2	00030503	Deflector Arm Spacer
3	00035030	Offset Deflector Bracket
4	00060029	Machine Screw, 1/4-20 x 2
5	00060033	Washer, 1/4, SS
6	712-0324	Nut, 1/4, SS
7	00060057	Machine Screw, 1/4-20 x 7/8
8	00060059	Nut, 1/4-20
9	00061052	Cotter Pin, 1/8 x 1, SS
10	00061053	Washer, 3/8, SS
11	00061066	Deflector Tube
12	01006253	Deflector Mount Lever
13	01006254	Deflector Mount Weldment
14	02000775	Socket Head Screw, 1/4-20 x 7/8


Shut-Off Plate Assembly



Ref.	Part Number	Description
1	00017288	Pivot Lever Assembly
2	00020492	Slide Lever
3	00020511	Remote Third Hole Wire Bracket
4	02004552	Cotter Pin
5	00060033	Washer, 1/4, SS
6	712-0324	Nut, 1/4-20, SS
7	00060056	Nut, 8-32
8	00060061	Pivot Lever Rod
9	00060083	Lock Washer



Ref.	Part Number	Description
10	01004186	Spring Clip
11	01004539	Pivot Assembly Mounting Plate
12	01004955	Shut-Off Plate Clip
13	01004956	Shut-Off Plate Spring
14	01005630	Washer, #8, SS
15	01005631	Screw, #8 x 3/8, SS
16	01005632	Screw, #8 x 5/8, SS
17	01006825	Shut-Off Plate
18	01009496	Hex Cap Screw, 8-32 x 1/2, SS

Control Assembly




Ref.	Part Number	Description
1	712-0161	Nut, #10-24
2	00011075	Washer, 5/16
3	00012152	Nut, 1/4-20
4	912-0429	Nut, 5/16-18
5	00012169	Washer, 5/16
6	00016771	Washer, 3/16
7	00060033	Washer, 1/4, SS
8	00083192	Idler Washer
9	936-0463	Washer, 1/4 x .630 x .0515
10	01009931	U-Nut, #10-16
11	01001714	Grip
12	01007997-0637	Control Lever Weldment
13	01009483	On/Off Lever Weldment
14	01009169P	3rd Hole Control
15	01009171	Remote Deflector Cable
16	01009172	Throttle Control
17	946-04566	Reverse Cable
18	946-04567	Forward Cable
19	01009251	On/Off Cable
20	01009322	Shoulder Bolt, 1/4 x 1/4
21	01009323-0637	Speed Control Lever
22	01009333	Compression Spring
23	01009358	Shoulder Bolt, 1/4 x 1.25
24	01009361	Shoulder Bolt, 5/16 x 1.50
25	01009363	Hex Cap Screw, 10-24 x .50
26	01009365	Rubber Grommet
27	01009369	On/Off Lever Knob
28	01009377	Nut, 10-24, w/Star Washer
29	01009459	Shoulder Bolt 3/8 x 1.50
30	01009482	Speed Control Grip
31	01002511	Jam Nut, 3/8-16

Transmission Assembly



Ref.	Part Number	Description
1	00011459	Washer, 1/2
2	712-0161	Lock Nut, #10-24 w/Nylon Insert
3	00012169	Washer, 5/16
4	712-04065	Nut, 3/8-16
5	00012187	Lug Nut, 1/2-20
6	00020508	Carriage Bolt, 5/16-18 x .75
7	00021961	E-Ring
8	00023796	Washer, .781 ID x 2.00 OD x .105
9	00060017	Washer, .06 x .776 x 1.25, SS
10	936-0463	Washer, 1/4 x .630 x .0515
11	712-3004A	Nut, 5/16-18, Hex Flange Lock
12	01001161	Self Tapping Screw, 5/16-18 x .625
13	912-3027	Nut, 1/4-20
14	914-0104	Cotter Pin, .072 x 1.12 Long
15	01003561	Nut, M8, Top Lock
16	01007935P	Transmission, Hydro Gear
17	734-04558	Wheel Assembly, 18 x 6.50-8
18	01009148	Brake Lever Rod
19	01009149	Brake Lever
20	711-05207	Ferule, .750 x .313
21	01009246	Wheel Hub Assembly
22	01009366	Rubber Grommet
23	01009458	Key, 3/16 x 3/16 x 2
24	732-04632	Extension Spring
25	01009737	Shoulder Bolt, 5/16 x 1.00
26	01009829	Damper Assembly
27	01010129	Self Tapping Screw, 1/4-20 x .75
28	703-07012-0637	Transmission Skid Plate
29	711-05108	Ferule, .625 x .25
30	912-0429	Nut, 5/16-18, Nylock
31	712-0711	Hex Jam Nut, 3/8-24
32	747-05070	Bypass Rod
33	732-04636	Spring, 0.340 x 1.38 LG
34	936-0175	Washer, .265 x .562 x .025
35	938-0380	Shoulder Bolt, .500 x .270, 3/8-16
36	936-0329	Washer, Lock

Decal Assembly



Ref.	Part Number	Description
1	00023817	Foot pad-Abrasive
2	777D09157	Decal, Cub Cadet Commercial
3	777D09015	Decal, Cub Cadet Commercial, Small
4	01009743	Decal, Throttle
5	01009744	Decal, Speed Control
6	01009745	Decal, Operator Panel
7	777I23117	Decal, Cub Cadet Commercial, XP
8	01009747	Decal, Parking Brake
9	01009748	Decal, Fwd/Rev
10	777D12837	Decal, Warning Spark



To order replacement parts, call the Customer Dealer Referral Line at 1-877-282-8684
or visit www.cubcadet.com to find the nearest Cub Cadet dealer in your area.

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
