


SPINNING REEL — EL1655H / 2055H



Key

No.	Part No.	Part Name
1	K09-4601	Spool assembly
2	K09-3801	Main shaft
3	B10-5701	Rotor nut
4	K09-2801	Rotor
5	B83-6701	Bail trip lever
6	K09-3301	Bail trip cover
7	K07-1501	Bail trip cover screw
8	B67-9303	Line roller screw
9	F03-6901	Bail arm
10	F03-7101	Bail arm screw
11	320-5901	Bail arm screw retainer
12	B55-4301	Line roller washer
13	L01-8201	Line roller
14	K09-3101	Bail
15	B84-2101	Bail trip cam screw
16	E21-3501	Bail spring shaft
17	K11-0301	Bail spring
18	F03-7001	Trigger lever
19	E36-9901	Trigger spring
20	E37-0001	Trigger screw
21	K09-3001	Bail spring cover
22	K07-1501	Bail spring cover screw
23	K09-7001	Rotor washer
24	K09-1801	Anti-reverse ratchet
25	K09-7101	Anti-reverse pawl spring
26	B54-6001	Ball bearing
27	K09-1501	Pinion gear
28	K09-5701	Body
29	K09-1301	Anti-reverse cam
30	144-0321	Anti-reverse cam spring
31	K09-2001	Anti-reverse pawl screw
32	K09-1901	Anti-reverse pawl
33	K50-0601	Bearing retainer screw

Key

No.	Part No.	Part Name
34	K09-1401	Anti-reverse lever
35	353-4402	Anti-reverse lever screw
36	B46-9505	Drag washer A
37	B76-9803	Click gear
38	E14-3301	Drag washer B
39	K05-0301	Eared washer A
40	E02-4401	Key washer
41	B83-9501	Eared washer B
42	B98-2901	Drag coil spring
43	B77-0004	Drag screw
44	B77-0301	Drag washer spring
45	K09-2501	Drag knob
46	352-1107	Drag knob screw
47	K09-3401	Oscillating gear collar
48	B74-3701	Oscillating gear
49	K09-3501	Oscillating slider
50	K09-4001	Oscillating slider retainer
51	351-0903	Oscillating block screw
52	K09-3601	Drive gear
53	373-7802	Drive gear washer
54	K09-6401	Side cover
55	K08-7801	Side cover screw
56	K09-4301	Handle assembly
57	K09-7301	Handle lock washer
58	B92-5001	Handle lock screw

EL2055H Special Parts:

1	K09-4701	Spool assembly
4	K09-2901	Rotor
5	B83-7301	Bail trip lever
14	K09-5501	Bail
28	K09-6001	Body
54	K09-6701	Side cover