


SPINNING REEL — EX600

※ These parts are not assembled in
silent anti-reverse model.



Key No. 2-8

F03-3901 Spool assembly

Key

No.	Part No.	Part Name
1	F03-3801	Drag knob
2	F44-2501	Drag washer retainer
3	F03-3201	Click plate washer
4	E13-6301	Drag knob click plate
5	E13-6001	Drag washer
6	E13-6201	Eared washer
7	E13-6102	Key washer
8	F03-4001	Spool assembly
9	F06-2701	Spool washer
10	B35-8601	Ball bearing A
11	E12-2301	Click leaf spring holder
12	B74-7702	Spool click leaf spring
13	F03-3501	Main shaft assembly
14	320-1402	Ball bearing retainer
15	341-9204	Rotor nut
16	F05-9601	Rotor assembly
17	F01-5001	Line roller screw
18	F03-0701	Bail arm
19	F01-3501	Bail arm screw
20	320-5901	Bail arm screw retainer
21	F01-4901	Line roller collar
22	B85-3101	"O" ring
23	F05-5601	Ball bearing B
24	F06-3201	Line roller
25	F03-0901	Bail
26	F05-9801	Bail trip cam screw
27	F03-1101	Bail spring shaft
28	E11-5901	Bail spring washer
29	F03-1201	Bail spring
30	F03-0501	Bail spring cover
31	F01-3701	Bail spring cover screw
32	F03-0801	Bail trip lever
33	F03-0601	Bail trip cover
34	F03-2901	Bearing retainer
35	351-1801	Bearing retainer screw
36	636-6401	Ball bearing C
37	E29-6101	Spacer
38	E27-1501	Anti-reverse ratchet

Key

No.	Part No.	Part Name
39	F05-3601	Pinion gear
40	F06-6602	Body
44	E26-8701	Anti-reverse cam spring
45	F01-2708	Anti-reverse lever
46	B33-9801	Worm shaft gear retainer
47	E39-3001	Worm shaft gear
48	E29-6501	Worm shaft bush
49	F03-0401	Worm shaft
50	F03-2801	Worm shield cover
51	F01-1004	Oscillating slider
52	E12-2403	Oscillating pawl
53	E12-4601	Oscillating pawl bush
54	375-0800	Oscillating pawl washer
55	E11-6801	Oscillating slider cover
56	E15-0203	Oscillating slider cover screw
57	375-4101	Worm shaft washer
58	E29-6701	Worm shaft retainer
59	E29-6601	Worm shaft collar
60	F03-3101	Water shield
61	F03-2002	Rear cover
62	F01-6301	Rear cover screw
63	E27-1301	Anti-reverse pawl
64	B95-9501	Anti-reverse pawl collar
65	B95-9602	Anti-reverse pawl spring A
66	351-6401	Anti-reverse pawl screw
67	F01-6401	Ball bearing D
68	E29-6901	Anti-reverse pawl spring B
69	F05-5701	Drive gear
70	375-8502	Drive gear washer
71	636-6401	Ball bearing C
72	F03-4101	Left side cover
73	351-1101	Side cover screw
74	501-8501	Handle collar
75	F04-5001	Handle screw
76	F01-7301	Handle screw cap
77	F03-3601	Handle assembly
78	375-8500	Bearing washer