


SPINNING REEL — PM2600H / 4000H



Key No. 2-8

Key No.	Part No.	Part Name
	E39-8701	Spool assembly
1	E40-2602	Drag knob
2	170-4101	Drag washer retainer
3	F03-9701	Drag washer retaining ring
4	F03-5101	Key washer
5	B36-0207	Drag washer
6	372-3832	Eared washer
7	F04-0001	Spool assembly
8	E39-7701	"O" ring
9	E39-9201	Spool washer A
10	F04-3401	Spool washer B
11	E12-2304	Click leaf spring holder
12	B74-7701	Spool click leaf spring
13	E26-7501	Main shaft washer
14	F03-5201	Main shaft
15	E33-3801	Rotor nut holding plate
16	B93-3001	Rotor nut holding plate screw
17	B43-7604	Rotor nut
18	E39-5802	Rotor
19	E39-6305	Bail spring screw
20	E10-7402	Bail spring cover screw
21	353-8207	Line roller screw
22	B11-2701	Lock washer
23	E39-6001	Bail arm
24	E00-7601	Bail arm screw
25	E26-6501	Line roller collar
26	B41-3001	Line roller bushing
27	E33-8901	Line roller
28	E39-8601	Bail
29	E32-6701	Bail spring shaft
30	E31-3901	Bail spring washer
31	E39-5901	Bail spring
32	E39-6101	Line guard shaft
33	B33-9801	Line guard retainer
34	E39-6201	Line guard plate
35	F06-3301	Line guard spring
36	B27-0701	Bearing washer
37	637-6101	Ball bearing
38	F03-5001	Spacing sleeve
39	E26-2701	Anti-reverse ratchet
40	E39-0201	Pinion gear
41	E33-2101	Pinion holder

Key

Key No.	Part No.	Part Name
42	E39-8101	Body assembly
43	E03-7801	Bearing retainer screw
44	E32-7801	Anti-reverse cam spring
45	F03-5402	Anti-reverse lever
46	E39-5402	Rear cover
47	320-5901	Worm shaft gear retainer
48	E39-0301	Worm shaft gear
49	E39-3501	Worm shaft bush
50	E39-5101	Oscillating slider
51	E26-4101	Oscillating pawl
52	E26-4201	Oscillating pawl bush
53	375-0800	Oscillating pawl washer
54	E26-4301	Oscillating slider cover
55	352-1502	Oscillating slider cover screw
56	E39-5201	Worm shaft
57	375-4101	Worm shaft washer
58	E19-1101	Worm shaft collar
59	F04-3101	Worm shaft retainer
60	E26-1901	Anti-reverse pawl plate
61	E26-2001	Anti-reverse pawl
62	E26-2101	Anti-reverse pawl collar
63	E26-2201	Anti-reverse pawl spring A
64	B83-5002	Anti-reverse pawl screw
65	E26-4501	Anti-reverse pawl spring B
66	E39-5301	Drive gear
67	371-2822	Drive gear washer
69	F04-3701	Side cover
70	B00-9702	Side cover screw A
71	B00-9701	Side cover screw B
72	E11-9601	Side cover screw C
73	F04-3901	Handle assembly
74	501-8401	Handle collar
75	L00-9102	Handle lock screw

PM4000H Special Parts:

2-8	E40-0901	Spool assembly
7	F04-0301	Spool assembly
8	E40-2901	"O" ring
18	E39-9702	Rotor
28	E40-0801	Bail
42	E39-8102	Body assembly
69	F04-3703	Side cover