




Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	6G446301	Drag Knob	42	6G472501	Ball Bearing (B)
2	6F373301	Drag Washer Retainer	43	6G193501	Collar (B)
3	6E467201	Key Washer	44	6B275403	Washer (C)
4	6E136001	Drag Washer	45	6F622301	Clutch Cam Retainer
2-5	6G451701	Spool Assembly	46	6F622201	Clutch Cam
2-5	6G451701	Spool Assembly (Extra Spool)	47	63758502	Washer (D)
6	6E467101	Washer (A)	48	6F732501	Spacing Sleeve
7	6F704901	Spool Click Leaf Spring	49	6G220601	Roller Clutch
8	6E122308	Click Leaf Spring Holder	50	6G279601	Ball Bearing (C)
9	6F811501	Click Gear	51	63758504	Washer (E)
12	6G291401	Main Shaft	52	6G291101	Pinion Gear
13	6G061601	Oscillating Slider	53	6G445801	Body
14	63510315	Screw (A)	54	6G193115	Anti-Reverse Lever
15	6F336102	Rotor Nut	55	6G193301	Anti-Reverse Cam Spring
16	6G206213	Rotor	56	6G114300	Washer (F)
17	6G195601	Screw (B)	57	6F691702	Oscillating Gear
18	6G206405	Bail Arm	58	6G206105	Rear Cover
19	6G224901	Screw (C)	59	6G400102	Screw (H)
21	6F897101	Washer (B)	60	6G061701	Drive Gear
22	6G281601	Ball Bearing (A)	61	63758500	Washer (G)
23	6F921601	Line Roller	62	66375702	Ball Bearing (D)
24	6G047601	Collar (A)	63	6G206008	Side Cover
25	6G514501	Bail Assembly	64	6G332903	Screw (I)
26	63516101	Screw (D)	65	6G333003	Screw (J)
27	6G017503	Bail Spring Shaft	66	6G445901	Handle Assembly
28	6G062401	Bail Spring	67	6F721001	Collar (C)
29	6G017401	Bail Spring Holder	68	6F676510	Screw (K)
30	6G206506	Cover (A)	69	6G256401	Washer (H)
31	6G205102	Screw (E)	70	6F016401	Ball Bearing (E)
32	6G195101	Bail Holder Nut	71	6G256401	Washer (I)
33	6G450101	Cover (B)	72	6G334001	Ball Bearing (F)
34	6G194101	Bail Trip Lever Spring	73	63753005	Washer (J)
35	6G265701	Bail Trip Lever			
37	6G194301	Brake Shoe			
39	6G193701	Screw (F)			
40	6G332701	Screw (G)			
41	6G193601	Bearing Retainer			

TDA 2000 SPECIAL PARTS

Key No.	Parts No.	Parts Name
2-5	6G451901	Spool assembly
2-5	6G451901	Spool assembly (Extra spool)