




Product Description:Chain Saw
Model Number:CS1810
Service Item Number:F840052001S01
Version:A
Issue Date: 2025/06/5



Service Part List_CS1810_Version A

No.	Product Model#	Part Number	Description	Qty
1	CS1810	2828587001	Kettle Cover Assembly	1
2	CS1810	2826726001	Pump ASSY	1
3	CS1810	3136534001	Rear Tube	1
4	CS1810	3706993007	Guide	1
5	CS1810	3810738002	Chain	1
6	CS1810	3130408001	Sheath	1
7	CS1810	3136825001	Front Handle	1
8	CS1810	5610291003	Tapping Screw	4
9	CS1810	3708646001	Wood Teeth	1
10	CS1810	5620566003	Hexalobular Socket Screw	2
11	CS1810	3136828001	Top Cover	1
12	CS1810	3580556001	Bushing	1
13	CS1810	3403739001	Brake Handle	1
14	CS1810	2827226001	Brake Assembly	1
15	CS1810	3660756001	Compression Spring	1
16	CS1810	5670028003	Pin	1
17	CS1810	3660802001	Tension Spring	1
18	CS1810	5620479001	Screw	38
19	CS1810	3710256001	Protecting Cover Plate	1
20	CS1810	3423869001	Cover Plate	1
21	CS1810	2852395001	Lead Screw and Lead Nut Set	1
22	CS1810	3520792001	Bevel Gear	4
23	CS1810	3123928003	Rubber Pole	1
24	CS1810	3553864001	Knob Rod	1
25	CS1810	3136821001	Trigger Lever	1
26	CS1810	3700353001	Washer	1
27	CS1810	5640641001	Hexagon Head Bolt	1
28	CS1810	5670870001	Hexagon pin	1
29	CS1810	3136820001	Compress Cover Plate	1
30	CS1810	3700182001	Washer B	1
31	CS1810	3136819001	Fan Baffle	1
32	CS1810	3520474001	Bush	2
33	CS1810	5680216001	Key	1
34	CS1810	3130336001	Worm	1
35	CS1810	5660011001	Circlips For Shaft	1
36	CS1810	5620019005	Hexagon Socket Screw	3
37	CS1810	5690474001	Felt Ring	1
38	CS1810	3556112001	Brake Disc	1
39	CS1810	5690440001	Felt Ring	1
40	CS1810	3556131001	Chain Wheel	1
41	CS1810	3709185001	Baffle Piece	1
42	CS1810	5660242001	"E" Ring	1
43	CS1810	3136824001	Brake Cover Plate	1
44	CS1810	3709191001	Chip Shield	1
45	CS1810	3135070001	Baffle	1
46	CS1810	2832590001	LED Driver Electric Assembly	1
47	CS1810	5610394001	Hexalobular Socket Tapping Screw	5
48	CS1810	3136369001	Cover Plate	1
49	CS1810	2832603001	Electric Assembly	1
50	CS1810	3660427002	Spring	1
51	CS1810	3135018001	Lock off Button	1

52	CS1810	2850767001	Switch Trigger Set	1
53	CS1810	3132739001	Push-out Lever Bracket	1
54	CS1810	3660979001	Compression Spring	1
55	CS1810	3131427001	Sliding Block	1
56	CS1810	3127507001	Support	1
57	CS1810	3660013001	Spring1	1
58	CS1810	3127497001	Power Pack Button	1
59	CS1810	3127498001	Power Pack Button	1
60	CS1810	2246551002	Nameplate	1
201	CS1810	2852987001	Kettle Assembly	1
202	CS1810	2853016001	Motor Assembly	1
203	CS1810	2852988001	Housing Assembly	1
204	CS1810	2852507002	Cover Plate Assembly	1