


Setup Guide for Mac • Installationshandbush für Mac • Guide d'installation pour Mac • Guida di installazione per Mac •
Guía de instalación para Mac • Installatie handleiding voor Mac • Průvodce nastavením pro Mac • Beállítási útmutató Mac-hez •
Instrukcja instalacji dla komputerów Mac • Руководство по настройке для Mac • Mac орнату нұсқаулығы • دليل الإعداد لماكنتوش •
Pedoman Pengaturan untuk Mac

1.

PP-100II

PP-100AP/PP-50



Note: The power cable and warranty card may not be included, depending on the country of purchase.

Anmerkung: Das Netzkabel und die Garantiekarte sind möglicherweise nicht beigelegt, je nach dem, in welchem Land Sie das Gerät gekauft haben.

Remarque: le câble d'alimentation et la carte de garantie ne sont pas systématiquement inclus, selon le pays d'achat.

Nota: il cavo di alimentazione e la scheda di garanzia potrebbero non essere inclusi, a seconda del paese di acquisto.

Nota: El cable de alimentación y la tarjeta de garantía pueden no estar incluidos en función del país de la compra.

Opmerking: De voedingskabel en garantiekarta kunnen afhankelijk van het land van aankoop niet zijn bijgevoegd.

Poznámka: Napájecí kabel a záruční list nemusí být součástí dodávky, v závislosti na zemi koupě.

Megjegyzés: a vásárlási ország függvényében lehet, hogy a termékhez nem mellékelünk elektromos kábelt és garanciajegyet.

Uwaga: kabel zasilający i karta gwarancyjna mogą nie być dołączone, w zależności od kraju zakupu.

Примечание: В зависимости от страны покупки в комплектации может не быть шнура питания и гарантийного талона


Ескертпе: Қуат кабелі және кепілдік талоны сатып алған еліңізге қарай бірге жеткізілмеуі мүмкін.

ملاحظة: ربما لا يكون كبل الطاقة وبطاقة الضمان مرفقين، وفقاً لبلد الشراء.


Catatan: Kabel Listrik dan kartu garansi mungkin tidak disertakan, tergantung dari masing-masing Negara.

2.

PP-100II/PP-100AP




PP-50




3.

PP-100II




4.

PP-100II/PP-100AP




PP-50




5.



PP-100II






PP-100AP







PP-50







6.




7.



8.




9.




10.


PP-100II




PP-100AP




PP-50



11.



Add "EPSON Disc Producer."
EPSON Disc Producer hinzufügen.
Ajoutez "EPSON Disc Producer."
Aggiungere "EPSON Disc Producer."
Añada "EPSON Disc Producer."
"EPSON Disc Producer" toevoegen.
Doplnit "EPSON Disc Producer."
„EPSON Disc Producer” hozzáadása
Dodaj „EPSON Disc Producer”
Добавьте "EPSON Disc Producer."
"EPSON Disc Producer" қосыңыз.
"EPSON Disc Producer" إضافة
Tambahkan "EPSON Disc Producer."



<http://www.adobe.com/>

Getting More Information • Mehr Informationen erhalten. • Obtenir des informations plus détaillées •
Per ottenere ulteriori informazioni • Obtener más información • Meer informatie verkrijgen •
Získání dalších informací • További információk • Aby uzyskać więcej informacji •
الحصول على مزيد من المعلومات •
Untuk informasi lebih lanjut