

Loading custom paper types for the SureColor P10000 and P20000 Production Edition printers:

Epson DisplayTrans II
Epson Poster Paper Production (175)
Epson Poster Paper Production (210)
All Vinyl, Poly and Tyvek signage medias
Photo Tex

Note: The following document shows you how to load custom paper types built by Epson America. Creating custom paper types for your SureColor P10000 and P20000 printers is highly recommended to achieve the best results.

The latest firmware is required to install these files. The printer must be on and display Ready on the LCD panel.

1. Open the EPSON LFP Remote Panel 2 software utility (pictured at right).
2. To import the provided custom paper types, click the **Media Settings Backup/Setup** button.
3. Load the included file
SC-P10000_P20000_Series_MediaSettings_v1.Cpb
4. Load current settings from the printer
The printer must be on and ready
5. Select the media(s) to be installed
6. Copy the Media Setting(s) to the Printer
7. Click-on "Import to Printer"

