

User Replaceable Items effective 12/01/2005

PowerLite 720c / 730c

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable (2-prong cable)	207 1477
RCA AV Cable	206 8507
Computer Cable (VGA Cable)	207 1748
USB Mouse Cable	110 1569
Lamp (V13H010L18)	H010L18
Remote Control	600 8203
Lens Cap with String	110 8344
User's Manual	402 5288
Navy Blue Carrying Case with handle and shoulder strap (outside compartment for cables)	1273485

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.