

User Replaceable Items effective 12/01/2005

PowerLite TW-100 and TW-100UG

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable	201 7328
Lamp (V13H010L17)	600 7189
Remote Control	600 7793
Lens Cap with String	109 4110
User's Manual	402 1788

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find...” tool in the right column of the [Epson Support](#) home page.