

User Replaceable Items effective 12/01/2005

PowerLite S3

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable (2-prong cable)	2071477
PL S3 Lamp (V13H010L33)	H010L33
Computer VGA Cable	2071748
Projector Remote Control	1306200
Lens Cap with String	130 4678
Projector Software CD (includes User's Guide)	CPD-19503
Soft (black) Carrying Case with shoulder strap	1400702

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find...” tool in the right column of the [Epson Support](#) home page.