

PowerLite 1810p / 1815p / 1825

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable	208 0118
Lamp (V13H010L40)	146 1869
Remote Control	145 2589
Computer Cable	211 0978
Projector Software CD (includes user's guide and registration)	
Air Filter Set	V13H134A08
Soft carrying case	145 6324
CD includes UG and Product Registration (1810/1815)	CPD-23266R1
 PL1815p / PL1825:	
Wireless LAN Card 802.11 a/b/g	211 4950
Security Screw for Wireless I/F	130 2469
USB 2.0 cable	210 9210
Projector Software CD (PL 1815)	
- NS connect v2.10	3101925
- SlideMaker2 v1.13	
- EMP Monitor v4.10	
 Projector Software CD (PL 1825)	
- NS connect v2.30	3102896
- SlideMaker2 v1.20	
- EMP Monitor v4.21	
CD includes UG and E-Reg (1825)	CPD-24803

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.