




USER MANUAL

PetCare Water Fountain



Anker Innovations Limited. All rights reserved. eufy Security and eufy Security Logo are trademarks of Anker Innovations Limited, registered in the United States and other countries. All other trademarks are the property of their respective owners.

Model:T7220 51005002492 V01

TABLE OF CONTENTS

01	IMPORTANT SAFETY INSTRUCTIONS
01	WHAT'S IN THE BOX
02	AT A GLANCE
04	GETTING STARTED
06	USING SMART PET FOUNTAIN
06	MAINTENANCE
07	SPECIFICATIONS
07	NOTICE


1 / IMPORTANT SAFETY INSTRUCTIONS

1. When the device is not in use, the power should be turned off.
2. The power should be turned off while cleaning the base. Ensure that it is fully dry before use.
3. Make sure the water level in the tank is between the "MIN" and "MAX" water line which is marked inside the main body.
4. The transparent cover is detachable. DO NOT lift the device by the cover when moving it.
5. Replace the Purification Filter and Sterilization Filter every 1.5 months.
6. Excess impurities on the filter will reduce water quality and lower the water penetration speed. We recommend cleaning the filters each time you clean the device.

2 / WHAT'S IN THE BOX



Water Fountain



Bite-proof
Charging
Cable (1.5m)



Sterilization
Filter



Purification
Filter x 2




User Manual




5V1A
Adapter


3 / AT A GLANCE



Inside View



Sterilization Filter




What it does:


Kills *Escherichia coli*, *Salmonella*, and *Candida albicans* to protect pets from getting acute gastroenteritis and feline dermatophytosis.

4 / GETTING STARTED


1. Place the sterilization filter in the filter cover and press down it until it sits at the bottom . Place the filter in the purification filter cover.
2. Align the filter cover with the groove under the drinking tray and turn it counter-clockwise until it locks in place.




3. Insert the head of the water pipe into the side outlet of the drinking tray. Make sure the water pipe is inserted correctly.



- 4. Pour water into the main body. Make sure the water level is between the "Min" and "Max" water lines that are marked on the inside.
- 5. Align the drinking tray with the main body as illustrated until it clicks into place.



- 6. Attach the transparent cover onto the main body by pressing it down until it is fixed into place.



5/ USING PETCARE WATER FOUNTAIN

- 1. Connect your PetCare Water Fountain to a power outlet using the provided USB charging cable and adapter (5V/1A).
- 2. After it is powered on, the PetCare Water Fountain will continuously dispense water.

Note: When the water level is lower than the MIN water line, the pump will stop working. It will resume normal operation after the water is filled.

6/ MAINTENANCE

For optimal performance, follow the instructions below to clean and maintain your PetCare Water Fountain regularly. Cleaning or replacement frequency will depend on your usage habits.

PetCare Water Fountain Part	Cleaning Frequency	Replacement Frequency
Sterilization filter	Once every week	Every two months
Purification filter	Once every week	Every two months
Water pump	Once every week	Replace after it is damaged

7 / SPECIFICATIONS

Dimension: 200 mm (Width) × 200 mm (Depth) × 207 mm (Height)

Net Weight: 750 g / 50 oz

Material: ABS

Capacity: 1.5L

Input: 5V=1A

8 / NOTICE

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/ TV technician for help.

FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure conditions. The min separation distance is 20cm.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

The following importer is the responsible party.

Company Name: POWER MOBILE LIFE LLC

Address: 400 108th Ave. NE Ste 400, Bellevue, WA 98004-5541

Telephone:1-800-988-7973

Customer Service

Anker Innovations Limited

Room 1318-19, Hollywood Plaza, 610 Nathan Road, Mongkok, Kowloon, Hong Kong

Warranty

12-month limited warranty



United States +1 (800) 988 7973 Mon-Fri 9AM-5PM (PT)

United Kingdom +44 (0) 1604 936 200 Mon-Fri 6AM-11AM (GMT)

Germany +49 (0) 69 9579 7960 Mon-Fri 6:00-11:00



Customer Support: support@eufylife.com



@EufyOfficial



@EufyOfficial



@EufyOfficial