





Quick Start Guide

Vacuuming



Remove the foam blocks beside the bumper before use.

If you cannot remove the objects surrounding the Charging Base, check whether RoboVac can return without assistance; if not, contact eufy Customer Service for help.





Always keep the Charging Base plugged in, otherwise RoboVac will not automatically return.

When the Charging Base is connected to AC power, the LED on the Charging Base is solid white.



Fully charge RoboVac before use. The LED on RoboVac will pulse blue while charging, and will be solid blue when fully charged.




Download the EufyHome app and follow the in-app instructions to complete the Wi-Fi connection. You will then be able to control RoboVac via this app. Refer to the "Use Your RoboVac with the EufyHome App" section in the Owner's Manual for details.



eufy

For FAQs and more information, please visit:
www.eufylife.com

Mopping




Cleaning and Maintenance



Important Tips

When using for the first time, follow RoboVac to observe and resolve any problems that may occur.



- A** Remove power cords and small objects from the floor that may entangle RoboVac.
- B** Fold tasseled edges of rugs underneath to prevent tangling RoboVac. Avoid cleaning dark-colored high-pile rugs or rugs thicker than 1.02 in / 26 mm as they may cause RoboVac to malfunction.
- C** It is strongly recommended to set a No-Go zone or a virtual boundary in the EufyHome app in front of fireplaces and certain areas (i.e. air vents) that may cause damage to RoboVac if entered.
- D** Keep RoboVac away from wet areas during cleaning.
- E** RoboVac may climb on top of objects less than 0.79 in / 20 mm in height. Remove these objects if possible.
- F** Anti-drop sensors will prevent RoboVac from tumbling down stairs and steep drops in most cases. Sensors are less effective if dirty or used on carpeted / reflective / dark-colored floors. It is recommended to place physical barriers or set a No-Go zone / a virtual boundary in the EufyHome app to block off areas where RoboVac may fall.