




Fender®


AMP STAND




PARTS



HARDWARE




1







2

A1





3



3





4




5




6



7




8




6


9




10




11




12




13




14




15




16




17



18



19



20

