

FISHER[®] RESEARCH
LABS

CW-10

OWNER'S MANUAL



**FISHER
RESEARCH LABS**
SINCE 1931
www.FisherLab.com

Table Of **Contents**

Set Up.....	3
Controls & Functions	3
Battery Replacement	3

SET UP

Your CW-10 Hand Held weapons detector comes ready to use. A 9-Volt battery was installed at the factory and the CW-10 is automatically calibrated when the unit is turned on; there is no tuning required. For quick operating instructions, read the condensed operating instructions on the unit.

CONTROLS & FUNCTIONS

Move the 3-way position switch forward for audio alarm or back for silent vibrate alarm. The CW-10 will operate in its selected mode until the switch is returned to the central (Power Off) position. The unit also has a LED light. A solid red light indicated a target has been detected, a flashing green light indicates the power is on and, a flashing red light is a low battery indicator.

To begin scanning, grasp the CW-10 with either hand. If you are using more than one unit or using in conjunction with Fisher's Portable Walk Through Metal Detector the M-Scope, Fisher recommends that there is a distance of 3 feet between units.

The CW-10 is a motion detector; it will detect metal as long as it is in motion. Move the unit as close to the subject being scanned as possible. The audio or vibrator will alarm and the LED will be solid red when a target is detected. Fisher recommends that you practice your search technique on a metallic object such as your key ring or watch to decide what distance and sweep speed will fit your needs.

BATTERY REPLACEMENT

The CW-10 runs on one 9-Volt battery housed in the handle section of the unit. The LED will flash red to indicate a low battery. To replace your battery, remove the strap and slide back the battery cover on the end of the handle. Tilt the unit and the battery will slip out. Replace with a new battery, slide the battery cover back on and, replace the strap. The battery cover will not slide back if the battery is inserted improperly, do not force the cover on.

SPECIFICATIONS

Operating Frequency	110 kHz
Audio Frequency	2700 Hz
Battery	Single 9 Volt (Included)
Battery Life	30 to 40 hours
Warranty	2 Year Limited Warranty
Operating Temperature	0°F to 160°F (-20°C to +70°C)
Detection Type	All Metal (Ferrous & Non-Ferrous)
Alarm Modes	Audio or Silent Vibrate
Switch Type	3-Position (Power / Audio / Vibrate)
Sensitivity	Factory Set
Low Battery Indicator	Yes (LED)
Dimensions (inches)	5.75 x 2.5 x 1
Dimensions (cm)	40 x 6.35 x 2.54
Weight (with battery)	11.2 oz / 317.5 g
Wight (without battery)	9.6 oz / 272 g

WARRANTY

This product is warranted against defects in materials and workmanship under normal use for two years from the date of purchase by the original owner. Liability in all events is limited to the purchase price paid. Liability under this warranty is limited to replacement or repair, at our option, of the product returned, shipping cost prepaid, to Fisher Research Labs. Damage due to neglect, accidental damage, misuse of this product or normal wear and tear is not covered by the warranty.



• **Phone**

+1 (800) 685-5050



• **Message**

contact@frsttx.com



• **Website**

www.Fisherlab.com



• **Address**

1120 Alza Drive El Paso, TX 79907



• **Text**

+1 (844) 674-1777



• **WhatsApp**

+1 (915) 633-8354



MADE IN THE USA

FROM USA AND GLOBAL COMPONENTS

FOLLOW US ON SOCIAL MEDIA

