


Track Layout



Thomas the Tank Engine & Friends™
CREATED BY BRITT ALLCROFT

Based on the Railway Series by The Reverend W Awdry.
©2019 Gullane (Thomas) Limited. Thomas the Tank Engine & Friends and Thomas & Friends are trademarks of Gullane (Thomas) Limited.
©2019 HIT Entertainment Limited. HIT and the HIT logo are trademarks of HIT Entertainment Limited.

©2019 Mattel. ® and ™ designate U.S. trademarks of Mattel, except as noted. **PRINTED IN CHINA.**
Mattel East Asia Ltd., Room 503-09, North Tower,
World Finance Centre, Harbour City, Tsimshatsui, HK, China.
Tel.: (852) 3185-6500.



GGH31 GGH31-0970
1101572073-DOM

Fisher-Price®


CONSUMER ASSISTANCE
1-800-432-5437 (US & Canada)
1-300 135 312 (Australia)

service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
Mississauga, Ontario L5R 3W2; www.service.mattel.com.
Great Britain: Mattel UK Ltd, Vanwell Business Park,
Mainheaden SL6 4UB, Heltline: 01268 500303,
www.service.mattel.com.
Mattel Europa B.V., Gondel 1, 1186 NJ Amstelveen, Nederland.
Australia: Mattel Australia Pty Ltd., 658 Church Street,
New Look Bag #870, Richmond, Victoria 3121 Australia.
Lieded: 16-18 William Pickering Drive,
Abany 1331, Auckland.
SOUTH AFRICA: Mattel South Africa (PTY) Ltd, Office 102 I3,
30 Melrose Boulevard, Johannesburg 2196.




LIFT & LOAD CARGO SET

INSTRUCTIONS

Keep these instructions for future reference as they contain important information.

What's Included




Includes 2 adaptors!
Compatible with other wood track including
Thomas & Friends™ Wooden Railway.

Item No : GGH31-0970-1101572073-DOM_IS
Version : DOM
Size : 16.6" W x 11.7" H (A3)
Paper : 100% Recycled Paper, 70 gsm
Color : Black
Date : 1/29/2019 (Edith Ng)

Instruction Sheet Size - Format 2
Sheet Size Open: 16.6" W x 11.7" H (A3)
Sheet Size Folded: 8.3" W x 11.7" H (folds to A4)

Front




Helpful Hint




Both sides of the crane should be assembled in the package.
However, if either side comes apart during play, you can snap them back into place as shown.


How to Play




Rotate the knob to choose the direction for your engine.




Attach a Troublesome Truck to Charlie and stop them beneath the shed.



Place the cargo into the groove on the roof, then flip the lever to drop the cargo into the Troublesome Truck.



Lift the edge of the flatbed to tip the cargo out of the Troublesome Truck and down the ramp.



Seat the figure in the crane. Rotate the knob to lift or lower the cargo and slide the crane to shift the cargo to the other side.

Back

