

fisher-price®



JCY36

CONSUMER INFORMATION



- Keep these instructions for future reference as they contain important information.





- Adult assembly is required. Tool required for assembly: Allen wrench (included).




- The mat, wedge, hedgehog squeaker, crinkle leaf, and cactus rattle are machine washable. Wash separately in cold water on the gentle cycle. Do not use bleach. Tumble dry on low heat. Do not iron. Do not dry clean.
- The frame, sun mirror, and silicone teething ring can be wiped with a clean, damp cloth. Do not immerse.

ASSEMBLED PARTS




CAUTION

This package contains small parts. For adult assembly only.





4.5 x 45 mm





ASSEMBLY



1



2




3




ASSEMBLY

4



5



WARNING

To prevent entanglement injury, never place the gym in a crib or playpen. Never add strings, ties or other products to the gym.



Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

UNITED STATES

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
Consumer Services: 1-800-432-5437.

CANADA

Mattel Canada Inc., 6155 Freemont Blvd., Mississauga,
Ontario L5R 3W2 Consumer Services/Service à la clientèle :
1-800-432-5437. www.service.mattel.com.

GREAT BRITAIN

Mattel U.K. Limited, The Porter Building, 1 Brunel Way, Slough SL1 1FQ, UK.
www.service.mattel.com/uk.

AUSTRALIA

Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond,
Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

NEW ZEALAND

16-18 William Pickering Drive, Albany 1331, Auckland.

SOUTH AFRICA

Mattel South Africa (PTY) LTD, Office 102 I3, 30 Melrose Boulevard, Johannesburg 2196.



©2024 Mattel.
PRINTED IN CHINA
JCY36-0970-DOM

