

Quick Start Guide




SAMSUNG Galaxy A17 5G

Rated IP54: Dust-resistant; protects against splashed water.



QR code for Samsung use
Printed in Korea
GH68-57672C

What's in the box



Phone

Quick Start Guide

Terms & Conditions




Charging cable



SIM Tool

Get to know your device



USB Type-C 3A cable included. For more information about charging, visit samsung.com/us/support/answer/ANS10001612/

Use only compatible charging devices and accessories. Damage caused by use of accessories which are not compatible may not be covered by warranty.

Get started

You may need your Google ID and password
and Wi-Fi password.

Activate your device

A physical SIM card is not needed for activation.

Your new device uses an eSIM.

To activate and download the eSIM,
power on the device and follow the prompts.

Need help?

Learn more about your device with
the **Device Help** app




Power on device



Side
button
Press and
hold

Follow the setup screens
and transfer content to your new device.



To launch, scan this code
with your camera



or visit www.att.com/device-support

Call our customer care team at
1-800-331-0500 or prepaid **1-800-901-9878**

© 2026 Samsung Electronics America, Inc. Samsung & Samsung Galaxy are registered trademarks of Samsung Electronics Co., Ltd. © 2026 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners. Screen images simulated. Appearance of device may vary. Images shown are for reference only. If you use a screen protector, make sure it allows for use of screen features.