



User Manual

Model: H1370
Govee Ceiling Fan with Lights

English

01

Français

09

IMPORTANT SAFETY INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS When using products, basic precautions should always be practiced including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

All safety messages will alert you of what the potential hazard is, tell you how to reduce the chance of injury, and let you know what can happen if the instructions are not followed.

- **WARNING:** To Reduce The Risk Of Fire, Electric Shock, Or Personal Injury, Mount Directly To A Structural Framing Member Or To An Outlet Box Marked Acceptable for Fan Support of 15.9 kg (35 lbs). For Outlet Box Mounting. Use Mounting Screws Provided With The Outlet Box.
- To avoid possible electrical shock, before installing or servicing your fan, disconnect the power by turning off the circuit breakers to the outlet box and associated wall switch location. If you cannot lock the circuit breakers in the off position, securely fasten a prominent warning device, such as a tag, to the service panel.
- To reduce the risk of electric shock, this fan must be installed with an isolating wall control/switch.
- **WARNING:**To reduce the risk of personal injury, do not bend the blade brackets when installing the blade brackets, balancing the blades, or cleaning the fan. Do not insert foreign objects in between rotating fan blades.
- **Chemical burn hazard.** Keep batteries away from children. This remote contains a lithium button cell battery. If a new or used lithium button/coin cell battery is swallowed or enters the body, it can cause severe internal burns and can lead to death in as little as 2 hours. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. Dispose of cells properly and keep away from children. Even used cells may cause injury.
- Non-rechargeable batteries are not to be recharged. Exhausted batteries are to be removed from the product.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and

knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. It is recommended that children be supervised to ensure that they are not using the appliance improperly.

- **WARNING:** To reduce the risk of fire or electric shock or injury to persons. do not use replacement parts that have not been recommended by the manufacturer (e.g. parts made at home using a 3D printer).
- Read all instructions and safety information before installing your new fan. Review the accompanying assembly diagrams.
- Make sure all electrical connections comply with local law and the national electrical code. Please hire a qualified electrician or consult a do-it -yourself wiring handbook if you are unfamiliar with installing electrical wiring.
- Make sure the installation site is roomy enough to allow fan blades to rotate. There is at least seven feet from the floor to fan blades' tips.
- If you are mounting the fan on a ceiling outlet box, please use a metal outlet box. Secure the box directly to the building structure. The outlet box and its support must be able to support the rotating fan (at least 35 lbs). Do not use a plastic outlet box. Attach the mounting bracket using the ceiling outlet box's hardware.
- After installing the fan, make sure all the connections are secured so that the fan won't fall.
- Do not insert anything between fan blades while the fan is operating.
- Turn the fan off and wait for it to stop before reversing fan's rotating direction.
- **WARNING:** To Reduce The Risk Of Fire Or Electric Shock, Do Not Use This Fan With Any Solid-State Speed Control Device. You must install the outlet box using the two steel screws and lock washers coming with the fan.
- The splices after being made should be turned upward and pushed carefully up into the outlet box.
- Instructions for supply connections: the white conductor of a fan identified as grounded conductor to be connected to a grounded conductor of power supply, the black conductor fan identified as ungrounded conductor to be connected to an ungrounded conductor of power supply, the green conductor of fan identified for equipment grounding to be connected to an equipment-grounding conductor.
- The total weight of the fan install to outlet box is 6.9 kg, check that the outlet box is securely installed in place such that it is able to support at least the fan weight.
- When mounted directly to the building structure, appliance installation shall not expose combustible material and do not install the appliance to a ceiling with combustible finish. The installation of the appliance cannot leave the wood of the rafters or any thermal insulation exposed to the interior of the room.


- To Reduce The Risk Of Electric Shock, Disconnect The Electrical Supply Circuit To The Fan Before Installing Light Kit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- **WARNING:** If unusual oscillating movement is observed, immediately stop using the ceiling fan and contact the manufacturer, its service agent or suitably qualified persons.
- **WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS, OBSERVE THE FOLLOWING:**
 - a. Use this unit only in the manner intended by the manufacturer. If you have questions, contact the manufacturer.
 - b. Before servicing or cleaning unit, switch power off at service panel and lock the service disconnecting means to prevent power from being switched on accidentally. When the service disconnecting means cannot be locked, securely fasten a prominent warning device, such as a tag, to the service panel.
 - c. Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction.
 - d. When cutting or drilling into wall or ceiling, do not damage electrical wiring and other hidden utilities.
 - e. If this unit is to be installed over a tub or shower, it must be marked as appropriate for the application and be connected to a GFCI (Ground Fault Circuit Interrupter) - protected branch circuit.
- Never touch uninsulated cables, especially AC cables, with bare hands.

SAVE THESE INSTRUCTIONS

Introduction


Thanks for choosing Govee Ceiling Fan! This product has been thoroughly tested and is suitable for offering ambiance to your living rooms, bedrooms, etc. The device can be controlled via the app and voice assistant. With Govee Home App, you can adjust the brightness, color temperature, change the color, and set multiple timers. A variety of scenes and music modes are preset in the app for you. Additionally, you can bring your creativity to the lights with DIY Mode!

What You Get



x 1

Ceiling Fan



x 1

Ceiling Bracket



x 1

User Manual



x 1

Quick Start
Guide



x1

Service Card



x 4

WoodScrew



x 4

Wire Nut (Optional)



x 4


1 to 1 Wire Connector



x 4

Plastic Screw Anchor

Control Panel



Buttons	Instructions
 Fan Power Button	Press to turn the fan on/off. Note: Long press the power button and the speed button for 10 seconds to restore the fan to factory settings and disconnect Wi-Fi and Bluetooth.
 Oscillation Button	Press to turn the fan blade oscillation function on/off.
 Airflow Direction Button	Press to change the airflow firection(Upward/Downward).
 Speed+ Button	Press to increase the speed of the fan.
 Speed- Button	Press to decrease the speed of the fan.
 Light Power Button	Press to power the Light on/off.
 Brightness+ Button	Press to increase the brightness of the lamp.
 Brightness- Button	Press to decrease the brightness of the lamp.
 Warm Button	Press to make colors warmer.
 Cool Button	Press to make colors cooler.
 Light Mode Button	Press to change Color/Scene. Tips: Enter the Device Settings page in Govee Home App. Tap “Preset Features” to manage the colors.

Installing Your Device

Assemble this ceiling light by following the Quick Start Guide.

Pairing Your Light with Govee Home App

What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11b/g/n bands. 5GHz is not supported.
1. Download Govee Home App from the App Store (iOS) or Google Play (Android). Log in with your account. New users need to create an account.
 2. Turn on the Bluetooth on your smartphone.

3. Open the app, tap the “+” icon in the top right corner and search for “H1370”.
4. Tap the device icon and follow the on-screen instructions to complete pairing.



Google Play is a trademark of Google LLC.

The Apple logo is a trademark of Apple Inc., registered in the U.S. and other countries and regions.

Apple Store is a service mark of Apple Inc., registered in the U.S. and other countries and regions.

Matter User Guide

1. How to use Matter

Step 1: Find the Matter QR code or device number on the product or on the “Device Settings” page in Govee Home App.

Step 2: Turn on the Bluetooth on your smartphone and keep it on.

Step 3: Download and open an app that supports Matter such as Amazon Alexa/Google Home/Apple HomeKit, etc.

Step 4: Use the device number or QR code on the device in the app to complete the network connection with Matter for the device.

2. Important:

You will need to complete the network connection of apps that support Matter (e.g. Amazon Alexa/Google Home/Apple HomeKit etc.) within 15 minutes after the product is powered on when using Matter for the first time.

An IPv6 network is required.

Changing the network may cause Matter to malfunction.

If the device cannot be connected to Matter’s ecosystem app network, please tap Network Reset in the Device Settings page to restore the device to factory settings before trying to reconnect to the network.

If you need to change the network when using Matter, close Govee Home App and power off the device. Then, power back on and complete the network connection of apps that support Matter (e.g. Amazon Alexa/Google Home/Apple HomeKit etc.) within 15 minutes.

Specifications

Model	H1370
Power Input	AC 120V 50/60Hz
Rated Power	69W
Main Light Displaying Technology	RGBICWW
Back Light Displaying Technology	RGBICWW
Lumens	3100lm@2700K 3300lm@6500K
Color Temperature	2700-6500K
Control Methods	Govee Home, Voice Control, Remote
Working Temperature	-10°C - 40°C / 14°F - 104°F
Remote Control Battery	CR2025 3V

Controlling the Light with Your Voice

1. Open the app, then tap the device icon to enter the details page.
2. Tap the settings icon in the top right corner.
3. Select “User Guide” and follow the on-screen instructions to control the device using your voice.

Troubleshooting

1. **Cannot connect to Govee Home App.**
 - a. Check if the light has been powered on.
 - b. Check if your smartphone’s Bluetooth has been turned on or try connecting the light to another smartphone.
 - c. Ensure that your smartphone is near the light when connecting for the first time.
 - d. If the problem persists, go to the “Device” page to delete the device and follow the previous instructions to reconnect.

2. Cannot connect to Wi-Fi.

- a. Check if the light has been powered on.
- b. Do not skip the Wi-Fi connection steps during the pairing process.
- c. Ensure that your Wi-Fi router is 2.4GHz capable. 5GHz is not supported.
- d. Ensure that you entered the correct Wi-Fi password during the Wi-Fi connection process.
- e. Shorten the distance between the device and the Wi-Fi router to less than 50ft (15m), then try reconnecting.
- f. Use another smartphone to pair with the device to check if your Wi-Fi network is working.

3. Cannot pair or connect with Alexa or Google Assistant.

- a. Ensure that the Wi-Fi connection is stable.
- b. Go to the app's "Settings" page and follow the instructions under "User Guide" to pair the device again.

4. The light does not display the selected color fully or some LED beads do not light up.

Please contact the Govee support team for a rapid product replacement.

Customer Service

 Warranty: 18-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @GOVEE  @goveeofficial  @govee.official

 @GoveeOfficial  @GOVEE

CONSIGNES DE SÉCURITÉ IMPORTANTES

CONSIGNES DE SÉCURITÉ IMPORTANTE Lors de l'utilisation des produits, il faut toujours prendre des précautions essentielles, notamment les suivantes :

LIRE ET SUIVRE TOUTES LES CONSIGNES DE SÉCURITÉ.

Tous les messages de sécurité vous avertiront du danger potentiel, vous indiqueront comment réduire les risques de blessures et vous informeront de ce qui peut arriver si les instructions ne sont pas suivies.

- **AVERTISSEMENT** : Pour réduire les risques d'incendie, d'électrocution ou de blessure corporelle, montez-le directement sur un élément de charpente structurelle ou sur une boîte de sortie marquée comme acceptable pour le support d'un ventilateur de 15,9 kg (35 lbs). Pour le montage de la boîte de sortie. Utilisez les vis de fixation fournies avec la boîte de sortie.
- Pour éviter tout risque d'électrocution, avant d'installer ou d'entretenir votre ventilateur, coupez l'alimentation en désactivant les disjoncteurs du boîte de sortie et de l'interrupteur mural correspondant. Si vous ne pouvez pas verrouiller les disjoncteurs en position d'arrêt, fixez solidement un dispositif d'avertissement bien visible, par exemple, une étiquette, sur le tableau électrique.
- Pour réduire les risques d'électrocution, ce ventilateur doit être installé avec un interrupteur/une commande mural(e) d'isolation.
- **AVERTISSEMENT** : Afin de réduire les risques de blessure, ne pas plier les supports des pales lors de leur installation, de l'équilibrage des pales ou du nettoyage du ventilateur. Ne pas insérer d'objets étrangers entre les pales rotatives du ventilateur.
- **Risque de brûlure chimique.** Tenez les piles hors de portée des enfants. Cette télécommande contient une pile bouton au lithium. Si une pile bouton au lithium, neuve ou usagée, est avalée ou pénètre dans le corps, elle peut provoquer de graves brûlures internes et entraîner la mort en seulement 2 heures. Fermez toujours complètement le compartiment à batteries. Si le compartiment à piles ne se ferme pas correctement, cessez d'utiliser le produit, retirez les piles et tenez-les hors de portée des enfants. Si vous pensez avoir avalé des piles ou qu'elles ont été placées à l'intérieur d'une partie quelconque du corps, veuillez consulter immédiatement un médecin. Éliminez les piles correctement et tenez-les hors de portée des enfants. Même les piles usagées peuvent causer des blessures.
- Les batteries non rechargeables ne doivent pas être rechargées. Les piles usagées doivent être retirées du produit.
- Cet appareil peut être utilisé par des enfants âgés de plus de 8 ans et par des personnes aux capacités physiques, sensorielles ou mentales réduites, ou manquant d'expérience et de connaissances, à condition qu'ils aient reçu une surveillance ou des instructions concernant

l'utilisation de l'appareil en toute sécurité et qu'ils comprennent les risques encourus. Les enfants ne doivent pas jouer avec l'appareil. Le nettoyage et l'entretien par l'utilisateur ne doivent pas être effectués par des enfants sans surveillance. Il est recommandé de surveiller les enfants afin de s'assurer qu'ils n'utilisent pas l'appareil de manière inappropriée.

- **AVERTISSEMENT** : Pour réduire les risques d'incendie, d'électrocution ou de blessures, n'utilisez pas de pièces de rechange non recommandées par le fabricant (par exemple, des pièces fabriquées à domicile à l'aide d'une imprimante 3D).
- Lisez attentivement toutes les instructions et les consignes de sécurité avant d'installer un nouveau ventilateur. Veuillez consulter les schémas de montage ci-joints.
- Assurez-vous que tous les raccordements électriques sont conformes à la loi locale et à la norme nationale de l'électricité. Veuillez engager un électricien qualifié ou consulter un manuel de câblage pour bricoleur si vous n'êtes pas familier avec l'installation de câblage électrique.
- Assurez-vous que le site d'installation est suffisamment grand pour permettre la rotation des pales du ventilateur. Il y a au moins sept pieds entre le sol et l'extrémité des pales du ventilateur.
- Si vous installez le ventilateur sur une boîte de sortie au plafond, veuillez utiliser une boîte de sortie métallique. Fixez la boîte directement à la structure du bâtiment. La boîte de sortie et son support doivent pouvoir supporter le ventilateur rotatif (au moins 35 lbs). N'utilisez pas de boîte de sortie en plastique. Fixez le support de montage à l'aide des éléments de fixation de la boîte de sortie au plafond.
- Après avoir installé le ventilateur, assurez-vous que toutes les connexions sont bien fixées si bien que le ventilateur ne tombe pas.
- N'insérez rien entre les pales du ventilateur lors de son fonctionnement.
- Éteignez le ventilateur et attendez qu'il s'arrête complètement avant d'inverser son sens de rotation.
- **AVERTISSEMENT** : Pour réduire les risques d'incendie ou d'électrocution, n'utilisez pas ce ventilateur avec un variateur de vitesse électronique. Vous devez installer la boîte de sortie en utilisant deux vis en acier et des rondelles frein fournies avec le ventilateur.
- Une fois les épissures effectuées, il faut les orienter vers le haut et les pousser minutieusement dans la boîte de sortie.
- Instructions pour les raccordements d'alimentation : le conducteur blanc du ventilateur, identifié comme conducteur de mise à la terre, doit être connecté à un conducteur de mise à la terre de l'alimentation électrique ; le conducteur noir du ventilateur, identifié comme conducteur non mis à la terre, doit être connecté à un conducteur non mis à la terre de l'alimentation électrique ; le conducteur vert du ventilateur, identifié pour la mise à la terre de l'équipement, doit être connecté à un conducteur de mise à la terre de l'équipement.
- Le poids total du ventilateur installé dans la boîte de sortie est de 6,9 kg. Vérifiez que la boîte de sortie est solidement installée et qu'elle peut supporter au moins le poids du ventilateur.
- Lorsqu'il est fixé directement à la structure du bâtiment, l'appareil installé ne doit pas exposer de matériaux combustibles et ne doit pas être installé sur un plafond avec un revêtement combustible. L'installation de l'appareil ne doit pas laisser le bois des chevrons ou tout isolant thermique exposé à l'intérieur de la pièce.


- Pour réduire les risques d'électrocution, veuillez débranchez le circuit d'alimentation électrique du ventilateur avant d'installer le kit de lumière.
- Cet appareil n'est pas destiné à être utilisé par des personnes (notamment des enfants) dont les capacités physiques, sensorielles ou mentales sont réduites ou qui manquent d'expérience et de connaissances, à moins qu'elles ne soient supervisées ou n'aient reçu des instructions concernant l'utilisation de l'appareil par une personne responsable de leur sécurité.
- Si le cordon d'alimentation est endommagé, il doit être remplacé par le fabricant, son agent de service ou des personnes de qualification similaire afin d'éviter tout danger.
- **AVERTISSEMENT** : Si un mouvement d'oscillation inhabituel est constaté, cessez immédiatement d'utiliser le ventilateur de plafond et contactez le fabricant, son service après-vente ou une personne qualifiée.
- **AVERTISSEMENT** : POUR RÉDUIRE LES RISQUES D'INCENDIE, D'ÉLECTROCUTION OU DE BLESSURES, RESPECTEZ LES CONSIGNES SUIVANTES :
 - a. Utilisez cet appareil uniquement de la manière prévue par le fabricant. Si vous avez des questions, veuillez contacter le fabricant.
 - b. Avant toute intervention sur l'appareil (entretien ou nettoyage), coupez l'alimentation au niveau du panneau de service et verrouillez le dispositif de déconnexion pour éviter toute remise sous tension accidentelle. Lorsque le dispositif de déconnexion ne peut pas être verrouillé, fixez solidement un dispositif d'avertissement bien visible, par exemple, une étiquette, sur le panneau de service.
 - c. Les travaux d'installation et le câblage électrique doivent être effectués par une ou plusieurs personnes qualifiées conformément à tous les codes et normes applicables, y compris les normes de construction coupe-feu.
 - d. Lors de la découpe ou du perçage dans un mur ou un plafond, veillez à ne pas endommager le câblage électrique et autres installations dissimulées.
 - e. Si cet appareil doit être installé au-dessus d'une baignoire ou d'une douche, il doit être marqué comme approprié pour cet usage et être raccordé à un circuit de dérivation protégé par un disjoncteur différentiel (GFCI).
- Ne touchez jamais les câbles non isolés à mains nues, en particulier les câbles CA.

CONSERVER CES INSTRUCTIONS

Introduction


Merci d'avoir choisi le ventilateur de plafond Govee ! Ce produit a fait l'objet de tests approfondis et convient pour créer une ambiance dans vos salons, chambres à coucher, etc. L'appareil peut être contrôlé via l'application et l'assistant vocal. L'application Govee Home vous permet de régler la luminosité, la température de couleur, de changer la couleur et de régler plusieurs minuteries. Une variété de scènes et de modes musicaux sont prédéfinies dans l'application pour vous. En outre, vous pouvez apporter votre créativité à l'éclairage grâce au mode DIY !

Contenu du carton



x 1

Ventilateur de
plafond



x 1

Support de
plafond



x 1

Manuel
d'utilisation



x 1

Guide de
démarrage
rapide



x 1

Carte de
service



x 4

vis à bois



x 4

Serre-fil (en option)



x 4


1-zu-1-Kabelverbinder



x 4

Kunststoff-Dübel

Panneau de commande



Boutons	Instructions
 Bouton marche/arrêt du ventilateur	Appuyez pour allumer/éteindre le ventilateur. Remarque : Appuyez longuement sur le bouton d'alimentation et le bouton de vitesse pendant 10 secondes pour réinitialiser le ventilateur aux paramètres d'usine et déconnecter le Wi-Fi et le Bluetooth.
 Bouton d'oscillation	Appuyez pour activer/désactiver la fonction d'oscillation des pales du ventilateur.
 Bouton de direction du flux d'air	Appuyez pour modifier la direction du flux d'air (Haut/Bas).
 Bouton Vitesse+	Appuyez pour augmenter la vitesse du ventilateur.
 Bouton Vitesse-	Appuyez pour diminuer la vitesse du ventilateur.
 Bouton marche/arrêt de la lampe	Appuyez pour allumer/éteindre la lumière.
 Bouton Luminosité+	Appuyez pour augmenter la luminosité de la lampe.
 Bouton Luminosité-	Appuyez pour diminuer la luminosité de la lampe.
WARM Bouton Chaud	Appuyez sur ce bouton pour rendre les couleurs plus chaudes.
COOL Bouton Froid	Appuyez sur ce bouton pour rendre les couleurs plus froides.
 Bouton de mode d'éclairage	Appuyez pour changer de couleur/scène. Astuces : Accédez à la page Paramètres de l'appareil dans l'Application Govee Home. Appuyez sur « Fonctionnalités prédéfinies » pour gérer les couleurs.

Installation de votre appareil

Assemblez ce plafonnier en suivant le guide de démarrage rapide.

Association de votre lampe à l'application Govee Home

Ce dont vous avez besoin :

- Un routeur Wi-Fi prenant en charge les bandes de 2,4 GHz et 802.11b/g/n. La bande 5 GHz n'est pas prise en charge.
1. Téléchargez l'application Govee Home depuis l'App Store (iOS) ou Google Play (Android). Connectez-vous à votre compte. Les nouveaux utilisateurs doivent créer un compte.
 2. Activez le Bluetooth sur votre smartphone.

3. Ouvrez l'application, appuyez sur l'icône « + » dans le coin supérieur droit et recherchez « H1370 ».
4. Appuyez sur l'icône de l'appareil et suivez les instructions à l'écran pour terminer l'association.



Google Play est une marque de Google LLC.

Le logo Apple est une marque commerciale d'Apple Inc., déposée aux États-Unis et dans d'autres pays et régions.

Apple Store est une marque de service d'Apple Inc., déposée aux États-Unis et dans d'autres pays et régions.

Manuel utilisateur de Matter

1. Comment utiliser la Matter

Étape 1 : Recherchez le code QR du Matter ou le numéro de l'appareil sur le produit ou sur la page « Paramètres de l'appareil » dans l'application Govee Home.

Étape 2 : Activez le Bluetooth sur votre smartphone et maintenez-le activé.

Étape 3 : Téléchargez et ouvrez une application prenant en charge Matter, telle qu'Amazon Alexa/Google Home/Apple HomeKit, etc.

Étape 4 : Utilisez le numéro de l'appareil ou le code QR sur l'appareil dans l'application pour terminer la connexion réseau à Matter pour l'appareil.

2. Important :

Vous devrez accomplir la connexion réseau des applications qui prennent en charge Matter (par exemple, Amazon Alexa/Google Home/Apple HomeKit, etc.) dans les 15 minutes suivant la mise sous tension du produit lorsque vous utilisez Matter pour la première fois.

Un réseau IPv6 est requis.

Le changement de réseau peut entraîner un dysfonctionnement de Matter.

Si l'appareil ne peut pas être connecté au réseau d'applications de l'écosystème de Matter, veuillez appuyer sur Réinitialisation du réseau dans la page Paramètres de l'appareil pour restaurer l'appareil aux paramètres d'usine avant d'essayer de se reconnecter au réseau.

Si vous devez changer de réseau lors de l'utilisation de Matter, fermez l'application Govee Home et éteignez l'appareil. Ensuite, rallumez l'appareil et finalisez la connexion réseau des applications qui prennent en charge Matter (par exemple Amazon Alexa/Google Home/Apple HomeKit, etc.) dans un délai de 15 minutes.

Caractéristiques techniques

Modèle	H1370
Entrée d'alimentation	CA 120V 50/60 Hz
Puissance nominale	69W
Technologie d'affichage de la lumière principale	RGBICWW
Technologie d'affichage de rétroéclairage	RGBICWW
Lumens	3100lm@2700K 3300lm@6500K
Température de couleur	2700-6500K
Méthodes de contrôle	Govee Home, commande vocale, télécommande
Température de fonctionnement	-10°C à 40°C / 14°F à 104°F
Pile pour télécommande	CR2025 3V

Contrôle de la lumière par la voix

1. Ouvrez l'application, puis appuyez sur l'icône de l'appareil pour accéder à la page des détails.
2. Appuyez sur l'icône des paramètres dans le coin supérieur droit.
3. Sélectionnez « Manuel utilisateur » et suivez les instructions à l'écran pour contrôler l'appareil à l'aide de votre voix.

Dépannage

1. **Impossible de se connecter à l'application Govee Home.**
 - a. Vérifiez que la lampe a été mise sous tension.
 - b. Vérifiez que le Bluetooth de votre smartphone a été activé ou essayez de connecter la lampe à un autre smartphone.
 - c. Assurez-vous que votre smartphone est à proximité de la lampe lors de la première connexion.
 - d. Si le problème persiste, accédez à la page « Appareil » pour supprimer l'appareil et suivez les instructions précédentes pour le reconnecter.

2. Impossible de connecter au Wi-Fi.

- Vérifiez que la lampe a été mise sous tension.
- N'ignorez pas les étapes de connexion Wi-Fi pendant le processus d'association.
- Assurez-vous que votre routeur Wi-Fi est compatible avec la bande 2,4 GHz. La bande 5 GHz n'est pas prise en charge.
- Assurez-vous d'avoir saisi le bon mot de passe Wi-Fi lors du processus de connexion Wi-Fi.
- Réduisez la distance entre l'appareil et le routeur Wi-Fi à moins de 50 pieds (15 m), puis réessayez la connexion.
- Utilisez un autre smartphone pour vous associer à l'appareil et vérifier que votre réseau Wi-Fi fonctionne.

3. Impossible de s'associer ou de se connecter à Alexa ou à l'Assistant Google.

- Assurez-vous que la connexion Wi-Fi est stable.
- Accédez à la page « Paramètres » et suivez les instructions sous « Manuel utilisateur » pour associer l'appareil à nouveau.

4. La lampe n'affiche pas complètement la couleur sélectionnée ou certaines billes LED ne s'allument pas.

Veuillez contacter l'équipe d'assistance Govee pour un remplacement rapide du produit.

Service clients

-  Garantie : Garantie limitée 18 mois
-  Assistance : Assistance technique à vie
-  E-mail : support@govee.com
-  Site Internet officiel : www.govee.com
-  @GOVEE  @goveeofficial  @govee.official
-  @GoveeOfficiel  @GOVEE

FCC and ISED Canada Statement

This device complies with Part 15 of the FCC Rules and Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC and ISED Radiation Exposure Statement

This equipment complies with FCC and ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This equipment meets the exemption from the routine evaluation limits in RSS-102. It should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Cet équipement est conforme aux limites d'exposition au rayonnement FCC et ISED établies pour un environnement non contrôlé, cet équipement devrait être installé et exploité avec une distance minimale de 20cm entre le radiateur et Votre corps.

ISED STATEMENT

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The Apple logo is a trademark of Apple Inc., registered in the U.S. and other countries and regions. Apple Store is a service mark of Apple Inc., registered in the U.S. and other countries and regions.

Le logo Apple est une marque commerciale d'Apple Inc., déposée aux États-Unis et dans d'autres pays et régions. Apple Store est une marque de service d'Apple Inc., déposée aux États-Unis et dans d'autres pays et régions.

Responsible party :

Name: GOVEE MOMENTS(US) TRADING LIMITED

Address: 2501 Chatham Rd Suite R Springfield IL 62704

Email: certification@govee.com

Contact information: <https://community.govee.com/support>



FOR INDOOR USE ONLY

POUR UNE UTILISATION EN INTÉRIEUR UNIQUEMENT

CAUTION: Risk of explosion if the battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

WARNING: The batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

Extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Be aware discharged battery may cause fire or smoke, tape the terminals to insulate them.

ATTENTION: Risque d'explosion si la batterie est remplacée par une autre batterie de type inadéquat.

AVERTISSEMENT: Les batteries (blocs-batteries ou batteries installées) ne doivent pas être exposées à une source de chaleur excessive tels que les rayons du soleil, incendies, etc. La pression atmosphérique extrêmement faible peut entraîner une explosion ou une fuite de gaz ou de liquide inflammable. Veuillez noter que les batteries déchargées peuvent provoquer de la fumée ou des incendies. Mettez du ruban adhésif sur les bornes pour les isoler.

The trademark Govee has been authorised to Shenzhen Qianyan Technology LTD. Copyright ©2021 Shenzhen Qianyan Technology LTD, All Rights Reserved.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Qianyan Technology LTD is under license.



WARNING: contains coin battery

1. Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
2. Even used batteries may cause severe injury or death.
3. Compatible battery types CR2025.
4. Nominal battery voltage DC 3V.
5. Call a local poison control center for treatment information.
6. Non-rechargeable batteries are not to be recharged.
7. Do not force discharge, recharge, disassemble, heat above (60 °C /140°F) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
8. Ensure the batteries are installed correctly according to polarity (+ and -).
9. Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
10. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
11. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.





Govee Home App

For FAQs and more information,
please visit: www.govee.com