


2. The heating plate and the thermal insulation base have high temperatures during use. Please do not touch them directly with your hands to prevent burns.
3. After use, please wait until the heating plate has completely cooled down before storing this machine to avoid burns.
4. Do not use this machine outdoors. It's only for household use.
5. Do not use this machine in a humid environment.
6. Check the power cord regularly.
7. Clean the machine with a damp cloth after unplugging and the machine has completely cooled down.

Get started now!

Make the best use of your Mini Heat Press2!



Mini Heat Press Limited Warranty

The warranty period of this machine is 1 year from the date of purchase. Other HTVRONT accessories (such as heat insulation base, etc.) are guaranteed for free within three months from the date of purchase. Warranty service is available when there's a malfunction in normal use during the warranty period. If consumers need warranty service, they need to provide proof of purchase.

To the extent permitted by applicable laws, HTVRONT is not responsible for the warranty in the following situations: malfunctions caused by improper use, maintenance, and storage by consumers; malfunctions caused by self-repair or dismantling by those who do not undertake the three-guarantee repair without the permission of our company; products that can continue to be used after repair when the warranty expired; damage caused by force majeure. Meanwhile, HTVRONT disclaims all implied and legal warranties, including warranties of merchantability and fitness for a particular purpose. The warranties that are allowed to be denied are for the duration of this warranty.

Proof of warranty purchase may be required.

Important Safety Instructions

Danger

1. Do not immerse the Mini Heat Press2 in water.

Warning Notes:

1. If the socket in your home is not suitable for the plug of this machine, you need to replace it with the corresponding socket.
2. Do not use the machine if it is dropped or has obvious signs of damage.
3. Do not let the machine work unattended.
4. This machine should be kept away from children, animals, and plants while in use.
5. Do not let the power cord touch the heating plate during the operation.



Precautions

1. This machine has to be working on a stable and flat surface. Place this machine in the thermal insulation base while not in use.